

# 1994 Mazda RX-7 Workshop Manual

## **WARNING**

Servicing a vehicle can be dangerous. If you have not received service-related training, the risks of injury and property damage increase. The recommended servicing procedures for the vehicle in this workshop manual were developed with Mazda-trained technicians in mind. This manual may be useful to non-Mazda trained technicians, but a technician with our service-related training and experience will be at less risk when performing servicing operations. However, all users of this manual are expected to know general safety procedures.

This manual contains "Warnings" and "Cautions" applicable to risks not normally encountered in a general technician's experience. They should be followed to reduce the risk of injury and the risk that improper service or repair may damage the vehicle or render it unsafe. It is also important to understand that the "Warnings" and "Cautions" are not exhaustive. It is impossible to warn of all the hazardous consequences that might result from failure to follow the procedures.

The procedures recommended and described in this manual are effective methods of performing service and repair. Some require tools specifically designed for a specific purpose. Nonrecommended procedures and tools should include consideration for safety of the technician and continued safe operation of the vehicle.

Parts should be replaced with genuine Mazda replacement parts, not parts of lesser quality. Use of a nonrecommended replacement part should include consideration for safety of the technician and continued safe operation of the vehicle.

# 1994 Mazda RX-7 Workshop Manual

## FOREWORD

A thorough familiarization with this manual is important for proper repair and maintenance.

It should always be kept in a handy place for quick and easy reference.

The contents of this manual, including drawings and specifications, are the latest available at the time of printing. As modifications affecting repair or maintenance occur, relevant information supplementary to this volume will be made available at Mazda dealers. This manual should be kept up-to-date.

Mazda Motor Corporation reserves the right to alter the specifications and contents of this manual without obligation or advance notice.

All rights reserved. No part of this book may be reproduced or used in any form or by any means, electronic or mechanical — including photocopying and recording and the use of any kind of information storage and retrieval system — without permission in writing.

## WARRANTY

The manufacturer's warranty on Mazda vehicles and engines can be voided if improper service or repairs are performed by persons other than those at an Authorized Mazda Dealer.

**Mazda Motor Corporation  
HIROSHIMA, JAPAN**

## APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN) shown on the following page.

## CONTENTS

Title		Section
General Information		GI
Pre-Delivery Inspection and Scheduled Maintenance		A
Engine		C
Lubrication System		D
Cooling System		E
Fuel and Emission Control Systems		F
Engine Electrical System		G
Clutch		H
Manual Transmission		J
Automatic Transmission	Electronically-Controlled	K
Propeller Shaft		L
Front and Rear Axles		M
Steering System		N
Braking System		P
Wheels and Tires		Q
Suspension		R
Body		S
*Body Electrical System		T
*Heater and Air Conditioner Systems		U
Technical Data		TD
Special Tools		ST
Wiring Diagram (Form No.5273-10-93H) (Part No. 9999-95-022G-94)		Z

\* Refer to the 1994 RX-7 Body Electrical Troubleshooting Manual (Form No. 1380-10-93H, Part No.9999-95-085F-94) for servicing of the body electrical components.

© 1993 Mazda Motor Corporation  
Printed in the U.S.A. (8/93)  
Form No. 1378-10-93H  
Part No. 9999-95-018B-94

# GENERAL INFORMATION

<b>SAFETY INFORMATION</b> .....	GI- 2
LUBRICANTS .....	GI- 2
JACKING POSITIONS .....	GI- 2
SAFETY STAND POSITIONS .....	GI- 2
VEHICLE LIFT POSITIONS .....	GI- 3
DYNAMOMETER .....	GI- 3
COMPRESSED AIR .....	GI- 3
<b>HOW TO USE THIS MANUAL</b> .....	GI- 4
ADVISORY MESSAGES .....	GI- 4
PREPARATION .....	GI- 4
REPAIR PROCEDURE .....	GI- 4
SYMBOLS .....	GI- 5
<b>IDENTIFICATION NUMBER LOCATIONS</b> ...	GI- 6
<b>UNITS</b> .....	GI- 6
<b>ABBREVIATIONS</b> .....	GI- 7
<b>SAE STANDARDS</b> .....	GI- 8
<b>FUNDAMENTAL PROCEDURES</b> .....	GI-11
PROTECTION OF THE VEHICLE .....	GI-11
PREPARATION OF TOOLS AND MEASURING EQUIPMENT .....	GI-11
SPECIAL TOOLS .....	GI-11
REMOVAL OF PARTS .....	GI-11
DISASSEMBLY .....	GI-11
REASSEMBLY .....	GI-12
ADJUSTMENTS .....	GI-13
RUBBER PARTS AND TUBING .....	GI-13
HOSE CLAMPS .....	GI-13
TORQUE FORMULAS .....	GI-13
VISE .....	GI-13
<b>ELECTRICAL TROUBLESHOOTING</b>	
<b>TOOLS</b> .....	GI-14
TEST LIGHT .....	GI-14
JUMPER WIRE .....	GI-14
VOLTMETER .....	GI-14
OHMMETER .....	GI-14
<b>ELECTRICAL PARTS</b> .....	GI-15
BATTERY CABLE .....	GI-15
CONNECTORS .....	GI-15
TERMINALS .....	GI-16
SENSORS, SWITCHES, AND RELAYS ...	GI-17
WIRING HARNESS .....	GI-17
FUSE .....	GI-17
<b>INSTALLATION OF MOBILE TWO-WAY RADIO   SYSTEM</b> .....	GI-18
<b>AUDIO ANTITHEFT SYSTEM</b> .....	GI-18
<b>TOWING</b> .....	GI-19

### SAFETY INFORMATION

#### LUBRICANTS

Avoid prolonged and repeated contact with petroleum-based oils. Used oil may irritate the skin, and can cause skin cancer and other skin disorders.

Wash thoroughly after working with oil. We recommend water soluble hand cleaners. Do not use kerosene, gasoline, or any other solvent, to remove oil from your skin.

If repeated or prolonged contact with oil is necessary, wear protective clothing. Soiled clothing, particularly those soiled with used oils and greases containing lead, should be cleaned at regular intervals.

#### JACKING POSITIONS


##### Warning

- **Improperly jacking a vehicle is dangerous. The vehicle can slip off the jack and cause serious injury. Use only the correct front and rear jacking positions and block the wheels.**

Use safety stands to support the vehicle after it has been lifted.


##### Front

At the center of the crossmember



##### Rear


At the center of the crossmember



#### SAFETY STAND POSITIONS


##### Front



Both sides of the vehicle



##### Rear

Both sides of the vehicle



**VEHICLE LIFT POSITIONS****Front****Rear**

GI

**DYNAMOMETER**

When test-running a vehicle on a dynamometer

- Place a fan, preferably a vehicle-speed proportional type, in front of the vehicle.
- Connect an exhaust gas ventilation unit.
- Cool the exhaust pipes with a fan.
- Keep the area around the vehicle uncluttered.
- Watch the water temperature gauge.

**COMPRESSED AIR**

When using compressed air to clean or remove parts

- Wear protective eyewear.
- Hold a rag over the opening to prevent parts from shooting out.
- Take precautions so that people around you are not struck by flying debris.

### HOW TO USE THIS MANUAL

#### ADVISORY MESSAGES

You'll find several **Warnings**, **Cautions**, and **Notes** in this manual.

##### Warning

- A **Warning** indicates a situation in which serious injury or death could result if the warning is ignored.

##### Caution

- A **Caution** indicates a situation in which damage to the vehicle could result if the caution is ignored.


##### Note

- A **Note** provides added information that will help you to complete a particular procedure.

#### PREPARATION

This points out the needed **SSTs** for the service operation. It is best to gather all necessary **SSTs** before beginning work.


**Example:**



#### REPAIR PROCEDURE

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and describes visual part inspection. If a damaged or worn part is found, repair or replace it as necessary.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration.
3. Pages related to service procedures are shown Under the illustration. Refer to this information when servicing the related part.

Example:



- \* 1: The numbers (①, etc.) refer to part identification and servicing procedures.
- \* 2: Units are in N·m {kgf·m, ft·lbf} unless otherwise specified.


**SYMBOLS**

There are six symbols indicating oil, grease, and sealant. These symbols show the points of applying such materials during service.


Symbol	Meaning	Kind
	Apply oil	New engine oil or gear oil as appropriate
	Apply brake fluid	FMVSS116: DOT-3
	Apply automatic transmission fluid	Dexron®II or M-III
	Apply grease	Appropriate grease
	Apply sealant	Appropriate sealant
	Apply petroleum jelly	Appropriate petroleum jelly

### IDENTIFICATION NUMBER LOCATIONS


VEHICLE IDENTIFICATION NUMBER (VIN)



AUTOMATIC TRANSMISSION MODEL AND NUMBER



ENGINE MODEL AND NUMBER



### UNITS

Electrical current .....	A (ampere)
Electric potential .....	V (volt)
Electric power .....	W (watt)
Length .....	mm (millimeters)
	in (inches)
Negative pressure .....	kPa (kilo Pascal)
	mmHg (millimeters of mercury)
	inHg (inches of mercury)
Positive pressure .....	kPa (kilo Pascal)
	kgf/cm <sup>2</sup> (kilogram force per square centimeter)
	psi (pounds per square inch)
Resistance .....	Ω (ohm)
Torque .....	N·m (Newton meter)
	kgf·m (kilogram force per meter)
	kgf·cm (kilogram force per centimeter)
	ft·lb (foot pounds)
	in·lb (inch pounds)
Volume .....	L (liter)
	US qt (U.S. quart)
	Imp qt (Imperial quart)



ABBREVIATIONS

AAS	Auto adjusting suspension
ABDC	After bottom dead center
ABS	Anti-lock braking system
ACC	Accessories
ACV	Air control valve
ASV	Air supply valve
AT	Automatic transmission
ATDC	After top dead center
ATF	Automatic transmission fluid
ATS	Ambient temperature sensor
AWS	Accelerated warm-up system
BAC	Bypass air control
BBDC	Before bottom dead center
BTDC	Before top dead center
EC-AT	Electronically controlled Automatic Transmission
ECPS	Electronically controlled power steering
ECU	Engine control unit
EGI	Electronic gasoline injection
E/L	Electrical load
ESA	Electronic spark advance
ESPS	Engine speed sensing power steering
ETS	Evaporator temperature sensor
EX	Exhaust
IC	Integrated circuit
IGN	Ignition
IN	Intake
INT	Intermittent
ISC	Idle speed control
LH	Left hand
LSD	Limited slip differential
M	Motor
MOP	Metering oil pump
MT	Manual transmission
OD	Overdrive
OFF	Switch off
ON	Switch on
PBV	Proportioning bypass valve
PCTS	Passenger compartment temperature sensor
PCV	Positive crankcase ventilation
PRC	Pressure regulator control
P/S	Power steering
P/W	Power window
RH	Right hand
RTS	Reduce torque signal
SLS	Slip lockup signal
SR	Sensor rotor
SST	Special service tool
ST	Start
SW	Switch
TDC	Top dead center
TNS	Tail number side
TRS	Torque reduced signal
VDI	Variable dynamic effect intake
VRIS	Variable resonance induction system
WSS	Wheel speed sensor
WTS	Water temperature sensor

GI

## SAE STANDARDS

In accordance with new regulations, SAE (Society of Automotive Engineers) standard names and abbreviations are now used in this manual. The table below lists the names and abbreviations that have been used in Mazda manuals up to now and their SAE equivalents.

## Engine and Emission Systems

Previous Standard		SAE Standard		
Abbreviation	Name	Abbreviation	Name	Remark
—	Accelerator Pedal	AP	Accelerator Pedal	
—	Air Cleaner	ACH	Air Cleaner Housing	
—	Air/Fuel (A/F) Solenoid Valve	MCS	Mixture Control Solenoid	F2 Carburetor
—	Airflow Meter	VAF	Volume Airflow Sensor	
—	Airflow Sensor	MAF	Mass Airflow Sensor	
—	Alternator	ALT	Alternator	
—	Atmospheric Pressure Sensor	BARO	Barometric Absolute Pressure Sensor	
—	Carburetor	CARB	Carburetor	
—	Catalytic Converter	OC	Oxidation Catalyst	
		TWC	Three-Way Catalyst	
		WU-TWC	Warm Up Three-Way Catalyst	#1
—	Circuit Opening Relay	FPR	Fuel Pump Relay	#2
—	Cooling Fan Control	CFC	Coolant Fan Control	
—	Crank Angle Sensor	CPS	Crankshaft Position Sensor	
—	Diagnosis Connector	DLC	Data Link Connector	
—	Direct Ignition	DLI	Distributorless Ignition	
EGI	Electronic Gasoline Injection System	CIS	Continuous Fuel Injection System	
—	Electronic Spark Ignition	EI	Electronic Ignition	#3
—	EGR Modulator Solenoid	EGRC	EGR Function Control	
—	EGR Gas Sensor	EGRS	EGR Function Sensor	#4
	EGR Position Sensor			
	EGR Position Switch			
ECU	Engine Control Unit	PCM	Powertrain Control Module	#5
		PCME	Powertrain Control Module (Engine)	
—	Engine Modification	EM	Engine Modification	
—	Engine Speed	RPM	Engine Speed	
—	Evaporative Emission Control System	EVAP	Fuel Evaporative System	
—	Exhaust Gas Recirculation System	EGR	Exhaust Gas Recirculation	System name
—	Feedback System	CLS	Closed Loop System	
—	Flexible Fuel	FF	Flexible Fuel	
—	Fuel Pump	FP	Fuel Pump	
—	IC Regulator	VR	Voltage Regulator	

#1: Directly connected to exhaust manifold

#2: In some models, there is a "Fuel Pump Relay" that controls pump speed.  
That relay is now called the "Fuel Pump Relay (Speed)".

#3: Controlled by the PCME (PCM)

#4: EGR valve controller device name

#5: Device that controls engine and powertrain

## Engine and Emission Systems (cont'd)

Previous Standard		SAE Standard		
Abbreviation	Name	Abbreviation	Name	Remark
—	Intake Air Thermosensor	IATS	Intake Air Temperature Sensor	
—	Intercooler	CAC	Charge Air Cooler	
—	ISC Solenoid Valve	IACV	Idle Air Control Valve	
—	Knock Sensor	KS	Knock Sensor	
—	Malfunction Indicator Light	MIL	Malfunction Indicator Light	
—	Multiport Fuel Injection	MFI	Multiport Fuel Injection	
—	Oxidizing Converter	OC	Oxidation Catalyst	
—	Oxygen Sensor	HO2S	Heated Oxygen Sensor	With heater
		O2S	Oxygen Sensor	
—	Open Loop	OL	Open Loop	
PTC	Positive Temperature Coefficient Heater	EFE	Early Fuel Evaporation	
—	Pressure Sensor	MAP	Manifold Absolute Pressure Sensor	
		MVS	Manifold Vacuum Sensor	Checks vacuum only
—	Reed Valve	SAPV	Secondary Air Pulse Valve	
—	Relief 1 Solenoid Valve	SABV	Secondary Air Bypass Valve	
—	Secondary Air Injection System	PAIR	Pulsed Secondary Air Injection	Pulsed injection
		AIR	Secondary Air Injection	#6
—	Sequential Fuel Injection	SMFI	Sequential Multipoint Fuel Injection	
—	Service Code(s)	DTC	Diagnostic Trouble Code(s)	
—	Spark Ignition	DI	Distributor Ignition	
—	Supercharger	SC	Supercharger	
—	Switching Solenoid Valve	SASV	Secondary Air Switching Valve	
—	Test Mode(s)	DTM	Diagnostic Test Mode(s)	#7
—	Three-Way Catalyst	TWC	Three-Way Catalyst	
—	Throttle Body	TB	Throttle Body	
—	Throttle Sensor	TPS	Throttle Position Sensor	
—	Turbocharger	TC	Turbocharger	
—	VAC	MDP	Manifold Differential Pressure	
—	Vacuum Switch	MVZS	Manifold Vacuum Zone Switch	
—	Water Thermosensor	ECTS	Engine Coolant Temperature Sensor	

#6: Supplies air to three-way catalytic

#7: Diagnostic trouble codes depend on the test mode


### Transmission (Transaxle) and Steering System

Previous Standard		SAE Standard		
Abbreviation	Name	Abbreviation	Name	Remark
—	Clutch Position	CPP	Clutch Pedal Position	
—	EC-AT Control Unit	PCMT	Powertrain Control Module (Transaxle)	FF
			Powertrain Control Module (Transmission)	FR
—	Fully Closed	CTP	Closed Throttle Position	
—	Fully Open	WOT	Wide Open Throttle	
—	Inhibitor Switch	PNS	Park/Neutral Switch	
—	Lock-Up Position	TCC	Torque Converter Clutch	
—	Output Signal(s)	PTCS	Powertrain Control Signal(s)	
—	Overdrive	4GR	Fourth Gear	
—	Power Steering Pressure Switch	SPS	Steering Pressure Sensor	
—	Pulse Generator	VSPG	Vehicle Speed Pulse Generator	
—	Vehicle Speed Sensor	VSS	Vehicle Speed Sensor	
—	3rd Gear	3GR	Third Gear	

### Body Electrical System and Heater and Air Conditioner Systems

Previous Standard		SAE standard		
Abbreviation	Name	Abbreviation	Name	Remark
—	A/C Switch	ACS	Air Conditioning Sensor	
—	Air Conditioner	A/C	Air Conditioner	
V <sub>B</sub>	Battery Voltage	B+	Battery Positive Voltage	
—	Coolant Level Sensor	COLS	Coolant Level Sensor	
—	Ground	GND	Ground	
—	Self-Diagnosis System	OBD	On-Board Diagnosis System	#8

#8: System name. Other related names are unchanged.



**FUNDAMENTAL PROCEDURES**


**PROTECTION OF THE VEHICLE**

Always be sure to cover fenders, seats, and floor areas before starting work.




**PREPARATION OF TOOLS AND MEASURING EQUIPMENT**

Be sure that all necessary tools and measuring equipment are available before starting any work.




**SPECIAL TOOLS**

Use special tools when they are required.




**REMOVAL OF PARTS**

While correcting a problem, try also to determine its cause. Begin work only after first learning which parts and subassemblies must be removed and disassembled for replacement or repair. After removing the part, plug all holes and ports to prevent foreign material from entering.




**DISASSEMBLY**

If the disassembly procedure is complex, requiring many parts to be disassembled, all parts should be disassembled in a way that will not affect their performance or external appearance and identified so that reassembly can be performed easily and efficiently.



### 1. Inspection of parts


When removed, each part should be carefully inspected for malfunctioning, deformation, damage, and other problems.



### 2. Arrangement of parts

All disassembled parts should be carefully arranged for reassembly.

Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.




### 3. Cleaning parts for reuse

All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.

#### Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.



### REASSEMBLY


Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts. Refer to STANDARD BOLT AND NUT TIGHTENING TORQUE in section TD for tightening torques not mentioned in the main text.


If removed, these parts should be replaced with new ones:

- |                |                 |
|----------------|-----------------|
| 1. Oil seals   | 4. Gaskets      |
| 2. O-rings     | 5. Lock washers |
| 3. Cotter pins | 6. Nylon nuts   |

Depending on location:


1. Sealant should be applied to gaskets.
2. Oil should be applied to the moving components of parts.
3. Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.






**ADJUSTMENTS**

Use suitable gauges and testers when making adjustments.




**RUBBER PARTS AND TUBING**

Prevent gasoline or oil from getting on rubber parts or tubing.



**HOSE CLAMPS**

When reinstalling, position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.




**TORQUE FORMULAS**

When using a torque wrench-SST combination, the written torque must be recalculated due to the extra length that the SST adds to the torque wrench. Recalculate the torque by using the following formulas. Choose the formula that applies to you.


Torque Unit	Formula	L&A Unit
N·m	$N \cdot m \times [L/(L+A)]$	centimeter
kgf·m	$kgf \cdot m \times [L/(L+A)]$	centimeter
kgf·cm	$kgf \cdot cm \times [L/(L+A)]$	centimeter
ft·lb	$ft \cdot lb \times [L/(L+A)]$	inch
in·lb	$in \cdot lb \times [L/(L+A)]$	inch

A = The length of the SST past the torque wrench drive.  
L = The length of the torque wrench.



**WISE**

When using a vise, put protective plates in the jaws of the vise to prevent damage to parts.




## ELECTRICAL TROUBLESHOOTING TOOLS

### TEST LIGHT

The test light, as shown in the figure, uses a 12V bulb. The two lead wires should be connected to probes. The test light is used for simple voltage checks and for checking for short circuits.

#### Caution

- Using a bulb over 3.4W when checking the control unit may damage the control unit.




### JUMPER WIRE

A jumper wire is used to create a temporary circuit. Connect the jumper wire between the terminals of a circuit to bypass a switch.


#### Caution

- Do not connect a jumper wire from the power source line to a body ground; this may cause burning or other damage to harnesses or electronic components.



### VOLTMETER

The DC voltmeter is used to measure circuit voltage. A voltmeter with a range of 15V or more is used by connecting the positive (+) probe (red lead wire) to the point where voltage is to be measured and the negative (-) probe (black lead wire) to a body ground.




### OHMMETER

The ohmmeter is used to measure the resistance between two points in a circuit, and to check for continuity and short circuits.

#### Caution

- Do not connect the ohmmeter to any circuit to which voltage is applied; this will damage the ohmmeter.






**ELECTRICAL PARTS**

**BATTERY CABLE**

Before disconnecting connectors or removing electrical parts, disconnect the negative battery cable.




**CONNECTORS**

**Data Link Connector**

Insert the probe into the service hole when connecting a jumper wire to the data link connector.


**Caution**

- Inserting a jumper wire probe into the data link connector terminal may damage the terminal.




**Disconnecting Connectors**

When disconnecting two connectors, grasp the connectors, not the wires.




Connectors can be disconnected by pressing or pulling the lock lever as shown.




**Locking Connectors**

When locking connectors, listen for a click that will indicate they are securely locked.

**Inspection**


1. When a tester is used to check for continuity or to measure voltage, insert the tester probe from the wiring harness side.




2. Check the terminals of waterproof connectors from the connector side, as they cannot be accessed from the wiring harness side.

**Caution**

- To prevent damage to the terminal, wrap a thin wire around the lead before inserting it into the terminal.


**TERMINALS****Inspection**

Pull lightly on individual wires to check that they are secured in the terminal.

**Replacement**


Use the appropriate tools to remove a terminal as shown. When installing a terminal, be sure to insert it until it locks securely.

Insert a thin piece of metal from the terminal side of the connector, and then, with the terminal locking tab pressed down, pull the terminal out from the connector.



**SENSORS, SWITCHES, AND RELAYS**

Handle sensors, switches, and relays carefully. Do not drop them or strike them against other objects.




**WIRING HARNESS**

**Wiring color codes**

Two-color wires are indicated by a two-color code symbol. The first letter indicates the base color of the wire and the second the color of the stripe.


CODE	COLOR	CODE	COLOR
B	Black	O	Orange
BR	Brown	P	Pink
G	Green	R	Red
GY	Gray	V	Violet
L	Blue	W	White
LB	Light Blue	Y	Yellow
LG	Light Green	—	—



**FUSE**

**Replacement**

1. When replacing a fuse, be sure to replace it with one of the specified capacity.  
If a fuse again fails after it has been replaced, the circuit probably has a short and the wiring should be checked.
2. Be sure the negative battery terminal is disconnected before replacing a main fuse (80A).
3. When replacing a pullout fuse, use the fuse puller supplied in the fuse box cover.




## INSTALLATION OF MOBILE TWO-WAY RADIO SYSTEM

If a mobile two-way radio system is installed improperly or if a high-powered type is used, the CIS and other systems may be affected.


When the vehicle is to be equipped with a mobile two-way radio, observe the following precautions:


1. Install the antenna at the farthest point from control modules.
2. Install the antenna feeder as far as possible from the control module harnesses (**at least 30 cm {11.8 in}**).
3. Ensure that the antenna and feeder are properly adjusted.
4. Do not install a high-powered mobile two-way radio system.



## AUDIO ANTITHEFT SYSTEM

An audio with an antitheft function is optionally available. Before removing the negative battery terminal or disconnecting the audio power source, obtain the code number and deactivate the audio antitheft system. (Refer to 1994 RX-7 Body Electrical Troubleshooting Manual.)





## TOWING

Proper towing equipment is necessary to prevent damage to the vehicle.

Laws and regulations applicable to vehicles in tow must always be observed.

As a general rule, towed vehicles should be pulled with the driving wheels off the ground. If excessive damage or other conditions prevent towing the vehicle with the driving wheels off the ground, use wheel dollies.

With either automatic or manual transmission.

1. Set the ignition switch in the ACC position;
2. Place the selector lever or shift lever in N (Neutral);
3. Release the parking brake.

### With manual transmission

If the transmission, rear axle, and steering system are not damaged, the vehicle may be towed on all four wheels. If any of these components are damaged, use wheel dollies.

### With automatic transmission

If excessive damage or other conditions prevent towing the vehicle with the driving wheels off the ground, use wheel dollies.

If all four wheels are on the ground, the vehicle may be towed only forward. Don't exceed 45 km/h (28 mph) and a distance of 15 km (10 miles); you could damage the transmission.


If speed must exceed 45 km/h (28 mph) or a towing distance of 15 km (10 miles), use one of these methods:

- Place the rear wheels on a dolly;
- Tow with the rear wheels off the ground;
- Disconnect the propeller shaft.

If the transmission or rear axle is inoperative, tow with the rear wheels off the ground.

### Caution

- Don't tow with sling-type equipment. This could damage your vehicle. Use wheel-lift or flatbed equipment.



### Caution

- Don't use the hook loops under the front for towing. They are designed ONLY for tying down the vehicle when it's being transported. Using them for towing will damage the bumper.

# PRE-DELIVERY INSPECTION AND SCHEDULED MAINTENANCE

<b>PRE-DELIVERY INSPECTION</b> .....	<b>A - 2</b>	<b>INSPECTION OF PARKING BRAKE</b> .....	<b>A -15</b>
<b>PRE-DELIVERY INSPECTION TABLE</b> .....	<b>A - 2</b>	<b>INSPECTION OF POWER BRAKE UNIT AND HOSES</b> .....	<b>A -15</b>
<b>SCHEDULED MAINTENANCE (EXCEPT CANADA)</b> .....	<b>A - 3</b>	<b>INSPECTION OF DISC BRAKES</b> .....	<b>A -15</b>
<b>SCHEDULE 1</b>		<b>INSPECTION OF POWER STEERING FLUID LEVEL</b> .....	<b>A -15</b>
<b>(NORMAL DRIVING CONDITIONS)</b> .....	<b>A - 3</b>	<b>INSPECTION OF STEERING OPERATION AND LINKAGE</b> .....	<b>A -15</b>
<b>SCHEDULE 2</b>		<b>INSPECTION OF STEERING LINKAGES, RACK GUIDE AND TIE ROD ENDS</b> .....	<b>A -16</b>
<b>(UNIQUE DRIVING CONDITIONS)</b> .....	<b>A - 5</b>	<b>INSPECTION OF SUSPENSION BALL JOINTS</b> .....	<b>A -16</b>
<b>SCHEDULED MAINTENANCE (CANADA)</b> ....	<b>A - 7</b>	<b>INSPECTION OF RACK SEAL BOOTS</b> .....	<b>A -16</b>
<b>REPLACEMENT OF ENGINE OIL</b> .....	<b>A - 9</b>	<b>INSPECTION OF MANUAL TRANSMISSION OIL</b> .....	<b>A -16</b>
<b>REPLACEMENT OF ENGINE OIL FILTER</b> ...	<b>A - 9</b>	<b>REPLACEMENT OF MANUAL TRANSMISSION OIL</b> .....	<b>A -17</b>
<b>INSPECTION OF DRIVE BELTS</b> .....	<b>A - 9</b>	<b>INSPECTION OF AUTOMATIC TRANSMISSION FLUID LEVEL</b> .....	<b>A -17</b>
<b>REPLACEMENT OF AIR CLEANER ELEMENT</b> .....	<b>A -10</b>	<b>INSPECTION OF DIFFERENTIAL OIL</b> .....	<b>A -18</b>
<b>INSPECTION OF SPARK PLUGS</b> .....	<b>A -10</b>	<b>REPLACEMENT OF DIFFERENTIAL OIL</b> ....	<b>A -18</b>
<b>INSPECTION OF COOLING SYSTEM</b> .....	<b>A -11</b>	<b>INSPECTION OF DRIVE SHAFT DUST BOOTS</b> .....	<b>A -18</b>
<b>REPLACEMENT OF ENGINE COOLANT</b> ....	<b>A -11</b>	<b>TIGHTENING BOLTS AND NUTS ON CHASSIS AND BODY</b> .....	<b>A -19</b>
<b>INSPECTION OF IDLE SPEED</b> .....	<b>A -11</b>	<b>INSPECTION OF EXHAUST SYSTEM HEAT SHIELDS</b> .....	<b>A -19</b>
<b>REPLACEMENT OF FUEL FILTER</b> .....	<b>A -12</b>	<b>INSPECTION OF SEAT BELTS, BUCKLES, RETRACTORS AND ANCHORS</b> .....	<b>A -19</b>
<b>INSPECTION OF FUEL LINES</b> .....	<b>A -12</b>		
<b>INSPECTION OF OIL-LEVEL WARNING SYSTEM</b> .....	<b>A -12</b>		
<b>INSPECTION OF COOLANT LEVEL WARNING SYSTEM</b> .....	<b>A -13</b>		
<b>INSPECTION OF CLUTCH PEDAL</b> .....	<b>A -13</b>		
<b>INSPECTION OF CLUTCH FLUID</b> .....	<b>A -14</b>		
<b>INSPECTION OF BRAKE PEDAL</b> .....	<b>A -14</b>		
<b>INSPECTION OF BRAKE FLUID</b> .....	<b>A -14</b>		
<b>INSPECTION OF BRAKE LINE, HOSES AND CONNECTIONS</b> .....	<b>A -14</b>		

## PRE-DELIVERY INSPECTION

## PRE-DELIVERY INSPECTION TABLE

The following items may be done at any time prior to delivery to your customer.

## EXTERIOR

**INSPECT** and **ADJUST**, if necessary, the following items to the specifications:

- Glass, exterior bright metal, and paint for damage
- Wheel lug nuts and locks  
89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf}
- All weather strips for damage and detachment
- Operation of hood release and lock
- Operation of fuel lid and rear hatch opener
- Door operation and alignment
- Headlight aim

**INSTALL** the following parts

- Power outside mirror (s)
- Front air deflector (if equipped)

## UNDER HOOD—ENGINE OFF

**INSPECT** and **ADJUST**, if necessary, the following items to the specifications:

- Fuel, coolant, and hydraulic lines, fittings, connections, and components for leaks
- Engine oil level
- Power steering fluid level
- Brake and clutch master cylinder fluid levels
- Windshield washer reservoir fluid level
- Radiator coolant level and specific gravity
- Tightness of battery terminals

## INTERIOR

**CHECK** the operations of the following items:

- Seat controls (sliding and reclining)
- Door locks
- Seat belts and warning system
- Ignition switch and steering lock
- Air bag system warning light
- Shift-lock system and Park/Neutral switch (AT only)
- Starter interlock switch (clutch pedal, MT only)
- All lights including warning and indicator lights and retractable headlight mechanism
- IC audible warning system
- Horn, wipers, and washers (front and rear, if equipped)
- Radio and antenna
- Cigarette lighter and clock
- Power outside mirror
- Power windows
- Heater, defroster, and air conditioner at all mode selections (if equipped)
- Sunroof (if equipped)

- Theft-deterrent system
- CHECK** the following items:

- Spare fuse
  - Upholstery and interior finishes
- CHECK** and **ADJUST**, if necessary, the following items:
- Height and free play of brake and clutch pedal

	Pedal height mm (in)	Pedal free play mm (in)
Clutch pedal	165.5–177.0 {6.516–6.968 in} (With carpet)	0.6–3.2 {0.02–0.13}
Brake pedal	164.5–176.0 {6.48–6.92} (With carpet)	3.0–8.0 {0.12–0.31}

- Parking brake  
7–10 notches / 200 N {20 kgf, 44 lbf}

## UNDER HOOD—ENGINE RUNNING AT OPERATING TEMPERATURE

**CHECK** the following items:

- Bypass air control system
- Automatic transmission fluid level

## ON HOIST

**CHECK** the following items:

- Manual transmission oil level
- Rear axle oil level
- Underside fuel, coolant, and hydraulic lines, fittings, connections, and components for leaks
- Tires for cuts and bruises
- Steering linkage, suspension, exhaust system, and all underside hardware for looseness or damage

## ROAD TEST

**CHECK** the following items:

- Brake operation
- Clutch operation
- Steering control
- Operation of meters and gauges
- Squeaks, rattles, or unusual noises
- Emergency locking retractors
- Cruise control system (if equipped)

## AFTER ROAD TEST

- CHECK** for necessary owner information materials, tools, and spare tire in vehicle
- REMOVE** identification color tape on directional tires

The following items must be done just before the delivery to your customer.

- Load test battery and charge if necessary
- Adjust tire pressure to the specification  
(Refer to section Q)
- Clean outside of vehicle
- Install fuses for accessories
- Remove seat and floor mat protective covers
- Vacuum inside of vehicle

**SCHEDULED MAINTENANCE (EXCEPT CANADA)**

**Schedule 1 (Normal Driving Conditions)**

If the vehicle is mainly operated where none of the “unique driving conditions” apply.

**Schedule 2 (Unique Driving Conditions)**

- Repeated short-distance driving.
- Driving in dusty conditions.
- Driving with extended use of brakes.
- Driving in areas where road salt or other corrosives are used.
- Driving on rough or muddy roads.
- Extended periods of idling or low-speed operation.
- Driving for long periods in cold temperatures or extremely humid climates.



**SCHEDULE 1 (NORMAL DRIVING CONDITIONS)**

**Chart symbols:**

**I:** Inspect, and repair, clean, or replace if necessary

**R:** Replace

**L:** Lubricate

**Remarks:**

- After 48 months or 96,000 kilometers {60,000 miles}, continue to follow the described maintenance at the recommended intervals.
- \*1 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.
- \*2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.



# A

## SCHEDULED MAINTENANCE

### Schedule 1 (Normal Driving Conditions)

Maintenance Interval	Number of months or kilometers (miles), whichever comes first									
	Months	6	12	18	24	30	36	42	48	
	×1,000	Kilometers	12	24	36	48	60	72	84	96
Maintenance Item		Miles	7.5	15	22.5	30	37.5	45	52.5	60

#### Engine

Engine Oil	Replace every 8,000 kilometers (5,000 miles)									
Oil Filter	Replace every 8,000 kilometers (5,000 miles)									
Drive Belts (Tension)				I						I

#### Air cleaner housing

Air Cleaner Element				R						R
---------------------	--	--	--	---	--	--	--	--	--	---

#### Ignition system

Spark Plugs				R						R
-------------	--	--	--	---	--	--	--	--	--	---

#### Fuel system

Idle Speed		I*2		I*2		I*2				I
Fuel Filter										R
Fuel Lines					I*1					I

#### Cooling system

Cooling System		I		I		I				I
Engine Coolant				R						R

#### Chassis & body

Brake Lines, Hoses & Connections				I						I
Disc Brakes				I						I
Steering Operation & Linkages				I						I
Front & Rear Suspension Ball Joints				I						I
Rear Suspension Uni Ball & Sliding Rubber Bushing				I						I
Manual Transmission Oil										R
Differential Oil										R
Driveshaft Dust Boots				I						I
Bolts & Nuts on Chassis & Body				I						I
Exhaust System Heat Shield				I						I
All Locks & Hinges	L	L	L	L	L	L	L	L	L	L

#### Air conditioner system (if equipped)

Refrigerant Amount		I		I		I				I
Compressor Operation		I		I		I				I

#### Electrical system

Engine Oil Level Warning System		I		I		I				I
Engine Coolant Level Warning System				I						I

### SCHEDULE 2 (UNIQUE DRIVING CONDITIONS)

**Chart symbols:**

**I** : Inspect, and repair, clean, or replace if necessary (Inspect, and replace if necessary.....Air cleaner element only)

**R**: Replace

**L**: Lubricate

A

**Remarks:**

- After 48 months or 96,000 kilometers {60,000 miles}, continue to follow the described maintenance at the recommended intervals.
- \*1 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.
- \*2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

# A

## SCHEDULED MAINTENANCE

### Schedule 2 (Unique Driving Conditions)

Maintenance Interval	Number of months or kilometers (miles), whichever comes first												
	Months	4	8	12	16	20	24	28	32	36	40	44	48
	× 1,000 Kilometers	8	16	24	32	40	48	56	64	72	80	88	96
Maintenance Item	× 1,000 Miles	5	10	15	20	25	30	35	40	45	50	55	60

#### Engine

Engine Oil	Replace every 5,000 kilometers {3,000 miles}												
Oil Filter	Replace every 5,000 kilometers {3,000 miles}												
Drive Belts							I						I

#### Air cleaner housing

Air Cleaner Element							R						R
---------------------	--	--	--	--	--	--	---	--	--	--	--	--	---

#### Ignition system

Spark Plugs							R						R
-------------	--	--	--	--	--	--	---	--	--	--	--	--	---

#### Cooling system

Cooling System			I				I			I			I
Engine Coolant							R						R

#### Fuel system

Fuel Filter													R
Fuel Lines							I*1						I
Idle Speed			I*2				I*2			I*2			I

#### Chassis & body

Brake Lines, Hoses & Connections							I						I
Brake Fluid							R						R
Disc Brakes			I				I			I			I
Steering Operation & Linkages							I						I
Front & Rear Suspension Ball Joints							I						I
Rear Suspension Uni Ball & Sliding Rubber Bushing							I						I
Manual Transmission Oil							R						R
Differential Oil							R						R
Driveshaft Dust Boots							I						I
Bolts & Nuts on Chassis & Body			I				I			I			I
Exhaust System Heat Shield							I						I
All Locks & Hinges	L	L	L	L	L	L	L	L	L	L	L	L	L

#### Air conditioner system (If equipped)

Refrigerant Amount			I				I			I			I
Compressor Operation			I				I			I			I

#### Electrical system

Engine Oil Level Warning System			I				I			I			I
Engine Coolant Level Warning System							I						I
Engine Oil (Puerto Rico)	Replace every 5,000 kilometers {3,000 miles}												

**SCHEDULED MAINTENANCE (CANADA)**

**Chart symbols:**

- I : Inspect, and repair, clean, or replace if necessary (Inspect, and replace if necessary.....Air cleaner element only)
- R : Replace
- L : Lubricate

**Remarks :**

- After 60 months or 100,000 kilometers, continue to follow the described maintenance at the recommended intervals.
- \*1 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

**Schedule (Canada)**



Maintenance Interval	Number of months or kilometers, whichever comes first																				
	Months	3	6	9	12	15	18	21	24	27	30	33	36	39	42	45	48	51	54	57	60
Maintenance item X 1,000 Kilometers	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	
<b>Engine</b>																					
Engine Oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Oil Filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Tension of All Drive Belts		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
<b>Air cleaner housing</b>																					
Air Cleaner Element																					R
<b>Ignition system</b>																					
Spark Plugs																					R
<b>Cooling system</b>																					
Engine Coolant Level & Strength		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Cooling System for Leaks																					
Engine Coolant																					R
<b>Fuel system</b>																					
Idle Speed																					
Fuel Lines & Hoses																					I*
Fuel Filter																					R
Emission Hoses & Tubes																					



**SCHEDULED MAINTENANCE SERVICES**

**Schedule (Canada) (Cont'd)**

Maintenance Interval	Number of months or kilometers, whichever comes first																					
	Months	3	6	9	12	15	18	21	24	27	30	33	36	39	42	45	48	51	54	57	60	
Maintenance item	X 1,000 Kilometers	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	
<b>Chassis &amp; body</b>																						
Manual Transmission Oil Level					I																	
Automatic Transmission Fluid Level		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Transmission Oil MT & AT											R										R	
Differential Oil Level		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Differential Oil											R										R	
Driveshaft Dust Boots																						
Brake Lines & Hoses																						
Brake & Clutch Fluid Level		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Brake Fluid											R										R	
Disc Brakes (Front & Rear)						I										I						
Tire Inflation Pressure & Tire Wear		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Rotate every 25,000 kilometers or every 15 months																						
Power Steering Fluid Level		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Steering Operation & Linkage (Includes Four Wheel Alignment)																					I	
Suspension Components Front & Rear																						
Rear Suspension Uniball & Sliding Rubber Bushing																						
All Chassis & Body Nuts & Bolts																					I	
Exhaust System Heat Shield																						
All Locks & Hinges		L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
Washer Fluid Level		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Function of All Lights		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Engine Oil Level Warning System																						
Engine Coolant Level Warning System																						
<b>Air conditioner system (if equipped)</b>																						
Refrigerant																						Inspect the refrigerant amount annually
Compressor																						Inspect the operation annually



**REPLACEMENT OF ENGINE OIL**

1. Warm up the engine if it is cold.
2. Remove the drain plug.
3. Remove the oil filler cap. This will allow the oil to drain more easily.
4. Fill engine oil to the "F" mark on the dipstick. Use oil with the proper SAE viscosity.

A

**Oil capacity:**

Total: 4.9 L {5.2 US qt, 4.3 Imp qt} .. except R1 model  
 5.4 L {5.7 US qt, 4.8 Imp qt} ..... R1 model

Oil replacement: 3.6L {3.8 US qt, 3.2 Imp qt}

Oil + oil filter replacement: 3.8L {4.0 US qt, 3.3 Imp qt}

**Note**

- After starting the engine, recheck the oil level and also check the drain plug washer for leaks.

**Typical specification:**

API service SG, SH grade (Mineral oil only)  
 ILSAC

**Recommended SAE viscosity numbers**

Temperature	(°C)	-30	-20	-10	0	10	20	30	40	50	
	(°F)	-20	0	20	40	60	80	100	120		
Engine oil		5W-30									
							10W-30				

**REPLACEMENT OF ENGINE OIL FILTER**


1. Remove the oil filter by using the oil filter wrench.
2. Using a clean rag, wipe the mounting surface on the engine.
3. Apply a small amount of clean engine oil to the rubber seal of the new filter.
4. Install the oil filter until the rubber seal contacts the base, and then tighten the filter an additional 1-1/6 turns by hand.
5. Start the engine and inspect for leaks around the filter seal.
6. Stop the engine and check the oil level; add oil if necessary.

**INSPECTION OF DRIVE BELTS**


1. Check the belt for cracks or any other damage.
2. If necessary, adjust the drive belt tension with thumb pressure of about 98N {10 kgf, 22 lbf}.

**Alternator and air pump drive belt**

1. Loosen the alternator mounting bolt and locknut.
2. Move the alternator to obtain proper belt tension.
3. Tighten the bolts and recheck the tension.




Deflection	7.0-7.5 mm {0.28-0.29 in}
------------	---------------------------



**Air conditioner drive belt (if equipped)**

1. Loosen the lock nut on the idler pulley.
2. Turn the adjusting bolt until the correct tension is obtained.
3. Tighten the lock nut and recheck the tension.


Deflection	4.5–5.0 mm {0.18–0.19 in}
------------	---------------------------



**Power steering oil pump drive belt**

1. Loosen the lock nut on the idler pulley.
2. Turn the adjusting bolt until the correct tension is obtained.
3. Tighten the lock nut and recheck the tension.

Deflection	4.5–5.0 mm {0.18–0.19 in}
------------	---------------------------



**REPLACEMENT OF AIR CLEANER ELEMENT**

Use only a genuine Mazda air cleaner element or one of equivalent quality.

**INSPECTION OF SPARK PLUGS**

Check the following points. If a problem is found, replace the spark plug.

- Damaged insulation
  - Worn electrodes
  - Carbon deposits
- If cleaning is necessary, use a plug cleaner. Clean the upper insulator, also.
- Damaged gasket
  - Burnt


**Plug gap: 1.0–1.1 mm {0.040–0.043 in}**


Plug position	NGK	Discrimination color
Leading side	BUR7EQ*, (BUR7EQ) (BUR6EQP) (BUR6EQ)	—
Trailing side	BUR9EQ*, (BUR9EQP) (BUR8EQP) (BUR8EQ)	Blue

\* Standard plug

**Caution**

- The electrode is platinum coated. The following can scratch its platinum coating and impair its performance.
  - (1) Adjusting the plug gap.
  - (2) Using a wire brush to clean the electrode.
  - (3) Using a plug cleaner for more than twenty (20) seconds, or at more than 588 kPa {6 kg/cm<sup>2</sup> 85 psi}





**INSPECTION OF COOLING SYSTEM**

1. Check the cooling system hoses (including the heater hoses) for cracks or wear.
2. Check the cooling system for leaks by applying a pressure of 142 kPa {1.45 kgf/cm<sup>2</sup>, 20.6 psi} with a radiator cap tester.


**Note**

- Do not pressurize the system to more than 142 kPa {1.45 kgf/cm<sup>2</sup>, 20.6 psi}.

If necessary, replace the hoses.

**Warning**

- Be careful to avoid injury from escaping steam or hot water when removing the radiator cap.



**REPLACEMENT OF ENGINE COOLANT**


Drain the engine coolant by removing the radiator drain plug.

**Warning**

- Be careful to avoid injury when checking a hot engine.

Fill with new coolant according to the recommended mixture ratio as follows.

Protection	Mixture percentage (volume)	
	Anti-freeze solution	Water
Above -16°C {3°F}	35	65
Above -26°C {-15°F}	45	55
Above -40°C {-40°F}	55	45



**INSPECTION OF IDLE SPEED**


**Preparation**

1. Warm up the engine to normal operating temperature.
2. Turn all electric loads OFF.
3. Connect the SST (SYSTEM SELECTOR) to the data link connector.
4. Connect a tachometer to the data link connector IG- terminal as shown.



# A

## SCHEDULED MAINTENANCE




### Idle Speed

1. Perform "Preparation".
2. Set SYSTEM SELECT to position 1.
3. Set TEST SW to SELF TEST.
4. With the cooling fan off, verify that the idle speed is within specification.

Idle speed: 700–750 (720  $\pm 30$ ) rpm

5. If not within the specification, adjust the idle by turning the air-adjusting screw. (AAS)
6. If not within specification when air adjusting screw fully closed, loosen the locknut and turn the throttle adjusting screw to set the idle.
7. Tighten the locknut and put a paint mark on the nut and throttle body.
8. Disconnect the SST.



### REPLACEMENT OF FUEL FILTER


Replace the fuel filter with a new one.

#### Note

- Be careful of the fuel flow direction on the filter.


#### Caution

- a) Cover the hoses with a rag since fuel will be splashed out when you disconnect the hoses.
- b) Keep sparks and open flames away from the fuel area.




### INSPECTION OF FUEL LINES


1. Check the fuel line fittings, connections and components for leaks.
2. There should be no wetness or stained areas that might indicate leaks.
3. Replace any defective hoses or clips.




### INSPECTION OF OIL-LEVEL WARNING SYSTEM

1. When you turn the ignition switch ON, the oil-level warning light comes ON.
2. Start the engine and the oil-level warning light should go OFF.
3. Disconnect the connector from the oil-level sensor and ground the terminal at idle. The oil-level warning light comes ON and the buzzer sounds.
4. Remove the sensor.
5. Check that the oil holes of the oil chamber are not clogged. If necessary, clean the oil holes with solvent.






6. Connect an ohmmeter to the oil-level sensor and check the continuity by moving the float up and down. When the float is on the upper side, the ohmmeter should not show any continuity. When moved to the lower side, it should show a continuity of the circuit. If this is found not to be so, replace the oil-level sensor.



**INSPECTION OF COOLANT LEVEL WARNING SYSTEM**


1. Turn the ignition switch ON. The coolant level warning light comes ON.
2. Start the engine and the coolant level warning light should go OFF.
3. Disconnect the connector from the coolant level sensor and make sure the coolant level warning light comes ON after 9-16 seconds and the buzzer sounds at idle.



4. Disconnect coolant level sensor connector.
5. Check continuity between the terminal of the coolant level sensor and a ground.

Coolnat level	Continuity
Below MIN	No
Above MIN	Yes

6. If not as specified, replace the coolant level sensor.



**INSPECTION OF CLUTCH PEDAL**

**Height**

Measure the distance from the upper surface of the pedal to the carpet.

**Pedal height: 165.5-177.0 mm {6.516-6.968 in}  
(with carpet)**


If necessary, adjust the pedal height.

**Free Play**

Depress the clutch pedal by hand until clutch resistance is felt.


**Free play: 0.6-3.2 mm {0.02-0.13 in}  
Total Free play: 5.1-14 mm {0.20-0.55 in}**

If necessary, adjust the pedal free play.



### INSPECTION OF CLUTCH FLUID

1. Make sure that fluid level in the reservoir is between the MAX and MIN mark.
2. If the fluid level is extremely low, check the clutch and brake systems for leakage.



### INSPECTION OF BRAKE PEDAL

#### Pedal Height Inspection


Check if the distance from the center of the upper surface of the pedal pad to the carpet is as specified.

**Pedal height: 164.5–176.0 mm {6.48–6.92 in}  
(with carpet)**

#### Pedal Play Inspection

1. Depress the pedal a few times to eliminate the vacuum in the system.
2. Lightly depress the pedal by hand until resistance is felt and check the free play.


**Free play: 3–8 mm {0.12–0.31 in}**



### INSPECTION OF BRAKE FLUID


Check that the brake fluid level is near the "MAX" level line on the see-through reservoir. If necessary, add brake fluid to bring the level to the "MAX" level line.

**Fluid specification:  
FMVSS 116 DOT-3**



### INSPECTION OF BRAKE LINE, HOSES AND CONNECTIONS


Check the brake lines and hoses for proper attachment and connections. There should not be any leaks, cracks, chafing, abrasion, deterioration, etc. on lines and connections.



**INSPECTION OF PARKING BRAKE**


1. Pull the brake lever with 200 N {20 kgf, 44 lbf} of force and measure the lever stroke.
2. If necessary, adjust the lever stroke by turning the adjusting nut.

**Lever notices: 7-10**



**INSPECTION OF POWER BRAKE UNIT AND HOSES**


1. Check the vacuum hoses, connectors, and check the valve for cracks, chafing, deterioration, etc.
2. Check the power brake for proper operation. To check, depress the brake pedal several times to make sure the pedal play does not change. Then, while depressing the brake pedal, start the engine. At this time, the pedal should go down a little.



**INSPECTION OF DISC BRAKES**

Check the following conditions of disc brake components.


1. Check caliper operation and inspect for leaks.
2. Check pads for wear.
3. Check condition and thickness of disc plate.



**INSPECTION OF POWER STEERING FLUID LEVEL**


Check the power steering fluid level. Add specified power steering fluid to MAX if necessary.

**Fluid specification: ATF Dexron® II or M-III**



**INSPECTION OF STEERING OPERATION AND LINKAGE**


1. Check the steering wheel free play. (Refer to page N-6.)  
**Free play: 0-30 mm {0-1.18 in}**
2. Check the steering for proper operation and for looseness of the steering housing.
3. Check the steering gear housing for fluid leakage or see page.
4. Check for excessive play on the tie rod ends and rack guide.
5. Check for damage of the dust boots.
6. Check for looseness or grease leakage of the tie rod ends.



### INSPECTION OF STEERING LINKAGES, RACK GUIDE AND TIE ROD ENDS


Check the steering linkage for looseness and damage. Check that there is:

1. No excessive play on tie rod ends and rack guide.
2. No looseness or grease leakage on tie rod ends.




### INSPECTION OF SUSPENSION BALL JOINTS

Check the ball joints for damage, looseness and grease leakage.



### INSPECTION OF RACK SEAL BOOTS

Check the boot for cracking or other damage. If a problem is found, replace the boot.



### INSPECTION OF MANUAL TRANSMISSION OIL

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the transmission cover.
3. Remove the filler plug.
4. Verify that the oil is up to the bottom of the check plug hole.
5. If the oil level is low, add the specified oil through the filler plug port.
6. Install a new filler plug.


**Tightening torque:**


**25–39 N·m {2.5–4.0 kgf·m, 19–28 ft·lbf}**

7. Install the transmission cover.

**Tightening torque:**

**7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}**






**REPLACEMENT OF MANUAL TRANSMISSION OIL**

1. Remove the transmission cover.
2. Remove plug A (with washer) and B, and drain the oil into a suitable container.
3. Wipe all plug clean.
4. Apply sealant to the B plug threads.
5. Install new plugs A (with new washer) and B.

**Tightening torque:**

- A:** 40–58 N·m {4.0–6.0 kgf·m, 29–43 ft·lbf}
- B:** 21–31 N·m {2.1–3.2 kgf·m, 16–23 ft·lbf}




6. Remove filler plug and add the specified oil through the filler plug port until the level rises to the bottom of the port.

**Specified oil:**

- Grade:** API service GL-4 or GL-5
- All-season:** SAE 75W-90
- Above 10°C {50°F}:** SAE 80W-90

**Capacity:** 2.5 L {2.6 US qt, 2.2 Imp qt}



7. Install a new filler plug.


**Tightening torque:**

**25–39 N·m {2.5–4.0 kgf·m, 19–28 ft·lbf}**

8. Install the transmission cover.


**Tightening torque:**

**7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}**




**INSPECTION OF AUTOMATIC TRANSMISSION FLUID LEVEL (Except CANADA)**

1. Park the vehicle on level ground.
2. Apply the parking brake and securely position wheel chocks to prevent the vehicle from rolling.
3. Warm up the engine until the ATF temperature reaches 60–70°C {140–158°F}.




4. While depressing the brake pedal, shift the selector lever to each range (P–L). Leave it a few seconds in each range.
5. Shift back to P range.



- Ensure that the ATF level is between the notches of the ATF dipstick. Add ATF to the specified level, if necessary.

**ATF Type: Dexron®II or M-III**  
**Capacity: 8.6 L {9.1 US qt, 7.6 Imp qt}**




### INSPECTION OF DIFFERENTIAL OIL

#### Note

- Park the vehicle on level ground.

- Remove the filler plug.
- Verify that the oil is at the bottom of the filler plug hole. If it is low, add the specified oil.
- Install a new washer and the filler plug.

**Tightening torque:**  
**39–53 N·m {4.0–5.5 kgf·m, 29–39 ft·lbf}**



### REPLACEMENT OF DIFFERENTIAL OIL

- Remove the filler and drain plugs.
- Drain the differential oil into a suitable container.
- Wipe the plugs clean.
- Install a new washer and the drain plug.

**Tightening torque:**  
**39–53 N·m {4.0–5.5 kgf·m, 29–39 ft·lbf}**

- Add the specified oil from the filler plug hole until it reaches the bottom of the hole.

#### Specified oil

##### Type

Above  $-18^{\circ}\text{C}$   $\{0^{\circ}\text{F}\}$ : API GL-4 or 5, SAE 90

Below  $-18^{\circ}\text{C}$   $\{0^{\circ}\text{F}\}$ : API GL-4 or 5, SAE 80

**Capacity: 1.30 L {1.38 US qt, 1.14 Imp qt}**


- Install a new washer and the filler plug.


**Tightening torque:**  
**39–53 N·m {4.0–5.5 kgf·m, 29–39 ft·lbf}**

On vehicles equipped with limited-slip differential, API GL-5, SAE 90 special lubricant is required for limited-slip differentials.

### INSPECTION OF DRIVE SHAFT DUST BOOTS


Check the dust boot on the drive shaft for cracks, damage, grease leakage, and a loose boot band.






**TIGHTENING BOLTS AND NUTS ON CHASSIS AND BODY**

1. Tighten all seat mounting bolts.
2. Retighten all loose nuts and bolts of front and rear suspensions to the specified torque. (Refer to Section R)



**INSPECTION OF EXHAUST SYSTEM HEAT SHIELDS**

1. Check the clearance between insulator and body, and also between the insulator and the exhaust system.
2. Visually inspect the pipes, hangers and connections for severe corrosion, leaks or damage.



**INSPECTION OF SEAT BELTS, BUCKLES, RETRACTORS AND ANCHORS**

1. Pull each seat belt to be sure it moves smoothly.
2. Check for scratches, tears, or wear of the webbing, and for bent metal fittings.

**Caution**

- Do not disassemble the buckle or ELR assembly.

3. Check operation of retractors.
4. Check tightness of belt anchor bolts.



Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.

C

# ENGINE

C


<b>INDEX</b> .....	C - 2
<b>OUTLINE</b> .....	C - 3
SPECIFICATIONS .....	C - 3
<b>TROUBLESHOOTING GUIDE</b> .....	C - 3
<b>ENGINE TUNE-UP PROCEDURE</b> .....	C - 5
PREPARATION .....	C - 5
ENGINE OIL .....	C - 5
ENGINE COOLANT .....	C - 5
DRIVE BELT .....	C - 5
<b>COMPRESSION</b> .....	C - 9
PREPARATION .....	C - 9
<b>ON-VEHICLE MAINTENANCE</b> .....	C - 11
REAR OIL SEAL .....	C - 11
PREPARATION .....	C - 11
<b>REMOVAL</b> .....	C - 14
PREPARATION .....	C - 14
PROCEDURE .....	C - 14
<b>ENGINE STAND MOUNTING</b> .....	C - 21
PREPARATION .....	C - 21
PROCEDURE .....	C - 21
<b>DISASSEMBLY</b> .....	C - 23
PREPARATION .....	C - 23
AUXILIARY PARTS (I) .....	C - 24
TURBOCHARGER .....	C - 25
AUXILIARY PARTS (II) .....	C - 30
HOUSING (EXTERNAL PARTS I) .....	C - 36
HOUSING (EXTERNAL PARTS II) .....	C - 39
HOUSING (INTERNAL PARTS) .....	C - 41
HOUSING (ROTOR) .....	C - 43
<b>CLEANING</b> .....	C - 49
PREPARATION .....	C - 49
<b>INSPECTION / REPAIR</b> .....	C - 51
PREPARATION .....	C - 51
<b>ASSEMBLY</b> .....	C - 60
PREPARATION .....	C - 60
HOUSING (ROTOR) .....	C - 61
HOUSING (INTERNAL PARTS) .....	C - 62
HOUSING (EXTERNAL PARTS II) .....	C - 74
HOUSING (EXTERNAL PARTS I) .....	C - 78
AUXILIARY PARTS (II) .....	C - 87
TURBOCHARGER .....	C - 93
AUXILIARY PARTS (I) .....	C - 98
<b>ENGINE STAND DISMOUNTING</b> .....	C -101
PROCEDURE .....	C -101
<b>INSTALLATION</b> .....	C -102
PREPARATION .....	C -102
PROCEDURE .....	C -103

INDEX

COMPRESSION INSPECTION, PAGE C-9  
STANDARD: 830 KPa {8.5 kg/cm<sup>2</sup>, 120 psi}-250 rpm

ENGINE COOLANT INSPECTION  
SERVICE, SECTION E

ENGINE OIL INSPECTION  
SERVICE, SECTION D



DRIVE BELT  
DEFLECTION AT 98N {10 kgf, 22 lbf}

mm {in}

DRIVE BELT	NEW	USED	LIMIT
ALTERNATOR	6.0-7.0 {0.24-0.27}	7.0-7.5 {0.28-0.29}	9.0 {0.35}
P/S·A/C	3.5-4.0 {0.14-0.15}	4.5-5.0 {0.18-0.19}	6.0 {0.24}

1. Rear oil seal  
Replacement ..... page C- 11

2. Engine  
Removal ..... page C- 14  
Disassembly ..... page C- 23  
Cleaning ..... page C- 49  
Inspection / Repair ..... page C- 51  
Assembly ..... page C- 60  
Installation ..... page C-102

OUTLINE

SPECIFICATIONS

Item			Engine	13B Turbo
Engine type				Rotary
Displacement		ml {cc, cu in}		654 {654, 40.0} × 2
Number of Cylinders and arrangement				2 rotors, longitudinal
Combustion chamber type				Bathtub
Compression ratio				9.0 : 1
Air induction				4-port induction
Port timing	Intake	Open	Primary	45° BTDC
			Secondary	32° BTDC
		Close	Primary	50° ABDC
			Secondary	50° ABDC
	Exhaust	Open		75° BBDC
		Close		48° ATDC
Fuel supply system				CIS
Ignition timing*		Trailing		20° ATDC (-20° BTDC)
		Leading		5° ATDC (-5° BTDC)
Idle speed*			rpm	700 - 750

\* TEN terminal of data link connector is grounded.

TROUBLESHOOTING GUIDE

Problem	Possible cause	Action	Page
Difficult starting	<b>Insufficient compression</b> Deformation or abnormal wear of side housing Deformation or abnormal wear of rotor housing Wear of rotor grooves Deformation of or loose rotor seals Worn or weak rotor seal springs	Replace Replace Replace Replace Replace	C-51 C-54 C-57, 58 C-57, 58 —
	<b>Malfunction of metering oil pump</b>		Section D
	<b>Malfunction of electrical system</b>		Section F
	<b>Malfunction of electrical system</b>		Section G
Poor idling	<b>Insufficient compression</b> Deformation or abnormal wear of side housing Deformation or abnormal wear of rotor housing Wear of rotor grooves Deformation of or loose rotor seals Worn or weak rotor seal springs	Replace Replace Replace Replace Replace	C-51 C-54 C-57, 58 C-57, 58 —
	<b>Malfunction of fuel system</b>		Section F
	<b>Malfunction of ignition system</b>		Section G

# C


## TROUBLESHOOTING GUIDE





Problem	Possible cause	Action	Page
<b>Insufficient power</b>	<b>Insufficient compression</b> Deformation or abnormal wear of side housing Deformation or abnormal wear of rotor housing Wear of rotor grooves Deformation or loose rotor seals Worn or weak rotor seal springs	Replace Replace Replace Replace	C-51 C-54 C-57, 58 C-57, 58
	<b>Malfunction of fuel system</b>		Section F
	<b>Malfunction of ignition system</b>		Section G
<b>Abnormal combustion</b>	<b>Malfunction of combustion chamber</b> Carbon accumulation	Remove and clean	C-49
	<b>Malfunction of fuel system</b>		Section F
	<b>Malfunction of ignition system</b>		Section G
<b>Excessive oil consumption</b>	<b>Leakage into combustion chamber</b> Deformation or abnormal wear of side housing Malfunction of rotor (blow holes) Scratched or burred rotor land Malfunction of oil seal (incorrect angle)	Replace Replace Replace Replace	C-51 C-54 C-54 C-56
	<b>Leakage into coolant passages</b> Deformed rotor housing Malfunction of sealing rubber	Replace Replace	C-54 —
	<b>Leakage to outside of engine</b>		Section D
	<b>Malfunction of lubrication system</b>		Section D
<b>Engine noise</b>	<b>Rotor seal noise</b> Malfunction of rotor seals Malfunction of housing Malfunction of seal spring Malfunction of metering oil pump	Replace Replace Replace	C-56, 57 C-51, 54 C-56, 57 Section D
	<b>Knocking noise</b> Accumulation of carbon	Remove and clean	C-49
	<b>Hitting noise</b> Malfunction of main hearing or rotor hearing Excessive end play Foreign matter in internal gear or stationary gear or malfunction of gear	Replace Adjust Replace	C-53, 56 C-74 C-53
	<b>Other</b> Malfunction of water pump bearing Loose drive belt Malfunction of alternator bearing Exhaust gas leakage Malfunction of fuel system	Adjust	Section E C-5 Section G Section F Section F

ENGINE TUNE-UP PROCEDURE

PREPARATION

SST

<p>49 9200 020</p> <p>Tension gauge, V-ribbed belt</p> 	<p>For inspection of drive belt tension</p>
--	---



ENGINE OIL

Warning

- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.

Inspection

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the dipstick and check the oil level and condition.
5. Add or replace oil if necessary.

Note

- The distance between the L and F marks on the dipstick represents 1.7L {1.8 US qt, 1.5 Imp qt}.

ENGINE COOLANT

Inspection

Coolant level (Engine cold)

Warning

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam can shoot out and cause serious injury. It can also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counter-clockwise to the first stop. Step back while the pressure escapes.

When you're sure all the pressure is gone, press down on the cap-still using a cloth-turn it, and remove it.

1. Verify that the coolant level is near the filler port neck.
2. Remove the coolant level dipstick from the coolant reservoir and verify that the coolant level is between the F and L marks. Add coolant if necessary.

Coolant quality

1. Verify that there is no buildup of rust or scale around the radiator cap and radiator filler neck.
2. Verify that the coolant is free of oil.
3. Replace the coolant if necessary.


DRIVE BELT

Inspection

1. Check the drive belts for wear, cracks, and fraying. Replace if necessary.
2. Verify that the drive belts are correctly mounted on the pulleys.

# C

## ENGINE TUNE-UP PROCEDURE




- Check the drive belt deflection when the engine is cold, or at least 30 minutes after the engine has stopped. Apply moderate pressure 98 N {10 kgf, 22 lbf} midway between the specified pulleys.

### Deflection

Drive belt	mm (in)		
	New*	Used	Limit
Alternator	6.0-7.0 {0.24-0.27}	7.0-7.5 {0.28-0.29}	9.0 {0.35}
P/S·A/C	3.5-4.0 {0.14-0.15}	4.5-5.0 {0.18-0.19}	6.0 {0.24}

\* A belt that has been on a running engine for less than five minutes.

- If the deflection is not within specification, adjust it.



### Drive belt tension check

#### Note

- Belt tension can be checked in place of belt deflection.
- Belt tension can be measured between any two pulleys.

- Using the SST, check the belt tension.

### Tension

Drive belt	N{kgf·lbf}		
	New*	Used	Limit
Alternator	690-780 {70-80, 160-170}	590-680 {60-70, 140-150}	320 {33, 73}
P/S·A/C	740-880 {75-90, 170-190}	540-630 {55-65, 130-140}	320 {33, 73}

\* A belt that has been on a running engine for less than five minutes.

- If the tension is not within specification, adjust it.


### Adjustment


#### Alternator

- Loosen bolt (A) and nut (B).
- Adjust the belt deflection by turning adjusting bolt (C).

#### Deflection

New: 6.0-7.0 mm {0.24-0.27 in}  
 Used: 7.0-7.5 mm {0.28-0.29 in}  
 Limit: 9.0 mm {0.35 in}






3. Tighten bolt (A) and nut (B).

**Tightening torque:**

**Bolt (A)** 38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}  
**Nut (B)** 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}



**P/S, A/C**

1. Loosen idler pulley locknut (A).
2. Adjust the belt deflection by turning adjusting bolt (B).


**Deflection**

**New:** 3.5–4.0 mm {0.14–0.15 in}  
**Used:** 4.5–5.0 mm {0.18–0.19 in}  
**Limit:** 6.0 mm {0.24 in}

3. Tighten nut (A).

**Tightening torque:**


**37–53 N·m {3.7–5.5 kgf·m, 27–39 ft·lbf}**



**Replacement**

**P/S, A/C**


1. Disconnect the air hoses shown in the figure.



2. Loosen idler pulley locknut (A).
3. Loosen adjusting bolt (B).
4. Remove the belt.

# C

## ENGINE TUNE-UP PROCEDURE



5. Install the new belt on the pulleys.
6. Adjust the belt deflection by turning adjusting bolt **B**.

### Deflection


3.5–4.0mm {0.14–0.15 in}

7. Tighten idler pulley locknut **A**.

### Tightening torque:


37–53 N·m {3.7–5.5 kgf·m, 27–39 ft·lbf}

8. Connect the air hoses.




### Alternator


1. Disconnect the air hoses shown in the figure.



2. Loosen air pump mount bolts **A** and **B**.



3. Loosen alternator mount bolt **A** and locknut **B**.
4. Loosen adjusting bolt **C**.
5. Remove the drive belt.




6. Install the new drive belt on the pulleys.
7. Tighten the air pump mount bolts **A** and **B** while applying the pressure to the drive belt.

### Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}





8. Adjust the belt deflection by turning adjusting bolt ③.

**Deflection**

6.0–7.0 mm {0.24–0.27 in}

9. Tighten alternator mount bolt ① and locknut ②.

**Tightening torque:**

Bolt ① 38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}

Nut ② 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}



10. Connect the air hoses.

## COMPRESSION


If the engine exhibits low power, poor fuel economy, or poor idle, check the following:

1. Ignition system (Refer to Section G.)
2. Compression
3. Fuel system (Refer to Section F.)


## PREPARATION

### SST

<p>49 F018 9A0</p> <p>Tester, compression</p>		<p>For Inspection of compression</p>
---	--	--



1. Check that the battery is fully charged. Recharge it if necessary.
2. Warm up the engine to the normal operating temperature, then stop it.
3. Allow about 10 minutes for the exhaust manifold to cool.
4. Remove the front and rear trailing-side spark plugs.
5. Disconnect the circuitopening relay and the igniter connector.




6. Connect the SST to the front rotor housing and the battery.
7. Fully depress the accelerator pedal and crank the engine for 5 to 10 seconds.
8. Record the compression of the three combustion chambers and cranking speed.

**Compression:**

690 kPa {7.0 kgf/cm<sup>2</sup>, 100 psi}–250 rpm


**Differential limit of chambers:**

150 kPa {1.5 kgf/cm<sup>2</sup>, 21 psi}–250 rpm




- 1) If pressure is below 290 kPa {3.0 kgf/cm<sup>2</sup>, 43 psi} at one or two chambers of a rotor, the tester indicates one correct measurement and two 00.0 readings.
- 2) If pressure is below 290 kPa {3.0 kgf/cm<sup>2</sup>, 43 psi} at three chambers, the tester indicates three 00.0 readings.
- 3) In the above cases, the cranking speed readings are all 00.0.

9. Check the rear chambers by using the same procedure.
10. Compensate the compression values if they are measured at cranking speeds other than standard or if they are measured at high altitude.



**Cranking speed compensation**

Compensate the compression according to the cranking speed.









**Altitude compensation**

Compensate the compression according to the altitude.

ON-VEHICLE MAINTENANCE

REAR OIL SEAL  
PREPARATION  
SST

<p>49 F011 101 Brake, ring gear</p> 	<p>For prevention of eccentric shaft rotation</p>	<p>49 0820 035 Box wrench, flywheel</p> 	<p>For removal of flywheel locknut</p>
<p>49 1881 055A Stopper, counterweight</p> 	<p>For prevention of eccentric shaft rotation</p>	<p>49 0839 305A Puller, counterweight</p> 	<p>For removal of counterweight</p>
<p>49 0813 225 Remover, oil seal</p> 	<p>For Removal of oil seal</p>		



Removal Note


1. Disconnect the negative battery cable.
2. Drain the engine oil.
3. Remove the manual transmission. (Refer to Section J.)  
Remove the automatic transmission. (Refer to Section K.)

(MT)

- (1) Remove the clutch cover and clutch disc. (Refer to Section H.)
- (2) Install the SST against the flywheel.

Caution


- Place a rag between the SST and the vacuum pipes to protect the pipes.




- (3) Remove the lock nut by using the SST.

# C


## ON-VEHICLE MAINTENANCE




- (4) Remove the flywheel by using the SST.
- (5) Remove the key.




- (AT)
- (1) Install the SST against the counterweight.




- (2) Remove the back plate and drive plate.
- (3) Remove the lock nut by using the SST.



- (4) Remove the counterweight by using the SST.



- (MT and AT)
- 4. Remove the oil seal by using the SST.




**Installation Note**

**Rear oil seal**


1. Apply engine oil to the seal lip.
2. Fit the oil seal onto the stationary gear.
3. Using a pipe and hammer, tap the oil seal in evenly until it is flush with the edge of the rear cover.

**Oil seal outer diameter: 95.0 mm {3.74 in}**



**Flywheel (MT)**

1. Fit the key to the eccentric shaft.
2. Install the flywheel to the eccentric shaft.
3. Apply thread-locking compound to the eccentric shaft threads.
4. Apply sealant to the contact surface of the locknut.




5. Install the lock nut and tighten it with the SST.

**Tightening torque:**

**400–490 N·m {40–50 kgf·m, 290–360 ft·lbf}**


**Caution**

- Place a rag between the SST and the vacuum pipes to protect pipes.



**Drive plate (AT)**

1. Fit the key to the eccentric shaft.
2. Install the counterweight to the eccentric shaft.
3. Apply thread-locking compound to the eccentric shaft threads.
4. Apply sealant to the contact surface of the lock nut.




5. Install the locknut and tighten it with the SST.

**Tightening torque:**

**400–490 N·m {40–50 kgf·m, 290–360 ft·lbf}**

# C

## REMOVAL



6. Install the drive plate and the back plate.

### Tightening torque:

**44–60 N·m {4.4–6.2 kgf·m 32–44 ft·lbf}**


### Steps After Installation

1. Add engine oil to the specified level.
2. Connect the negative battery cable.
3. Start the engine and do the following:
  - (1) Check for leakage of engine oil.
  - (2) Perform engine adjustments as necessary.
  - (3) Recheck the oil level.

## REMOVAL

### PREPARATION

#### SST

49 W023 585A		For prevention of P/S oil pump rotation
Adjust wrench		


### PROCEDURE

#### Warning

- Release the fuel pressure. (Refer to Section F)
- Keep sparks and open flames away from fuel area.

1. Disconnect the negative battery cable.
2. Drain the engine coolant and engine oil.
3. Remove the hood.
4. Remove the transmission. (Refer to Section J or K.)
5. Disconnect the powertrain control module. (Refer to Section F.)
6. Remove in the order shown in the figure, referring to **Removal Note**.

Step 1




- 1. Undercover
- 2. Fresh-air duct
- 3. Battery and box
- 4. Strut bar  
Removal Note ..... page C-16
- 5. Accelerator cable
- 6. Air cleaner housing
- 7. Hose
- 8. Water hose
- 9. Air hose
- 10. Radiator hose (upper)

- 11. Fuse box  
Removal Note ..... page C-16
- 12. Drive belt  
Removal Note ..... page C- 7
- 13. P/S oil pump pulley  
Removal Note ..... page C-16
- 14. P/S oil pump  
Removal Note ..... page C-16
- 15. A/C compressor  
Removal Note ..... page C-16

# C


## REMOVAL



### Removal Note


#### Strut bar

1. Remove the strut bar.
2. Temporarily tighten the lock nut to the stud bolt.




### Fuse box

Remove the fuse box with the harness still connected.




### P/S oil pump pulley

1. Hold the P/S oil pump pulley by using the SST.
2. Remove the P/S oil pump pulley nut.
3. Remove the P/S oil pump pulley.



### P/S oil pump

1. Remove the P/S oil pump with the hose still connected.
2. Position the pump away from the engine, and support it with wire.




### A/C Compressor


1. Remove the A/C compressor with the hoses still connected.
2. Position the compressor away from the engine, and support it with wire.



**Step 2**  
Disconnect the harness connectors and hoses.



Step 3



1. Radiator hose (lower)

2. Oil pipe

Removal Note ..... page C-19

3. Insulator

Removal Note ..... page C-19


4. Front exhaust pipe

Removal Note ..... page C-19

5. Split air pipe

6. Oil cooler pipe (AT)


Removal Note ..... page C-19



**Removal Note**


**Oil pipe**

Remove the clip and disconnect the oil pipe, using a drain pan to catch the oil.




**Insulator**

Remove the insulators in the order shown in the figure. Keep the surface of the insulator free from oil.




**Front exhaust pipe**

1. Disconnect the oxygen sensor harness.
2. Remove the front exhaust pipe.



**Oil cooler pipe (AT)**


1. Disconnect the oil cooler pipe.



2. Remove the nut shown in the figure.


# C

## REMOVAL












3. Remove the bolt shown in the figure and disconnect the oil cooler pipe from the engine.


**Step 4**  
Remove the engine assembly.



ENGINE STAND MOUNTING

PREPARATION  
SST


<p>49 0107 680A Stand, engine</p> 	<p>For disassembly / assembly of engine</p>	<p>49 L010 1A0 Hanger set, engine stand</p> 	<p>For disassembly / assembly of engine</p>
<p>49 L011 101 Plate (Part of 49 L011 1A0)</p> 	<p>For disassembly / assembly of engine</p>	<p>49 L010 102 Arms (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>
<p>49 L010 103 Hooks (Part of 49 L011 1A0)</p> 	<p>For disassembly / assembly of engine</p>	<p>49 L010 104 Nuts (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>
<p>49 L010 105 Bolts (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>	<p>49 L010 106 Bolts (Part of 49 L010 1A0)</p> 	<p>For disassembly / assembly of engine</p>
<p>49 1114 005 Hanger, engine</p> 	<p>For disassembly / assembly of engine</p>		




**PROCEDURE**  
When using 49 L010 1A0  
1. Remove the oil pipe.

# C


## ENGINE STAND MOUNTING




2. Remove the A/C compressor and P/S oil pump bracket.
3. Remove the stud.



4. Install the SST (arms) to the block holes shown in the figure and loosely tighten bolts A.



5. Assemble the SST (bolts, nuts, hooks and plate).
6. Install the SST assembly to the respective arms while adjusting parallelism between the arms and plate by turning the bolts and nuts.




### Warning


- Although the engine stand has a self-locking brake system, there is a possibility that the brake may not be effective in the following situations:

1. When the engine is held in an unbalanced position.
2. While rotating the engine, if it passes through an unbalanced position.

Either of these situations could lead to sudden, rapid movement of the engine and mounting stand handle and cause serious injury. Never keep the engine in an unbalanced position, and always hold the rotating handle firmly when turning the engine.




7. Tighten the bolts and nuts to affix the SST.
8. Install the engine on the SST (engine stand).



**When using 49 1114 005**









1. Remove the oil pipe, engine mounts, and P/S oil pump bracket.
2. Install the SST as shown in the figure.



3. Mount the engine on the SST (engine stand).

**DISASSEMBLY**

**PREPARATION  
SST**

<p>49 F011 101 Brake, ring gear</p> 	<p>For prevention of engine rotation</p>	<p>49 1881 055A Stopper, counterweight</p> 	<p>For prevention of engine rotation</p>
<p>49 0820 035 Box wrench, flywheel</p> 	<p>For removal/ installation of locknut</p>	<p>49 0839 305A Puller, counterweight</p> 	<p>For removal of counterweight</p>
<p>49 0813 215A Puller, tubular dowel</p> 	<p>For removal of tubular dowel</p>	<p>49 0813 225 Remover, oil seal</p> 	<p>For removal of oil seal</p>
<p>49 0813 250 Case, seal</p> 	<p>For arrangement of rotor seals</p>	<p>49 H018 001 Wrench, knock sensor</p> 	<p>For removal of knock sensor</p>

**Warning**

- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.


# C

## DISASSEMBLY

1. Code all identical parts (such as rotors, rotor oil seals, rotor seals, and seal springs) so that they can be reinstalled in the location from which they were removed.
2. Clean the parts with a steam cleaner; blow off any remaining water with compressed air.

### AUXILIARY PARTS (I)

1. Drain the engine oil.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



1. Drive belt
2. Water pump pulley
3. Drive belt pulley
4. Alternator and bracket


5. Air pump and bracket
6. Pressure chamber
7. Air pipe and bracket
8. Engine mount (RH and LH)



**TURBOCHARGER****Turbocharger handling procedures.**


- Holding the actuator, the rod, or the actuator hose when removing and carrying the turbocharger can cause damage.
- Set the turbine down with the shaft horizontal.
- Replace damaged studs and nuts. Use only the specified studs and nuts. Using damaged or unspecified studs and nuts can cause gas leakage because of insufficient clamping.
- Protect the oil pipe from deformation. Deformation will inhibit oil flow and may damage the turbocharger due to overheating.
- Foreign material in the oil line can damage the turbocharger. Keep the oil line clean.
- Cover the turbocharger air port and exhaust port with tape to keep out foreign material. It can damage the turbocharger's internal components.
- Protect the insulators from deformation and oil. Deformed or oily insulators can lead to damage to the turbocharger due to overheating.

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- 1. Air pipe
- 2. Air pipe and control valve  
Disassembly Note ..... page C-27
- 3. Vacuum pipe and hoses  
Disassembly Note ..... page C-27

- 4. Air intake pipe
- 5. Turbo control actuator  
Disassembly Note ..... page C-27
- 6. Clip
- 7. Turbocharger assembly  
Disassembly Note ..... page C-28




**Disassembly Note**  
**Air pipe and control valve**

1. Disconnect the hoses shown in the figure.




2. Disconnect the vacuum hoses shown in the figure.  
 3. Remove the air pipe and control valve assembly.




**Vacuum pipe and hoses**

1. Disconnect the vacuum hoses shown in the figure.  
 2. Remove the nuts shown in the figure.  
 3. Disconnect the vacuum pipe and hoses from the turbocharger.



**Turbo control actuator**

1. Remove the clip shown in the figure.



2. Remove the bolts and remove the turbo control actuator.

# C


## DISASSEMBLY

### Turbocharger assembly


#### Caution

- Hold the pipe by using a wrench.


1. Use two wrenches when disconnecting the oil inlet pipe.





2. Disconnect the water hose and oil inlet pipe.




3. Disconnect the oil outlet pipes.



4. Disconnect the water hose.







5. Remove the bolts and nuts and remove the turbocharger assembly.

**AUXILIARY PARTS (II)**

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- |                               |                                  |
|-------------------------------|----------------------------------|
| 1. Seal plate                 | 5. Surge tank assembly           |
| 2. Exhaust manifold insulator | Disassembly Note ..... page C-31 |
| 3. Exhaust manifold           | 6. Intake manifold assembly      |
| 4. Exhaust manifold gasket    | Disassembly Note ..... page C-32 |




**Disassembly Note**  
**Surge tank assembly**


1. Remove the bolts shown in the figure.
2. Disconnect the duty solenoid valve from the surge tank.




3. Disconnect the vacuum hoses and blowby hose shown in the figure.
4. Loosen the bolt shown in the figure.



5. Disconnect the hoses and connectors shown in the figure.




6. Disconnect the connector shown in the figure.



7. Remove the bolts and remove the surge tank assembly.


# C

## DISASSEMBLY




### Intake manifold assembly


1. Disconnect the hose shown in the figure.



2. Disconnect the fuel hose and vacuum hose shown in the figure.




3. Remove the oxygen sensor connector.




4. Remove the nut shown in the figure.

5. Remove the three-way solenoid.




6. Disconnect the vacuum hoses shown in the figure.







7. Disconnect the vacuum hoses shown in the figure.




8. Disconnect the fuel injector connectors.



9. Disconnect the connectors.




10. Remove the intake manifold assembly.



11. Disconnect the vacuum hose.

**Vacuum pipe assembly**

Disassemble in the order shown in the figure.




1. Vacuum chamber (AT)  
2. Ignition coil assembly

3. Oil filler pipe  
4. Vacuum chamber


**Harness**

Disconnect the harness connectors shown in the figure.




**HOUSING (EXTERNAL PARTS I)**


Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- |   |  |
|---|--|
| 1. Drive plate (AT)<br>Disassembly Note ..... page C-37   | 7. Water pump body<br>Service ..... Section E        |
| 2. Fuel delivery pipe and mixing plate<br>Disassembly Note ..... page C-37<br>Service ..... Section F | 8. Metering oil pump<br>Service ..... Section D      |
| 3. Oil inlet pipe   | 9. Engine hanger                                     |
| 4. Oil filter and body  | 10. Oil pan<br>Disassembly Note ..... page C-38      |
| 5. Oil pipe   | 11. Oil strainer                                     |
| 6. Metering oil nozzle<br>Service ..... Section D   | 12. Knock sensor<br>Disassembly Note ..... page C-38 |

**Disassembly Note****Drive plate (AT)**


1. Attach the SST to the counterweight.




2. Remove the retainer and the drive plate.

**Fuel delivery pipe and mixing plate**

1. Remove the fuel delivery pipe and spacer.



2. Reach into the intake port and push out the mixing plate by hand.

**Oil pan**


1. Remove the oil pan attaching bolts.

**Caution**


- Pry tools can easily scratch the oil pan contact surfaces. Prying off the oil pan can also easily bend the oil pan flange. Refer to the following instructions before removing the oil pan.

# C

## DISASSEMBLY



2. Remove the oil pan by inserting screwdriver into only the areas shown in the figure.




### Knock sensor

Remove the knock sensor by using the SST.

**HOUSING (EXTERNAL PARTS II)**


Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- |  |   |
|--|---|
| 1. Eccentric shaft lock bolt<br>Disassembly Note ..... page C-40 | 12. Oil pump sprocket wheel<br>Disassembly Note ..... page C-40 |
| 2. Pulley boss   | 13. Oil pump drive chain<br>Inspection ..... page C-59          |
| 3. Eccentric shaft bypass valve<br>Inspection ..... page C-59    | 14. Oil pump drive sprocket<br>Inspection ..... page C-59       |
| 4. Spring  | 15. Oil pump<br>Service ..... Section D                         |
| 5. Front cover   | 16. Balance weight  |
| 6. Oil seal<br>Disassembly Note ..... page C-40                  | 17. Key   |
| 7. Plug  | 18. Thrust washer<br>Inspection ..... page C-59                 |
| 8. Control valve spring  | 19. Needle bearing<br>Inspection ..... page C-59                |
| 9. Control valve   | 20. Spacer  |

# C


## DISASSEMBLY




### Disassembly Note

#### Eccentric shaft lock bolt

1. Attach the SST to the flywheel (MT) or counterweight (AT).




2. Remove the eccentric shaft lock bolt.



#### Oil seal

Remove the oil seal by using a screwdriver protected with a rag.




#### Oil pump sprocket wheel

1. Lift the lock washer tab and remove the sprocket lock nut.
2. Remove the oil pump drive gear, sprocket wheel, and drive chain as an assembly.



**HOUSING (INTERNAL PARTS)**


Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- |   |           |  |           |
|---|-----------|--|-----------|
| 1. Flywheel (MT) / Counterweight (AT)<br>Disassembly Note ..... | page C-44 | 12. Tubular dowel<br>Disassembly Note .....        | page C-47 |
| 2. Tension bolts<br>Disassembly Note .....                      | page C-45 | 13. Intermediate housing<br>Disassembly Note ..... | page C-47 |
| 3. Rear housing<br>Disassembly Note .....                       | page C-45 | Inspection .....                                   | page C-51 |
| 4. Rear oil seal<br>Disassembly Note .....                      | page C-45 | 14. Front rotor housing<br>Disassembly Note .....  | page C-47 |
| 5. Rear stationary gear<br>Inspection .....                     | page C-52 | Inspection .....                                   | page C-54 |
| 6. Oil regulator valve<br>Service .....                         | Section D | 15. Eccentric shaft<br>Inspection .....            | page C-58 |
| 7. Oil pressure switch<br>Disassembly Note .....                | page C-45 | 16. Front rotor<br>Disassembly Note .....          | page C-47 |
| 8. Heat gauge unit  |           | Inspection .....                                   | page C-54 |
| 9. Tubular dowel<br>Disassembly Note .....                      | page C-46 | 17. Plate  |           |
| 10. Rear rotor housing<br>Disassembly Note .....                | page C-46 | 18. Needle bearing<br>Inspection .....             | page C-59 |
| Inspection .....  | page C-54 | 19. Thrust washer<br>Inspection .....              | page C-59 |
| 11. Rear rotor<br>Disassembly Note .....                        | page C-46 | 20. Front stationary gear<br>Inspection .....      | page C-52 |
| Inspection .....  | page C-54 | 21. Front housing<br>Inspection .....              | page C-51 |


**HOUSING (ROTOR)**

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- 1. Apex seal and side piece  
Inspection ..... page C-57
- 2. Second piece  
Inspection ..... page C-57
- 3. Apex seal spring (short)
- 4. Apex seal spring (long)
- 5. Corner seal  
Inspection ..... page C-58
- 6. Corner seal spring

- 7. Side seal  
Inspection ..... page C-57
- 8. Side seal spring
- 9. Oil seal and O-ring  
Disassembly Note ..... page C-48  
Inspection ..... page C-56
- 10. Oil seal spring
- 11. Rotor bearing  
Inspection ..... page C-56
- 12. Rotor  
Inspection ..... page C-55



**Disassembly Note  
Flywheel (MT)**


1. Remove the flywheel nut by using the SST.



2. Remove the flywheel by using the SST.


3. Remove the key.

4. Remove the SST.




**Counterweight (AT)**

1. Remove the counterweight nut by using the SST.




2. Remove the counterweight by using the SST.




3. Remove the key by using a pryer protected with rag.


4. Remove the SST.

**Tension bolts**


1. Loosen the tension bolts gradually and in the sequence shown in the figure; then remove them.




2. Rotor seals (apex, side, and corner) are identified by the numbers near each corresponding groove on the rotor face. Place them in the SST according to the numbers.

**Rear housing**


1. Remove the rear housing.
2. If the seals stick to the housing when it is removed, put them back into their original position.

**Oil pressure sensor**


- Remove the oil pressure sensor by using a wrench.

**Rear oil seal**


- Remove the oil seal cover and the oil seal from the rear housing.

**Tubular dowel**

Remove the tubular dowels by using the SST.


**Rear rotor housing**

1. Remove the side pieces and place them in the SST.




2. Remove the rotor housing. Be careful not to drop the apex seals.

3. Remove the O-ring from the upper dowel hole.

**Rear rotor**

1. Remove the seals and springs, and place them in position in the SST.




2. Remove the rotor.


If the seals stick on the intermediate housing surface, put them back into their respective position in the rotor.

**Caution**

- Place the rotor on a soft surface to prevent damaging it.




3. Remove the seals and springs, and put them in position in the SST.
4. Mark the rotor with an "R" for proper reassembly.




#### Tubular dowel

Remove the tubular dowels by using the SST.




#### Intermediate housing

1. Turn the eccentric shaft so that the rotor journal faces in the short axial direction.
2. Remove the intermediate housing while pushing the eccentric shaft up.
3. If the seals stick to the intermediate housing surface, put them back into their respective position in the rotor.
4. Remove the sealing rubbers.



#### Front rotor housing

1. Remove the side pieces and place them in the SST.
2. Remove the rotor housing. Be careful not to drop the apex seals.
3. Remove the O-ring from the upper dowel hole.




#### Front rotor

Remove the front rotor in the same procedure as the removal of the rear rotor.

# C

## DISASSEMBLY




### Rotor oil seal


1. Remove the outer oil seal from the rotor by using the SST.
2. Remove the inner oil seal in the same manner.
3. Remove the oil seal springs.
4. Remove the O-ring from the oil seal.




**CLEANING****PREPARATION  
SST**

<p>49 0813 225</p> <p>Remover, oil seal</p> 	<p>For cleaning of rotor</p>
---	--------------------------------------

Clean all parts, making sure to remove any gasket fragments, dirt, oil, grease, carbon, and other materials.

**Side Housing (front, intermediate and rear housings)**


1. Remove the sealing agent from the housing surface by using a cloth or a brush soaked in solvent or thinner.




2. Remove all carbon from the rotor chamber surface by using extrafine emery paper.

**Caution**


- Carbon scrapers can damage the surface.

**Rotor Housing**

1. Inspect for traces of gas or water leakage along the inner margin of the rotor housings.
2. Remove all carbon from the inner surface of the rotor housing by wiping with a cloth soaked in solvent or thinner.



3. Remove all deposits and rust from the coolant passages of the housing.
4. Remove the sealing agent from the housing by wiping with a cloth or brush soaked in solvent or thinner.




#### Rotor

1. Remove the carbon from the rotor by using a nonabrasive sponge and carbon cleaner.

#### Caution

- Cleaning materials can damage the soft material coating on the side surfaces.

2. Remove the carbon from each groove.
3. Wash the rotor with a cleaning solution.




#### Rotor Seal (apex, side and corner seals)

1. Remove the carbon from each seal by using the SST.
2. Wash the seals with a cleaning solution.

#### Caution

- Emery paper will damage the seals. Don't use emery paper.






#### Eccentric Shaft


1. Wash the eccentric shaft with a cleaning solution.
2. Blow the oil passages to clean with compressed air.

INSPECTION / REPAIR

PREPARATION  
SST

<p>49 0727 570 Body, gauge</p> 	<p>For inspection of side housing</p>	<p>49 0813 235 Replacer main bearing</p> 	<p>For removal / installation of main bearing</p>
<p>49 0839 165 Gauge, corner seal</p> 	<p>For inspection of corner seal</p>	<p>49 0813 240 Replacer rotor bush</p> 	<p>For removal / installation of rotor hearing</p>


1. Clean all parts, making sure to remove any gasket fragments, dirt, oil, grease, carbon, moisture residue, and other foreign materials. (Refer to page C-50.)
2. Inspect and repair in the specified order.




**Side Housing (front, intermediate and rear housings)**

1. Check the housing surface for warpage in the four directions shown in the figure. If necessary, replace the housing.

**Warpage: 0.04 mm {0.0016 in} max.**




2. Check the contact surface for wear by using a dial indicator mounted on the SST. Slide the gauge across the area as indicated in the figure.



(1) Side seal wear

**Wear: 0.10 mm {0.0039 in} max.**




(2) Side seal wear, overlapping oil seal wear

**Wear: 0.01 mm {0.0004 in} max.**


(3) Side seal wear, outside oil seal wear

**Wear: 0.10 mm {0.0039 in} max.**




(4) Oil seal wear

**Wear: 0.02 mm {0.0008 in} max.**



**Stationary Gear**

1. Check the front and rear stationary gear for cracked, scored, worn, and chipped teeth.



2. If necessary, replace the stationary gear.


(1) (Front stationary gear)

Remove the plate, needle bearing, and thrust plate.


(Rear stationary gear)

Remove the attaching bolts.

(2) Remove the stationary gear by using the SST.




- (3) (Rear stationary gear only)  
Apply petroleum jelly to a new O-ring and install it on the rear stationary gear. Apply sealant to the stationary gear flange.




- (4) Install the stationary gear to the housing so that the slot of the stationary gear is fit over the dowel on the housing.
- (5) (Front stationary gear)  
Install the thrust plate, needle bearing, and plate.  
(Rear stationary gear)  
Tighten the attaching bolts.

**Tightening torque:**  
16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}




**Main Bearing**

- 1. Check the main bearing for wear, scoring, flaking, and other damage.
- 2. Measure the main bearing clearance. Measure the inner diameter of the main bearing and the outer diameter of the eccentric shaft main journal.



- 3. The inside and outside journal specifications are different.


**Standard clearance:**  
0.08–0.11 mm {0.0032–0.0043 in} outside  
0.06–0.08 mm {0.0024–0.0031 in} inside  
**Maximum:** 0.13 mm {0.0051 in} outside  
0.11 mm {0.0043 in} inside




- 4. If necessary, replace the main bearing.
  - (1) Remove the stationary gear. (Refer to page C-52.)
  - (2) Remove the screw.

# C


## INSPECTION / REPAIR




- (3) Place the stationary gear on the support with the gear facing upward.
- (4) Press out the main bearing by using the **SST** without the adapter ring. Discard the bearing.



- (5) Place the stationary gear on the support with the gear downward.
- (6) Place the new main bearing on the stationary gear so that the small hole is in line with the screw hole of the stationary gear.




- (7) Press in the main bearing by using the **SST**.




- (8) Remove the thread-locking compound from the screw and screw hole threads.
- (9) Apply new thread-locking compound to the screw threads and tighten the screw.

**Tightening torque:**  
 $3.3-4.7 \text{ N}\cdot\text{m}$  { $33-48 \text{ kgf}\cdot\text{cm}$ ,  $29-41 \text{ in}\cdot\text{lbf}$ }



### Rotor Housing


1. Check the chromium plated surface on the rotor housing for scoring, flaking, and other damage.
2. Check the width difference of the rotor housing.
  - (1) Measure the rotor housing width at the points **A**, **B**, **C**, and **D**, as shown in the figure.



- (2) Calculate the difference between the value of point **A** and the minimum value among points **B**, **C**, and **D**.


**Difference: 0.06 mm {0.0024 in} max.**

3. If the difference exceeds the specification, replace the rotor housing.



#### Rotor


1. Carefully inspect the rotor and replace if it is severely worn or damaged.
2. Check the internal gear for cracked, scored, worn, and chipped teeth.




3. Check the clearance between the side housing and rotor. Measure the rotor housing width (point **A**) and the maximum rotor width at the three points indicated in the figure.

**Standard: 0.12–0.21 mm {0.0048–0.0082 in}**

**Clearance: 0.10 mm {0.0039 in} min.**




4. If the clearance is less than specified, replace the rotor assembly.



5. Check the corner seal bore for wear by using the **SST**.

- (1) If neither end of the gauge goes into the bore, use the original corner seal.
- (2) If only one end of the gauge goes into the bore, replace the corner seal.
- (3) If both ends of the gauge go into the bore, replace the rotor.




### Rotor Bearing

1. Check the rotor bearing for wear, flaking, scoring, and other damage.
2. Check the rotor bearing clearance. Measure the inner diameter of the rotor bearing and the outer diameter of the eccentric shaft rotor journal.


**Standard clearance:**

0.06–0.08 mm {0.0024–0.0031 in}


**Clearance: 0.10 mm {0.0039 in} max.**



3. If not within specification, replace the rotor bearing.
  - (1) Place the rotor on a support with the internal gear downward.
  - (2) Press the bearing out of the rotor by using the SST without the adapter ring.




- (3) Place the rotor on the support with the internal gear facing upward.
- (4) Place the new rotor bearing on the rotor so that the bearing lug is in line with the slot of the rotor bore.
- (5) Using the SST, press the bearing in until it is flush with the rotor boss.



### Rotor Oil Seal

1. Inspect the oil seal for wear and damage. If necessary, replace it.
2. Check the oil seal lip width.

**Lip width: 0.5 mm {0.020 in} max.**




3. Install the oil seal springs and oil seals into their respective grooves.
4. Check the oil seals for free vertical movement.
5. Check the oil seal protrusion.

**Protrusion: 0.5 mm {0.020 in} min.**

6. If necessary, replace the oil seal or the spring.




**Apex Seal**


1. Check the apex seal for wear, cracks, and other damage. If necessary, replace it.
2. Measure the combined height of the upper and lower apex seals at two points.

**Standard height: 8.5 mm {0.33 in}**  
**Height: 6.5 mm {0.256 in} min.**

3. If the apex seal height is below 6.5 mm {0.256 in}, replace the apex seals together with apex seal springs.




4. Check the apex seals for warpage. Put two apex seals together, top-to-top, and check the warpage. Do this with all three seals. If warpage exists in the middle of the seals, replace the apex seals. If the warpage exists in the ends of the seals, the seals can be reused.



5. Check the clearance between the apex seal and the groove. Place the apex seal in its respective groove in the rotor, and measure the apex seal clearance. If necessary, replace it.

**Standard clearance**  
**0.051–0.101 mm {0.0020–0.0039 in}**  
**Maximum: 0.15 mm {0.0059 in}**




6. Check the long apex seal spring free height. If necessary, replace it.

**Free height: 3.5 mm {0.138 in}**


**Note**

- Replace the short apex seal spring only when the apex seals are replaced in step 3.

**Side Seal**


1. Inspect the side seal for wear and damage. If necessary, replace it.
2. Install the side seal spring and side seal into their respective groove.
3. Check the side seal for free vertical movement.
4. Check the side seal protrusion.

**Protrusion: 0.5 mm {0.020 in} min.**




5. Check the clearance between the side seal and the groove.

**Standard clearance:**  
 0.028–0.078 mm {0.0011–0.0030 in}  
**Clearance:** 0.10 mm {0.0039 in} max.




6. Check the clearance between the side seal and the corner seal.

**Standard clearance:**  
 0.05–0.15 mm {0.0020–0.0059 in}  
**Clearance:** 0.40 mm {0.016 in} max.



7. If necessary, replace the side seal.  
 Adjust the clearance between the new side seal and corner seal by carefully lapping the nonfinished end.

**Adjusted clearance:**  
 0.05–0.15 mm {0.002–0.0059 in}




#### Corner Seal

1. Inspect the corner seal and soft seal for wear, cracks, and other damage. If necessary, replace them.
2. Install the corner seal spring and corner seal into its respective groove.
3. Check the corner seal for free vertical movement.
4. Check the corner seal protrusion.


**Protrusion:** 0.5 mm {0.020 in} min.

5. If necessary, replace the corner seal and/or the spring.




#### Eccentric Shaft

1. Check the eccentric shaft for cracks, scoring, wear, and other damage.
2. Verify that the oil passages are open.




3. Check the eccentric shaft runout. Measure the runout at the end of the shaft, and replace the shaft if necessary.

**Runout: 0.06 mm {0.0024 in} max.**




4. Check the oil jet spring for weakness, and check for sticking and damage of the steel ball.
5. Check the oil seal and pilot bearing. (Refer to section C.)




#### **Needle Bearing and Thrust washer**

1. Check the needle bearing for wear and damage.
2. Check the bearing housing and thrust plate for wear and other damage.



#### **Oil Pump Drive Chain and Sprocket Wheel**

1. Check the oil pump drive chain for broken links.
2. Check the oil pump drive sprocket and oil pump sprocket wheel for cracks and worn or damaged teeth. If necessary, replace with new parts.



#### **Eccentric Shaft Bypass Valve**





1. Place the eccentric shaft bypass valve in oil and heat up the oil gradually.
2. Check the protrusion of the valve at 60°C {140°F}.

**Protrusion: 6 mm {0.24 in} min.**

3. If not as specified, replace the bypass valve.

### ASSEMBLY

#### PREPARATION SST


<p>49 H018 001</p> <p>Wrench, knock sensor</p> 	<p>For installation of knock sensor</p>	<p>49 F011 101</p> <p>Brake, ring gear</p> 	<p>For prevention of engine rotation</p>
<p>49 0820 035</p> <p>Box wrench, flywheel</p> 	<p>For removal / installation of locknut</p>	<p>49 1881 055A</p> <p>Stopper counter weight</p> 	<p>For prevention of engine rotation</p>

1. Do not reuse gaskets or oil seals.
2. Clean all parts before reinstallation.
3. Apply clean engine oil to all sliding and rotating parts.
4. Install identical parts (such as rotor seals, seal springs, rotor oil seals, and rotor) in the exact positions from which they were removed.
5. Replace plain bearings if they are peeling, burned, or otherwise damaged.
6. Tighten all bolts and nuts to the specified torques.

#### Caution

- **Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.**


HOUSING (ROTOR)








# C

## ASSEMBLY

### HOUSING (INTERNAL PARTS) Torque Specifications





**Rotor Oil Seal**

1. Verify that the oil seal moves smoothly in the groove without the O-ring in place. Do not deform the oil seal lip.
2. Install the oil seal springs in their respective grooves on the rotor with the round edge of the spring fitted in the stopper hole of the oil seal grooves.

3. The oil seal springs are identified by a paint mark.  
Cream . . . for front faces of the front and rear rotors.  
Blue . . . . for rear faces of the front and rear rotors.

4. Apply engine oil to the new O-ring.
5. Install the O-ring in the oil seal.
6. Place the inner oil seal in the oil seal groove so that the square edge of the spring fits into the notch of the oil seal.


7. Press in the oil seal by using a used oil seal until the lip of the new oil seal is approximately 0.4 mm {0.016 in} below the surface of the rotor.
8. Push the oil seal slowly by hand and make sure it moves freely.

**Front Housing**


1. Mount the front housing to the SST.
2. Position the thrust plate with the chamfer facing toward the front housing. Install the needle bearing and plate.

**Tightening torque:**

16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}




3. Apply petroleum jelly to the new outer and inner sealing rubbers.
4. Install the outer sealing rubber so that the white paint faces the side wall of the groove.



5. Install the inner sealing rubber so that the blue paint faces the outer wall of the groove and the seam is placed within the position shown in the figure.
6. Fit the sealing rubbers in the intermediate housing so that their joints are positioned between points A and B of the housing, and the painted sides face as shown in the figure.

#### Caution


- Twisting the sealing rubber and allowing oil or grease on it can damage the rubber.



7. Apply engine oil to the contact surfaces, stationary gear, and main bearing.


#### Caution

- Do not apply engine oil to the sealing rubber. It will adversely effect the petroleum jelly previously applied.




#### Front rotor

1. Apply engine oil to the oil seal, side seal, main bearing, and internal gear of the rotor.




2. Place the rotor on the front housing and engage the housing stationary gear and the rotor internal gear. Position the rotor so that one of its apexes (apex seal groove) points the bottom of the engine (intake bottom dead center).





3. Insert the SST into each apex seal groove and verify that the grooves in the rotor and corner seals are aligned.




**Eccentric shaft**

1. Apply engine oil to the eccentric shaft journals.

**Caution**


- The eccentric shaft can scratch or damage the rotor bearing and main bearing when inserted.

2. Align the eccentricity of the eccentric shaft and the rotor, and insert the eccentric shaft into the rotor and housing.




**Rotor housing**

1. Coat a new O-ring with petroleum jelly and fit it in the tubular dowel hole in the rotor housing.
2. Degrease the rotor housing pedestal and apply sealant. (Shaded areas in the figure.)




3. Apply engine oil to the rotor housing inner surface and install it to the front housing.



4. Coat the tubular dowel with engine oil and insert it into the tubular dowel holes in the rotor housing and front housing, making sure that the dowel is fully inserted.

# C


## ASSEMBLY




### Apex seal

1. When apex seals are reused, assemble them in the following procedure. When new apex seals are used, go to step 2.


- (1) Remove any old bonding agent from the contact surfaces of the apex seal and side piece with a knife and degrease them with paint thinner.
- (2) Apply a drop of bonding agent to the contact surface of the apex seal and side seal.




- (3) Adhere the apex seal and side piece to the specified length. The joint must be plane.
- (4) Remove excessive bonding agent with a knife.




2. Install the second piece to the apex seal and side piece that is assembled in step 1. Face the side piece to the rear of the engine and insert the assembly into the apex seal groove in the rotor.




3. Install the short apex seal spring between the apex seal and apex seal groove. Face the spring toward the apex seal and press until the spring is fastened by the spring stopper on the side piece.



4. Install the long apex seal spring over the short apex seal spring. Press the spring until it is fastened by the spring stopper on the side piece.



5. Install the corner seals.
6. Install the side seals.





#### Intermediate housing

1. Apply petroleum jelly to the new sealing rubbers.
2. Fit the sealing rubbers in the intermediate housing so that their joints are positioned between points A and B of the housing, and the painted sides face as shown in the figure.

#### Caution


- Twisting the sealing rubber and allowing oil or grease on it can damage the rubber.



3. Apply engine oil to the seals of the front rotor.
4. Apply engine oil to the front of the contact surface of the intermediate housing.

#### Caution


- Do not apply engine oil to the sealing rubber. It will adversely effect the petroleum jelly previously applied.



5. Coat new O-ring with petroleum jelly and fit it in the tubular dowel hole in the rotor housing.
6. Degrease the rotor housing pedestal and apply sealant.
7. Turn the eccentric shaft so that its rear rotor journal eccentricity is aligned with the narrower axis of the engine.


# C

## ASSEMBLY



### Caution



- The side piece on the rotor can scratch or damage the intermediate housing during assembly if it is caught between the rotor housing and intermediate housing.



8. Working with another person, hold the eccentric shaft up approx. 3cm (1.2 in) from underside and assemble the intermediate housing over the rotor housing.
9. Apply petroleum jelly to the new sealing rubbers.
10. Fit the sealing rubbers in the intermediate housing so that their joints are positioned between points A and B of the housing, and the painted sides face as shown in the figure.

### Caution


- Twisting the sealing rubber and allowing oil or grease on it can damage the rubber.



11. Apply engine oil to the seals of the front rotor.
12. Apply engine oil to the front of the sliding surface of the intermediate housing.


### Caution

- Do not apply engine oil to the sealing rubber. It will adversely effect the petroleum jelly previously applied.




### Rear rotor


1. Apply engine oil to the oil seal, side seal, and main bearing of the rotor.



2. Install the rotor on the eccentric shaft as shown in the figure.




3. Insert the SST into each apex seal groove and verify that the grooves in the rotor and corner seals are aligned.




**Rotor housing**

1. Coat the new O-ring with petroleum jelly and fit it in the tubular dowel hole in the rotor housing.
2. Degrease the rotor housing pedestal and apply liquid gasket. (Shaded areas in the figure.)




3. Apply engine oil to the rotor housing inner surface and install it to the intermediate housing.



4. Coat the tubular dowel with engine oil and insert it into the tubular dowel holes in the rotor housing and intermediate housing, making sure that the dowel is fully inserted.


# C

## ASSEMBLY



### Rear Housing


1. Apply clean engine oil to a new rear oil seal and the groove of the rear stationary gear.
2. Install the oil seal into the rear stationary gear.



3. Install the oil regulator valve.

### Tightening torque:


69–78 N·m {7.0–8.0 kgf·m, 51–57 ft·lbf}




4. Apply sealant to the oil pressure switch threads. Do not allow sealant in the pressure switch hole.
5. Install the oil pressure switch.

### Tightening torque:


11–15 N·m {1.1–1.6 kgf·m, 8.0–11 ft·lbf}



6. Apply petroleum jelly to the new outer and inner sealing rubbers.
7. Install the outer sealing rubber so that the white paint faces the side wall of the groove.




8. Install the inner sealing rubber so that the blue paint faces the outer wall of the groove and so that the seam is placed within position shown in the figure.
9. Verify that the outer and inner sealing rubbers are not twisted.




10. Apply clean engine oil to the contact surfaces, stationary gear, and main bearing.

**Caution**


- Do not apply engine oil to the sealing rubber. It will adversely effect the petroleum jelly previously applied.




11. Apply clean engine oil to the rotor oil seal of the rear side of the rotor.



12. Apply petroleum jelly to a new O-ring and fit it into the rear rotor housing.  
13. Apply sealant to the shaded areas shown in the figure.



14. Install the rear housing on the rear rotor housing.  
15. Verify that the side pieces of the front and rear apex seals are not wedged between the rotor housing and side housing.



**Tension Bolt**

1. Apply clean engine oil to new seal washers and install them on the tension bolts.
2. Apply clean engine oil to the bolt threads.
3. Install the tension bolts and tighten them gradually in the order shown in the figure.


The bolt with the "m" mark is for the No. 17 position.  
The bolt with the protector tube is for the No. 18 position.

**Tightening torque:**

32-39 N·m {3.2-4.0 kgf·m, 24-28 ft·lbf}

# C


## ASSEMBLY




4. Turn the eccentric shaft and make sure that it rotates easily and smoothly.

### Flywheel (MT)

1. Apply clean engine oil to the oil seal in the rear housing.
2. Fit the key to the eccentric shaft.
3. Install the flywheel to the eccentric shaft.




4. Apply thread-locking compound to the eccentric shaft threads.
5. Apply sealant to the contact surface of the locknut.



6. Install the lock nut and tighten it by using the SST.


### Tightening torque:

400–490 N·m {40–50 kgf·m, 290–360 ft·lbf}




### Counterweight (AT)

1. Apply clean engine oil to the oil seal in the rear housing.
2. Fit the key into the eccentric shaft.
3. Install the counterweight onto the eccentric shaft.



4. Apply thread-locking compound to the eccentric shaft threads.
5. Apply sealant to the contact surface of the locknut.







6. Install the lock nut and tighten it by using the SST.

**Tightening torque:**  
400–490 N·m {40–50 kgf·m, 290–360 ft·lbf}


**HOUSING (EXTERNAL PARTS II)**  
**Torque Specifications**




**Balance Weight, Bearing, and Spacer**

1. Install the following parts to the eccentric shaft:

- (1) Spacer
- (2) Thrust needle bearing
- (3) Thrust washer
- (4) Balance weight
- (5) Oil pump drive sprocket
- (6) Drive gear




2. Verify that the needle bearing is not caught by the spacer.



3. Install the eccentric shaft pulley boss and tighten the new pulley lock bolt.

**Tightening torque:**  
 240–270 N·m {24–28 kgf·m, 180–200 ft·lbf}


4. Remove the SST.



5. Measure the end play of the eccentric shaft.


**Standard:**  
 0.040–0.070 mm {0.0016–0.0027 in}  
**Maximum:**  
 0.09 mm {0.0035 in} max.

If the end play is not within specification, continue from step 6 and replace the spacer.



6. Attach the SST to the flywheel (MT) or to the counterweight (AT).


7. Remove the eccentric shaft lock bolt, drive gear, and oil pump drive sprocket.



8. If the end play is less than specified, replace the spacer with a thicker one. If the end play is more than specified, install a thinner spacer.

**Spacer stamp and thickness**


Stamp	Thickness	mm {in}	Stamp	Thickness	mm {in}
A	7.975–7.995	{0.3140–0.3147}	D	8.035–8.055	{0.3164–0.3171}
B	7.995–8.015	{0.3148–0.3155}	E	8.055–8.075	{0.3172–0.3179}
C	8.015–8.035	{0.3156–0.3163}			

**Oil pump**


1. Apply clean engine oil to the oil pump shaft.
2. Install the oil pump to the front housing.

**Tightening torque:**

**6.1–9.8 N·m {70–100 kgf·cm, 61–86.8 in·lbf}**



3. Install the key to the oil pump shaft.
4. Install the oil pump drive gear, oil pump sprocket wheel, and drive chain as an assembly.




5. Install the key to the eccentric shaft.
6. Install a new washer and oil pump lock nut.


**Tightening torque:**

**32–46 N·m {3.2–4.7 kgf·m, 24–33 ft·lbf}**


7. Bend the washer to lock the nut.



8. Install the drive gear so that the chamfered surface faces the housing.


**Front Cover**

1. Apply clean engine oil to the new front oil seal and the groove of the front cover.
2. Install the oil seal in the front cover.




3. Install the oil pressure control valve in the front cover.

**Tightening torque:**  
 40–49 N·m {4.0–5.0 kgf·m, 29–36 ft·lbf}




4. Apply petroleum jelly to the new O-ring and backup ring.



5. Install the front cover along with a new gasket.


**Tightening torque:**  
 16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}



**Eccentric Shaft Lock Bolt and Bypass Valve**

1. Install the eccentric shaft pulley boss.
2. Temporarily install the lock bolt, and tighten it by hand.
3. Remove the lock bolt, and measure the pulley boss protrusion. If it is over the limit, the needle bearing may be caught by the spacer. Remove and reinstall the needle bearing, if necessary.


**Protrusion: 2.44 mm {0.0961} max.**




4. Install the bypass valve and spring into the eccentric shaft.
5. Apply clean engine oil to the new O-ring and install it on the lock bolt.
6. Apply sealant to the flange face of a new lock bolt.
7. Install the lock bolt.

**Tightening torque:**  
 240–270 N·m {24–28 kgf·m, 180–200 ft·lbf}

**HOUSING (EXTERNAL PARTS I)**  
**Torque Specifications**




**Oil Strainer**


Install the oil strainer along with a new gasket.

**Tightening torque:**

8.9–11.7 N·m {90–120 kgf·cm, 79–104 in·lbf}

**Oil Pan**


1. Cut away the part of the gasket that projects from between the front cover and the housing.




2. Clean the contact surface of the housing and oil pan with degreaser and a soft cloth.
3. Apply silicone sealant and install oil pan;

**Without gasket;** Apply a 4–6 mm {0.16–0.24 in} continuous bead of silicone sealant along the inside edge of the housing, inboard of the bolt holes. Overlap the ends and install the oil pan within five minutes.

**With gasket;** Apply a 4–6 mm {0.16–0.24 in} continuous bead of silicone sealant along the inside edge of the oil pan and the housing side of the gasket, inboard of the bolt holes. Overlap the ends and install the oil pan within five minutes.

**Caution**


- If the bolts are reused, remove the old sealant from the bolt threads. Tightening a bolt that has old sealant on it can cause thread damage.



4. Install the oil pan and tighten the bolts gradually and evenly.

**Tightening torque:**


8.9–11.7 N·m {90–120 kgf·cm, 79–104 in·lbf}

**Metering oil pump**


1. Apply engine oil to the new O-ring.
2. Install the metering oil pump to the front housing.

**Tightening torque:**

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

**Water pump**


1. Install the washer and new gasket to the front housing.



2. Install the water pump to the front housing.

**Tightening torque:**


18–26 N·m {1.8–2.7 kgf·m, 14–19 ft·lbf}



3. Install the metering oil pump harness and the metering oil tube to the water pump housing.

**Tightening torque:**

7.9–10.7 N·m {80–110 kgf·cm, 69.5–95.4 in·lbf}

**Engine hanger**


1. Install the engine hanger to the front housing.

**Tightening torque:**

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

2. Mount the metering oil pump connector to the engine hanger.






**Metering oil nozzle**

Install the oil nozzles and connect the metering oil tubes using new washers. The oil tube ends are colored.

- White: Front rotor housing
- Yellow: Rear rotor housing


**Tightening torque:**

16–20 N·m {1.6–2.1 kgf·m, 12–15 ft·lbf}




**Oil inlet pipe**

Install the oil inlet pipe and new washers as an assembly and hand tighten the connecting bolt.




**Fuel delivery pipe and mixing plate**

1. Apply clean engine oil to the air bleed socket.
2. Install the air bleed socket into the engine.



3. Install the mixing plate by aligning the mixing plate tab with the housing notch.

4. Install the fuel delivery pipe.




5. Install the fuel delivery pipe.

**Tightening torque:**

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

# C

## ASSEMBLY




### Oil filter body

Install the oil filter body along with new O-rings.

### Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




### Oil pipe

Install the oil pipe along with a new gasket.

### Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




### Drive plate (AT)

1. Attach the SST to the counterweight.
2. Install the drive plate and the back plate.
3. Tighten the bolts in two or three steps in the order shown in the figure.

### Tightening torque:

44–60 N·m {4.4–6.2 kgf·m, 32–44 ft·lbf}



### Knock sensor


Install the knock sensor and tighten it by using the SST.

### Tightening torque:

20–34 N·m {2.0–3.5 kgf·m, 15–25 ft·lbf}

**Harness**

Connect the harness connectors shown in the figure.





# C

## ASSEMBLY

### Vacuum pipe assembly

Connect the hoses and connectors shown in the figure.

### Torque Specifications





### Vacuum pipe

1. Install the vacuum pipe and ground harness.


### Tightening torque:

19-25 N·m {1.9-2.6 kgf·m, 14-18 ft·lbf}


2. Install the harness and hoses as shown in the figure.



3. Connect the vacuum hoses.




4. Connect the water hose.

**Ignition coil assembly and vacuum chamber**

1. Install the ignition coil assembly

**Tightening torque:**


**7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}**



2. Install the vacuum chamber. (AT)

**Tightening torque:**


**7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}**

**Vacuum chamber**

1. Connect the vacuum hose.
2. Install the vacuum chamber.

**Tightening torque:**

**7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}**


**Oil filler pipe**


Install the oil filler pipe along with a new O-ring.

**Tightening torque:**


**7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}**

**AUXILIARY PARTS (II)**  
**Torque Specifications**




**Intake manifold assembly**

1. Install the new intake manifold gasket on the engine.




2. Connect the vacuum hose to the intake manifold.




3. Install the intake manifold.

**Tightening torque:**

**16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}**




4. Connect the fuel injector connectors.




5. Connect the vacuum hoses as shown in the figure.






6. Connect the connectors shown in the figure.




7. Connect the vacuum hoses as shown in the figure.




8. Install the three-way solenoid shown in the figure.

**Tightening torque:**

**7.9–10.7 N·m {80–110 kgf·cm, 69.5–95.4 in·lbf}**




9. Mount the oxygen sensor connector.




10. Connect the fuel hose and vacuum hose.

# C

## ASSEMBLY



11. Connect the fuel hose shown in the figure.




### Surge tank assembly


1. Install the surge tank assembly and the ground harness.

### Tightening torque:


16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}



2. Connect the connector shown in the figure.



3. Connect the connector and the hoses shown in the figure.




4. Tighten the bolt.

### Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}


5. Connect the vacuum hoses and the blowby hose as shown in the figure.



6. Connect the duty solenoid valve as shown in the figure.

**Tightening torque:**

**7.9–10.7 N·m {80–110 kgf·cm, 69.5–95.4 in·lbf}**




**Exhaust manifold**

1. Retighten the studs to the specified torque.


**Tightening torque:**

**30–35 N·m {3.0–3.6 kgf·m, 22–26 ft·lbf}**



2. Install the gaskets with the crimped side facing the exhaust manifold.


3. Install the exhaust manifold.



4. Install the exhaust manifold.

**Tightening torque:**

**65–78 N·m {6.6–8.0 kgf·m, 48–57 ft·lbf}**



**Exhaust manifold insulator**


1. Install the exhaust manifold insulator.

**Tightening torque:**

**7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}**

# C


## ASSEMBLY



2. Install the exhaust manifold insulator.

**Tightening torque:**

**7.9–10.7 N·m {80–110 kgf·cm, 69.5–95.4 in·lbf}**




**Oil seal plate**

Install the oil seal plate.

**Tightening torque:**

**7.9–10.7 N·m {80–110 kgf·cm, 69.5–95.4 in·lbf}**


**TURBOCHARGER**  
Torque specifications



N·m (kgf·m, ft·lbf)

# C

## ASSEMBLY




### Turbocharger

1. Retighten the stud to the specified torque.


#### Tightening torque:

Ⓐ : 16–23 N·m {1.6–2.4 kgf·m, 12–17 ft·lbf}

Ⓑ : 7.9–11.7 N·m {80–120 kgf·cm, 70–104 in·lbf}



2. Install the new turbocharger gaskets.




3. Install the turbocharger assembly.

#### Tightening torque:

Ⓐ : 38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}

Ⓑ : 22–29 N·m {2.2–3.0 kgf·m, 16–21 ft·lbf}


Ⓒ : 44–57 N·m {4.4–5.9 kgf·m, 32–42 ft·lbf}



4. Connect the oil outlet pipe along with a new gasket.

#### Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




5. Connect the oil outlet pipe along with a new gasket.

#### Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



6. Connect the oil inlet pipe and water hose.



7. Use two wrenches to tighten the oil inlet pipe connector bolt.


**Tightening torque:**

**18–22 N·m {1.8–2.3 kgf·m, 14–16 ft·lbf}**


8. Tighten the oil inlet pipe connecting bolt. (Refer to page C-80)

**Tightening torque:**

**24–35 N·m {2.4–3.6 kgf·m, 18–26 ft·lbf}**



9. Connect the water hose.




10. Install the turbo control actuator.


**Tightening torque:**

**16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}**


11. Connect the air hoses.



12. Install a new clip on the actuator rod.




**Air intake pipe**  
Install the air intake pipe.



**Vacuum pipe**  
1. Install the vacuum pipe.


**Tightening torque:**  
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

2. Connect the vacuum hoses.




**Air pipe and control valve**

1. Apply clean engine oil to the new O-ring, and install it between the air pipe and control valve.




2. Install the air pipe and control valve on the turbo-charger assembly along with new gaskets.

**Tightening torque:**  
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




3. Connect the vacuum hoses shown in the figures.





4. Connect the hoses shown in the figure.


**Air pipe**


Install the air pipe along with a new gasket.

**Tightening torque:**

**7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}**


### AUXILIARY PARTS (I) Torque specifications






**Engine mount right and left**  
Install the engine mount right and left.

**Tightening torque:**  
75–93 N·m {7.6–9.5 kgf·m, 55–68 ft·lbf}




**Air pipe and bracket**  
1. Install the air pipe bracket.

**Tightening torque:**  
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




2. Install the air pipe.

**Tightening torque:**  
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




3. Install the pressure chamber.

**Tightening torque:**  
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




**Air pump**

1. Install the air pump and bracket and hand tighten the mounting bolts.
2. Connect the connector and air hose.

**Alternator and bracket**


Install the alternator and bracket and hand tighten the mounting bolts.

**Drive belt pulley**

Install the drive belt pulley as shown in the figure.

**Tightening torque:**

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

**Water pump pulley**


1. Install the water pump pulley and hand tighten the mounting bolts.
2. Install the drive belt. (Refer to page C-5.)
3. Tighten the water pump pulley bolts to specified torque.

**Tightening torque:**

7.9–11.7 N·m {80–120 kgf·cm, 70–104 in·lbf}

**ENGINE STAND DISMOUNTING****PROCEDURE**

1. Remove the engine from the engine stand.
2. Remove the SST from the engine.



3. Install the new studs into the front housing.
4. Install new washers and the oil pipe.

**Tightening torque:****54–68 N·m {5.5–7.0 kgf·m, 40–50 ft·lbf}**


# C

## INSTALLATION

---

### INSTALLATION

#### PREPARATION SST

<p>49 W023 585A</p> <p>Adjust wrench</p> 	<p>For removal / installation of locknut</p>
--	--



## PROCEDURE

### Step 1

#### Warning

- A vehicle that is lifted but not securely supported on safety stands is dangerous. It can slip or fall, causing death or serious injury. Never work around or under a lifted vehicle if it is not securely supported on safety stands.

#### Torque specifications




#### Engine

1. Suspend the engine.
2. Slowly lower the engine. Keep it from swinging or bumping into components in the engine compartment. Align the engine mounts with the cross member mounting holes.

# C

## INSTALLATION



### Engine mount


Install and tighten the engine mount nuts.

### Tightening torque:


46-67 N·m {4.6-6.9 kgf·m, 34-49 ft·lbf}

### Step 2

### Torque specifications








**Oil Cooler Pipe (AT)**

1. Install the oil cooler pipe.
2. Tighten the bolt.

**Tightening torque:**


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




3. Tighten the nut shown in the figure.

**Tightening torque:**

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



4. Connect the oil cooler hose.




**Front Exhaust Pipe**

1. Connect the front exhaust pipe along with a new gasket.

**Tightening torque:**


38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}

2. Install the oxygen sensor harness.




**Insulator**


1. Install the front exhaust pipe insulator and hand tighten the bolts.



2. Install the turbo insulator and hand tighten the bolts.




3. Install the center insulator and hand tighten the bolts.




4. Tighten the insulator bolt.

**Tightening torque:**  
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




5. Install the insulator.

**Tightening torque:**  
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




6. Install the engine mount insulator.

**Tightening torque:**  
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




**Oil Pipe**

1. Connect the oil pipe and install the retaining clip.



2. Verify that the oil pipe is securely locked.



**Radiator hose (lower)**

Connect the lower radiator hose.

# C



## INSTALLATION

### Step 3

Connect the harness connectors and the hoses shown in the figure.




Step 4  
Torque specifications



**A/C compressor**  
Install the A/C compressor to the bracket.

**Tightening torque:**  
19-25 N·m {1.9-2.6 kgf·m, 14-18 ft·lbf}


**P/S oil pump**

1. Install the P/S oil pump to the bracket.

**Tightening torque:**

**32–46 N·m {3.2–4.7 kgf·m, 24–33 ft·lbf}**


2. Connect the connector.

**P/S oil pump pulley**

1. Install the P/S oil pump pulley to the pump body and hand tighten the nut.
2. Tighten the pulley nut while holding the pulley with the SST.

**Tightening torque:**


**40–58 N·m {4.0–6.0 kgf·m, 29–43 ft·lbf}**

**Fuse box**


Install the fuse box.

**Tightening torque:**


**7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}**

**Radiator hose (upper)**


Connect the upper radiator hose.

**Air hose**

Connect the air hose.




**Water hose**  
Connect the water hose.




**Hose**  
Install the hose.

**Tightening torque:**  
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




**Air cleaner housing**  
1. Connect the air hose.  
2. Install the air cleaner housing.

**Tightening torque:**  
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




**Accelerator cable**  
1. Install the accelerator cable.  
2. Adjust the cable deflection.

**Deflection:**  
1–3 mm {0.04–0.12 in}



**Strut bar**  
1. Remove the upper nuts.  
2. Install the strut bar.

**Tightening torque:**  
30–36 N·m {3.0–3.7 kgf·m, 22–26 ft·lbf}


**Battery and carrier**

1. Install the battery carrier.

**Tightening torque:**

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

2. Install the battery.
3. Connect the positive battery cable.

**Fresh-air duct**

Install the fresh-air duct.

**Tightening torque:**

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

**Steps After Installation**

1. Connect the powertrain control module. (Refer to section F.)
2. Fill the radiator with the specified amount and type of engine coolant. (Refer to section E.)
3. Fill the engine with the specified amount and type of engine oil. (Refer to section D.)
4. Fill the transmission with the specified amount and type of transmission oil.  
(MT: Refer to section J, AT: Refer to section K)
5. Install the hood.
6. Start the engine and check the following.
  - (1) check for engine oil, transmission oil, and engine coolant leakage.
  - (2) check the ignition timing and idle speed. (refer to section F)
  - (3) check the operation of the emission control system.
7. Turn off the engine and check drive belt deflection. (refer to page C-6)
8. Perform a road test.
9. Recheck the oil and coolant levels.



Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.


D

## LUBRICATION SYSTEM

<b>INDEX</b> .....	D - 2
<b>OUTLINE</b> .....	D - 3
<b>SPECIFICATIONS</b> .....	D - 3
<b>TROUBLESHOOTING GUIDE</b> .....	D - 4
<b>OIL PRESSURE</b> .....	D - 5
<b>PREPARATION</b> .....	D - 5
<b>INSPECTION</b> .....	D - 5
<b>ENGINE OIL</b> .....	D - 6
<b>INSPECTION</b> .....	D - 6
<b>REPLACEMENT</b> .....	D - 6
<b>OIL FILTER</b> .....	D - 7
<b>REPLACEMENT</b> .....	D - 7
<b>OIL COOLER</b> .....	D - 8
<b>REMOVAL / INSTALLATION</b> .....	D - 8
<b>OIL PAN</b> .....	D - 9
<b>PREPARATION</b> .....	D - 9
<b>REMOVAL / INSTALLATION</b> .....	D -10
<b>OIL PRESSURE CONTROL VALVE</b> .....	D -13
<b>REMOVAL / INSTALLATION</b> .....	D -13
<b>METERING OIL PUMP</b> .....	D -14
<b>PREPARATION</b> .....	D -14
<b>INSPECTION</b> .....	D -15
<b>OIL PUMP</b> .....	D -17
<b>DISASSEMBLY/ASSEMBLY</b> .....	D -17
<b>INSPECTION</b> .....	D -18

D

INDEX



- 1. Oil filter  
 Replacement ..... page D-7
- 2. Oil cooler  
 Removal / Installation ..... page D-8


- 3. Oil pan  
 Removal / Installation ..... page D-10
- 4. Metering oil pump  
 Inspection ..... page D-14

OUTLINE

SPECIFICATIONS

Item		Engine model	13B Turbo	
Lubrication system			Force-fed	
Oil pump	Type		Trochoid	
	Number of rotors		2	
	Diameter × width of rotor	mm {in}	50 × 17.5 {1.97 × 0.69}	
Control valve relief pressure		kPa{kgf·cm <sup>2</sup> , psi}	1080 {11.0, 156}	
Oil cooler	Type		Air-cooled, with bypass valve	
	Relief temperature	°C {°F}	60–65 {140–149} or below	
	Relief pressure differential	kPa{kgf·cm <sup>2</sup> , psi}	349 {3.56, 50} at 60°C {149°F}	
Regulator valve relief pressure		kPa{kgf·cm <sup>2</sup> , psi}	780 {8.0, 110}	
Oil filter	Type		Full-flow, paper element	
	Relief pressure differential	kPa{kgf·cm <sup>2</sup> , psi}	98 {1.0, 14}	
Eccentric shaft bypass valve relief temperature		°C {°F}	60 {140} or below	
Engine oil	Total (dry engine)	L {US qt, Imp qt}	4.9 {5.2, 4.3} ... except R1 model 5.4 {5.7, 4.8} ... R1 model	
	Oil replacement	L {US qt, Imp qt}	3.6 {3.8, 3.2}	
	Oil replacement (with oil filter)	L {US qt, Imp qt}	3.8 {4.0, 3.3}	
	Oil filter L {US qt, Imp qt}	Factory installed		0.19 {0.20, 0.17}
		Service part		0.17 {0.18, 0.15}
Grade			API Service SG, SH (ECII) ILSAC (Mineral oil only)	

Recommended SAE Viscosity



Anticipated ambient temperature range before the succeeding oil change, °C {°F}

### TROUBLESHOOTING GUIDE

Problem	Possible Cause	Action	Page
<b>Engine hard starting</b>	Improper oil Insufficient oil	Replace Add oil	D-6 D-6
<b>Excessive oil consumption</b>	Malfunction of metering oil pump mechanical component Faulty oil nozzle Oil leakage	Inspect Inspect Repair	D-14 D-17 —
<b>Oil leakage</b>	Loose drain plug or damaged washer Faulty seal at oil pan Damaged front cover Loose front cover bolt or oil pan bolt Damaged sealing rubber, O-ring, or front cover gasket Malfunction of oil seal Loose oil filter Loose or damaged oil level sensor or oil pressure gauge Damaged oil cooler or oil cooler hose Damaged oil tube	Tighten or replace Repair Replace Tighten Replace Replace Tighten Tighten or replace Replace Replace	D-9 D-9 — — — — D-7 — D-8 —
<b>Oil pressure drop*</b>	Oil leakage Insufficient oil Worn or damaged oil pump gear Clogged oil strainer Malfunction of oil pressure control valve Malfunction of oil pressure regulator valve Clogged oil filter Malfunction of eccentric shaft bypass valve Excessive oil clearance between eccentric shaft and main bearing	Repair Add oil Refer to Section C Clean Replace Replace Replace Refer to Section C Refer to Section C	— D-6 — — D-13 D-9 D-7 — —
<b>Oil pressure gauge does not work</b>	Oil pressure drop Malfunction of oil pressure gauge unit Malfunction of electrical system	As described above Refer to Section T Refer to Section T	D-5 — —
<b>Oil level warning indicator illuminates when engine is running</b>	Insufficient oil Malfunction of oil level sensor Malfunction of electrical system	Add oil Refer to Section T Refer to Section T	D-6 — —
<b>Poor acceleration</b>	Malfunction of metering oil pump electrical component	Inspect	D-14
<b>Rough idle</b>	Malfunction of metering oil pump electrical component	Inspect	D-14


\* Oil pressure becomes low when the engine is cold because the eccentric shaft bypass valve operates.

## OIL PRESSURE


**Warning**

- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.


**PREPARATION****SST**

<p>49 0187 280</p> <p>Gauge, oil-pressure</p>	 <p>For inspection of oil pressure</p>
---	---

D

**INSPECTION**


1. Disconnect the connector and remove the oil pressure sensor.



2. Install the SST.
3. Start the engine and let it warm up to operating temperature.
4. Run the engine at 3,000 rpm and note the gauge reading.

**Oil pressure: 340 kPa {3.5 kgf·cm<sup>2</sup>, 50 psi} min**

5. If the pressure is not as specified, check for the cause and repair. (Refer to Troubleshooting Guide.)
6. Remove the SST.




7. Apply sealant to the oil pressure sensor threads. Do not allow sealant in the pressure sensor hole.
8. Install the oil pressure sensor.

**Tightening torque:**

**11–15 N·m {1.1–1.6 kgf·m, 8–11 ft·lbf}**

9. Connect the sensor connector.




**ENGINE OIL**

**INSPECTION**

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the dipstick and check the oil level and condition.
5. Add or replace oil as necessary.

**Note**

- The distance between the L and F marks on the dipstick represents 1.7 L {1.8 US qt, 1.5 Imp qt}.




**REPLACEMENT**

**Warning**

- When the engine and the oil are hot, they can badly burn. Don't burn yourself with either.

1. Warm up the engine to the normal operating temperature and stop it.
2. Remove the oil filler cap and the oil drain plug.
3. Drain the oil into a container.
4. Install a new gasket and the drain plug.



**Tightening torque:**

**30–41 N·m {3.0–4.2 kgf·m, 22–30 ft·lbf}**


5. Refill the engine with the specified type and amount of engine oil.

**Oil capacity:**

L {US qt, Imp qt}

Total (dry engine)	4.9 {5.2, 4.3}...except R1 model 5.4 {5.7, 4.8}...R1 model
Engine oil replacement	3.6 {3.8, 3.2}
Engine oil replacement (with oil filter)	3.8 {4.0, 3.3}

6. Refit the oil filler cap.
7. Run the engine a few minutes and stop it.
8. Recheck the oil level and add oil if necessary.

**OIL FILTER****REPLACEMENT**

1. Remove the oil filter by using the oil filter wrench.
2. Using a clean rag, wipe the mounting surface of the engine.
3. Apply a small amount of clean engine oil to the rubber seal of the new filter.
4. Install the oil filter and tighten it until the rubber seal contacts the base, and then tighten the filter an additional 1-1/6 turns by hand.
5. Start the engine and inspect for leaks around the filter seal.
6. Stop the engine and check the oil level; add oil if necessary.

**Note**

- The factory installed oil filter and the service part filter are different.

**Service oil filter capacity:**

**0.17 L {0.18 US qt, 0.15 Imp qt}**

D

### OIL COOLER


#### REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.

#### Note

(In case of two oil cooler are equipped)


- LH oil cooler is shown.  
Remove / install RH oil cooler in same procedure.



1. Light bezel
2. Brake pipe air duct
3. Oil cooler hoses  
Removal Note ..... page D-9

4. Oil cooler  
Removal Note ..... page D-9
5. Air duct (oil cooler)






**Removal Note**

**Oil cooler hose**

Remove the clip and disconnect the oil cooler hose, using a drain pan to catch the oil.



**Oil cooler**

1. Remove the light bezel.
2. Remove the mounting bracket nuts.
3. Remove the oil cooler.

D

**Steps After Installation**

Fill the engine with the specified amount and type of engine oil. (Refer to page D-6.)

**OIL PAN**


**PREPARATION**

**SST**

<p>49 G017 5A0 Support, engine</p>	<p>For support of engine</p>	<p>49 G017 501 Bar (Part of 49 G017 5A0)</p>	<p>For support of engine</p>
<p>49 G017 502 Support (Part of 49 G017 5A0)</p>	<p>For support of engine</p>	<p>49 G017 503 Hook (Part of 49 G017 5A0)</p>	<p>For support of engine</p>


**REMOVAL / INSTALLATION**

1. Disconnect the negative battery cable.
2. Remove the undercover.
3. Drain the engine oil.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.




- 1. Undercover
- 2. Stabilizer
- 3. Engine mount bracket  
Removal Note ..... page D-11
- 4. Steering gear box

- 5. Crossmember  
Removal Note ..... page D-11
- 6. Oil pan  
Removal Note ..... page D-11  
Installation Note ..... page D-12




**Removal Note**  
**Engine mount bracket**

1. Assemble the SST and connect the hook to the front engine hanger.




2. Remove the engine mounting nuts.
3. Turn the bolt of the SST clockwise to lift the engine.



**Crossmember**

1. Remove the power steering oil hose bracket from the crossmember.
2. Remove the bolts and nuts (arrows) and the crossmember.




**Oil pan**

1. Remove the engine mount brackets from the engine.
2. Disconnect the oil level sensor connector and remove it from the harness bracket.
3. Remove the oil pan mounting bolts.

**Caution**


- Pry tools can easily scratch the oil pan contact surfaces. Prying off the oil pan can also easily bend the oil pan flange. Refer to the following instructions before removing the oil pan.



4. Insert a screwdriver only between the points shown in the figure to pry the oil pan loose.

# D

## OIL PAN




### Installation Note

#### Oil pan

1. Remove all foreign material from the oil pan contact surfaces.

#### Caution

- If the bolts are reused, remove the old sealant from the bolt threads. Tightening bolts with old sealant on them may cause cracking inside the bolt holes.




2. Apply silicone sealant to the contact surfaces of the oil pan and the engine side of the new gasket.
3. Install the oil pan within five minutes of applying the sealant.

#### Tightening torque:


8.9–11.7 N·m {90–120 kgf·cm, 79–104 in·lbf}

### Steps After Installation

Fill the engine with the specified amount and type of engine oil. (Refer to page D-6.)

**OIL PRESSURE CONTROL VALVE****REMOVAL / INSTALLATION**

1. Remove the parts in the following order.
  - (1) Oil pan (Refer to page D-9.)
  - (2) Cap bolt and spring
  - (3) Control plunger
2. Install in the reverse order.
3. Check the engine for oil leakage and check the oil level.

**INSPECTION**

1. Check each part for damage and scoring. Replace if necessary.
2. Measure the free length of the spring, and if necessary, replace it.



**Free length: 73.0 mm {2.87 in}**

# D

## METERING OIL PUMP

### METERING OIL PUMP

#### PREPARATION SST

<p>49 H018 9A1 Self-Diagnosis Checker</p> 	<p>For diagnosis of metering oil pump system</p>	<p>49 B019 9A0 System Selector</p> 	<p>For diagnosis of metering oil pump system</p>
---	--	---	--

Malfunctions related to the metering oil pump may be described as electrical component problems and mechanical component problems.

#### Electrical Component Related Problem

1. Check for service codes by using the SST. (Refer to section F.)
2. If service code No. 20, 26, 27 or 37 appears, check the metering oil pump following the diagnosis chart below.

#### Diagnosis Chart


Service Code No.	Possible Cause	Action
20 (Metering oil pump position sensor)	<ul style="list-style-type: none"> <li>• Open or short circuit in position sensor wiring</li> <li>• Open or short circuit in wiring between powertrain control module and position sensor</li> <li>• Loose connection of position sensor or powertrain control module</li> </ul>	Perform Inspection 2 (page D-16)
26 (Metering oil pump control system)	<ul style="list-style-type: none"> <li>• Open or short circuit in wiring between powertrain control module and stepping motor</li> <li>• Loose connection of metering oil pump or powertrain control module</li> <li>• Damaged stepping motor</li> <li>• Insufficient powertrain control module voltage</li> </ul>	Perform Inspection 1 (page D-15)
27 (Metering oil pump control system)	<ul style="list-style-type: none"> <li>• Open or short circuit in wiring between powertrain control module and stepping motor</li> <li>• Loose connection of metering oil pump or powertrain control module</li> <li>• Damaged stepping motor</li> <li>• Position sensor inaccurate</li> <li>• Insufficient powertrain control module voltage</li> </ul>	Perform Inspection 1 (page D-15)
37 (Battery positive voltage drop)	<ul style="list-style-type: none"> <li>• Malfunction of charging system</li> </ul>	Refer to Section G

#### Control Module Terminal


4Y	4W	4U	4S	4Q	4O	4M	4K	4I	4G	4E	4C	4A	3O	3M	3K	3I	3G	3E	3C	3A	2K	2I	2G	2E	2C	2A	U	S	Q	O	M	K	I	G	E	C	A
4Z	4X	4V	4T	4R	4P	4N	4L	4J	4H	4F	4D	4B	3P	3N	3L	3J	3H	3F	3D	3B	2L	2J	2H	2F	2D	2B	V	T	R	P	N	L	J	H	F	D	B

**INSPECTION**

**1. Metering oil pump control system**



2. Metering oil pump position sensor




**Mechanical Component Related Problem**

Excessive oil consumption may be caused by a metering oil pump malfunction.

Before replacing the metering oil pump, refer to “Oil leakage” in the Troubleshooting Guide (page D–4) and perform the electrical component inspection (pages D–15 and D–16).






**Oil nozzle**

1. Remove the oil nozzles from the rotor housing and the intake manifold.
2. Verify that air passes in only one direction as shown. If not so, replace the oil nozzle.

**OIL PUMP**

**DISASSEMBLY / ASSEMBLY**


1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- |                     |                      |                      |
|---------------------|----------------------|----------------------|
| 1. Snap ring        | 5. Screw             | 9. Front inner rotor |
| 2. Rear outer rotor | Assembly Note        | Assembly Note        |
| Assembly Note       | ..... page D-19      | ..... page D-18      |
| ..... page D-18     | 6. Body              | 10. Key              |
| 3. Rear inner rotor | 7. Center plate      | 11. Shaft            |
| Assembly Note       | 8. Front outer rotor |                      |
| ..... page D-18     | Assembly Note        |                      |
| 4. Key              | ..... page D-18      |                      |

# D

## OIL PUMP




### INSPECTION

1. Inspect the oil pump parts for wear and damage. Replace as necessary.
2. Measure the clearance between the lobes of rotors by using a feeler gauge.

#### Standard clearance:

0.03–0.12 mm {0.0012–0.0047 in}

Maximum: 0.15 mm {0.0059 in}




3. Measure the clearance between the outer rotor and the pump body.

#### Standard clearance:


0.20–0.25 mm {0.0079–0.0098 in}

Maximum: 0.30 mm {0.0118 in}



4. Inspect the side clearance of the rotors.

(1) Using a straightedge and a feeler gauge, measure the depth of the rotor in the pump body.



(2) Measure the depth of the rotor sliding surface from the pump mounting surface.


(3) Add these two depth to obtain the side clearance.

(4) If not as specified, grind or replace the pump body.

#### Standard end clearance:

0.03–0.125 mm {0.0012–0.0049 in}

Maximum: 0.15 mm {0.0059 in}




### Assembly Note

#### Outer rotor and inner rotor

Install the front and rear outer and inner rotors so that the tally marks on the rotors face the front housing.

## OIL PUMP

**D**



### **Screw**

To prevent the screw from loosening, stake it after installation.


**Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.**

# **COOLING SYSTEM**

<b>INDEX</b> .....	<b>E - 2</b>
<b>OUTLINE</b> .....	<b>E - 3</b>
<b>SPECIFICATIONS</b> .....	<b>E - 3</b>
<b>TROUBLESHOOTING GUIDE</b> .....	<b>E - 3</b>
<b>ENGINE COOLANT</b> .....	<b>E - 4</b>
<b>PREPARATION</b> .....	<b>E - 4</b>
<b>INSPECTION</b> .....	<b>E - 4</b>
<b>REPLACEMENT</b> .....	<b>E - 5</b>
<b>RADIATOR CAP</b> .....	<b>E - 7</b>
<b>PREPARATION</b> .....	<b>E - 7</b>
<b>INSPECTION</b> .....	<b>E - 7</b>
<b>RADIATOR AND COOLANT FAN</b> .....	<b>E - 8</b>
<b>REMOVAL / INSTALLATION</b> .....	<b>E - 8</b>
<b>INSPECTION</b> .....	<b>E -10</b>
<b>REPLACEMENT</b> .....	<b>E -12</b>
<b>COOLANT FAN RELAY</b> .....	<b>E -13</b>
<b>REMOVAL / INSTALLATION</b> .....	<b>E -13</b>
<b>INSPECTION</b> .....	<b>E -13</b>
<b>THERMOSTAT</b> .....	<b>E -14</b>
<b>REMOVAL / INSTALLATION</b> .....	<b>E -14</b>
<b>INSPECTION</b> .....	<b>E -15</b>
<b>WATER PUMP AND WATER</b>	
<b>THERMOSENSOR</b> .....	<b>E -15</b>
<b>REMOVAL / INSTALLATION</b> .....	<b>E -15</b>
<b>INSPECTION</b> .....	<b>E -17</b>

**E**

## INDEX



- 1. Radiator cap  
Inspection ..... page E- 7
- 2. Radiator  
Removal / Installation ..... page E- 8  
Inspection ..... page E-10
- 3. Coolant fan motor  
Inspection ..... page E-11  
Replacement ..... page E-12

- 4. Coolant fan relay  
Removal / Installation ..... page E-13  
Inspection ..... page E-13
- 5. Thermostat  
Removal / Installation ..... page E-14  
Inspection ..... page E-15
- 6. Water pump and water thermostitch  
Removal / Installation ..... page E-15  
Inspection ..... page E-17

OUTLINE

SPECIFICATIONS

Item		Engine model	13B Turbo
Cooling system			Water-cooled, forced circulation
Coolant capacity		L {US qt, Imp qt}	8.8 {9.3, 7.7}
Water pump	Type		Centrifugal
	Water seal		Unified mechanical seal
Thermostat	Type		Wax, bottom-bypass
	Opening temperature	°C {°F}	80.5-83.5 {177-182}
	Full-open temperature	°C {°F}	95 {203}
	Full-open lift	mm {in}	8-10 {0.31-0.39}
Radiator	Type		Corrugated fin
	Cap valve opening pressure	kPa {kgf/cm <sup>2</sup> , psi}	113-142 {1.15-1.45, 16.4-20.6}
Coolant fan	Motor current	A	High: 10.6-16.6, Med: 6.5-12.5, Low: 5.8-11.8
	Number of blades		No.1: 5, No.2: 4
	Outer diameter of blades	mm {in}	No.1, No.2: 300 {11.8}



E


TROUBLESHOOTING GUIDE

Problem	Possible cause	Action	Page
Overheating	Coolant level insufficient	Add	E-5
	Coolant leakage	Repair	—
	Radiator fins clogged	Clean	E-10
	Radiator cap malfunction	Replace	E-7
	Coolant fan malfunction	Replace	E-11
	Thermostat malfunction	Replace	E-15
	Water passage clogged	Clean	E-5
	Water pump malfunction	Replace	E-16
Corrosion	Impurities in coolant	Replace	E-5

## ENGINE COOLANT

PREPARATION  
SST

<p>49 9200 145</p> <p>Adapter set, radiator cap tester</p> 	<p>For inspection of cooling system pressure</p>	<p>49 9200 146</p> <p>Adapter A (Part of 49 9200 145)</p> 	<p>For inspection of cooling system pressure</p>
--	--	---	--




## INSPECTION

## Coolant Level (Engine cold)

1. Verify that the coolant level is near the filler neck.
2. Verify that the coolant level on the dipstick is between the F and L.
3. Add coolant if necessary.

## Note

- The distance between the L and F marks on the dipstick represents 1.0 Liter {1.1 US qt, 0.9 Imp qt}.



## Coolant Quality

## Warning

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counter-clockwise to the first stop. Step back while the pressure escapes. When you're sure all the pressure is gone, press down on the cap-still using a cloth-turn it, and remove it.

1. Verify that there is no buildup of rust or scale around the radiator cap or filler neck.
2. Verify that coolant is free of oil. Replace the coolant if necessary.


## Coolant Leakage


1. Connect a radiator tester (commercially available) and the SST to the radiator filler neck.

## Caution

- Applying more than 142 kPa {1.45 kgf/cm<sup>2</sup>, 20.6 psi} can damage the hoses, fittings, and other components, and cause leaks.

2. Apply 142 kPa {1.45 kgf/cm<sup>2</sup>, 20.6 psi} of pressure to the system.
3. Verify that the pressure is held.
4. If not as specified, check for coolant leakage.





**Coolant Protection**

**Caution**

- The engine has aluminum parts that can be damaged by alcohol or methanol antifreeze. Do not use alcohol or methanol in the cooling system. Use only ethylene-glycol-based coolant.


**Caution**

- Use only soft (demineralized) water in the coolant mixture. Water that contains minerals will cut down on the coolant's effectiveness.

1. Measure the coolant temperature and the specific gravity with a thermometer and a hydrometer.
2. Determine the coolant protection by referring to the graph shown.
3. If the coolant protection is not proper, add water or coolant.

**Antifreeze solution mixture percentage**

Coolant protection	Volume percentage		Gravity at 20°C {68°F}
	Water	Coolant	
Above -16°C {3°F}	65	35	1.054
Above -26°C {15°F}	55	45	1.066
Above -40°C {40°F}	45	55	1.078



**REPLACEMENT**

**Draining**

**Warning**

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.

When you're sure all the pressure is gone, press down on the cap-still using a cloth-turn it, and remove it.

1. Remove the radiator cap.
2. Loosen the radiator drain plug.
3. Drain the coolant into a container.
4. Flush the cooling system with water until all traces of color are gone.
5. Let the system drain completely.
6. Install and tighten the drain plug.



**Refilling**

Use the proper amount and mixture of ethylene-glycol based coolant. (Refer to Coolant Protection, page E-5)

1. Slowly pour the coolant into the radiator up to the coolant filler neck.

**Filling pace:**

1.0 L {1.1 US qt, 0.9 Imp qt}/min. max

**Coolant capacity:**

8.8 L {9.3 US qt, 7.7 Imp qt}/min. max

2. Fill the coolant reservoir up to the F mark.
3. Securely install the radiator cap and the coolant filler cap.
4. Start the engine and let it idle about 10 minutes until it warms up.
5. If the coolant level warning light comes on while warming up, turn the engine off and inspect the drain plug and water hoses for leaks.
6. Stop the engine and allow it to cool.

**Warning**



- **Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counter-clockwise to the first stop. Step back while the pressure escapes.**


**When you're sure all the pressure is gone, press down on the cap-still using a cloth-turn it, and remove it.**

7. Check the coolant level. If it's low, repeat the procedure from step 1.
8. Fill the reservoir to the F mark.

## RADIATOR CAP

### PREPARATION SST

<p>49 9200 145</p> <p>Adapter set, radiator cap tester</p> 	<p>For inspection of radiator cap valve</p>	<p>49 9200 147</p> <p>Adapter B (Part of 49 9200 145)</p> 	<p>For inspection of radiator cap valve</p>
--	---	---	---




### INSPECTION

#### Radiator Cap Valve

1. Remove foreign material (such as water residue) from between the radiator cap valve and the valve seat.
2. Attach the radiator cap to a radiator cap tester (commercially available) by using the SST. Apply pressure gradually to 113–142 kPa {1.15–1.45 kgf/cm<sup>2</sup>, 16.4–20.6 psi}.
3. Wait about 10 seconds. Verify that the pressure has not decreased.
4. If not as specified, replace the radiator cap.

#### Negative Pressure Valve

1. Pull the negative pressure valve to open it. Verify that it closes completely when released.
2. Check for damage on the contact surfaces and for cracked or deformed seal packing.
3. Replace the radiator cap if a problem is found.




## RADIATOR AND COOLANT FAN

## REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E-5)
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal.


## STEP 1



1. Fresh-air duct
2. Air cleaner housing
3. Battery and carrier
4. Radiator hose (upper)


5. Relay box
6. Coolant fan motor connector

## STEP 2



- 1. Undercover
- 2. Stabilizer and bracket  
Removal/Inspection ..... Section R
- 3. Radiator hose (lower)
- 4. Air separation hose


- 5. Oil cooler hose (AT)
- 6. Radiator and coolant fan  
Removal Note ..... below  
Inspection ..... page E-10




### Removal Note Radiator and coolant fan

While removing the radiator and cooling fan, do not disconnect the A/C piping.


1. Remove the bolts shown in the figure.
2. Position the A/C condenser away from the radiator and secure it with wire.




3. Remove the P/S oil pump pipe bracket shown in the figure.



4. Remove the A/C compressor high-pressure pipe bracket as shown in the figure.



5. Remove the radiator bracket.  
6. Remove the radiator and coolant fan.




### INSPECTION

#### Radiator


Check for the following and repair or replace the radiator as necessary.

1. Cracks, damage and water leakage
2. Bent fins (repair with a screwdriver)
3. Damaged radiator inlet, outlet, and hose connectors

**Coolant fan motor**


1. Verify that the battery is fully charged.
2. Disconnect the fan motor connectors.
3. Connect battery positive voltage and an ammeter as shown to the fan motor connector for low-speed inspection.
4. Verify that the fan motor operates smoothly at the standard current.

**Current: 5.8–11.8A**



5. Connect battery positive voltage, an ammeter, and a switch to the fan motor connector as shown for medium-speed inspection.
6. Verify that the fan motor operates smoothly at the standard current or less with the switch ON.

**Current: 6.5–12.5A**



7. Connect battery positive voltage, an ammeter, and a switch to the fan motor connector as shown for high-speed inspection.
8. Verify that the fan motor operates smoothly at the standard current or less with the switch ON.

**Current: 10.6–16.6A**


9. Check the other fan motor as described above.
10. If a fan motor does not operate as specified, replace it.

# E

## RADIATOR AND COOLANT FAN


### REPLACEMENT

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Radiator cowling
2. Coolant fan


3. Coolant fan motor




**COOLANT FAN RELAY**

**REMOVAL / INSTALLATION**

Slide the coolant fan relays off the bracket.



The relay positions are shown in the figure.



**INSPECTION**

1. Check continuity of the relay as shown.

Terminal	Continuity
a-b	No
c-d	Yes

2. Apply 12V between terminals c and d.  
Check for continuity between terminals a and b.
3. If not as specified, replace the fan relay.

**Steps After Installation**


1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E-5.)
2. Start the engine and check for leaks.



### THERMOSTAT

#### REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E-5)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal, referring to Installation Note.




1. Fresh-air duct
2. Air cleaner housing
3. Water hose
4. Air pump
5. Drive belt

6. Radiator hose (upper)
7. Coolant level sensor connector
8. Thermostat cover
9. Thermostat and gasket

Removal/Installation ..... Section C

Inspection ..... page E-15  
 Installation Note ..... page E-15



### INSPECTION

1. Visually check that the thermostat valve is airtight.
2. Place the thermostat and a thermometer in water.
3. Heat the water and check the following.


**Initial-opening temperature:**

**80.5–83.5°C {177–182°F}**

**Full-open temperature: 95°C {203°F}**

**Full-open lift: 8.0–10 mm {0.31–0.39 in} min.**

4. Check the thermostat gasket; if damaged, replace the thermostat assembly.



### Installation Note

#### Thermostat

Install the thermostat into the thermostat case with the jiggle pin at the top.


### Steps After Installation

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E-5,6.)
2. Connect the negative battery cable.
3. Start the engine and check for leaks.
4. Bleed the cooling system. (Refer to page E-6.)

## WATER PUMP AND WATER THERMOSENSOR


### REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E-5)
3. Remove in the order shown in the figure (page E-16), referring to **Removal Note**.
4. Install in the reverse order of removal.



N·m {kgf·m, ft·lbf}


- |                                  |   |
|----------------------------------|---|
| 1. Fresh-air duct                | 11. Alternator and strap                      |
| 2. Battery and carrier           | 12. Air pump and strap                        |
| 3. Air funnel and air hose       | 13. Radiator hose (upper)                     |
| 4. Accelerator cable             | 14. Charge air cooler and air separation tank |
| Service .....                    | Removal Note .....                            |
| Section F                        | page E-17                                     |
| 5. Air cleaner housing           | 15. Subframe                                  |
| 6. Water hose (filler port)      | 16. Radiator hose (lower)                     |
| 7. Air pipe and air hose         | 17. Heater hose                               |
| 8. Water pump pulley             | 18. Water hose (water pump body)              |
| 9. Drive belt                    | 19. Metering oil tube                         |
| Removal/Installation .....       | 20. Water pump and pump body                  |
| Section C                        | Removal Note .....                            |
| 10. Water hose (water pump body) | page E-17                                     |
|                                  | 21. Water thermostat                          |
|                                  | Inspection .....                              |
|                                  | Installation Note .....                       |
|                                  | page E-17                                     |
|                                  | page E-17                                     |



### Removal Note


#### Charge air cooler and air separation tank

Do not remove the air duct from the body.




### Water pump and pump body

1. Remove the metering oil pump connector from the engine hanger.



2. Remove the bolt A shown in the figure.
3. Position the metering oil tube and metering oil pump harness under the lower radiator hose.
4. Remove the nuts B shown in the figure.
5. Remove the water pump and pump body.




### INSPECTION

#### Water Thermosensor

1. Place the switch and a thermometer in water.
2. Heat the water gradually and check resistance of the switch.

Coolant	Resistance
101°C {214°F}	0.5 Ω max.
108°C {236°F}	1 MΩ min

3. If not as specified, replace the water thermosensor.



### Installation Note

#### Water thermosensor

1. Apply a small amount of engine coolant to the new O-ring.
2. Install the water thermosensor.

#### Tightening torque:

5.9–8.8 Nm {60–90 kgf·cm, 52–78 in·lbf}


Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.

# FUEL AND EMISSION CONTROL SYSTEMS

<b>INDEX</b> .....	F- 2	<b>SYSTEM OPERATION</b> .....	F-126
<b>OUTLINE</b> .....	F- 7	<b>EGR VALVE</b> .....	F-127
<b>SYSTEM DIAGRAM</b> .....	F- 7	<b>EGR FUNCTION SENSOR</b> .....	F-127
<b>WIRING DIAGRAM</b> .....	F- 8	<b>SOLENOID VALVE (EGR)</b> .....	F-127
<b>VACCUUM HOSE ROUTING DIAGRAM</b> .....	F- 10	<b>THREE-WAY CATALYST SYSTEM</b> .....	F-128
<b>SPECIFICATIONS</b> .....	F- 11	<b>THREE-WAY CATALYST</b> .....	F-128
<b>COMPONENT DESCRIPTIONS</b> .....	F- 12	<b>FUEL EVAPORATIVE SYSTEM</b> .....	F-129
<b>ENGINE TUNE-UP</b> .....	F- 15	<b>SYSTEM OPERATION</b> .....	F-130
<b>BASIC INSPECTION</b> .....	F- 15	<b>SOLENOID VALVE (PURGE CONTROL)</b> .....	F-131
<b>ADJUSTMENT</b> .....	F- 16	<b>CHACOAL CANISTER</b> .....	F-131
<b>ON-BOARD DIAGNOSIS FUNCTION</b> .....	F- 18	<b>CHECK VALVE (TWO-WAY)</b> .....	F-132
<b>DIAGNOSTIC TROUBLE CODE NUMBER</b> .....	F- 20	<b>CHECK VALVE (ONE-WAY)</b> .....	F-132
<b>SWITCH MONITOR FUNCTION</b> .....	F- 67	<b>SEPARATOR</b> .....	F-132
<b>OXYGEN SENSOR MONITOR FUNCTION</b> .....	F- 75	<b>FUEL VAPOR VALVE</b> .....	F-132
<b>KNOCK SENSOR MONITOR FUNCTION</b> .....	F- 75	<b>DECELERATION CONTROL SYSTEM</b> .....	F-133
<b>INTAKE AIR SYSTEM</b> .....	F- 76	<b>DASHPOT</b> .....	F-134
<b>AIR BYPASS VALVE</b> .....	F- 77	<b>ANTI AFTERBURN CONTROL</b> .....	F-134
<b>CHARGE AIR COOLER</b> .....	F- 78	<b>ELECTRICAL LOAD (E/L) CONTROL</b>	
<b>THROTTLE BODY</b> .....	F- 79	<b>SYSTEM</b> .....	F-135
<b>EXTENSION MANIFOLD</b> .....	F- 79	<b>SYSTEM OPERATION</b> .....	F-136
<b>INTAKE MANIFOLD</b> .....	F- 79	<b>DOUBLE THROTTLE CONTROL SYSTEM</b> .....	F-137
<b>ACCELERATOR PEDAL</b> .....	F- 80	<b>SYSTEM OPERATION</b> .....	F-138
<b>ACCELERATOR CABLE</b> .....	F- 80	<b>ACTUATOR</b>	
<b>IDLE-SPEED CONTROL SYSTEM</b> .....	F- 81	<b>(DOUBLE THROTTLE CONTROL)</b> .....	F-139
<b>SYSTEM OPERATION</b> .....	F- 82	<b>CHECK VALVE</b> .....	F-139
<b>IDLE AIR CONTROL VALVE</b> .....	F- 83	<b>A/C CUT-OFF SYSTEM</b> .....	F-140
<b>SOLENOID VALVE (AWS)</b> .....	F- 83	<b>SYSTEM OPERATION</b> .....	F-141
<b>SEQUENTIAL TWIN TURBOCHARGER SYSTEM</b> ..	F- 84	<b>A/C RELAY</b> .....	F-142
<b>ACTUATOR (TURBO CONTROL)</b> .....	F- 86	<b>DECHOKE CONTROL SYSTEM</b> .....	F-143
<b>ACTUATOR (CHARGE CONTROL)</b> .....	F- 87	<b>SYSTEM OPERATION</b> .....	F-143
<b>CHARGE RELIEF VALVE</b> .....	F- 88	<b>ELECTRICAL COOLANT FAN CONTROL</b>	
<b>TURBOCHARGER</b> .....	F- 89	<b>SYSTEM</b> .....	F-144
<b>CHECK VALVE</b> .....	F- 90	<b>SYSTEM OPERATION</b> .....	F-146
<b>SOLENOID VALVE (TURBO PRECONTROL,</b>		<b>FAN RELAY</b> .....	F-146
<b>WASTEGASTE CONTROL)</b> .....	F- 93	<b>CONTROL SYSTEM</b> .....	F-147
<b>FUEL SYSTEM</b> .....	F- 94	<b>STRUCTURAL VIEW</b> .....	F-148
<b>PRECAUTION</b> .....	F- 95	<b>POWERTRAIN CONTROL MODULE (ENGINE)</b>	
<b>SYSTEM OPERATION</b> .....	F- 96	<b>(PCME)</b> .....	F-150
<b>FUEL TANK</b> .....	F- 98	<b>CRANKSHAFT POSITION SENSOR</b> .....	F-166
<b>FUEL PUMP</b> .....	F-100	<b>MANIFOLD ABSOLUTE PRESSURE SENSOR</b> ..	F-167
<b>FUEL FILTER</b> .....	F-103	<b>THROTTLE POSITION SENSOR</b> .....	F-168
<b>PRESSURE REGURATOR</b> .....	F-104	<b>ENGINE COOLANT TEMPERATURE</b>	
<b>INJECTOR</b> .....	F-105	<b>SENSOR</b> .....	F-169
<b>FUEL PUMP CONTROL SYSTEM</b> .....	F-108	<b>INTAKE AIR TEMPERATURE SENSOR</b> .....	F-169
<b>FUEL PUMP RESISTOR</b> .....	F-109	<b>FUEL THERMOSENSOR</b> .....	F-170
<b>FUEL PUMP RELAY (SPEED)</b> .....	F-110	<b>OXYGEN SENSOR</b> .....	F-170
<b>PRESSURE REGULATOR CONTROL (PRC)</b>		<b>KNOCK SENSOR</b> .....	F-171
<b>SYSTEM</b> .....	F-111	<b>STEERING PRESSURE SENSOR</b> .....	F-172
<b>SYSTEM OPERATION</b> .....	F-112	<b>STOPLIGHT SWITCH</b> .....	F-172
<b>EXHAUST SYSTEM</b> .....	F-113	<b>NEUTRAL SWITCH (MT)</b> .....	F-172
<b>COMPONENT PARTS</b> .....	F-113	<b>CLUTCH SWITCH (MT)</b> .....	F-173
<b>OUTLINE OF EMISSION SYSTEM</b> .....	F-114	<b>1-2 SWITCH (MT)</b> .....	F-173
<b>STRUCTURAL VIEW</b> .....	F-114	<b>MAIN RELAY (EGI RELAY)</b> .....	F-174
<b>SECONDARY AIR INJECTION</b> .....	F-115	<b>FUEL PUMP RELAY</b> .....	F-174
<b>AIR CONTROL VALVE (ACV)</b> .....	F-117	<b>HEAT HAZARD SENSOR</b> .....	F-175
<b>SOLENOID VALVE (PORT AIR BYPASS)</b> .....	F-119	<b>MILEAGE SWITCH</b> .....	F-175
<b>SOLENOID VALVE (SPLIT AIR BYPASS)</b> .....	F-120	<b>SOLENOID VALVES</b> .....	F-176
<b>CHECK VALVE (PORT AIR)</b> .....	F-120	<b>TROUBLESHOOTING GUIDE</b> .....	F-178
<b>CHECK VALVE (SPLIT AIR)</b> .....	F-120	<b>QUICK DIAGNOSIS CHART</b> .....	F-178
<b>CHECK VALVE</b> .....	F-120	<b>RELATIONSHIP CHART</b> .....	F-182
<b>AIR PUMP</b> .....	F-121	<b>USING THIS SECTION</b> .....	F-184
<b>AIR PUMP DRIVE BELT</b> .....	F-122	<b>DIAGNOSTIC INDEX</b> .....	F-186
<b>AIR PUMP RELAY</b> .....	F-123	<b>PRECAUTION</b> .....	F-189
<b>SOLENOID VALVE (RELIEF2)</b> .....	F-123	<b>SYMPTOM TROUBLESHOOTING</b> .....	F-190
<b>POSITIVE CRANKCASE VENTILATION (PCV)</b>		<b>SERVICE POINTS</b> .....	F-218
<b>SYSTEM</b> .....	F-124	<b>OUTLINE</b> .....	F-218
<b>PCV VALVE</b> .....	F-124	<b>WIRING DIAGRAM</b> .....	F-224
<b>EXHAUST GAS RECIRCULATION (EGR)</b> .....	F-125	<b>ELECTRICAL DIAGNOSIS SUPPORT</b> .....	F-228


## INDEX

### Intake Air System




1. Fresh air duct Removal / Inspection / Installation .....	page F- 76	9. Intake manifold Inspection .....	page F- 79
2. Resonance chamber Removal / Inspection / Installation .....	page F- 76	10. Extension manifold Installation .....	page F- 79
3. Air cleaner housing Inspection .....	page F- 16	11. Accelerator cable Inspection / Adjustment .....	page F- 80
4. Air bypass valve Inspection .....	page F- 77	12. Actuator (Turbo control) Inspection .....	page F- 86
5. Charge air cooler Removal / Inspection / Installation .....	page F- 78	13. Actuator (Charge control) Inspection .....	page F- 87
6. Throttle body Inspection / Adjustment .....	page F- 79	14. Change relief valve Inspection .....	page F- 88
7. Double throttle valve Inspection .....	page F- 79	15. Turbocharger Inspection .....	page F- 89
8. Actuator (Double throttle control) Inspection .....	page F-139	16. Actuator (Turbo precontrol) Inspection .....	page F- 89
		17. Actuator (Wastegate control) Inspection .....	page F- 90

Fuel System and Evaporative Emission Control System



- |   |            |
|---|------------|
| 1. Fuel tank                                    |            |
| Removal / Inspection /                          |            |
| Installation .....                              | page F- 99 |
| 2. Fuel pump                                    |            |
| Inspection .....                                | page F-100 |
| Removal / Installation .....                    | page F- 99 |
| Disassembly / Assembly .....                    | page F-102 |
| 3. Fuel filter (High pressure)                  |            |
| Replacement .....                               | page F-103 |
| 4. Pressure regulator                           |            |
| Inspection .....                                | page F-104 |
| Removal / Installation .....                    | page F-105 |
| 5. Injector                                     |            |
| Inspection (On vehicle) /                       |            |
| Removal / Installation .....                    | page F-105 |
| Inspection .....                                | page F-107 |
| 6. Pulsation damper                             |            |
| Removal .....                                   | page F-105 |
| 7. Check valve (two-way)                        |            |
| Inspection .....                                | page F-132 |
| 8. Check valve (one-way)                        |            |
| Inspection .....                                | page F-132 |
| 9. Separator                                    |            |
| Inspection .....                                | page F-132 |
| 10. Fuel vapor valve                            |            |
| Inspection .....                                | page F-132 |
| 11. Solenoid valve (Pressure regulator control) |            |
| Removal / Installation .....                    | page F-176 |
| Inspection .....                                | page F-177 |
| 12. Solenoid valve (Purge control)              |            |
| Removal / Installation .....                    | page F-131 |
| Inspection .....                                | page F-131 |
| 13. Catch tank                                  |            |
| 14. Chacoal canister                            |            |
| Inspection .....                                | page F-131 |

**Exhaust System**




- 1. Main silencer  
Removal / Inspection /  
Installation ..... page F-113
- 2. Three-way catalyst  
Removal / Inspection /  
Installation ..... page F-113
- 3. Warm-up three-way catalyst  
Removal / Inspection /  
Installation ..... page F-113

- 4. Exhaust manifold  
Removal / Inspection  
Installation ..... page F-113
- 5. Secondary air pipe  
Removal / Inspection /  
Installation ..... page F-113
- 6. Check valve (Split air)  
Inspection ..... page F-120




Control System (Input Devices)




- |  |  |
|--|--|
| 1. Powertrain control module (engine) (PCME)<br>Removal / Installation /<br>Inspection ..... page F-150            | 10. Steering pressure sensor<br>Inspection (On vehicle) /<br>Removal / Installation ..... page F-172 |
| 2. Crankshaft position sensor<br>Removal / Installation ..... page F-166   | 11. Stoplight switch<br>Inspection /<br>Removal / Installation ..... page F-172                      |
| 3. Manifold absolute pressure sensor<br>Inspection ..... page F-167  | 12. Neutral switch (MT)<br>Inspection ..... page F-172<br>Removal / Installation ..... page F-173    |
| 4. Throttle position sensor<br>Inspection / Adjustment ..... page F-168<br>Removal / Installation ..... page F-169 | 13. Clutch switch (MT)<br>Inspection /<br>Removal / Installation ..... page F-173                    |
| 5. Engine coolant temperature sensor<br>Removal / Installation /<br>Inspection ..... page F-169                    | 14. 1-2 switch (MT)<br>Inspection /<br>Removal / Installation ..... page F-173                       |
| 6. Intake air temperature sensor<br>Removal / Installation /<br>Inspection ..... page F-169                        | 15. EGR Function Sensor<br>Inspection /<br>Removal / Installation ..... page F-127                   |
| 7. Fuel thermosensor<br>Removal / Installation /<br>Inspection ..... page F-170                                    | 16. Mileage switch<br>Inspection ..... page F-175  |
| 8. Oxygen sensor<br>Inspection ..... page F-170<br>Removal / Installation ..... page F-113                         | 17. Heat hazard sensor<br>Inspection /<br>Removal / Installation ..... page F-175                    |
| 9. Knock sensor<br>Inspection (On vehicle) /<br>Removal / Installation ..... page F-171                            | 18. E/L unit<br>Inspection ..... page F-136<br>Removal / Installation ..... page F-150               |

Control System (Output Devices)





1. Main relay		
Inspection .....	page F-174	
2. Fuel pump relay		
Inspection .....	page F-174	
3. Solenoid valves		
Removal / Installation .....	page F-176	
Inspection .....	page F-177	
4. Idle air control valve		
Removal / Installation .....	page F- 83	
Inspection .....	page F- 83	
5. Solenoid valve (AWS)		
Removal / Installation .....	page F- 83	
Inspection .....	page F- 83	
6. Solenoid valve (Turbo precontrol)		
Removal / Installation .....	page F- 93	
Inspection .....	page F- 93	
7. Solenoid valve (Wastegate control)		
Removal / Installation .....	page F- 93	
Inspection .....	page F- 93	
8. Solenoid valve (Turbo control)		
Removal / Installation .....	page F- 93	
Inspection .....	page F- 93	
9. Solenoid valve (Port air bypass)		
Removal / Installation .....	page F-119	
Inspection .....	page F-119	
10. Solenoid valve (Relief 2)		
Removal / Installation .....	page F-119	
Inspection .....	page F-119	
11. Solenoid valve (Split air bypass)		
Removal / Installation .....	page F-119	
Inspection .....	page F-120	
12. A/C relay		
Inspection .....	page F-142	
13. Fan relay		
Inspection .....	page F-146	
14. Fuel pump relay (speed)		
Inspection .....	page F-110	
15. Fuel pump resistor		
Removal / Installation .....	page F-109	
Inspection .....	page F-109	
16. Air pump relay		
Inspection .....	page F-123	
17. Data link connector		
18. Air pump		
Inspection /		
Removal / Installation .....	page F-121	
19. Check valve (Port air)		
Inspection .....	page F-120	

OUTLINE  
SYSTEM DIAGRAM




WIRING DIAGRAM





F

VACCUM HOSE ROUTING DIAGRAM



**SPECIFICATIONS**

Item		Specification
Idle speed*	rpm	700-750 (720 $\begin{smallmatrix} +30 \\ -20 \end{smallmatrix}$ )
Ignition timing*	Leading	ATDC 5°
	Trailing	ATDC 20°
<b>Air cleaner housing</b>		
Element type		Oil permeated
<b>Throttle body</b>		
Type		Horizontal draft (2 stage-3 barrel)
Throat diameter	Primary	mm {in} 45 {1.772}
	Secondary	mm {in} 50 {1.969} × 2
Dashpot touch angle		° 8
Water thermostatic Valve Operation (full open) temperature		°C {°F} 55-65 {131-149} or more
<b>Charge air cooler</b>		
Type		Air cooled
Core size {w × h × t}		mm {in} 294 × 114 × 65 {11.575 × 4.4882 × 2.5591}
<b>Turbocharger</b>		
System type		Sequential twin turbo charged
Cooling method		water + engine oil
Boost control actuator		turbo pre-control + wastegate control
Boost control method		Solenoid valve (duty-controlled) × 2
<b>Fuel filter</b>		
Type	Low-pressure	Nylon element
	High-pressure	paper element
<b>Pressure regulator</b>		
Type		Diaphragm
Regulated pressure		kPa {kgf/cm <sup>2</sup> , psi} 250-260 {2.5-2.6, 35.6-37.0}
<b>Fuel pump</b>		
Type		Impeller (In tank)
Output pressure		kPa {kgf/cm <sup>2</sup> , psi} 490-740 {50-7.5, 71.1-106.7}
<b>Injector</b>		
Type		Side-feeding
Injection volume	Primary	ml {cc, fl oz}/min 550 {550, 16.5}
	Secondary	ml {cc, fl oz}/min 850 {850, 25.5}
<b>Three-way catalyst</b>		
Type	Warm-up three-way catalyst	Metal
	Three-way catalyst	Monolithic
<b>Air pump</b>		
Capacity		cm <sup>3</sup> {cc}/rev 375 {375}
Output		L/min MT 130-200, AT 160-200
<b>Fuel</b>		
Specification		Unleaded premium (RON95 or higher)

\* TEN terminal of data link connector is grounded.

## COMPONENT DESCRIPTIONS

Component	Function	Remark
1-2 switch	Detects gear position (1st, 2nd)	MT only
Actuator (charge control)	Controls charge control valve	—
Actuator (Double throttle control)	Controls double throttle valve	Installed on extension manifold
Actuator (Turbo control)	Controls turbo control valve	Controlled by two solenoid valves
Actuator (Turbo precontrol)	Controls turbo precontrol valve	Part of turbocharger assembly
Actuator (Wastegate control)	Controls wastegate control valve	Part of turbocharger assembly
Air Bypass Valve	Reduces sound of intake air entering air cleaner housing from turbocharger deceleration	
Air Cleaner Element	Filters air entering throttle chamber	Oil permeated type
Air Control Valve	Directs air to one of three locations: exhaust port, three-way catalyst, or relief air silencer	Consists of two valves: Secondary air bypass valve Secondary air switching valve
Air pump	Supplies secondary air to air control valve	With electromagnetic clutch
Barometric Absolute Pressure Sensor	Detects atmospheric pressure; sends signal to PCME	Built in PCME
Charcoal Canister	Stores fuel tank fumes when engine is stopped	Vented to atmosphere through charcoal and air filter
Clutch switch	Detects clutch condition (engaged / disengaged)	MT only
Crankshaft position Sensor	Detects eccentric shaft angle at 30° intervals and front rotor position; sends signal to PCME	—
Dashpot	Prevents sudden throttle valve closing during deceleration	—
Data link connector	<b>Service connector terminals:</b> 1. CIS self-diagnosis 2. PCMT on-board diagnosis [AT] 3. Initial set 4. Fuel pump check 5. Engine speed output 6. Switch and oxygen sensor monitor 7. Supply battery positive voltage 8. Ground 9. A/C self-diagnosis 10. Cruise control self-diagnosis 11. Electrical coolant fan self-diagnosis	<b>25-pin (located near fuse box)</b> 1. FEN terminal 2. TAT and FAT terminal 3. TEN terminal 4. F/P terminal 5. IG- terminal 6. MEN terminal 7. +B terminal 8. GND terminal 9. TAC and FAC terminal 10. TSC and FSC terminal 11. TFA terminal
Engine coolant temperature sensor	Detect coolant temperature; send signals to PCME	• Installed in engine
Fuel filter	Filters particles from fuel	
Fuel pump	Provides fuel to injectors	• Operates while engine running • In fuel tank
Fuel pump relay	Voltage for fuel pump while engine running	—
Igniter	Receives spark signal from PCME and generates high voltage in ignition coil	
Ignition switch (START position)	Sends engine cranking signal to PCME	—
Injector	Injects fuel into intake port	• Controlled by signal from PCME (side-feed type)
Intake air temperature sensor	Detects intake air temperature; sends signal to PCME	• Installed in extension manifold
Knock sensor	Detects engine knocking; sends signal to PCME	—
Main relay	Supplies current to output devices and PCME	—
Manifold absolute pressure sensor	Detects intake manifold pressure; sends signal to PCME	—
Neutral/Clutch switches (MT)	Detects in-gear condition; sends signal to PCME	• Switch is ON in neutral
Oxygen sensor	Detects oxygen concentration; sends signal to PCME	• Zirconic and platinum coat






Component	Function	Remark
Park/neutral switch (AT)	Detects load condition; sends signal to PCME	—
PCV valve	Controls blowby gas introduced into engine	—
Powertrain control module (engine) (PCME)	<p><b>Detects the following:</b></p> <ol style="list-style-type: none"> <li>1. Engine speed</li> <li>2. Knocking signal</li> <li>3. Vehicle speed</li> <li>4. Engine coolant temperature</li> <li>5. Intake air temperature</li> <li>6. Throttle valve opening angle (full range)</li> <li>7. Intake manifold pressure</li> <li>8. Atmospheric pressure</li> <li>9. Oxygen concentration</li> <li>10. Air/Fuel ratio</li> <li>11. Throttle valve opening angle (narrow range)</li> <li>12. Metering oil pump (MOP) position signal</li> <li>13. Fuel temperature</li> <li>14. Gear position</li> <li>15. Clutch condition</li> <li>16. In-gear condition</li> <li>17. Power steering operation</li> <li>18. Braking signal</li> <li>19. Starter signal</li> <li>20. Electrical Load (E/L) condition</li> <li>21. EGR condition</li> </ol> <p><b>Control operation of the following</b></p> <ol style="list-style-type: none"> <li>1. Fuel injection system</li> <li>2. Ignition control system</li> <li>3. Idle speed control system</li> <li>4. Pressure regulator control system</li> <li>5. Secondary air injection</li> </ol> <p>6. Accelerated warm-up System</p> <p>7. Sequential twin turbocharger control system</p> <p>8. Exhaust Gas Recirculation control system</p> <p>9. Double throttle control system</p> <p>10. A/C control system</p> <p>11. Electric coolant fan control system</p> <p>12. Lock-up control system</p> <p>13. Slip control system</p> <p>14. On-board diagnosis function</p> <p>15. Monitor function</p> <p>16. Back up function</p>	<ol style="list-style-type: none"> <li>1. Crankshaft position sensor</li> <li>2. Knock sensor</li> <li>3. Vehicle speed sensor</li> <li>4. Engine coolant temperature sensor</li> <li>5. Intake air temperature sensor</li> <li>6. Throttle position sensor (full range)</li> <li>7. Manifold absolute pressure sensor</li> <li>8. Barometric absolute pressure sensor</li> <li>9. Oxygen sensor</li> <li>10. Oxygen sensor</li> <li>11. Throttle position sensor (narrow range)</li> <li>12. MOP position sensor</li> <li>13. Fuel thermosensor</li> <li>14. 1-2 switch (MT)</li> <li>15. Clutch switch (MT)</li> <li>16. Neutral switch (MT)</li> <li>17. Steering pressure sensor</li> <li>18. Stoplight switch</li> <li>19. Ignition switch</li> <li>20. E/L unit</li> <li>21. EGR function sensor</li> </ol> <p>Injector Igniter Solenoid valve (Idle air control [IAC]) Solenoid valve (Pressure Regulator control [PRC]) Solenoid valve (Split air bypass [SAB]) Solenoid valve (Port air bypass [PAB]) Secondary air switching valve Solenoid valve (Relief No.2 [RELIEF2]) Secondary air bypass valve Solenoid valve (AWS) Solenoid valve (Turbo control No.1 [TCNT1]) Solenoid valve (Turbo control No.2 [TCNT2]) Solenoid valve (Wastegate control [WGCNT]) Solenoid valve (Turbo precontrol [TPCNT]) Solenoid valve (Change control [CCNT]) Solenoid valve (Change relief [CRF]) Solenoid valve (EGR) Solenoid valve (DTCNT) A/C relay Fan relay PCMT PCMT Self-diagnosis checker Self-diagnosis checker</p>
Pressure regulator	Adjusts fuel pressure supply to injectors	—
Pulsation dumper	Absorbs fuel pulsations	—
Secondary air bypass valve	Controls relief valve	● Installed below extension manifold
Secondary air switching valve	Controls switching valve of air control valve	● Installed below extension manifold
Solenoid valve (IAC)	Supplies bypass air into intake manifold	● Controlled by duty signal from PCME
Solenoid valve (PRC)	Controls vacuum to pressure regulator	● Installed below extension manifold
Solenoid valve (SAB)	Controls split air volume	● Installed in ACV
Solenoid valve (RELIEF2)	Controls relief valve	● Installed in ACV
Solenoid valve (PAB)	Controls port air volume	● Installed in ACV
Solenoid valve (AWS)	Controls accelerated warm-up system	● Installed in extension manifold
Solenoid valve (TCNT1)	Controls turbo control valve	● Installed in ACV (pressure applied)
Solenoid valve (TCNT2)	Controls turbo control valve	● Installed below extension manifold (vacuum applied)

Component	Function	Remark
Solenoid valve (WGCNT)	Controls wastegate valve	<ul style="list-style-type: none"> <li>Controlled by duty signal from PCME</li> </ul>
Solenoid valve (TPCNT)	Controls turbo precontrol valve	<ul style="list-style-type: none"> <li>Controlled by duty signal from PCME</li> </ul>
Solenoid valve (CCNT)	Controls charge control valve	<ul style="list-style-type: none"> <li>Installed below extension manifold</li> </ul>
Solenoid valve (CRF)	Controls charge relief valve	<ul style="list-style-type: none"> <li>Installed below extension manifold</li> </ul>
Solenoid valve (EGR)	Controls EGR valve	<ul style="list-style-type: none"> <li>Installed below extension manifold</li> </ul>
Solenoid valve (DTCNT)	Controls double throttle valve	<ul style="list-style-type: none"> <li>Installed below extension manifold</li> </ul>
Solenoid valve (PURGE)	Controls evaporative fumes from charcoal canister to intake manifold	<ul style="list-style-type: none"> <li>Controlled by duty signal from PCME</li> </ul>
Steering pressure sensor	Detects P/S operation	<ul style="list-style-type: none"> <li>Steering pressure sensor ON when steering wheel turned</li> </ul>
Stoplight switch	Detects braking; sends signal to PCME	—
Three-Way Catalyst	Reduces HO, CO and NOx	—
Throttle body	Controls intake air amount	—
Throttle position sensor	Detects throttle valve opening angle	<ul style="list-style-type: none"> <li>Installed on throttle body</li> </ul>
Vehicle speed sensor	Detects vehicle speed; sends signal to PCME	<ul style="list-style-type: none"> <li>Installed in instrument cluster</li> </ul>

ENGINE TUNE-UP

PREPARATION  
SST

<p>498 B019 9A0</p>  <p>System Selector</p>	<p>For inspection of ignition timing and idle speed and diagnosis</p>	<p>49 H018 9A1</p>  <p>Self-Diagnosis Checker</p>	<p>For diagnosis</p>
--	---	--	----------------------



**BASIC INSPECTION**


**Engine Oil**

1. Remove the dipstick and check the engine oil level and condition.
2. Add or change oil as necessary.


**Coolant (engine cold)**

**Warning**

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system.
- Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counter-clockwise to the first stop. Step back while the pressure escapes.
- When you're sure all the pressure is gone, press down on the cap-still using a cloth-turn it, and remove it.




1. Remove the coolant level gauge from the coolant reservoir.
2. Verify that the coolant level is between the and marks of the gauge.
3. Add coolant if necessary.



**Battery**

**Terminal and cable**


1. Remove any corrosion on the clamps or battery posts and coat them with grease.
2. Verify that the battery top is clean. If necessary, clean with baking soda and water.
3. Verify that cables are not frayed or corroded. Repair or replace if necessary.
4. Verify that cable clamps are tight.
5. Verify that the rubber protector completely covers the positive terminal and clamp.



**Electrolyte level and specific gravity**

1. Verify that the electrolyte level is between the "Upper" and "Lower" level marks.
2. Add distilled water if necessary. Do not over fill.
3. Check the specific gravity with a hydrometer.

**Specific Gravity: 1.27-1.29 {at 20°C [68°F]}**




### Air Cleaner Element Inspection

1. Check the air cleaner element for excessive dirt and for oil and damage.

#### Caution

- Cleaning the element with compressed air will reduce the element's ability to filter the air. Don't use compressed air to clean the element.


2. Replace the element if necessary.



### ADJUSTMENT

#### Preparation


1. Warm up the engine to normal operating temperature.
2. Turn all electric loads OFF.
3. Connect the SST to the data link connector.
4. Connect a tachometer to the data link connector IG- terminal as shown.



#### Ignition Timing


The ignition timing is set at the factory and must not be adjusted. Any adjustment will negatively effect the engine performance.

1. Perform preparation (refer to above.)
2. Verify that the electric coolant fan does not operate.
3. Remove the fuel filler cap.
4. Set SYSTEM SELECT to position 1.
5. Set TEST SW to SELF-TEST.
6. If the SST is not used, connect a jumper wire between the TEN terminal and the GND terminal of the data link connector.
7. Make sure the idle speed is within specification; if not, adjust the idle speed.
8. Connect a timing light to the high-tension lead of the front trailing-side.








#### Note

- Some timing lights will not illuminate even if the ignition is working properly.



9. Verify that the timing mark (white) on the crankshaft position sensor plate is aligned with the indicator pin.

**Ignition timing: Trailing side: 20° ATDC (-20° BTDC)  
Leading side: 5° ATDC (-5° BTDC)  
Idle speed (Neutral or P range): 550-950 rpm**



10. If the timing is incorrect, check the following procedure.
- Verify that no trouble code number is present. If trouble code number present, check for cause by referring to the specified check sequence. (Refer to page F-20)
  - 05-knock sensor
  - 13-Manifold absolute pressure sensor

**Input devices**

- E/L, P/S, A/C, Coolant fan
- Crankshaft position sensor (NE, signal)
- Manifold absolute pressure sensor
- Throttle position sensor
- Neutral SW / Clutch SW (MT)
- Park / Neutral signal (AT)

**Others**

PCME terminal 3I (Refer to page F-152)

11. Disconnect the SST.  
 12. Verify that the ignition timing advances when the engine is above 1,500 RPM.

**Idle Speed**

Because the idle speed is controlled automatically by the PCME, it is usually not necessary to check and adjust the idle speed control valve. However, if the engine is idling roughly, use the following procedure to make adjustments.

1. Perform "Preparation". (Refer to page F-16)

2. Set SYSTEM SELECT to position 1  
 3. Set TEST SW to SELF TEST  
 4. With the coolant fan off, verify that the idle speed is within specification.

**Idle speed: 700-750 (720  $\pm$ 30  $\frac{-20}{}$  rpm)**


5. If not within the specification, adjust the idle by turning the air-adjusting screw (AAS).  
 6. If not within the specification when air adjusting screw fully closed, loosen the locknut and turn the throttle adjusting screw to set the idle.  
 7. Tighten the locknut and put a paint mark on the nut and throttle body.  
 8. Disconnect the SST.

ON-BOARD DIAGNOSIS FUNCTION



DESCRIPTION




When trouble occurs in the main input or output devices, check for the cause by using the SST. Failure of input and output devices is indicated and retrieved from the powertrain control module (engine) (PCME) as diagnostic trouble code numbers.

For input devices, the PCME continuously checks for malfunctions. For output devices, it checks for malfunctions only in a three-second period after the ignition switch is turned to ON, or the TEN terminal of the data link connector is grounded.



**PREPARATION**  
**SST**

<p>49 B019 9A0 System Selector</p> 	<p>For diagnosis</p>	<p>49 H018 9A1 Self-Diagnosis Checker</p> 	<p>For diagnosis</p>
--	--------------------------	---	--------------------------



### DIAGNOSTIC TROUBLE CODE NUMBER

#### Inspection Procedure

1. Connect the SST to the Self-Diagnosis Checker to the data link connector.
2. Set system select to position 1.
3. Set the test switch to SELF TEST.
4. Connect the SST to the System Selector and a ground.
5. Set the select switch to position A.
6. Turn the ignition switch ON.
7. Verify the "88" flashes on the digital display and the buzzer sounds for 3 sec. after turning the ignition switch ON.
8. If "88" does not flash, check the main relay (refer to page F-174), power supply circuit, and data link connector wiring.
9. If "88" flashes and the buzzer sounds continuously for more than 20 sec., check for a short circuit between the PCME terminal 1 F and the data link connector. Replace the PCME if necessary, perform Steps 3 and 7 again.
10. Note any code numbers and check for the causes by referring to the check sequences shown on pages F-26 through F-65. Repair as necessary.
11. After repairs, cancel the code numbers by performing the "After-repair procedure". (Refer to page F-66.)




**Principle of Code Cycle**

Trouble codes are determined as shown below.


**1. Code cycle break**

The time between trouble code cycles is 4.0 seconds (the time the buzzer is off).



**2. Second digit of trouble code (ones position)**


The digit in the ones position of the trouble code represents the number of times the buzzer sounds 0.4 second during one cycle.



**3. First digit of trouble code (tens position)**

The digit in the tens position of the trouble code represents the number of times the buzzer is on 1.2 seconds during one cycle.














The buzzer is off for 1.6 seconds between the long and short pulses.















# F

## ON-BOARD DIAGNOSIS FUNCTION

### Diagnostic Trouble Code Numbers












No.	Indicator flashing pattern	Diagnosed circuit	Condition	Point	Memorized	Page
02	ON OFF 	Crankshaft position sensor (NE signal)	No NE signal	<ul style="list-style-type: none"> <li>• Crankshaft position sensor connector</li> <li>• Wiring from crankshaft position sensor to PCME</li> <li>• Crankshaft position sensor</li> </ul>	Yes	F-26
03	ON OFF 	Crankshaft position sensor (G signal)	No G signal	<ul style="list-style-type: none"> <li>• Crankshaft position sensor connector</li> <li>• Wiring from crankshaft position sensor to PCME</li> <li>• Crankshaft position sensor</li> </ul>	Yes	F-27
05	ON OFF 	Knock sensor	Open or short circuit	<ul style="list-style-type: none"> <li>• Knock sensor connector</li> <li>• Wiring from knock sensor to PCME</li> <li>• Knock sensor</li> </ul>	Yes	F-28
06	ON OFF 	Vehicle speed Sensor	No vehicle speed sensor signal	<ul style="list-style-type: none"> <li>• Vehicle speed sensor connector</li> <li>• Wiring from vehicle speed sensor to PCME</li> </ul>	Yes	F-29
09	ON OFF 	Engine coolant temperature sensor	Open or short circuit	<ul style="list-style-type: none"> <li>• Engine coolant temperature sensor connector</li> <li>• Wiring from engine coolant temperature sensor to PCME</li> <li>• Engine coolant temperature sensor resistance</li> </ul>	Yes	F-30
11	ON OFF 	Intake air temperature sensor		<ul style="list-style-type: none"> <li>• Intake air temperature sensor connector</li> <li>• Wiring from intake air temperature sensor to PCME</li> <li>• Intake air temperature sensor resistance</li> </ul>	Yes	F-31
12	ON OFF 	Throttle position sensor (Full range)		<ul style="list-style-type: none"> <li>• Throttle position sensor connector</li> <li>• Wiring from throttle position sensor to PCME</li> </ul>	Yes	F-32
13	ON OFF 	Manifold absolute pressure sensor		<ul style="list-style-type: none"> <li>• Manifold absolute pressure sensor connector</li> <li>• Wiring from manifold absolute pressure sensor to PCME</li> <li>• Manifold absolute pressure sensor resistance</li> </ul>	Yes	F-33
14	ON OFF 	Barometric absolute pressure sensor (in PCME)		<ul style="list-style-type: none"> <li>• PCME</li> </ul>	Yes	F-34
15	ON OFF 	Oxygen sensor (Inactivation)	Sensor output continues less than 0.55V 25 sec. in closed loop zone	<ul style="list-style-type: none"> <li>• Oxygen sensor connector</li> <li>• Wiring from oxygen sensor to PCME</li> <li>• Oxygen sensor</li> </ul>	Yes	F-34
16	ON OFF 	EGR function sensor	Open or short circuit	<ul style="list-style-type: none"> <li>• EGR function sensor connector</li> <li>• Wiring from EGR function sensor to PCME</li> <li>• EGR function sensor</li> </ul>	Yes	F-35
17	ON OFF 	Oxygen sensor (Inversion)	Sensor output not changed 120 sec. in closed loop zone	<ul style="list-style-type: none"> <li>• Fuel pressure</li> <li>• Injection fuel leakage</li> <li>• Ignition system</li> <li>• Air leakage</li> <li>• PCME</li> </ul>	Yes	F-36
18	ON OFF 	Throttle position sensor (Narrow range)	Open or short circuit	<ul style="list-style-type: none"> <li>• Throttle position sensor connector</li> <li>• Wiring from throttle position sensor to PCME</li> </ul>	Yes	F-38

# ON-BOARD DIAGNOSIS FUNCTION





No.	Indicator flashing pattern	Diagnosed circuit	Condition	Point	Memorized	Page	
20	ON OFF 	Metering oil pump position sensor	Open or Short circuit	<ul style="list-style-type: none"> <li>• MOP connector</li> <li>• Wiring from MOP position sensor to PCME</li> <li>• MOP position sensor continuity</li> </ul>	Yes	F-39	
23	ON OFF 	Fuel thermosensor		<ul style="list-style-type: none"> <li>• Fuel thermosensor connector</li> <li>• Wiring from Fuel thermosensor to PCME</li> <li>• Fuel thermosensor resistance</li> </ul>	Yes	F-40	
25	ON OFF 	Solenoid valve (pressure regulator control)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-41	
26	ON OFF 	Metering oil pump (stepping moter)		<ul style="list-style-type: none"> <li>• MOP connector</li> <li>• Wiring from MOP to PCME</li> <li>• MOP continuity</li> </ul>	Yes	F-42	
27	ON OFF 	Metering oil pump	Open or short circuit or Sticking of MOP sensor	<ul style="list-style-type: none"> <li>• MOP connector</li> <li>• Wiring from MOP to PCME</li> <li>• Mop continuity</li> </ul>	Yes	F-43	
28	ON OFF 	Solenoid valve (EGR)	Open or short circuit	<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-44	
30	ON OFF 	Solenoid valve (Split air bypass)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-45	
31	ON OFF 	Secondary air bypass valve		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-46	
32	ON OFF 	Secondary air switching valve		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	Yes	F-47	
33	ON OFF 	Solenoid valve (Port air bypass)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-48	
34	ON OFF 	Solenoid valve (Idle air control)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-49	
37	ON OFF 	Metering Oil Pump		Low battery positive voltage	<ul style="list-style-type: none"> <li>• Charging system</li> <li>• MOP connector</li> <li>• Wiring from MOP to PCME</li> </ul>	Yes	F-50

# F

## ON-BOARD DIAGNOSIS FUNCTION

No.	Indicator flashing pattern	Diagnosed circuit	Condition	Point	Memo-rized	Page
38	ON  OFF	Solenoid valve (Accelerated warm-up system)	Open or Short Circuit	<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-51
39	ON  OFF	Solenoid valve (Relief 2)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-52
40	ON  OFF	Solenoid valve (Purge control)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-53
42	ON  OFF	Solenoid valve (Turbo precontrol)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-54
43	ON  OFF	Solenoid valve (Wastegate control)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-55
44	ON  OFF	Solenoid valve (Turbo control)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	Yes	F-56
45	ON  OFF	Solenoid valve (Charge control)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	Yes	F-57
46	ON  OFF	Solenoid valve (Charge relief)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-58
50	ON  OFF	Solenoid valve (Double throttle control)		<ul style="list-style-type: none"> <li>• Solenoid valve connector</li> <li>• Wiring from solenoid valve to PCME</li> <li>• Solenoid valve continuity</li> </ul>	No	F-59
51	ON  OFF	Fuel pump relay (speed)		<ul style="list-style-type: none"> <li>• Fuel pump relay connector</li> <li>• Wiring from relay to PCME</li> <li>• Relay continuity</li> </ul>	Yes	F-60
54	ON  OFF	Air pump relay		<ul style="list-style-type: none"> <li>• Air pump relay connector</li> <li>• Wiring from relay to PCME</li> <li>• Relay continuity</li> </ul>	No	F-61

# ON-BOARD DIAGNOSIS FUNCTION

No.	Indicator flashing pattern	Diagnosed circuit	Condition	Point	Memo-rized	Page
71	ON  OFF	Injector (Front secondary)	Open circuit	<ul style="list-style-type: none"> <li>• Injector connector</li> <li>• Wiring from Injector to PCME</li> <li>• Injector resistance</li> </ul>	Yes	F-62
73	ON  OFF	Injector (Rear secondary)		<ul style="list-style-type: none"> <li>• Injector connector</li> <li>• Wiring from injector to PCME</li> <li>• Injector resistance</li> </ul>	Yes	F-63
76	ON  OFF	Slip lock up off signal (PCMT)	Open or Short circuit	<ul style="list-style-type: none"> <li>• PCMT connector</li> <li>• Wiring from PCMT to PCME</li> </ul>	No	F-64
77	ON  OFF	Torque reduced signal (PCMT)		<ul style="list-style-type: none"> <li>• PCMT connector</li> <li>• Wiring from PCMT to PCME</li> </ul>	No	F-65

**Note**

- If more than one failure is present, the code numbers will be indicated in numerical order.

After repairs, cancel the code numbers by performing the "After-repair procedure".  
(Refer to page F-66.)

# F


## ON-BOARD DIAGNOSIS FUNCTION

### Troubleshooting

If a trouble code number is shown on the SST, check for the cause by referring to the related chart.

CODE No.	02 (CRANKSHAFT POSITION SENSOR [NE SENSOR])		
STEP	INSPECTION		ACTION
1	Is Code No.03 also present?	Yes	Go to next step
		No	Go to step 5
2	Does crankshaft position sensor circuit have poor connection?	Yes	Repair connector and/or wiring harness
		No	Go to next step
3	Is resistance of crankshaft position sensor [NE SENSOR] OK? <b>Resistance: 0.95–1.25 kΩ (20°F [68°F])</b>	Yes	Go to next step
		No	Replace crankshaft position sensor <b>⇨ page F-166</b>
4	Is clearance of crankshaft position sensor [NE signal] OK? <b>Clearance: 1.0–2.0 mm (0.039–0.078 in)</b>	Yes	Go to next step
		No	Adjust clearance <b>⇨ page F-166</b>
5	Is there continuity between ground and 4E or ground and 4H terminal? (at harness side)	Yes	Check for short circuit in wiring (Crankshaft position sensor–4H or 4E terminal)
		No	Go to next step
6	Disconnect connector from PCME; is resistance between 4E and 4H terminals OK? <b>Resistance: 0.95–1.25 KΩ (20°C [68°F])</b>	Yes	Replace PCME <b>⇨ page F-150</b>
		No	Check for open circuit in wiring (Crankshaft position sensor–4H or 4E terminal)

### Circuit Diagram




# ON-BOARD DIAGNOSIS FUNCTION

# F

CODE No.	03 (CRANKSHAFT POSITION SENSOR [G SENSOR])		
STEP	INSPECTION		ACTION
1	Is Code No.02 also present?	Yes	Go to next step
		No	Go to step 5
2	Does crankshaft position sensor circuit have poor connection?	Yes	Repair connector and/or wiring harness
		No	Go to next step
3	Is resistance of crankshaft position sensor [G SENSOR] OK?  <b>Resistance: 0.95–1.25 KΩ (20°F [68°F])</b>	Yes	Go to next step
		No	Replace crankshaft position sensor [G SENSOR] <span style="float: right;">☞ page F-166</span>
4	Is clearance of crankshaft position sensor [G signal] OK?  <b>Clearance: 1.0–2.0 mm (0.039–0.0178 in)</b>	Yes	Go to step
		No	Adjust clearance <span style="float: right;">☞ page F-166</span>
5	Is there continuity between ground and 4G or ground and 4H terminal? (at harness side)	Yes	Check for short circuit in wiring (Crankshaft position sensor-4H or 4G terminal)
		No	Go to next step
6	Disconnect connector from PCME; is resistance between 4G and 4H terminals OK?  <b>Resistance: 0.95–1.25 KΩ (20°C [68°F])</b>	Yes	Replace PCME <span style="float: right;">☞ page F-150</span>
		No	check for open circuit in wiring (Crankshaft position sensor-4G or 4H terminal)

## Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION

CODE No.		05 (KNOCK SENSOR)	
STEP	INSPECTION		ACTION
1	Does knock sensor circuit have a poor connection?	Yes	Repair connector and/or wiring harness
		No	Go to next step
2	Is there continuity between knock sensor and PCME terminal 3M?	Yes	Check continuity between PCME terminal 3M and ground ⇒ If continuity, repair or replace wiring ⇒ If no continuity, go to next step
		No	Repair wiring harness
3	Try known good knock sensor, is same code No. present?	Yes	Replace PCME <span style="float: right;">⇨ page F-166</span>
		No	Replace knock sensor <span style="float: right;">⇨ page F-171</span>

### Circuit Diagram






# ON-BOARD DIAGNOSIS FUNCTION

# F

CODE No.	06 (VEHICLE SPEED SENSOR)								
STEP	INSPECTION		ACTION						
1	Is speedometer working correctly	Yes	Go to next step						
		No	Go to step 5						
2	Check for PCMT trouble code. Is code No.07 also present?	Yes	Go to step 5						
		No	Go to next step						
3	Does vehicle speed sensor circuit have a poor connection?	Yes	Repair connector and/or wiring harness						
		No	Go to next step						
4	Is there vehicle speed sensor terminal 1M voltage OK?  <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">While driving</td> <td style="text-align: center;">2-2.5V</td> </tr> <tr> <td style="text-align: center;">Idle</td> <td style="text-align: center;">0V or 4-5V</td> </tr> </tbody> </table>	Condition	Voltage	While driving	2-2.5V	Idle	0V or 4-5V	Yes	Check for open or short circuit wiring harness (Vehicle speed sensor terminal 3E-PCME terminal 1M)  ⇒ If OK go to step 8 ⇒ If not OK, repair wiring harness
		Condition	Voltage						
		While driving	2-2.5V						
Idle	0V or 4-5V								
No	Go to next step								
5	Remove vehicle speed sensor Is resistance felt when turning sensor driven gear by hand?	Yes	Go to next step						
		No	Replace vehicle speed sensor						
6	Disconnect vehicle speed sensor connector and connect circuit tester Does pointer of circuit tester move slightly when driven gear is slowly turned?	Yes	Go to next step						
		No	Replace vehicle speed sensor						
7	Disconnect vehicle speed sensor connector Is resistance of sensor OK?  <b>Resistance: Approx. 290 Ω (20°C [68°F]); (reference)</b>	Yes	Check wiring and connectors from vehicle speed sensor to speedometer  ⇒ If OK, go to next step ⇒ If not OK, repair wiring and/or connector						
		No	Replace vehicle speed sensor						
8	Disconnect negative battery cable for at least 20 seconds Connect battery cable and recheck for trouble code Is trouble code displayed?	Yes	Replace PCME <span style="float: right;">page F-150</span>						
		No	Intermittent poor connection Check for cause						

## Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION


CODE No.	09 (ENGINE COOLANT TEMPERATURE SENSOR)										
STEP	INSPECTION		ACTION								
1	Does the engine coolant temperature sensor circuit have a poor connection?	Yes	Repair connector and/or wiring harness								
		No	Go to next step								
2	Is engine coolant temperature sensor B terminal voltage OK with engine coolant temperature sensor connector disconnected?  <table border="1" style="width: 100%;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Approx. 5.0V</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Approx. 5.0V	Yes	Go to next step				
		Condition	Voltage								
Ignition switch ON	Approx. 5.0V										
No	Check for short or open circuit in wiring harness (Engine coolant temperature sensor B terminal-PCME terminal 3E) ⇒ If OK, replace PCME ⇒ If not OK, repair wiring harness										
3	Is there continuity between engine coolant temperature sensor A terminal and a ground	Yes	Go to next step								
		No	Repair wiring harness								
4	Is resistance of engine coolant temperature sensor OK?  <table border="1" style="width: 100%;"> <thead> <tr> <th>Coolant temp.</th> <th>Resistance {kΩ}</th> </tr> </thead> <tbody> <tr> <td>-20°C {-4°F}</td> <td>14.6-17.8</td> </tr> <tr> <td>20°C {68°F}</td> <td>2.2-2.7</td> </tr> <tr> <td>80°C {176°F}</td> <td>0.29-0.35</td> </tr> </tbody> </table>	Coolant temp.	Resistance {kΩ}	-20°C {-4°F}	14.6-17.8	20°C {68°F}	2.2-2.7	80°C {176°F}	0.29-0.35	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>
		Coolant temp.	Resistance {kΩ}								
-20°C {-4°F}	14.6-17.8										
20°C {68°F}	2.2-2.7										
80°C {176°F}	0.29-0.35										
No	Replace engine coolant temperature sensor <span style="float: right;">⇨ page F-169</span>										

### Circuit Diagram




CODE No.	11 (INTAKE AIR TEMPERATURE SENSOR)							
STEP	INSPECTION	ACTION						
1	Does the engine coolant temperature sensor circuit have a poor connection?	Yes	Repair connector and/or wiring harness					
		No	Go to next step					
2	Is Intake air temperature sensor B terminal voltage OK with intake air temperature sensor connector disconnected?	Yes	Go to next step					
		No	Check for short or open circuit in wiring harness (Intake air temperature sensor B terminal-PCME terminal 3L) ⇒ If OK, replace PCME ⇒ If not OK, repair wiring harness					
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Ignition switch ON</td> <td style="text-align: center;">Approx. 5.0V</td> </tr> </tbody> </table>		Condition	Voltage	Ignition switch ON	Approx. 5.0V			
Condition	Voltage							
Ignition switch ON	Approx. 5.0V							
3	Is there continuity between intake air temperature sensor A terminal and a ground	Yes	Go to next step					
		No	Repair wiring harness					
4	Is resistance of intake air temperature sensor OK?	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>					
		No	Replace intake air temperature sensor <span style="float: right;">⇨ page F-169</span>					
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Temperature</th> <th style="width: 50%;">Resistance (kΩ)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">20°C {68°F}</td> <td style="text-align: center;">2.2-2.7</td> </tr> <tr> <td style="text-align: center;">85°C {185°F}</td> <td style="text-align: center;">0.29-0.35</td> </tr> </tbody> </table>		Temperature	Resistance (kΩ)	20°C {68°F}	2.2-2.7	85°C {185°F}	0.29-0.35	
Temperature	Resistance (kΩ)							
20°C {68°F}	2.2-2.7							
85°C {185°F}	0.29-0.35							

### Circuit Diagram




CODE No.	12 (THROTTLE POSITION SENSOR [FULL RANGE])								
STEP	INSPECTION		ACTION						
1	Does throttle position sensor circuit have a poor connection?	Yes	Repair connector and/or wiring harness						
		No	Go to next step						
2	Is throttle position sensor A terminal voltage OK with throttle position sensor disconnected?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Approx. 5.0V</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Approx. 5.0V	Yes	Go to next step		
		Condition	Voltage						
Ignition switch ON	Approx. 5.0V								
No	Check for open or short circuit in wiring harness (Throttle position sensor A terminal-PCME terminal 3I)  ⇨ If OK, replace PCME ⇨ If not OK, repair wiring harness								
3	Is there continuity between throttle position sensor and PCME?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Throttle position sensor terminal</th> <th>PCME</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>3G</td> </tr> <tr> <td>C</td> <td>4D</td> </tr> </tbody> </table>	Throttle position sensor terminal	PCME	D	3G	C	4D	Yes	Check for short circuit in wiring harness (Throttle position sensor D terminal-PCME terminal 3G)  ⇨ If OK, go to next step ⇨ If not OK, repair wiring harness
		Throttle position sensor terminal	PCME						
D	3G								
C	4D								
No	Repair wiring harness								
4	Is there continuity between terminals A and D with throttle valve closed throttle position to fully opened OK?	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>						
		No	Replace throttle position sensor <span style="float: right;">⇨ page F-168</span>						

### Circuit Diagram



CODE No.	13 (MANIFOLD ABSOLUTE PRESSURE SENSOR)										
STEP	INSPECTION	ACTION									
1	Does manifold absolute pressure sensor circuit have a poor connection?	Yes	Repair connector and/or wiring harness								
		No	Go to next step								
2	Is connector C terminal voltage OK with manifold absolute pressure sensor connector disconnected?  <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Ignition switch ON</td> <td style="text-align: center;">Approx. 5.0V</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Approx. 5.0V	Yes	Go to next step				
		Condition	Voltage								
Ignition switch ON	Approx. 5.0V										
No	Check for open or short circuit in wiring harness (manifold absolute pressure sensor C terminal-PCME terminal 3I)										
3	Is there continuity between manifold absolute pressure sensor B terminal and PCME terminal 4D	Yes	Go to next step								
		No	Repair wiring harness								
4	Is output A terminal voltage of manifold absolute pressure sensor OK?  <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Pressure or Vacuum</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">66 kPa {500 mmHg, 19.7 inHg} (Vacuum)</td> <td style="text-align: center;">1.3-1.6V</td> </tr> <tr> <td style="text-align: center;">0 kPa {0 mmHg, 0 inHg}</td> <td style="text-align: center;">2.3-2.8V</td> </tr> <tr> <td style="text-align: center;">98.7 kPa {740 mmHg, 29.1 inHg} (Pressure)</td> <td style="text-align: center;">4.3-4.6V</td> </tr> </tbody> </table>	Pressure or Vacuum	Voltage	66 kPa {500 mmHg, 19.7 inHg} (Vacuum)	1.3-1.6V	0 kPa {0 mmHg, 0 inHg}	2.3-2.8V	98.7 kPa {740 mmHg, 29.1 inHg} (Pressure)	4.3-4.6V	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>
		Pressure or Vacuum	Voltage								
		66 kPa {500 mmHg, 19.7 inHg} (Vacuum)	1.3-1.6V								
		0 kPa {0 mmHg, 0 inHg}	2.3-2.8V								
98.7 kPa {740 mmHg, 29.1 inHg} (Pressure)	4.3-4.6V										
No	Replace manifold absolute pressure sensor <span style="float: right;">⇨ page F-167</span>										

### Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION

<b>CODE No.</b>	<b>14 (BAROMETRIC ABSOLUTE PRESSURE SENSOR-IN PCME)</b>	
<b>STEP</b>	<b>ACTION</b>	
1	Replace PCME	⇨ page F-150


<b>CODE No.</b>	<b>15 (OXYGEN SENSOR-INACTIVATION)</b>		
If Code No.15 and 17 are both present, first perform the checking procedure for Code No.17.			
<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>	
1	Does oxygen sensor circuit have a poor connection?	Yes	Repair connector and/or wiring harness
		No	Go to next step
2	Is oxygen sensor output voltage OK?	Yes	Go to next step
		No	Replace oxygen sensor ⇨ page F-113
3	Is there continuity between oxygen sensor and PCME terminal 3C?	Yes	Check for short circuit in wiring ⇨ page F-150 ⇨ If OK, replace PCME ⇨ If not OK, repair wire harness
		No	Repair wiring harness

### Circuit Diagram



CODE No.	16 (EGR FUNCTION SENSOR)		
STEP	INSPECTION		ACTION
1	Does EGR function sensor circuit have a poor connection?	Yes	Repair connector and/or wiring harness
		No	Go to next step
2	Is connector A terminal voltage OK with EGR function sensor connector disconnected.	Yes	Go to next step
		No	Check for open or short circuit in wiring harness (EGR function sensor A terminal-PCME terminal 3J)
3	Is there continuity between EGR function sensor B terminal and PCME terminal 4D?	Yes	Go to next step
		No	Repair wiring harness
4	Is EGR function sensor OK? <span style="float: right;">☞ page F-127</span>	Yes	Replace PCME <span style="float: right;">☞ page F-150</span>
		No	Replace EGR valve

### Circuit Diagram



# F

## ON-BOARD DIAGNOSIS FUNCTION


CODE No.		17 (OXYGEN SENSOR (INVERSION))	
STEP	INSPECTION		ACTION
1	Is the same Code No. present following after repair procedure?  ☞ page F-66	Yes	Go to next step
		No	Check oxygen sensor circuit for a poor connection  ⇒ If OK, perform troubleshooting Code No.15
2	Does monitor lamp of Self-Diagnosis Checker illuminate at idle after the engine has been warmed up and run at 2500-3000 rpm for 3 min?	Yes	Go to next step  A/F mixture rich
		No	Go to Step 6  A/F mixture is lean or misfire is occurring
3	Is there air leakage in intake air system components?	Yes	Go to next step
		No	Repair or replace ☞ page F-76
4	Is fuel line pressure correct at idle?  ☞ page F-104  <b>Fuel line pressure:</b> <b>190-220 kPa (1.9-2.3 kgf/cm<sup>2</sup>, 28-32 psi)</b>	Yes	Go to next step
		No	<b>High pressure</b> Check if fuel return hose is clogged or restricted  ☞ page F-104  ⇒ If OK, replace pressure regulator
5	Is there fuel leakage at injector?  ☞ page F-107	Yes	Replace injector ☞ page F-105
		No	Check engine coolant temperature sensor? ☞ page F-169  ⇒ If it is OK, replace oxygen sensor ⇒ If it is not OK, replace it
6	Disconnect each high tension lead at idle; does engine speed decrease equally at each rotor?	Yes	Go to next step
		No	Go to Step 8
7	Is fuel line pressure correct at idle?  ☞ page F-97  <b>Fuel line pressure:</b> <b>190-220 kPa (1.9-2.3 kgf/cm<sup>2</sup>, 28-32 psi)</b>	Yes	Go to next step
		No	<b>Low pressure</b> Check fuel line pressure while pinching fuel return hose  ⇒ If it <b>quickly</b> increases, check pressure regulator ☞ page F-104 ⇒ If it <b>gradually</b> increases, check for clogging between fuel pump and pressure regulator ⇒ If hose is not clogged, check fuel pump maximum pressure ☞ page F-101
8	Is there a misfire of a dead rotor from step 6 inspection?	Yes	Repair or replace ignition system component(s)
		No	Go to next step



B+: Battery positive voltage

STEP	INSPECTION		ACTION
9	Is there an injector operating sound at idle of dead rotor from step 6 inspection?	Yes	Go to next step
		No	Check for approx. B+ at injector terminal wire ⇨ If there is, replace injector ⇨ If there is not, check for a short or open circuit in wire harness
10	Replace injector at dead rotor from step 6 inspection ⇨ page F-105  Is the same Code No. present following afterrepair procedure?	Yes	Try known good oxygen sensor ⇨ If it is OK, replace oxygen sensor ⇨ If it is not OK, replace PCME
		No	System OK

### Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION


CODE No.	18 (THROTTLE POSITION SENSOR [NARROW RANGE])								
STEP	INSPECTION		ACTION						
1	Does throttle position sensor circuit have a poor connection?	Yes	Repair connector and/or wiring harness						
		No	Go to next step						
2	Is throttle position sensor A terminal voltage OK with throttle position sensor disconnected?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Approx. 5.0V</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Approx. 5.0V	Yes	Go to next step		
		Condition	Voltage						
Ignition switch ON	Approx. 5.0V								
No	Check for open or short circuit in wiring harness (Throttle position sensor A terminal -PCME terminal 3I)  ⇨ If OK, replace PCME ⇨ If not OK, repair wiring harness								
3	Is there continuity between throttle position sensor and PCME?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Throttle position sensor terminal</th> <th>PCME</th> </tr> </thead> <tbody> <tr> <td>B</td> <td>3F</td> </tr> <tr> <td>C</td> <td>4D</td> </tr> </tbody> </table>	Throttle position sensor terminal	PCME	B	3F	C	4D	Yes	Check for short circuit in wiring harness (Throttle position sensor B terminal-PCME terminal 3F)  ⇨ If OK, go to next step ⇨ If not OK, repair wiring harness
		Throttle position sensor terminal	PCME						
B	3F								
C	4D								
No	Repair wiring harness								
4	Is there continuity between terminals A and B with throttle valve closed to fully opened OK?	Yes	Replace PCME <span style="float: right;">☛ page F-150</span>						
		No	Replace throttle position sensor <span style="float: right;">☛ page F-168</span>						

### Circuit Diagram



CODE No.	20 (METERING OIL PUMP POSITION SENSOR)								
STEP	INSPECTION		ACTION						
1	Are there any poor connections at metering oil pump and PCME connectors?	Yes	Repair or replace connector						
		No	Go to next step						
2	Is PCME terminal 3A voltage OK?  <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Idle</td> <td style="text-align: center;">1.1V</td> </tr> <tr> <td style="text-align: center;">Acceleration</td> <td style="text-align: center;">1.1V-4.2V</td> </tr> </tbody> </table>	Condition	Voltage	Idle	1.1V	Acceleration	1.1V-4.2V	Yes	Go to step 4
		Condition	Voltage						
Idle	1.1V								
Acceleration	1.1V-4.2V								
		No	Go to next step						
3	Is resistance of MOP position sensor OK? Resistance: J-H 0.4-12 kΩ J-I 1.0-2 kΩ H-I 9.4-12 kΩ	Yes	Repair wiring harness (Mop position sensor-PCME terminal 3A)						
		No	Replace MOP						
4	Disconnect negative battery cable for at least 20 seconds Connect battery cable and recheck for trouble code Is trouble code displayed?	Yes	Replace PCME						
		No	Intermittent poor connection check for cause.						

### Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION


CODE No.	23 (FUEL THERMOSENSOR)										
STEP	INSPECTION		ACTION								
1	Does the fuel thermosensor circuit have a poor connection?	Yes	Repair connector and/or harness								
		No	Go to next step								
2	Is fuel thermosensor B terminal voltage OK with fuel thermosensor connector disconnected?  <table border="1" style="width: 100%;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Approx. 5.0V</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Approx. 5.0V	Yes	Go to next step				
		Condition	Voltage								
Ignition switch ON	Approx. 5.0V										
No	Check for short or open circuit in wiring harness (Fuel thermosensor B terminal -PCME terminal 1U)  ⇨ If OK, replace PCME ⇨ If not OK, repair wiring harness										
3	Is there continuity between fuel thermosensor A terminal and a ground?	Yes	Go to next step								
		No	Repair wiring harness								
4	Is resistance of fuel thermosensor OK?  <table border="1" style="width: 100%;"> <thead> <tr> <th>Fuel temp</th> <th>Resistance (kΩ)</th> </tr> </thead> <tbody> <tr> <td>-20°C (-4°F)</td> <td>14.6-17.8</td> </tr> <tr> <td>20°C (68°F)</td> <td>2.2-2.7</td> </tr> <tr> <td>80°C (176°F)</td> <td>0.29-0.35</td> </tr> </tbody> </table>	Fuel temp	Resistance (kΩ)	-20°C (-4°F)	14.6-17.8	20°C (68°F)	2.2-2.7	80°C (176°F)	0.29-0.35	Yes	Replace PCME <span style="float: right;">☞ page F-150</span>
		Fuel temp	Resistance (kΩ)								
-20°C (-4°F)	14.6-17.8										
20°C (68°F)	2.2-2.7										
80°C (176°F)	0.29-0.35										
No	Replace fuel thermosensor <span style="float: right;">☞ page F-170</span>										

### Circuit Diagram



CODE No.	25 (SOLENOID VALVE-PRESSURE REGULATOR CONTROL [PRC])						
STEP	INSPECTION	ACTION					
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector A terminal voltage OK with solenoid valve connector disconnected?  <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Ignition switch ON</td> <td style="text-align: center;">Battery positive voltage</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
		Condition	Voltage				
Ignition switch ON	Battery positive voltage						
		No	Check for open or short circuit in wiring harness (Solenoid valve A terminal-Main relay D terminal)				
3	Is there continuity between solenoid valve B terminal and PCME terminal 4M?	Yes	Check for short circuit in wiring harness (Solenoid valve B terminal-PCME terminal 4M)  ⇨ If OK, go to next step ⇨ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float: right;">⇨ page F-176</span>	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>				
		No	Replace solenoid valve				

### Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION

CODE No.	26 (METERING OIL PUMP STEPPING MOTOR)												
STEP	INSPECTION		ACTION										
1	Are there any poor connections at metering oil pump and PCME connector?	Yes	Repair or replace connector										
		No	Go to next step										
2	Is resistance of MOP stepping motor OK? <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>terminal</th> <th>Resistance {kΩ}</th> </tr> </thead> <tbody> <tr> <td>C - SM A</td> <td rowspan="4" style="text-align: center; vertical-align: middle;">16-31</td> </tr> <tr> <td>C - SM E</td> </tr> <tr> <td>D - SM B</td> </tr> <tr> <td>D - SM F</td> </tr> </tbody> </table>	terminal	Resistance {kΩ}	C - SM A	16-31	C - SM E	D - SM B	D - SM F	Yes	Go to next step			
		terminal	Resistance {kΩ}										
C - SM A	16-31												
C - SM E													
D - SM B													
D - SM F													
No	Replace MOP												
3	Is continuity between MOP stepping motor and PCME terminals OK? <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>MOP terminal</th> <th>PCME terminal</th> </tr> </thead> <tbody> <tr> <td>SM A</td> <td>4I</td> </tr> <tr> <td>SM B</td> <td>4J</td> </tr> <tr> <td>SM E</td> <td>4K</td> </tr> <tr> <td>SM F</td> <td>4L</td> </tr> </tbody> </table>	MOP terminal	PCME terminal	SM A	4I	SM B	4J	SM E	4K	SM F	4L	Yes	Repair wiring harness (MOP-Main relay)
		MOP terminal	PCME terminal										
SM A	4I												
SM B	4J												
SM E	4K												
SM F	4L												
No	Repair wiring harness (MOP-PCME terminals)												
4	Disconnect negative battery cable for at least 20 seconds Connect battery cable and recheck for trouble code Is trouble code displayed?	Yes	Replace PCME										
		No	Intermittent poor connection check for cause										

### Circuit Diagram



# ON-BOARD DIAGNOSIS FUNCTION

# F

B+: Battery positive voltage

CODE No.	27 (METERING OIL PUMP)														
STEP	INSPECTION		ACTION												
1	Are there any poor connections at metering oil pump and PCME connector?	Yes	Repair or replace connector												
		No	Go to next step												
2	Is PCME terminal 3A voltage OK? <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Idle</td> <td style="text-align: center;">1.1V</td> </tr> <tr> <td style="text-align: center;">Acceleration</td> <td style="text-align: center;">1.0V-4.2V</td> </tr> </tbody> </table>	Condition	Voltage	Idle	1.1V	Acceleration	1.0V-4.2V	Yes	Go to step 4						
		Condition	Voltage												
Idle	1.1V														
Acceleration	1.0V-4.2V														
		No	Go to next step												
3	Is resistance of MOP position sensor OK? Resistance: J-H 0.4-12 kΩ J-I 10-2 kΩ H-I 0.4-12 kΩ	Yes	Go to next step												
		No	Replace MOP												
4	Is PCME terminals voltage OK? Specification: (Idle) <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Stepping Motor</th> <th style="text-align: center;">PCME terminal</th> <th style="text-align: center;">Output voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">SM A</td> <td style="text-align: center;">4I</td> <td rowspan="4" style="text-align: center;">One terminal: B+ Three terminals: 5-9 V</td> </tr> <tr> <td style="text-align: center;">SM B</td> <td style="text-align: center;">4J</td> </tr> <tr> <td style="text-align: center;">SM E</td> <td style="text-align: center;">4K</td> </tr> <tr> <td style="text-align: center;">SM F</td> <td style="text-align: center;">4L</td> </tr> </tbody> </table>	Stepping Motor	PCME terminal	Output voltage	SM A	4I	One terminal: B+ Three terminals: 5-9 V	SM B	4J	SM E	4K	SM F	4L	Yes	Go to step 7
		Stepping Motor	PCME terminal	Output voltage											
		SM A	4I	One terminal: B+ Three terminals: 5-9 V											
		SM B	4J												
SM E	4K														
SM F	4L														
		No	Go to next step												
5	Is resistance of MOP stepping motor OK? <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">terminal</th> <th style="text-align: center;">Resistance { kΩ }</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">C - SM A</td> <td rowspan="4" style="text-align: center;">16-31</td> </tr> <tr> <td style="text-align: center;">C - SM E</td> </tr> <tr> <td style="text-align: center;">D - SM B</td> </tr> <tr> <td style="text-align: center;">D - SM F</td> </tr> </tbody> </table>	terminal	Resistance { kΩ }	C - SM A	16-31	C - SM E	D - SM B	D - SM F	Yes	Go to next step					
		terminal	Resistance { kΩ }												
		C - SM A	16-31												
		C - SM E													
D - SM B															
D - SM F															
		No	Replace MOP												
6	Is continuity between MOP stepping motor and PCME terminals OK? <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">MOP terminal</th> <th style="text-align: center;">PCME terminal</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">SM A</td> <td style="text-align: center;">4I</td> </tr> <tr> <td style="text-align: center;">SM B</td> <td style="text-align: center;">4J</td> </tr> <tr> <td style="text-align: center;">SM E</td> <td style="text-align: center;">4K</td> </tr> <tr> <td style="text-align: center;">SM F</td> <td style="text-align: center;">4L</td> </tr> </tbody> </table>	MOP terminal	PCME terminal	SM A	4I	SM B	4J	SM E	4K	SM F	4L	Yes	Repair wiring harness (MOP-Main relay)		
		MOP terminal	PCME terminal												
		SM A	4I												
		SM B	4J												
SM E	4K														
SM F	4L														
		No	Repair wiring harness (MOP-PCME terminals)												
7	Disconnect negative battery cable for at least 20 seconds Connect battery cable and recheck for trouble code Is trouble code displayed?	Yes	Replace PCME												
		No	Intermittent poor connection check for cause												


**Circuit Diagram**  
(Refer to page F-42)

# F

## ON-BOARD DIAGNOSIS FUNCTION

CODE No.	28 (SOLENOID VALVE-EGR)						
STEP	INSPECTION		ACTION				
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?	Yes	Go to next step				
		No	Check for open or short circuit in wiring harness (Solenoid valve B terminal–Main relay D terminal)				
<table border="1"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>		Condition	Voltage	Ignition switch ON	Battery positive voltage		
Condition	Voltage						
Ignition switch ON	Battery positive voltage						
3	Is there Continuity between solenoid valve A terminal and PCME terminal 4O?	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal–PCME terminal 4O)  ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float:right">↔ page F-176</span>	Yes	Replace PCME <span style="float:right">↔ page F-150</span>				
		No	Replace solenoid valve				


### Circuit Diagram





CODE No.	30 (SOLENOID VALVE-SPLIT AIR BYPASS)						
STEP	INSPECTION		ACTION				
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector A terminal voltage OK with solenoid valve connector disconnected?  <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Ignition switch ON</td> <td style="text-align: center;">Battery positive voltage</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
		Condition	Voltage				
Ignition switch ON	Battery positive voltage						
		No	Check for open or short circuit in wiring harness (Solenoid valve A terminal-Main relay D terminal)				
3	Is there continuity between solenoid valve B terminal and PCME terminal 4F?	Yes	Check for short circuit in wiring harness (Solenoid valve B terminal-PCME terminal 4F)  ⇨ If OK, go to next step ⇨ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float: right;">☞ page F-120</span>	Yes	Replace PCME <span style="float: right;">☞ page F-150</span>				
		No	Replace solenoid valve				

### Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION


CODE No.		31 (SECONDARY AIR BYPASS VALVE)					
STEP	INSPECTION		ACTION				
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
		Condition	Voltage				
Ignition switch ON	Battery positive voltage						
No	Check for open or short circuit in wiring harness (Solenoid valve B terminal–Main relay D terminal)						
3	Is there continuity between solenoid valve A terminal and PCME terminal 3P?	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal–PCME terminal 3P)  ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float: right;">⇨ page F-123</span>	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>				
		No	Replace solenoid valve				

### Circuit Diagram




CODE No.		32 (SECONDARY AIR SWITCHING VALVE)					
STEP	INSPECTION		ACTION				
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?	Yes	Go to next step				
		No	Check for open or short circuit in wiring harness (Solenoid valve B terminal–Main relay D terminal)				
<table border="1"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>		Condition	Voltage	Ignition switch ON	Battery positive voltage		
Condition	Voltage						
Ignition switch ON	Battery positive voltage						
3	Is there continuity between solenoid valve A terminal and PCME terminal 4N?	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal–PCME terminal 4N) ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float:right">page F-176</span>	Yes	Replace PCME <span style="float:right">page F-150</span>				
		No	Replace solenoid valve				

Circuit Diagram




CODE No.	33 (SOLENOID VALVE-PORT AIR BYPASS)						
STEP	INSPECTION		ACTION				
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector A terminal voltage OK with solenoid valve connector disconnected?	Yes	Go to next step				
		No	Check for open or short circuit in wiring harness (Solenoid valve A terminal-Main relay D terminal)				
<table border="1"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>		Condition	Voltage	Ignition switch ON	Battery positive voltage		
Condition	Voltage						
Ignition switch ON	Battery positive voltage						
3	Is there continuity between solenoid valve B terminal and PCME terminal 3N?	Yes	Check for short circuit in wiring harness (Solenoid valve B terminal-PCME terminal 3N) ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float:right">⇨ page F-119</span>	Yes	Replace PCME <span style="float:right">⇨ page F-150</span>				
		No	Replace solenoid valve				

### Circuit Diagram



CODE No.	34 (SOLENOID VALVE-IDLE AIR CONTROL)		
STEP	INSPECTION		ACTION
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness
		No	Go to next step
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?	Yes	Go to next step
		No	Check for open or short circuit in wiring harness (Solenoid valve B terminal-Main relay D terminal)
3	Is there continuity between solenoid valve A terminal and PCME terminal 4Q?	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal-PCME terminal 4Q) ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness
		No	Repair wiring harness
4	Is solenoid valve OK? <span style="float:right">☞ page F-83</span>	Yes	Replace PCME <span style="float:right">☞ page F-150</span>
		No	Replace solenoid valve

Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION


CODE No.	37 (METERING OIL PUMP)		
STEP	INSPECTION		ACTION
1	Is battery positive voltage OK? <b>Specification: 12-14V (at idle)</b>	Yes	Go to next step
		No	Repair charging system and/or Battery
2	Disconnect negative battery cable for at least 20 seconds Connect battery cable and recheck for trouble code Is trouble code displayed?	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>
		No	Intermittent poor connection Check for cause

### Circuit Diagram



CODE No.	38 (SOLENOID VALVE-ACCELERATED WARM-UP SYSTEM [AWS])						
STEP	INSPECTION		ACTION				
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?	Yes	Go to next step				
		No	Check for open or short circuit in wiring harness (Solenoid valve B terminal-Main relay D terminal)				
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Ignition switch ON</td> <td style="text-align: center;">Battery positive voltage</td> </tr> </tbody> </table>		Condition	Voltage	Ignition switch ON	Battery positive voltage		
Condition	Voltage						
Ignition switch ON	Battery positive voltage						
3	Is there continuity between solenoid valve A terminal and PCME terminal 4P?	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal-PCME terminal 4P)  ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float: right;">☞ page F-83</span>	Yes	Replace PCME <span style="float: right;">☞ page F-150</span>				
		No	Replace solenoid valve				

### Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION

CODE No.	39 (SOLENOID VALVE-RELIEF 2)						
STEP	INSPECTION		ACTION				
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector A terminal voltage OK with solenoid valve connector disconnected? <table border="1" data-bbox="218 436 715 506"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
		Condition	Voltage				
Ignition switch ON	Battery positive voltage						
No	Check for open or short circuit in wiring harness (Solenoid valve A terminal-Main relay D terminal)						
3	Is there continuity between solenoid valve B terminal and PCME terminal 3K?	Yes	Check for short circuit in wiring harness (Solenoid valve B terminal-PCME terminal 3K) ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float: right;">⇨ page F-123</span>	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>				
		No	Replace solenoid valve				


### Circuit Diagram






CODE No.		40 (SOLENOID VALVE-PURGE CONTROL [PURGE])					
STEP	INSPECTION	ACTION					
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?	Yes	Go to next step				
		No	Check for open or short circuit in wiring harness (Solenoid valve B terminal–Main relay D terminal)				
<table border="1"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>		Condition	Voltage	Ignition switch ON	Battery positive voltage		
Condition	Voltage						
Ignition switch ON	Battery positive voltage						
3	Is there continuity between solenoid valve A terminal and PCME terminal 3H?	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal–PCME terminal 3H) ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float:right">☞ page F-131</span>	Yes	Replace PCME <span style="float:right">☞ page F-150</span>				
		No	Replace solenoid valve				

Circuit Diagram




CODE No.		42 (SOLENOID VALVE-TURBO PRECONTROL)					
STEP	INSPECTION	ACTION					
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
		Condition	Voltage				
Ignition switch ON	Battery positive voltage						
No	Check for open or short circuit in wiring harness (Solenoid valve B terminal-Main relay D terminal)						
3	Is there continuity between solenoid valve A terminal and PCME terminal 4V?	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal-PCME terminal 4V)  ⇨ If OK, go to next step ⇨ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float: right;">⇨ page F-93</span>	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>				
		No	Replace solenoid valve				

### Circuit Diagram




CODE No.		43 (SOLENOID VALVE-WASTEGATE CONTROL)					
STEP	INSPECTION	ACTION					
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?  <table border="1" style="width: 100%; text-align: center;"> <tr> <th>Condition</th> <th>Voltage</th> </tr> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </table>	Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
		Condition	Voltage				
Ignition switch ON	Battery positive voltage						
No	Check for open or short circuit in wiring harness (Solenoid valve B terminal-Main relay D terminal)						
3	Is there continuity between solenoid valve A terminal and PCME terminal 4U?  <div style="text-align: right;">☞ page F-93</div>	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal-PCME terminal 4U)  ⇨ If OK, go to next step ⇨ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK?  <div style="text-align: right;">☞ page F-93</div>	Yes	Replace PCME  <div style="text-align: right;">☞ page F-150</div>				
		No	Replace solenoid valve				

Circuit Diagram




CODE No.		44 (SOLENOID VALVE-TURBO CONTROL)					
STEP	INSPECTION	ACTION					
1	Does solenoid valves circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
		Condition	Voltage				
Ignition switch ON	Battery positive voltage						
No	Check for open or short circuit in wiring harness (Solenoid valves B terminal–Main relay D terminal)						
3	Is there continuity between solenoid valves A terminal and PCME terminal 4R?	Yes	Check for short circuit in wiring harness (Solenoid valves A terminal–PCME terminal 4R)  ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float: right;">⇨ page F-93</span>	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>				
		No	Replace solenoid valve				

### Circuit Diagram




CODE No.	45 (SOLENOID VALVE-CHARGE CONTROL)						
STEP	INSPECTION		ACTION				
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?	Yes	Go to next step				
		No	Check for open or short circuit in wiring harness (Solenoid valve B terminal-Main relay D terminal)				
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Ignition switch ON</td> <td style="text-align: center;">Battery positive voltage</td> </tr> </tbody> </table>		Condition	Voltage	Ignition switch ON	Battery positive voltage		
Condition	Voltage						
Ignition switch ON	Battery positive voltage						
3	Is there continuity between solenoid valve A terminal and PCME terminal 4T?	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal-PCME terminal 4T)  ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float: right;">⇨ page F-176</span>	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>				
		No	Replace solenoid valve				

### Circuit Diagram




CODE No.		46 (SOLENOID VALVE-CHARGE RELIEF)					
STEP	INSPECTION	ACTION					
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
		Condition	Voltage				
Ignition switch ON	Battery positive voltage						
No	Check for open or short circuit in wiring harness (Solenoid valve B terminal–Main relay D terminal)						
3	Is there continuity between solenoid valve A terminal and PCME terminal 4S?	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal–PCME terminal 4S)  ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float: right;">⇨ page F-176</span>	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>				
		No	Replace solenoid valve				

### Circuit Diagram



CODE No.		50 (SOLENOID VALVE-DOUBLE THROTTLE CONTROL)					
STEP	INSPECTION	ACTION					
1	Does solenoid valve circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with solenoid valve connector disconnected?	Yes	Go to next step				
		No	Check for open or short circuit in wiring harness (Solenoid valve B terminal-Main relay D terminal)				
<table border="1"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>		Condition	Voltage	Ignition switch ON	Battery positive voltage		
Condition	Voltage						
Ignition switch ON	Battery positive voltage						
3	Is there continuity between solenoid valve A terminal and PCME terminal 30?	Yes	Check for short circuit in wiring harness (Solenoid valve A terminal-PCME terminal 30) ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is solenoid valve OK? <span style="float:right">☞ page F-176</span>	Yes	Replace PCME <span style="float:right">☞ page F-150</span>				
		No	Replace solenoid valve				

Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION

CODE No.	51 (FUEL PUMP RELAY [SPEED])							
STEP	INSPECTION		ACTION					
1	Does fuel pump relay (speed) circuit have a poor connection?		Yes	Repair connector and/or wiring harness				
			No	Go to next step				
2	Is connector A terminal voltage OK with fuel pump relay (speed) connector disconnected? <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th>Condition</th> <th>Voltage</th> </tr> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </table>		Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
			Condition	Voltage				
Ignition switch ON	Battery positive voltage							
		No	Check for open or short circuit in wiring harness (Fuel pump relay A terminal–Main relay D terminal)					
3	Is there Continuity between fuel pump relay (speed) B terminal and PCME terminal 1K?		Yes	Check for short circuit in wiring harness (Fuel pump relay (speed) B terminal–PCME terminal 1K)  ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
			No	Repair wiring harness				
4	Is fuel pump relay (speed) OK? <span style="float: right;">⇨ page F-110</span>		Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>				
			No	Replace fuel pump relay (speed)				


### Circuit Diagram





CODE No.	54 (AIR PUMP RELAY)						
STEP	INSPECTION		ACTION				
1	Does air pump relay circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector B terminal voltage OK with air pump relay connector disconnected?	Yes	Go to next step				
		No	Check for open or short circuit in wiring harness (Air pump relay B terminal–Main relay D terminal)				
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Ignition switch ON</td> <td style="text-align: center;">Battery positive voltage</td> </tr> </tbody> </table>		Condition	Voltage	Ignition switch ON	Battery positive voltage		
Condition	Voltage						
Ignition switch ON	Battery positive voltage						
3	Is there continuity between air pump relay C terminal and PCME terminal 2J?	Yes	Check for short circuit in wiring harness (Air pump relay C terminal–PCME terminal 2J)  ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness				
		No	Repair wiring harness				
4	Is air pump relay OK? <span style="float: right;">↔ page F-123</span>	Yes	Replace PCME <span style="float: right;">↔ page F-150</span>				
		No	Replace air pump relay				

### Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION


CODE No.	71 (INJECTOR [FRONT SECONDARY])						
STEP	INSPECTION	ACTION					
1	Does injector circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector A terminal voltage OK with injector connector disconnected?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch ON</td> <td>Battery positive voltage</td> </tr> </tbody> </table>	Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
		Condition	Voltage				
Ignition switch ON	Battery positive voltage						
No	Check for open or short circuit in wiring harness (Injector A terminal–Main relay D terminal)						
3	Is injector resistance OK?  <b>Resistance: 13.5 Ω (20°C [68°F])</b>	Yes	Go to next step				
		No	Replace injector				
4	Is there continuity between injector terminal and PCME terminal?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Injector terminal</th> <th>PCME</th> </tr> </thead> <tbody> <tr> <td>B</td> <td>4X</td> </tr> </tbody> </table>	Injector terminal	PCME	B	4X	Yes	Check for short circuit in wiring harness (Injector-PCME)  ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness
		Injector terminal	PCME				
B	4X						
No	Repair wiring harness						
5	Disconnect negative battery cable for at least 20 seconds Connect battery cable and recheck for trouble code Is trouble code displayed?	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>				
		No	Intermittent poor connection Check for cause				

### Circuit Diagram



CODE No.	73 (INJECTOR [REAR SECONDARY])						
STEP	INSPECTION	ACTION					
1	Does injector circuit have a poor connection?	Yes	Repair connector and/or wiring harness				
		No	Go to next step				
2	Is connector A terminal voltage OK with injector connector disconnected?  <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Voltage</th> </tr> <tr> <td style="text-align: center;">Ignition switch ON</td> <td style="text-align: center;">Battery positive voltage</td> </tr> </table>	Condition	Voltage	Ignition switch ON	Battery positive voltage	Yes	Go to next step
		Condition	Voltage				
Ignition switch ON	Battery positive voltage						
		No	Check for open or short circuit in wiring harness (Injector A terminal-Main relay D terminal)				
3	Is injector resistance OK?  <b>Resistance: 13.8 Ω (20°C [68°F])</b>	Yes	Go to next step				
		No	Replace injector				
4	Is there continuity between injector terminal and PCME terminal?  <table border="1" style="margin: 5px auto; border-collapse: collapse;"> <tr> <th style="width: 50%;">Injector terminal</th> <th style="width: 50%;">PCME</th> </tr> <tr> <td style="text-align: center;">B</td> <td style="text-align: center;">4Z</td> </tr> </table>	Injector terminal	PCME	B	4Z	Yes	Check for short circuit in wiring harness (Injector-PCME)  ⇒ If OK, go to next step ⇒ If not OK, repair wiring harness
		Injector terminal	PCME				
B	4Z						
		No	Repair wiring harness				
5	Disconnect negative battery cable for at least 20 seconds Connect battery cable and recheck for trouble code Is trouble code displayed?	Yes	Replace PCME <span style="float: right;">page F-150</span>				
		No	Intermittent poor connection Check for cause				

### Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION

CODE No.	76 (SLIP LOCKUP OFF SIGNAL)		
STEP	INSPECTION		ACTION
1	Is there poor connection in Lockup off signal circuit between PCME and PCMT?	Yes	Repair or replace connector
		No	Go to next step
2	Is there continuity between PCME terminal 2G and PCMT terminal 2H	Yes	Go to next step
		No	Check for open circuit in wiring harness (PCMT-PCME)
3	Is PCMT terminal 2H voltage OK?	Yes	Go to next step
		No	Check for cause <span style="float: right;">☞ page F-156</span>
4	Is PCME terminal 2G voltage OK?	Yes	Replace PCME <span style="float: right;">☞ page F-150</span>
		No	Check for short circuit in wiring harness (PCMT-PCME)

### Circuit Diagram




# ON-BOARD DIAGNOSIS FUNCTION

# F


CODE No.	77 (TORQUE REDUCED SIGNAL)		
STEP	INSPECTION		ACTION
1	Is there poor connection in torque reduced signal circuit between PCME and PCMT?	Yes	Repair or replace connector
		No	Go to next step
2	Is there continuity between PCME terminal 2D and PCMT terminal 2C?	Yes	Go to next step
		No	Check for open circuit in wiring harness (PCMT-PCME)
3	Is PCMT terminal 2C voltage OK?	Yes	Go to next step
		No	Check for cause <span style="float: right;">⇨ page F-156</span>
4	Is PCME terminal 2D voltage OK?	Yes	Replace PCME <span style="float: right;">⇨ page F-150</span>
		No	Check for short circuit in wiring harness (PCMT-PCME)

### Circuit Diagram




# F

## ON-BOARD DIAGNOSIS FUNCTION




### After-repair Procedure

Cancel the memory of trouble code number by disconnecting the negative battery cable for 20 sec and depress the brake pedal. Reconnect the negative battery cable.



### Self-Diagnosis Checker

1. Connect the SST (System Selector) to the data link connector.
2. Set system select to position 1.
3. Set the test switch to SELF TEST.




4. Connect the SST (Self-Diagnosis Checker) to the System Selector and a ground.
5. Set the select switch of the Self-Diagnosis Checker to position A.
6. Turn the ignition switch ON.
7. Verify that no trouble code numbers are displayed.

## SWITCH MONITOR FUNCTION

Individual switches can be inspected by the SST (Self-Diagnosis Checker)

### Preparation



The TEN terminal of the data link connector must be grounded and the ignition switch turned to ON (engine off). If any switch remains activated, the monitor lamp will be illuminated.



Switch	Self-Diagnosis Checker (Monitor lamp)		Remarks
	Lamp ON	Lamp OFF	
Clutch switch (MT)	Pedal depressed	Pedal released	In neutral
Neutral switch (MT)	In gear	Neutral	Clutch pedal released
Park/neutral switch (AT)	L, S, D or R range	N or P range	—
Headlight switch	ON	OFF	Headlight switch I or II position
Blower switch	ON	OFF	At 3rd or 4th position
Rear window defroster switch	ON	OFF	—
Air conditioning sensor	ON	OFF	Blower switch at 1st or 2nd position
Stoplight switch	Pedal depressed	Pedal released	—

# F

## ON-BOARD DIAGNOSIS FUNCTION



### Inspection Procedure Self-Diagnosis Checker


1. Connect the SST (System Selector) to the data link connector.
2. Set system select to position 1.
3. Set TEST SW to SELF-TEST.
4. Connect the SST (Self-Diagnosis Checker) to the System Selector and a ground.
5. Set the select switch of the Self-Diagnosis Checker to position A.
6. Turn the ignition switch ON.
7. Check if the Monitor Lamp illuminates when each switch is made to function as described.

### Caution

- If either switch remains activated, the monitor lamp will be illuminated.
- Do not start the engine.




**Procedure**




# F

## ON-BOARD DIAGNOSIS FUNCTION

### Neutral switch (MT)



### Clutch switch (MT)



**Air conditioning sensor**

Turn blower switch to 1st position  
Turn Air conditioning sensor ON  
Is monitor lamp illuminated?

NO

PC: ● Air conditioning sensor malfunction  
● Open circuit in wire harness (Air conditioning sensor-Blower switch)  
● PCME terminal 3B voltage incorrect  
● PCME malfunction

☞ 1994 RX-7 Body electrical troubleshooting manual  
☞ page F-150


YES

Air conditioning sensor OK


# F

## ON-BOARD DIAGNOSIS FUNCTION

### Rear window defroster switch




**Park/neutral switch (AT)**




# F

## ON-BOARD DIAGNOSIS FUNCTION

### Blower switch



### Stoplight switch



**OXYGEN SENSOR MONITOR FUNCTION**

**Engine Signal Monitor**

With the SST see to O<sub>2</sub> Monitor, the oxygen sensor is monitored by the Self-Diagnosis Checker as described.

Condition		Item monitored	Function
Engine	System selector switch		
Vehicle running	O <sub>2</sub> monitor	Oxygen sensor output signal	Oxygen sensor output more than 0.45 V Monitor lamp: Flashes

**KNOCK SENSOR MONITOR FUNCTION**

With the System selector set to Engine Signal Monitor. SELF-TEST the knock sensor is monitored by the Self-Diagnosis Checker as described below.


Item monitored	Condition			Function
	Test	Ignition switch	System selector switch	
Knock sensor output signal	Tap the engine hanger lightly with hammer	ON	SELF-TEST	Monitor lamp: Flashes

### INTAKE AIR SYSTEM

#### COMPONENT PARTS


#### Removal / Inspection / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**. (Refer to page F-77.)
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**. (Refer to page F-77.)






- |  |   |
|--|---|
| 1. Fresh air duct<br>Inspect for damage and cracks   | 11. Throttle body<br>Inspection ..... page F-79                                 |
| 2. Accelerator cable                                 | 12. Extension manifold<br>Inspection ..... page F-79                            |
| 3. Air intake hose<br>Inspect for damage             | 13. Fuel hose   |
| 4. Air cleaner housing<br>Inspection ..... page F-16 | 14. Connector   |
| 5. Air bypass valve<br>Inspection ..... page F-77    | 15. Vacuum hose   |
| 6. Pressure chamber                                  | 16. Intake manifold<br>Inspection ..... page F-79                               |
| 7. Air intake pipe<br>Inspect for damage and cracks  | 17. Idle air control valve<br>Inspection ..... page F-83                        |
| 8. Water hose  | 18. Solenoid valve (AWS)<br>Inspection ..... page F-83                          |
| 9. Connector   | 19. Charge air cooler<br>Removal / Inspection /<br>Installation ..... page F-78 |
| 10. Vacuum hose                                      |   |




**Removal Note**

1. Loosen the drain plug and radiator cap and drain the coolant from radiator.
2. Remove the water hose from the throttle body.
3. After installation of the throttle body, refill the radiator. (Refer to section E.)



**Installation Note**

Install the air intake hose clamp and hose same place as shown in the figure.



**AIR BYPASS VALVE**

**Inspection**


1. Remove the air bypass valve.
2. Connect a vacuum pump to the air bypass valve port A.
3. Check the operation of the air bypass valve.

Apply approx. 14-22 kPa {100-170 mmHg, 3.9-6.7 inHg}	Air flow
Apply approx. 31.3 kPa {235 mmHg, 9.2 inHg}	Fully open

### CHARGE AIR COOLER


#### Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect the charge air cooler visually and repair or replace if necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.




N·m {kgf·cm, in·lbf}

- |                              |                      |
|------------------------------|----------------------|
| 1. Fresh air duct            | 4. Air hose          |
| 2. Charge air cooler bracket | 5. Charge air cooler |
| 3. Air separation tank       |                      |



#### Installation Note

Install the air intake hose and hose clamp same place as shown in the figure.




**THROTTLE BODY**

**Inspection**

**Fast idle cam**


1. Verify that the indicated mark on the fast idle cam is aligned with the center of the cam.
2. Warm up the engine to operating temperature and verify that the waxrod extends outward fully and the idle cam separates from the roller at 55–65°C {131–149°F}.
3. Adjust the adjust screws if necessary.



**Adjustment**

1. To adjust the first idle cam separates point D turn adjust screw B.
2. To adjust the first idle cam opening temperature turn adjust screw A.


Temperature	Position
-20°C {-4°F}	A
0°C {32°F}	B
25°C {77°F}	C
60°C {140°F}	D



**Double throttle valve**

**Inspection**


1. Verify that the No.2 secondary throttle valve and linkage move smoothly when primary throttle valve is fully opened.
2. Replace throttle body if necessary.



**EXTENSION MANIFOLD**

**Inspection**

1. Visually check for cracks or damage and replace it if necessary.
2. Check for distortion of extension manifold and replace if necessary.




**INTAKE MANIFOLD**

1. Visually check for cracks or damage and replace if necessary.
2. Check for distortion of the intake manifold and replace it if necessary.


**ACCELERATOR PEDAL**

**Removal / Inspection / Installation**

1. Remove in the order shown in the figure.
2. Visually check the accelerator pedal and retainer for cracks or damage.
3. Install in the reverse order of removal.



- |   |                      |
|---|----------------------|
| 1. Accelerator cable<br>Inspection / Adjustment ..... below | 4. Shaft             |
| 2. Retainer   | 5. Return spring     |
| 3. Clip   | 6. Accelerator pedal |



**ACCELERATOR CABLE**

**Inspection / Adjustment**

1. Warm up the engine at normal operating temperature.
2. Depress the accelerator pedal to the floor and check that the throttle valve is fully opened.
3. Inspect the play of the accelerator cable.


**Play: 1-3 mm {0.04-0.12 in}**

4. Loosen nuts A to adjust the play if necessary.

**IDLE-SPEED CONTROL SYSTEM**


**DESCRIPTION**

Idle-speed control system controls the bypass air amount that passes through the throttle valve, the idle-speed control system performs closed loop control so that engine idle smoothly and at the target speed. The system also performs the function of the AAV (anti-afterburns valve), there by eliminating the AAV and simplifying deceleration control system.



# F

## IDLE-SPEED CONTROL SYSTEM




### SYSTEM OPERATION


1. Warm up the engine and let it idle.
2. Verify that the fast idle cam separates.
3. Turn all electrical loads OFF.
4. Connect a tachometer to the data link connector terminal IG-.
5. With the coolant fan off, verify that the idle speed is within specification.

**Idle speed (Neutral or P range): 700–750 (720  $\pm$ <sub>20</sub><sup>+30</sup>) rpm**

6. Verify that the idle speed is within specification under the condition below.




Condition	Idle speed (rpm)	
	MT	AT
No load	700–750 (720 $\pm$ <sub>20</sub> <sup>+30</sup> )	
Electrical load ON	775–825	
Air conditioner ON	875–925	775–825



**IDLE AIR CONTROL VALVE**

**Removal / Installation**

1. Disconnect negative battery cable.
2. Remove the extension manifold. (Refer to page F-76.)
3. Disconnect the solenoid valve connector.
4. Remove the idle air control valve as shown in figure.
5. Install in the reverse order of removal.




**Inspection**

1. Remove the solenoid valve. (Refer to above.)
2. Measure the solenoid valve resistance with an ohmmeter.

**Resistance: 10.7-12.3 Ω (20°C {68°F})**


3. If not as specified, replace solenoid valve.



**SOLENOID VALVE (ACCELERATED WARM-UP SYSTEM [AWS])**

**Removal / Installation**

1. Disconnect negative battery cable.
2. Remove the extension manifold. (Refer to page F-76.)
3. Disconnect the solenoid valve connector.
4. Remove the solenoid valve (AWS) as shown in the figure.
5. Install in the reverse order of removal.



**Inspection**


1. Remove the solenoid valve. (Refer to page F-76.)
2. Measure the solenoid valve resistance with an ohmmeter.

**Resistance: 9.3-11.3 Ω (20°C {68°F})**

3. If not as specified, replace solenoid valve.

### SEQUENTIAL TWIN TURBOCHARGER SYSTEM

- The sequential twin turbocharger system consists of two turbochargers (primary and secondary) fitted in line with each other. In the low-speed, light-load range, turbocharging is done only by the primary turbocharger; in the high-speed, heavy-load range, turbocharging is done by the primary and secondary turbochargers in union.
- To prevent a drop of boost pressure when the secondary turbocharger begins to operate, the secondary turbocharger is made to spin prior to its operation.
- The sequential twin turbocharger system consists of the primary and secondary turbochargers and the actuators and solenoid valves (turbo precontrol, turbo control, wastegate control, charge control, charge relief).








### Operation

Devices		Engine speed	
		Low-speed light-load	High-speed Heavy-load
Turbocharger	Primary	Boost pressure	
	Secondary	Stop	Boost
Solenoid valve	Turbo precontrol	Duty control	
	Wastegate control	Duty 95% (Fully closed)	
	Charge relief	OFF	ON
	Charge control	ON	OFF
	Turbo control	OFF	ON



**PREPARATION  
SST**

<p>49 F088 740 Pressure tester</p> 	<p>For inspection of turbocharger</p>	<p>49 F018 902 Adapter harness</p> 	<p>For inspection of solenoid valve</p>
--	---------------------------------------	--	---



## ACTUATOR (TURBO CONTROL [TCNT])

### System Operation

1. Connect the SST (Engine signal Monitor Adaptor Harness) to the PCME as shown.
2. Start the engine and verify that the actuator rod is moved once.
3. Run it idle.
4. Short the PCME terminal 4R and verify that the actuator rod is pulled into the actuator.
5. If the actuator rod is not moved, check the following condition below.

- **Vacuum tube**

Inspect vacuum line fitting, connections and components for leaks. (Refer to page F-10.)

- **Vacuum and pressure chamber**

Visually check for clogging damage or crack.

- **Solenoid valve (Turbo control)**

Inspection (Refer to page F-176.)

- **Actuator (Turbo control)**

Inspection (Refer to below.)


### Inspection

1. Disconnect the air hose and attached it to the SST as shown.
2. Adjust the compressed air pressure to 49 kPa. {0.5 kg·f/cm<sup>2</sup>, 7.1 psi}
3. Verify that the actuator rod is move when applying and releasing air pressure.

### Caution

- **Applying more than 79.4 kPa {0.81 kgf/cm<sup>2</sup>, 11.5 psi} of compressed can damage the actuator.**


4. If not as specified, replace the actuator. (Refer to page F-91.)



**ACTUATOR (CHARGE CONTROL)**


**System Operation**

1. Start the engine and verify that the actuator rod is pulled into the actuator.
2. If the actuator rod is not pulled, check the following condition below.
  - Vacuum tube  
Inspect vacuum line fitting, connections and components for leak. (Refer to page F-10.)
  - Vacuum chamber  
Inspect the damage or crack.
  - Solenoid valve (Charge control)  
Inspection (Refer to page F-176.)
  - Actuator (Charge control)  
Inspection (Refer to below.)
  - Shutter valve  
Inspection (Refer to below.)




**Inspection**


1. Disconnect the vacuum hose from the actuator.
2. Connect a vacuum pump.
3. Verify that the actuator rod is pulled when applying vacuum more than 6.7 kPa {50 mmHg, 1.9 inHg}
4. If not as specified, replace the actuator. (Refer to page F-91.)

**CHARGE RELIEF VALVE****Removal / Installation**



1. Remove in the order shown in figure.
2. Install in the reverse order of removal.

**System operation**

1. Connect the SST (Engine Signal Monitor Adaptor Harness) to the PCME as shown.
2. Turn ignition switch to ON.
3. Short the PCME terminal 4S and verify that the operating sound is heard when the solenoid valve ON.
4. If no sound is heard, check the solenoid valve.  
(Refer to page F-176.)

**Inspection**

1. Remove the charge relief valve.
2. Connect a vacuum pump to port A.
3. Apply approx. 26.7 kPa {200 mmHg, 7.87 inHg} to port A and verify that air flows between B and C.
4. Replace if necessary.



**TURBOCHARGER**  
**Actuator (Turbo precontrol)**  
**System operation**

1. Connect the SST (Engine Signal Monitor Adaptor Harness) to the PCME.
2. Turn ignition switch to ON.
3. Short the PCME terminal 4V and verify that the operating sound is heard.
4. If no sound is heard, check the solenoid valve. (Refer to page F-93.)


**Inspection**

1. Disconnect the air hoses and attached one to the SST and plug the other pipe as shown.
2. Verify that the actuator rod is moved when applying compressed air pressure to 69-98 kPa {0.7-1.0 kgf/cm<sup>2</sup>, 10-14 psi}

**Caution**


- Applying more than 98 kPa {1.0 kgf/cm<sup>2</sup>, 14 psi} of compressed can damage the actuator.

3. Replace turbocharger, if necessary. (Refer to page F-91.)



### Actuator (wastegate control) System Operation

1. Connect the SST (Engine Signal Monitor Adaptor Harness) to the PCME.
2. Turn ignition switch to ON.
3. Short the PCME terminal 4U and verify that the operating sound is heard.
4. If no sound is heard, check the solenoid valve (Refer to page F-93.)




### Inspection

1. Disconnect the air hoses and attached one to the SST and plug the other pipe as shown.
2. Verify that the actuator rod is moved when applying pressed air pressure to 69-98 kPa {0.7-1.0 kgf/cm<sup>2</sup> 10-14 psi}

### Caution

- Applying more than 98 kPa {1.0 kgf/cm<sup>2</sup>, 14 psi} of compressed can damage the actuator.

3. Replace turbocharger, if necessary. (Refer to page F-91.)



### CHECK VALVE

#### Inspection


1. Remove the check valve.
2. Blow through A and verify that air flows from B.
3. Blow through B and verify that air does not flow from A.

## Removal / Installation


### Turbocharger handling procedures.

- Holding the actuator, the rod, or the actuator hose when removing and carrying the turbocharger can cause damage.
- Set the turbine down with the shaft horizontal.
- Replace damaged studs and nuts. Use only the specified studs and nuts. Using damaged or unspecified studs and nuts can cause gas leakage because of insufficient clamping.
- Cover the turbocharger air port and exhaust port with tape to keep out foreign material. Foreign material may damage the turbocharger's internal components.

1. Disconnect the negative battery cable.
2. Lift up the vehicle.
3. Drain the engine coolant.
4. Remove in the order shown in the figure.
5. Install in the reverse order of removal, referring to **Installation Note**.




- |   |                                   |
|---|-----------------------------------|
| 1. Negative battery cable               | 16. Air hose                      |
| 2. Under cover                          | 17. Air pipe                      |
| 3. Bracket                              | 18. Charge control valve assembly |
| 4. Three-way catalyst assembly          | Inspection ..... page F-87        |
| 5. Insulator                            | 19. Air intake pipe (Secondary)   |
| 6. Oxygen sensor                        | 20. Air intake pipe (Primary)     |
| 7. Warm-up three-way catalyst           | 21. Water hose                    |
| 8. Fresh air duct                       | 22. Oil return pipes              |
| 9. Air hoses                            | 23. Oil pipe                      |
| 10. Air cleaner housing                 | 24. Water hose                    |
| 11. Accelerator cable                   | 25. Turbocharger                  |
| Removal / Installation ..... page F-80  | Inspection ..... below            |
| Inspection / Adjustment ..... page F-80 | 26. Actuator (Turbo control)      |
| 12. Pressure chamber                    | Inspection ..... page F-86        |
| 13. Air pipe                            |                                   |
| 14. Drive belt                          |                                   |
| 15. Air pump                            |                                   |



**Installation Note**


1. Verify that the paint mark on the actuator rod is aligned with actuator bracket end.
2. If the mark is not aligned, adjust the actuator rod length



3. Check the stud bolt tightening torque before installing turbocharger.

**Tightening torque**

- A: 16-24 N·m {1.6-2.4 kgf·m, 12-17 ft·lbf}
- B: 8-12 N·m {0.8-1.2 kgf·m, 5.8-8.7 ft·lbf}



**Inspection**


1. Be sure the engine is cool.
2. Remove the turbocharger.
3. Check that the compressor wheel assembly turns smoothly.
4. If there is excessive drag or noise, replace the turbocharger.



**SOLENOID VALVE (TURBO PRECONTROL, WASTEGATE CONTROL)**


**Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Pressure chamber
2. Connectors
3. Vacuum hoses

4. Solenoid valve. (Turbo precontrol)  
Inspection ..... below
5. Solenoid valve. (Wastegate control)  
Inspection ..... below



**Inspection**

1. Remove the solenoid valve.
2. Blow through the solenoid valve from hose A and check that air does not flow from B to A.



3. Apply battery positive voltage to solenoid valve and check that air does flow the solenoid valve from A to B.
4. If not as specified, measure the resistance.

**Resistance: 29-33  $\Omega$  {20°C [68°F]}**

### FUEL SYSTEM

#### DESCRIPTION

This system supplies the necessary fuel at constant pressure to the injectors.

Fuel is metered and injected into intake manifold and intake port according to the injection control signals from the PCME (Powertrain Control Module (Engine)).


This system consists of fuel pump, fuel filters, pressure regulator, pulsation dumper, solenoid valve (Pressure regulator control), and injectors.

#### SECONDARY INJECTOR - OPERATING RANGE



When the engine speed is above 2750 RPM and the total fuel injection amount is above the present amount (pre-programmed in the ECU), the secondary fuel injector operates.



The total fuel injection amount is determined by engine speed, intake manifold pressure, intake air temperature and atmospheric pressure.

For troubleshooting the secondary fuel injector, please refer to the self-diagnosis function-service code No. 71 and 73.



## PREPARATION SST

<p>49 L018 901 Injector checker</p> 	<p>For inspection of injector</p>	<p>49 F013 102 Hose injector checker</p> 	<p>For inspection of injector</p>
---	-----------------------------------	--	-----------------------------------



## PRECAUTION

### Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.


Fuel in the fuel system is under high pressure when the engine is not running.

### Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the following "Fuel Line Safety Procedures".

### Fuel Line Safety Procedures


- A. Release the fuel pressure before disconnecting a fuel line.
  1. Start the engine.
  2. Remove the fuel pump relay.
  3. After the engine stalls, turn the ignition switch to OFF.
  4. Install the fuel pump relay.
- B. Avoid leakage.
  1. When disconnecting a fuel line hose, wrap a rag around it to protect against fuel leakage.
  2. Plug the hose after removal.
- C. Install hose clamps to secure the fuel pressure gauge connections.



### Priming Fuel System

After releasing the fuel pressure for repairs or inspection, the system must be primed to avoid excessive cranking when first starting the engine. Follow the steps below.

1. Connect the data link connector terminals **F/P** and **GND** with a jumper wire.
2. Turn the ignition switch **ON** for **Approximately 10 seconds** and check for fuel leaks.
3. Turn the ignition switch **OFF** and remove the jumper wire.




### SYSTEM OPERATION


#### Fuel Pressure Hold Inspection

#### Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-95.



1. Disconnect the negative battery terminal.
2. Install a fuel pressure gauge as shown.
3. Connect the negative battery terminal.






4. Connect the data link connector terminals **F/P** and **GND** with a jumper wire.
5. Turn the ignition switch **ON** for **10 seconds** to operate the fuel pump.
6. Turn the ignition switch **OFF** and disconnect the jumper wire.
7. Observe the fuel pressure **5 minutes**.

#### Fuel pressure:

**More than 150 kPa {1.5 kg/cm<sup>2</sup>, 21 psi}**

8. If not as specified, perform the following inspections.
  - Fuel pump hold pressure. (Refer to page F-100.)
  - Pressure regulator fuel line pressure. (Refer to page F-104.)
  - Injector fuel leakage. (Refer to page F-107.)



**Fuel Line Pressure Inspection**

**Warning**

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-95.

1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge as shown in the figure.
3. Connect the negative battery cable.

4. Connect data link connector terminals **F/P** and **GND** with a jumper wire.
5. Turn the ignition switch **ON**.
6. Measure the fuel line pressure.

**Fuel line pressure:**

**250–260 kPa {2.5–2.7 kg/cm<sup>2</sup>, 36–38 psi}**

**Pressure low** – Measure fuel pump maximum pressure. (Refer to page F-101.) If as specified, the fuel line or fuel filter might be clogged or restricted.

**Pressure high** – Replace the pressure regulator. (Refer to page F-105.)


### FUEL TANK

#### Removal / Inspection / Installation

##### Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-95.
- Repairing a fuel tank that has not been properly steam cleaned can be dangerous. Explosion or fire may cause death or serious injury. Always properly steam clean a fuel tank before repairing it.


1. Drain the fuel from the fuel tank.
2. Remove in the order shown in the figure.
3. Inspect the fuel tank components visually and repair or replace if necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.




- |                                  |                                  |            |
|----------------------------------|----------------------------------|------------|
| 1. Battery cable                 | 8. Check valve                   |            |
| 2. Fuel hoses                    | Inspection .....                 | page F-132 |
| Installation Note .....          | 9. Separator                     |            |
| page F-99                        | Inspect for cracks and corrosion |            |
| 3. Evaporative hoses             | 10. Fuel vapor valve             |            |
| Installation Note .....          | Inspection .....                 | page F-132 |
| page F-99                        | 11. Fuel pump                    |            |
| 4. Under cover                   | Inspection .....                 | page F-101 |
| 5. Fuel filler pipe              | Removal / Installation .....     | page F- 98 |
| 6. Fuel tank strap               | Assembly / Disassembly .....     | page F-102 |
| 7. Fuel tank                     | 12. Nonreturn valve              |            |
| Inspect for cracks and corrosion |                                  |            |

**Installation Note**

1. Push the ends of the main fuel hose, fuel return hose, and evaporative hoses onto the fuel tank fittings at **least 25 mm {1.0 in}**.
2. Push the fuel filter hose onto the fuel tank pipe and filter pipe at **least 35 mm {1.4 in}**.
3. Push the evaporative hoses onto the fuel vapor valve at **least 20 mm {0.8 in}**.
4. Push the evaporative hoses onto the check valve at **least 17 mm {0.7 in}**.




5. Connect the fuel filler hose and breather hose onto the fuel tank as shown in the figure.



**Nonreturn Valve**

Verify that the nonreturn valve operates under its own weight as shown in the figure.




### FUEL PUMP

#### Inspection

#### Fuel pump operation


1. Connect the data link connector terminals F/P and GND with a jumper wire.
2. Remove the fuel filler cap.
3. Turn the ignition switch ON.
4. Listen for operational sound of the fuel pump at the filler inlet.
5. Install the fuel filler cap.



6. If no sound was heard, measure the voltage the fuel pump connector wire W/R.

#### Voltage: Battery positive voltage

7. If not correct, check the fuel pump relay and its circuits. (Refer to page F-110.)
8. If the voltage is normal, check for continuity between fuel pump connector A and B.
9. If there is no continuity, replace the fuel pump.




#### Hold pressure


Perform the inspection if the fuel pressure hold inspection is not as specified.

#### Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-95.



1. Disconnect the negative battery terminal.
2. Connect a fuel pressure gauge to the fuel main pipe and plug the outlet of the fuel pressure gauge as shown. (Install clamps as shown.)
3. Connect the negative battery terminal.







4. Connect data link connector terminals F/P and GND with a jumper wire.
5. Turn the ignition switch ON and measure the fuel pressure.

#### Fuel pressure:

490-740 kPa {5.0-7.5 kgf/cm<sup>2</sup>, 71-106 psi}

6. Turn the ignition switch OFF and disconnect the jumper wire.
7. If not as specified, replace the fuel pump.





**Fuel pump maximum pressure**

**Warning**

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-95.

1. Disconnect the negative battery terminal.
2. Connect a fuel pressure gauge to the fuel main pipe and plug the outlet of the gauge as shown. (Install clamps as shown.)
3. Connect the negative battery terminal.
4. Connect data link connector terminals **F/P** and **GND** with a jumper wire.
5. Turn the ignition switch ON to operate the fuel pump.
6. Measure the pump maximum pressure.

**Fuel pump maximum pressure:**  
 490-740 kPa {5.0-7.5 kgf/cm<sup>2</sup>, 71-107 psi}

7. Turn the ignition switch OFF and disconnect the jumper wire.
8. If not as specified, replace the fuel pump.

**Continuity Inspection**


1. Remove the luggage room carpet.
2. Remove the acoustic wave guide assembly. (if equipped)
3. Disconnect the fuel pump connector.
4. Check for continuity between the fuel pump connector A and B.
5. If there is none, replace the fuel pump. (Refer to page F-98.)

### Disassembly / Assembly

#### Warning

- When replacing the fuel system parts, keep sparks, cigarettes, and open flames away from the fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-95.

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




1. Fuel pump connector
2. Bracket
3. Mounting rubber
4. Fuel pump

5. O-ring
6. Seal rubber
7. Fuel filter (Low pressure side)

#### Assembly Note

After installing the fuel pump to the bracket, pull the pump down so that it is tight against the bracket.



## FUEL FILTER Replacement


### Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

### High-pressure side


The fuel filter must be replaced at the intervals outlined in the maintenance schedule.

1. Before removing the fuel filter, release the fuel pressure from the fuel system.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.
4. Verify that the fuel hoses are pushed fully onto the fuel filter nipple.



1. Under cover

2. Fuel filter (High-pressure side)




### PRESSURE REGULATOR

#### Inspection Fuel line pressure

##### Warning

- Fuel line spills and leaks can be dangerous. Fuel can ignite and cause serious injuries or death and can damage the vehicle. Fuel can also irritate skin and eyes. To prevent this from happening, release the fuel pressure according to "Fuel Line Safety Procedures" on page F-95.




1. Disconnect the negative battery terminal.
2. Connect a fuel pressure gauge between the fuel filter and the fuel main hose. (Install clamps as shown.)
3. Connect the negative battery terminal.
4. Start the engine and run it at idle.
5. Measure the fuel line pressure.

##### Fuel line pressure:

190–220 kPa {1.9–2.3 kgf/cm<sup>2</sup>, 28–32 psi}

#### Removal / Installation (Refer to page F-105)



**INJECTOR**

**Inspection (On-vehicle)**


1. Warm up the engine and run it idle.
2. Listen for the operational sound of primary injector with a screwdriver or a sound scope.

**Removal / Installation**

**Warning**


- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-95.

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to Installation Note.




1. Negative battery cable
2. Extension manifold (Refer to page F-76)
3. Connector
4. Fuel hoses
5. Fuel distributor assembly (Primary)
6. Fuel distributor assembly (Secondary)
7. Cover

8. Injector (Primary)  
Inspection ..... page F-107
9. Injector (Secondary)  
Inspection ..... page F-107
10. Pulsation damper
11. Pressure regulator  
Inspection ..... page F-104
12. Insulator
13. Air bleed socket




### Installation Note Injector installation

1. Use new O-rings.
2. Apply a small amount of clean engine oil to the O-rings before installing them.
3. Install the injector squarely into fuel distributor and gradually twist it.
4. Verify that the deposit is not to the holder inside of fuel distributor.
5. If there is, clean the holder inside by used to gasoline.




### Fuel leakage test

1. Install the fuel hose.
2. Connect the data link connector terminals F/P and GND with a jumper wire.
3. Turn the ignition switch ON and check for fuel leaks from the fuel distributor.
4. If fuel leaks, check the injector O-ring and fuel distributor.



### Air bleed socket installation

Align the tab of the air bleed socket with the notches in the intermediate housing.




**Inspection**

**Injector resistance**

1. Disconnect injector connector as shown in figure.
2. Measure the resistance of the injection with an ohmmeter.

**Resistance: Approx. 13.8 Ω {20°C [68°F]}**

3. If not as specified, replace the injector.




**Fuel leakage test**

**Warning**


- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

1. Remove the injector together with fuel distributor.
2. Connect the SST as shown in figure.
3. Connect the data link connector terminals F/P and GND with a jumper wire.
4. Turn the ignition switch ON and check for fuel leaks from the injector.

**Fuel leakage: Less than 1 drop / 5 min.**



5. If not as specified, check the injector O-ring and fuel distributor contact face.
6. Install the injector.
7. Turn the ignition switch ON and check for fuel leaks from injector.
8. If not as specified, replace the injector.




**Volume Test**

1. Remove the injectors together with the fuel distributor.
2. Connect the SST as shown in figure.

**Warning**

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

3. Check the injection volume with a graduated container.



**Injection volume**

**Primary injector:**

128–147 ml {128–147 cc, 3.84–4.41 fl oz} / 15 sec.


**Secondary injector:**

198–227 ml {198–227 cc, 5.94–6.81 fl oz} / 15 sec.

4. If not as specified, replace the injector.

**FUEL PUMP CONTROL SYSTEM****Description**

- The PCME turns the fuel pump ON/OFF via the fuel pump relay. By controlling the fuel pump relay (speed), the PCME also controls fuel pump operation in two phases to improve fuel pump reliability and ensure the necessary fuel amount.

**Fuel pump relay**

- The fuel pump relay is controlled by the PCME and turns the fuel pump ON/OFF.

**Fuel pump relay (speed)**

- The fuel pump relay (speed) is controlled by the PCME and controls fuel pump operation voltage via the fuel pump resistor.

**Fuel pump resistor**

- The fuel pump resistor controls fuel pump operation voltage. During low-speed engine operation, fuel pump voltage is supplied via the fuel pump resistor.

**Operation**


- (1) In low-speed range (1K terminal of PCME is battery positive voltage)
  - The fuel pump is driven by voltage from the fuel pump resistor.
- (2) In high-speed range (1K terminal of is 0V)
  - The fuel pump is driven by battery positive voltage.

**Operating conditions**

The system operates when either of the following conditions is met.

- During engine start-up
- Solenoid valve (pressure regulator control) operating
- High speed and heavy load






**FUEL PUMP RESISTOR**

**Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




**Inspection**

1. Disconnect fuel pump resistor connector.
2. Measure resistance of the fuel pump resistor with an ohmmeter.

**Resistance 0.57-0.70  $\Omega$  {at 20°C [68°F]}**

3. Replace the fuel pump resistor if necessary.




**FUEL PUMP RELAY (SPEED)**

**Inspection**

**Operation check**

Listen for operational sound of the fuel pump relay (speed) when ignition switch ON.



**Continuity Inspection**

Check continuity between the terminals with ohmmeter.


B+: Battery positive voltage

Terminal A-B	Terminal C-D
Apply B+	Yes
Not apply B+	No

**PRESSURE REGULATOR CONTROL (PRC) SYSTEM**



**DESCRIPTION**

- This system cancels the vacuum applied to the pressure regulator and increases the fuel pressure during hot engine start-up and for a period immediately following engine start-up. This improves hot starting as well as providing smooth idle.



**Operation**

To prevent vapor-lock during hot restart idle, vacuum to the pressure regulator is momentarily cut, and fuel injection pressure is increased.



## SYSTEM OPERATION

**Warning**

- Fuel line spills and leaks can be dangerous. Fuel can ignite and cause serious injuries or death and can damage the vehicle. Fuel can also irritate skin and eyes. To prevent this from happening, release the fuel pressure according to "Fuel Line Safety Procedures" on page F-95.

1. Remove the fuel pump relay.
2. Connect a fuel pressure gauge to the main hose.
3. Connect the fuel pump relay.
4. Start the engine and run it idle.
5. Verify the fuel pressure.

**Fuel line pressure**

190–220 kPa {1.9–2.3 kgf/cm<sup>2</sup>, 28–32 psi}

6. Short the PCME Terminal 4M and verify that fuel pressure.

**Fuel line pressure**

250–260 kPa {2.5–2.7 kgf/cm<sup>2</sup>, 36–38 psi}

7. If not as specified, check the pressure regulator and solenoid valve.

**EXHAUST SYSTEM**


**COMPONENT PARTS**

**Inspection (On-vehicle)**

Start the engine and verify that there is no exhaust gas leakage from the exhaust system components.

**Removal / Inspection / Installation**

1. Remove in the order shown in the figure.
2. Check all parts and repair or replace if necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.




- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Bracket</li> <li>2. Secondary air pipe.<br/>Inspect for deterioration and restriction.</li> <li>3. Three-way catalyst<br/>Inspect for deterioration and restriction.</li> <li>4. Main silencer<br/>Inspect for deterioration and restriction.</li> <li>5. Insulator</li> </ol> | <ol style="list-style-type: none"> <li>6. Warm-up three-way catalyst<br/>Inspect for deterioration and restriction.</li> <li>7. Turbocharger<br/>Removal ..... Refer to page F-89</li> <li>8. Insulator</li> <li>9. Exhaust manifold<br/>Inspect for deterioration and restriction.</li> <li>10. Insulator</li> </ol> |
|--|---|

**Installation Note**

Check the stud bolt tightening torque before installing exhaust manifold.

**Tightening torque:**

30-35 N·m {3.0-3.6 kgf·m, 22-26 ft·lbf}




**OUTLINE OF EMISSION SYSTEM**

**STRUCTURAL VIEW**

The following systems are employed to reduce CO, HC, and NOx emissions.

1. Secondary air injection
2. Positive crankcase ventilation system
3. Fuel evaporative system
4. Three-way catalyst
5. Deceleration control system
6. Exhaust gas recirculation




SECONDARY AIR INJECTION

DESCRIPTION

The secondary air injection helps to clean the exhaust gas by introducing fresh air into the exhaust port or three-way catalyst in relation to the during condition.

The PCME controls secondary air by actuating the solenoid valves (secondary air switching, secondary air bypass, relief 2, port air bypass, split air bypass) and the air pump relay.



This system consist of an air control valve (ACV), three way solenoid valves, air pump relay and powertrain control module (engine).







# F

## SECONDARY AIR INJECTION

### PREPARATION SST

<p>49 2113 011B Air pump gauge set</p>  An illustration of an air pump gauge set, including a circular gauge with a needle, a flexible hose, and three small circular components.	<p>For inspection of air pump</p>	<p>49 F018 902 Adapter harness</p>  An illustration of an adapter harness, showing a coiled cable with two rectangular connectors at the ends.	<p>For inspection of solenoid valve</p>
--	---	--	---





**AIR CONTROL VALVE (ACV)**

**Switching Valve**

**System operation**

1. Connect the SST (Engine Signal Monitor Adapter Harness) to the PCME as shown.
2. Start the engine and run it idle.
3. Short the PCME terminal 4N and verify that the engine condition change (idle roughing).
4. If the engine condition does not change, check the following below.
  - Vacuum tube  
Inspect the vacuum line fitting, connections and components for leaks. (Refer to page F-10)
  - Secondary air switching valve  
Inspection (Refer to page F-176)
  - Air relief valve  
Inspection (Refer to page F-118)
  - Air pump  
Inspection (Refer to page F-121)
  - Air pump relay  
Inspection (Refer to page F-123)


**Inspection**

1. Remove the air control valve. (Refer to page F-119.)
2. Connect a vacuum pump to port A.
3. Verify that the switching valve opens at a vacuum 14.7 kPa {110 mmHg, 4.3 inHg}.

**Caution**

- Applying vacuum greater than 66.7 kPa {500 mmHg, 19.7 inHg} can damage the air control valve.


4. If not as specified, replace air control valve. (Refer to page F-119.)



**Air Relief Valve  
System operation  
Engine Signal Monitor**


1. Connect the SST (Engine Signal Monitor Adaptor Harness) to the PCME as shown.
2. Start the engine and run it idle.
3. Verify that air does not flow from air relief Valve.
4. Short the PCME terminal 3P and verify that the air flows from air relief valve.
5. If the air does not flow, check the following condition below.

- Vacuum tube  
Inspect the vacuum line fitting, connections and components for leaks. (Refer to page F-10)
- Secondary air bypass valve  
Inspection (Refer to page F-176)
- Air pump  
Inspection (Refer to page F-121)
- Air pump relay.  
Inspection (Refer to page F-123)



**Inspection**


1. Remove the air control valve. (Refer to page F-119.)
2. Connect a vacuum pump to port A.



3. Verify that the air relief valve opens at a vacuum 19.3 kPa {145 mmHg, 5.7 inHg}.

**Caution**


- Applying vacuum greater than 66.7 kPa {500 mmHg, 19.7 inHg} can damage the air control valve.



4. If not as specified, replace air control valve.


**Removal / Installation**

1. Remove the extension manifold. (Refer to page F-76.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



- |                                   |            |
|-----------------------------------|------------|
| 1. Solenoid valve (Turbo control) |            |
| Inspection .....                  | page F-176 |
| 2. Air control valve              |            |
| 3. Gasket                         |            |
| 4. Check valve (Port air)         |            |
| Inspection .....                  | page F-120 |

- |                                      |            |
|--------------------------------------|------------|
| 5. Solenoid valve (Port air bypass)  |            |
| Inspection .....                     | below      |
| 6. Solenoid valve (Split air bypass) |            |
| Inspection .....                     | page F-120 |
| 7. Solenoid valve (Relief2)          |            |
| Inspection .....                     | page F-123 |



**SOLENOID VALVE (PORT AIR BYPASS)**

**System Operation**


1. Connect the SST (Engine Signal Monitor Adaptor Harness) to the PCME.
2. Turn ignition switch ON.
3. Short the PCME terminal 3N and verify that the operational sound is heard.

**Inspection**

1. Disconnect the solenoid valve (Port air bypass) connector.
2. Measure the solenoid valve resistance with an ohmmeter.

**Resistance: 26.6-32.6 Ω (20°C [68°F])**

3. If not as specified, replace solenoid valve. (Above)



### SOLENOID VALVE (SPLIT AIR BYPASS)

#### System Operation


1. Connect the SST (Engine Signal Monitor Adaptor Harness) to the PCME.
2. Turn ignition switch ON.
3. Short the PCME terminal 4F and verify that the operational sound is heard.

#### Inspection

1. Disconnect the solenoid valve.
2. Measure the solenoid valve resistance with an ohmmeter.

**Resistance: 27–32  $\Omega$  {20°C [68°F]}**


3. If not as specified, replace solenoid valve. (Refer to page F-119.)



### CHECK VALVE (PORT AIR)

#### Inspection


1. Disconnect the air hose (From air pump to air control valve) at the air control valve.
2. Start the engine and run it idle.
3. Verify that the exhaust gas does not flow from air control valve.
4. If the exhaust gas flows from air control valve, replace the check valve (port air). (Refer to page F-119.)



### CHECK VALVE (SPLIT AIR)

#### Inspection


1. Disconnect the air hose (From air control valve to air pipe) at the air pipe.
2. Start the engine.
3. Increase the engine speed to 2,000 rpm and verify that the exhaust gas does not flow from split air pipe.
4. If not as specified, replace the check valve (Split air).



### CHECK VALVE

#### Inspection

1. Remove the check valve.
2. Blow through A and verify that air flows from B.
3. Blow through B and verify that air does not flow from A.




**AIR PUMP  
System Operation**

1. Start the engine.
2. Increase the engine speed to above 3250 rpm and verify that the air pump magnetic clutch OFF.


**Inspection  
Magnetic clutch**

1. Connect the SST (Engine Signal Monitor Adaptor Harness) to the PCME.
2. Turn ignition switch ON.
3. Short the PCME terminal 2J and verify that the magnetic clutch OFF.
4. If the magnetic clutch does not OFF, check the air pump relay. (Refer to page F-123.)
5. If the relay is OK, disconnect the air pump connector and check the continuity.
6. If not as specified, replace the air pump.



**Continuity**


1. Disconnect the air pump connector.
2. Check for continuity between terminals.
3. If no continuity, replace the air pump.



**Pressure**

1. Disconnect air hose (from air control valve to air pump) at the air control valve.
2. Connect the SST to the air hose.
3. Start the engine and run it idle.
4. Measure the pressure.


**Pressure**  
More than 4.9 kPa {0.05 kgf/cm<sup>2</sup>, 0.7 psi}



5. If not as specified, replace the air pump.

### Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




Nm{kgf·m,ft·lbf}

1. Air hoses
2. Connector
3. Drive belt

Inspection ..... below

4. Bracket
5. Air pump

Inspection ..... page F-121




### AIR PUMP DRIVE BELT

#### Inspection

1. Check the drive belt for cracks deterioration or oil contamination.
2. Replace if necessary.
3. If the belt is noisy, check for loose or misaligned pulleys.

#### Adjustment


Refer to section C.



**AIR PUMP RELAY**

**Inspection (On-vehicle)**

Check that a "clicking" sound is heard at the Air pump relay when turning the ignition switch ON and OFF.




**Inspection**

1. Disconnect the air pump relay.
2. Apply Battery positive voltage and ground to terminals B and D of the relay.
3. Check continuity of the relay.

B+: Battery positive voltage

Operation	A-C terminals
B+ Applied	Continuity
B+ Not applied	No continuity



**SOLENOID VALVE (RELIEF2)**

**System Operation**

**Engine Signal Monitor**

1. Connect the SST (Engine Signal Monitor Adaptor Harness) to the PCME.
2. Turn ignition switch ON.
3. Short the PCME terminal 3K and verify that the operation sound is heard.

**Inspection**

1. Disconnect the solenoid valve. (Refer to page F-119.)
2. Measure the solenoid valve resistance with an ohmmeter.

**Resistance 27-32 Ω {20°C [68°F]}**

3. If not as specified, replace solenoid valve. (Refer to page F-119.)



## POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM

## DESCRIPTION


The PCV valve is operated by the intake manifold vacuum.

When the engine is running at idle, the PCV valve is opened slightly and a small amount of blow by gas is drawn into the dynamic chamber to be burned.

As the engine speed rises the PCV valve is opened further, allowing a larger amount of blow by gas to be drawn into the intake manifold.

PCV VALVE  
Inspection

1. Warm up the engine to the normal operating temperature and run it at idle.
2. Disconnect the PCV valve with the ventilation hose.
3. Block the PCV valve opening.
4. Verify that vacuum is felt.



5. Remove the PCV valve.
6. Blow through the valve from port A and verify that air comes out of port B.
7. Blow through the valve from port B and verify that no air comes out of port A.
8. Replace the PCV valve if necessary.




EXHAUST GAS RECIRCULATION (EGR)

DESCRIPTION

This system recirculates a small amount of exhaust gas into the intake manifold to reduce the combustion temperature, and reduce NOx emissions.

This system consists of the EGR valve, EGR function sensor, solenoid valve, PCME and input devices.



Operation

**Cold engine (Engine coolant temperature: below 70°C [158°F])**


EGR operation is stopped to improve drivability when the engine is cold.


**Warm engine**

The PCME controls the solenoid valve to supply EGR gases as described below.

Operating condition	EGR operation	Remark
Idle	Stopped	—
Deceleration		
High engine speed		Above 3850 rpm
Heavy load		—
Others	Supplied EGR gas	<ul style="list-style-type: none"> <li>● MT 5th gear, AT OD position</li> <li>● Engine speed above 1700 rpm</li> </ul>

### PREPARATION SST

<p>49 F018 902</p> <p>Adapter harness</p> 	<p>For inspection of solenoid valve</p>
---	---




### SYSTEM OPERATION

1. Connect the SST (Engine Signal Monitor Adaptor Harness) to the PCME as shown.
2. Start the engine.
3. Accelerates the engine and verify that PCME terminal 4O voltage B+ while the engine is still cold.
4. Warm up the engine to normal operating temperature and run it at idle.
5. Short the PCME terminal 4O and verify that the engine runs roughly or stalls at idle.

**EGR VALVE**


**Removal / Installation**

1. Remove the intake air system component parts. (Refer to page F-76.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



1. Insulator
2. Connector

3. EGR valve  
Inspection ..... below



**Inspection**

1. Connect a vacuum pump as shown and apply vacuum.
2. Verify that the EGR valve moves at more than the specified vacuum.

**Specification:**

11-15.3 kPa {85-115 mmHg, 3.3-4.5 inHg}

3. If not as specified, replace EGR valve.

**EGR FUNCTION SENSOR**


**Inspection**

1. Remove the EGR valve. (Refer to above)
2. Connect an ohmmeter between the terminals.
3. Connect a vacuum pump as shown and apply vacuum.
4. Verify that the EGR function sensor ON (continue) at more than the specified vacuum.

**Specification:**

11-15.3 kPa {85-115 mmHg, 3.3-4.5 inHg}

5. If not as specified, replace EGR valve.



**SOLENOID VALVE (EGR)**


**Inspection**

(Refer to page F-176)

THREE-WAY CATALYST SYSTEM

DESCRIPTION

Two sets three-way catalysts are used to reduce CO, HC, and NOx emissions. For efficient operation, the warm-up three-way catalyst is placed close to the exhaust manifold so that it will heat up quickly and purify exhaust gas efficiently when engine runs at idle.




The three-way catalysts reduce CO and HC, emissions through oxidization and NOx emissions by chemical reaction.

Three-way catalyst	Type
Warm-up three-way catalyst	Metal
Three-way catalyst	Monolythic

Operation

- (1) Before the engine is warmed up, when large amounts of CO and HC are ceated, the three-way catalyst is supplied port air and uses both the first and second stages as the oxidization catalyst.
- (2) In the normal driving range, the three-way catalyst is supplied split air and uses the first stage as the ternary catalyst and second stage as the oxidization catalyst.
- (3) During high-speed driving, an additional air to the three-way catalyst is cut off, and the first and second stages are used the ternary catalyst.

	First stage	Second stage	Remark
Port air	Oxidation	Oxidation	Low-speed range, Deceleration range
Split air	Ternary	Oxidation	Cruising range
Air cut	Ternary	Ternary	High-speed range




THREE-WAY CATALYST (WARM-UP THREE-WAY CATALYST AND THREE-WAY CATALYST)

Inspection

1. Check the three-way catalyst for deterioration or clog-ging.
2. Check the insulation covers welded onto the three-way catalyst for damage.
3. Excessive heat will occur at the floor if the insulation cover is touching the three-way catalyst.

FUEL EVAPORATIVE SYSTEM

DESCRIPTION



The fuel evaporative system temporarily stores in the canister the evaporative fumes generated in the fuel tank. The stored gas is then passed into the air intake system for combustion when the engine is running. This operation prevents evaporative fumes from flowing out to the atmosphere. Sending a large volume of evaporative fumes at one time into the air intake system deteriorates the air fuel ratio; thus, the PCME uses the solenoid valve (purge control) to regulate this volume.


**Operation**

**With engine stopped and no load applied**


The evaporative fumes from the fuel tank are absorbed by the charcoal canister.

**With engine running and load applied**

The evaporative fumes absorbed by the charcoal canister are drawn into the engine via the solenoid valve (purge control). The volume of fumes drawn depends on engine conditions.

**SYSTEM OPERATION**


1. Warm up the engine to normal operating temperature and run it at idle.
2. Disconnect the vacuum hose from the solenoid valve (purge control) as shown in the figure, and verify that no vacuum is felt at the solenoid valve.
3. If not as specified, check the solenoid valve.



**SOLENOID VALVE (PURGE CONTROL)**

**Removal / Installation**

1. Disconnect the vacuum hoses and connector from solenoid valve.
2. Remove the mounting nuts and solenoid valve.
3. Install in the reverse order of removal.




**Inspection**

1. Disconnect the vacuum hoses and connector from the solenoid valve.
2. Blow into the valve and verify that no air flows through it.
3. Apply battery positive voltage as shown in the figure.
4. Blow into the valve and verify that air flows through it.
5. If not as specified, measure the solenoid valve resistance with an ohmmeter.

**Resistance: 30-34  $\Omega$  (20°C [68°F])**

6. If not as specified, replace the solenoid valve.




**CHARCOAL CANISTER**

**Inspection**

Visually check for damage and replace the charcoal canister if necessary.

# F

## FUEL EVAPORATIVE SYSTEM




### CHECK VALVE (TWO-WAY)

#### Inspection

1. Remove the check valve.
2. Check the operation of the check valve by using a vacuum pump.


Apply approx. 5 kPa (37 mmHg, 1.46 inHg) vacuum at port A	Air flow
Apply approx. 6 kPa (44 mmHg, 1.73 inHg) vacuum at port B	Air flow



### CHECK VALVE (ONE-WAY)

#### Inspection


1. Remove the check valve.
2. Blow through the check valve from port A, and check that the air flows from port B.
3. Blow through the check valve from port B, and check there is no flow.



### SEPARATOR

#### Inspection


Visually check for damage and replace the separator if necessary.



### FUEL VAPOR VALVE

#### Inspection

1. Remove the valve.
2. Blow through the valve and verify that air flows in the direction shown.




3. Turn the valve over and blow through the valve. Verify that no air flows.
4. Replace the valve if necessary.




**DECELERATION CONTROL SYSTEM**

**DESCRIPTION**

- Dashpot : To prevent the throttle valves from closing suddenly.
- Idle air control valve : To prevent afterburn, air is supplied to intake manifold during deceleration.
- Fuel cut control : To improve the fuel economy and to prevent engine bucking during deceleration.
- Air bypass valve : Bypasses compressed air from after the turbocharger to air cleaner housing during deceleration to prevent noise.






**DASHPOT**


**Inspection**

1. Open the throttle valve fully, then push the dashpot rod with a finger and verify that the rod goes in slowly.
2. Release the rod and verify that it comes out quickly.
3. Replace it, if necessary.




**Adjustment**

1. Warm up the engine to the normal operating temperature and run it idle.
2. Verify that the fast idle cam separates.
3. Turn all electrical loads OFF.
4. Connect a tachometer to the data link connector terminal IG-.




5. Open the throttle valve until the dashpot rod separates from the lever.
6. Check the engine speed when the dashpot rod touches to the lever.

**Engine speed: 2600–3000 {2800 ± 200} rpm**



7. Loosen the locknut and adjust by turning the dashpot, if necessary.



**ANTI AFTERBURN CONTROL**

**System operation**


1. Start the engine and run it at idle.
2. Disconnect the idle air control valve connector.
3. Increase the engine speed to over 4,000 rpm then decrease the engine speed rapidly.
4. Verify that the engine speed decrease roughly at 1500–1000 rpm.

**ELECTRICAL LOAD (E/L) CONTROL SYSTEM**

**DESCRIPTION**



The engine speed increases when any of the following switches are ON.

- Rear window defroster switch
- Headlight switch
- Blower switch 3rd or 4th position.




**PREPARATION**

**SST**

<p>49 B019 9A0 System Selector</p> 	<p>For diagnosis</p>	<p>49 H018 9A1 Self-Diagnosis Checker</p> 	<p>For diagnosis</p>
--	----------------------	---	----------------------


# F

## ELECTRICAL LOAD (E/L) CONTROL SYSTEM



### SYSTEM OPERATION

1. Connect the SST (System selector) to the data link connector.
2. Set switch A to position 1 and TEST SW to SELF-TEST.
3. Connect the SST (Self-Diagnosis Checker) to the System Selector and a ground.
4. Set the select switch to position A.
5. Turn ignition switch ON.
6. Check if the monitor lamp illuminates when E/L unit relative switch is made to function. (Refer to page F-67.)



### Inspection

1. Remove the E/L unit. (Refer to page F-150.)
2. Connect the E/L unit connector.
3. Measure the voltage at each terminal by using a voltmeter.
4. If any E/L unit terminal voltage is incorrect, check the input or output device and related wiring harness. If they are normal, replace the E/L unit.

### Terminal voltage

B+: Battery positive voltage


Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
A	—	—	Main relay	Ignition switch ON	B+	—
B	○		TNS relay	Position light ON	Below 1.0V	—
				Position light OFF	B+	
C	—	—	—	—	—	—
D	○		Rear window defroster ready	Rear window defroster OFF	B+	Ignition switch ON
				Rear window defroster ON	Below 1.0V	
E	○		Blower motor relay	Blower switch 3rd or 4th position	Below 1.0V	Ignition switch ON
				Blower switch 1st or 2nd position	B+	
F	—	—	—	—	—	—
G	—	—	—	—	—	—
H		○	Self-Diagnosis checker Data link connector (FEN)	Buzzer sounded for 3 sec, after ignition switch OFF → ON	Below 2.5V	<ul style="list-style-type: none"> <li>• With Self-Diagnosis Checker and System Selector</li> <li>• With System Selector test switch at SELF TEST</li> </ul>
				Buzzer not sounded for after 3 sec.	B+	
				Buzzer sounded	Below 2.5V	
				Buzzer not sounded	B+	
I	—	—	—	—	—	—
J	—	—	—	—	—	—
K		○	Malfunction indicator lamp (MIL)	Lamp illuminated for 3 sec. after ignition switch ON	Below 2.5V	With system selector test switch at SELF TEST
				Lamp not illuminated after 3 sec.	B+	
				Lamp illuminated	Below 2.5V	
				Lamp not illuminated	B+	
L	—	—	—	—	—	—
M	—	—	Ground	Constant	0V	—
N		○	PCME	Electrical load ON	Below 4.0V	Ignition switch ON
				Electrical load OFF	4.5-5.5V	
O	—	—	—	—	—	—
P	—	—	—	—	—	—

## DOUBLE THROTTLE CONTROL SYSTEM

## DESCRIPTION



The response delay of the manifold absolute pressure sensor followed mounted by rapid acceleration temporarily causes a lean fuel mixture. The double throttle control system prevents hesitation caused by this lean fuel mixture by slightly delaying the opening of the double throttle valve after the secondary throttle valve.

The double throttle valve is controlled by the PCME through the solenoid valve.




## OPERATION

When the engine coolant temperature below 80°C {176°F} the PCME turns the solenoid valve ON, applies vacuum to the actuator (double throttle control), and closes the double throttle valve.



### SYSTEM OPERATION

1. Start the engine and verify that the actuator (Double throttle control) rod is pulled into actuator while engine is cold.
2. If the actuator rod is not pulled, check the following condition below.
  - Vacuum tube  
Inspect vacuum line fitting, connections and components for leaks. (Refer to page F-10.)
  - Vacuum chamber  
Visually check for dogging damage or crack.
  - Actuator  
Inspection (Refer to below.)
  - Solenoid valve (Double throttle control)  
Inspection (Refer to page F-176.)
  - Engine coolant temperature sensor  
Inspection (Refer to page F-169.)
3. Verify that the actuator rod is returned, when warm up the engine to normal operating temperature.
4. If the actuator rod is not return, check the following condition below.
  - Solenoid valve (Double throttle control)  
Inspection (Refer to page F-176.)
  - Engine coolant temperature sensor  
Inspection (Refer to page F-169.)




**ACTUATOR (DOUBLE THROTTLE CONTROL)**

**Inspection**

1. Disconnect vacuum hose.
2. Connect a vacuum pump and verify that actuator rod is pulled into actuator when apply the vacuum more than **22.0–28.7 kPa {165–215 mmHg, 6.5–8.5 inHg}**
3. If not as specified, replace the actuator.

**Removal / Installation**

(Refer to page F-76.)



**CHECK VALVE**


**Inspection**

1. Remove the check valve.
2. Blow through A and check that air flows from B.
3. Blow through B and check that air does not flow from A.

**A/C CUT-OFF SYSTEM**

**DESCRIPTION**


An A/C cut-off system is used to improve idle smoothness immediately after starting the engine and to improve acceleration performance.



**Operation**

Engine condition	Purpose	Cut off period
After engine started	Improved idle	Approx. 8 sec.
Throttle valve wide open throttle	Improved drivability	Approx. 7 sec.
Engine coolant temperature over 117°C [243°F]	Prevent engine from over heating	Engine coolant temperature under 115°C [239°F]






## SYSTEM OPERATION

1. Start the engine and let it idle.
2. Turn the A/C sensor and blower switch ON, and verify that no engine speed decrease.
3. Turn the blower switch OFF and verify that no engine speed increase.
4. If not as specified, check for cause.
  - Idle air control valve  
Inspection (Refer to page F-82.)
  - A/C signal (PCME terminal 1E)  
Inspection (Refer to page F-152.)

# F


## A/C CUT-OFF SYSTEM



### Inspection

#### Acceleration cut-off

1. Turn ignition switch ON.
2. Shift transmission into gear (MT) on shift into D range (AT).
3. Turn the A/C sensor and blower switch ON.
4. Open the throttle valve fully and verify that the magnetic clutch disengage (click is heard) then renganges after approx. 5 seconds.



### A/C RELAY

#### Continuity Inspection

Check continuity between the terminals with ohmmeter.


B+: Battery positive voltage

Terminal A-B	Terminal C-D
Apply B+	Yes
Not Apply B+	No

**DECHOKE CONTROL SYSTEM**


**DESCRIPTION**

To facilitate starting the engine if the spark plugs become fouled, such as when the engine is flooded, fuel injection is cut if the throttle valve is held wide open throttle while cranking the engine. This allows the spark plugs to dry and purges excess fuel from the cylinders.



**SYSTEM OPERATION**

1. Verify that the engine will not start and no operational sound of primary injector with a screwdriver or a soundscope when cranked at normal speed with the throttle wide open throttle.



2. If the engine starts, and operational sound of primary injector is heard, inspect the throttle position sensor (Refer to page F-182) and the PCME terminal 1 C voltage. (Refer to page F-152.)


# F

## COOLING FAN CONTROL SYSTEM

### COOLING FAN CONTROL SYSTEM


#### DESCRIPTION

To improve idle smoothness and engine reliability, the cooling fan control system controls the electrical fan speed by ECM. This system consists of the cooling fan, cooling fan relays, cooling fan control module, ECM, and input devices.




#### Operation

Engine condition (No electrical load)	A/C operation	Cooling fan relay No.1	Cooling fan relay No.2	Cooling fan relay No.3	Cooling fan relay No.4	Cooling fan operation
Engine coolant temperature below 105 °C {221 °F }	OFF	OFF	OFF	OFF	OFF	OFF
	ON	ON	OFF	OFF	OFF	LOW
Engine coolant temperature 105—108 °C {221—226 °F }	OFF	OFF	ON	OFF	ON	LOW
	ON	ON	ON	OFF	ON	MIDDLE
Engine coolant temperature above 108 °C {226 °F } (Engine coolant temperature switch ON)	OFF	OFF	ON	ON	ON	MIDDLE
	ON	ON	ON	ON	ON	HIGH
In 10 min. after ignition switch is turned OFF. Engine coolant temperature above 108 °C {226 °F } for more than 2 min. before ignition switch is turned OFF.	—	OFF	ON	ON	ON	MIDDLE
	—	OFF	ON	OFF	ON	LOW
Engine coolant temperature sensor malfunction	—	OFF	ON	OFF	ON	LOW
TFA terminal ground	—	OFF	ON	OFF	ON	LOW



**SYSTEM INSPECTION**


1. Verify that the engine coolant temperature is below 80 °C {176 °F}
2. Turn the ignition switch to ON for 15 sec. or longer.
3. Turn the ignition switch to OFF.
4. Ground the check connector by using a jumper wire.
5. Turn the ignition switch to ON and verify that the cooling fan operates approx. 100—150sec. after the ignition switch is turned to ON.
6. If the cooling fan will not operate, inspect the following. Cooling fan control module terminal voltage (Refer to page F-146.)
  - Battery positive voltage
  - Fan control signal
  - Engine coolant temperature signal
  - Ground



7. Turn the ignition switch to OFF.
8. Verify that the cooling fan keep operating after the ignition switch is turned to OFF.
9. If not, replace the cooling fan control module. (Refer to page F-146.)
10. Wait for approx. 20 sec.
11. Disconnect cooling fan relay connector A. Verify that the cooling fan operates at low speed.
12. If not, inspect the cooling fan relay. (Refer to page F-146-1.)
13. Connect cooling fan relay connector A. Verify that the cooling fan operates at the speed before connector A is disconnected.
14. Disconnect the jumper wire from the check connector. Verify that the cooling fan operates at low speed.
15. Turn the ignition switch to ON.
16. Verify that the cooling fan stops 8—12 sec. after the ignition switch is turned to ON.
17. If not as specified, replace the cooling fan control module. (Refer to page F-146.)

# F

## COOLING FAN CONTROL SYSTEM





### COOLING FAN CONTROL MODULE

#### Removal / Installation

1. Remove the ECM. (Refer to page F-150.)
2. Disconnect the cooling fan control module connector.
3. Loosen nut A as shown.
4. Remove the cooling fan control module.
5. Install in the reverse order of removal.

#### Tightening torque

Nut A: 7.9—10.7 N·m {80—110 kgf·cm, 70—95.4 in·lbf }



#### Inspection

1. With the cooling fan control module connector connected, measure the voltage at each terminal of the connector. Using a voltmeter, ground the negative lead to the body and insert the positive lead in each terminal of the connector.
2. If there is any incorrect output voltage while all input voltages are correct, inspect related systems. When the systems are normal, replace the cooling fan control module.



#### Terminal voltage

B+ : Battery positive voltage

Terminal	Signal	Connected to	Test condition	Voltage (V)	Possible malfunction
A	—	—	—	—	—
B	—	—	—	—	—
C	Engine coolant temperature (for cooling fan)	Engine coolant temperature switch	Engine coolant temperature below 108 °C {226 °F }	B+	<ul style="list-style-type: none"> <li>• Engine coolant temperature switch</li> <li>• Cooling fan relay (Refer to F-146-1)</li> </ul>
			Engine coolant temperature above 108 °C {226 °F }	Below 1.0	
D	—	—	—	—	—
E	Cooling fan relay No.2, 4	Cooling fan relay No.2, 4	Cooling fan not operating	B+	<ul style="list-style-type: none"> <li>• Cooling fan relay (Refer to F-146-1)</li> </ul>
			During cooling fan operating	Below 1.0	
			TFA terminal of data link connector is grounded	Below 1.0	
F	—	—	—	—	—
G	—	—	—	—	—
H	—	—	—	—	—
I	—	—	—	—	—
J	Ground	Ground	Constant	Below 1.0	<ul style="list-style-type: none"> <li>• Cooling fan control module terminal J -Ground</li> </ul>

B+ : Battery positive voltage

Terminal	Signal	Connected to	Test condition	Voltage (V)	Possible malfunction
K	—	—	—	—	—
L	—	—	—	—	—
M	—	—	—	—	—
N	—	—	—	—	—
O	Power supply	Main relay	Ignition switch OFF	Below 1.0	• Main relay
			Ignition switch ON	B+	
P	Power supply (Condenser fan)	Battery	Constant	B+	• A/C fuse



**COOLING FAN RELAY (No.1, 2, 3, 4)**

**Inspection**

1. Disconnect the cooling fan relay.
2. Apply battery positive voltage and ground to terminals A and B of the cooling fan relay.
3. Check continuity of the relay.






B+ : Battery positive voltage

Operation	Ⓐ Type—Terminals D—E Ⓑ Type—Terminals C—D
B+ applied	Continuity
B+ not applied	No continuity

4. If not as specified, replace the cooling fan relay.


**CONTROL SYSTEM**

**PREPARATION  
SST**

<p>49 9200 162 Engine Signal Monitor</p> 	<p>For inspection of PCME terminal voltage.</p>	<p>49 F018 902 Adaptor harness</p> 	<p>For inspection of PCME terminal voltage</p>
<p>49 F018 903 Sheet</p> 	<p>For inspection of PCME terminal voltage.</p>	<p>49 H018 9A1 Self-Diagnosis Checker</p> 	<p>For inspection of oxygen sensor and knock sensor</p>
<p>49 B019 9A0 System Selector</p> 	<p>For inspection of oxygen sensor and knock sensor.</p>		



### STRUCTURAL VIEW




1. Powertrain control module (engine) (PCME)
  - Removal / Installation ..... page F-150
  - Inspection ..... page F-150
2. Main relay
  - Inspection ..... page F-174
3. Fuel pump relay
  - Inspection (On vehicle) ..... page F-175
  - Inspection ..... page F-175
4. Crankshaft position sensor
  - Removal / Installation ..... page F-166
  - Inspection ..... page F-166
5. Manifold absolute pressure sensor
  - Inspection ..... page F-167
6. Throttle position sensor
  - Inspection ..... page F-168
  - Adjustment ..... page F-168
  - Removal / Installation ..... page F-168
7. Engine coolant temperature sensor
  - Removal / Installation ..... page F-169
  - Inspection
8. Intake air temperature sensor
  - Removal / Installation ..... page F-169
  - Inspection ..... page F-169
9. Fuel thermosensor
  - Removal / Installation ..... page F-170
  - Inspection ..... page F-170
10. Oxygen sensor
  - Inspection ..... page F-170
  - Removal / Installation ..... page F-170
11. Knock sensor
  - Inspection (On vehicle) ..... page F-171
  - Removal / Installation ..... page F-171
12. Steering pressure sensor
  - Inspection (On vehicle) ..... page F-172
  - Removal / Installation ..... page F-172
13. Stoplight switch
  - Inspection ..... page F-172
  - Removal / Installation ..... page F-172
14. Neutral switch (MT)
  - Inspection ..... page F-172
  - Removal / Installation ..... page F-172
15. Clutch switch (MT)
  - Inspection ..... page F-173
  - Removal / Installation ..... page F-173
16. 1-2 switch (MT)
  - Inspection ..... page F-173
  - Removal / Installation ..... page F-173
17. EGR position sensor
  - Inspection ..... page F-127
  - Removal / Installation ..... page F-127
18. Mileage switch
  - Inspection ..... page F-175
19. Heat hazard sensor
  - Inspection ..... page F-175
  - Removal / Installation ..... page F-175
20. Solenoid valves
  - Removal / Installation ..... page F-176
  - Inspection ..... page F-177

### POWERTRAIN CONTROL MODULE (ENGINE) (PCME)



#### Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Battery cable
2. Scuff plate
3. Front side trim
4. Connectors

5. PCME  
Inspection  
(Engine Signal Monitor) ..... page F-151
6. Connector
7. E/L unit  
Inspection ..... page F-136



### Inspection Engine signal Monitor

1. Connect the SSTs to the PCME as shown.

Use connector A of the adapter to measure voltage at terminals 1A through 1V and 3A through 3P, and use connector B to measure voltage at the terminals 2A through 2L and 4A through 4Z.

2. Place the SST (Sheet: 76-pin type) on the SST (Engine Signal Monitor).

3. Measure the voltage at each terminal.

4. If any PCME terminal voltage is incorrect, check the input or output device and related wiring. If they are normal, replace the PCME.

### Caution

- Applying voltage to SST terminals A or B will damage the SST.



# F

## CONTROL SYSTEM

### Terminal voltage

#### 1. Using the engine signal monitor

B+: Battery positive voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark	
1A	—	—	Battery	Constant	B+	For backup	
1B	○		Main relay (FUEL INJ relay)	Ignition switch	OFF	0V	—
					ON	B+	
1C	○		Ignition switch (START)	While cranking		B+	—
				Ignition switch ON		Below 1.0V	
1D		○	Self-Diagnosis checker (monitor lamp)	Test switch at SELF TEST Lamp illuminated for 3 sec. after ignition switch OFF → ON		4.5–5.5V	With Self-Diagnosis checker and System Selector
				Lamp not illuminated after 3 sec.		B+	
				Test switch at O <sub>2</sub> MONITOR Lamp illuminated		4.5–5.5V	
				Test switch at O <sub>2</sub> MONITOR Lamp not illuminated		B+	
1E	○		Air conditioning sensor	Air conditioning sensor ON		Below 3.0V	<ul style="list-style-type: none"> <li>• With Blower SW ON</li> <li>• Ignition switch ON</li> </ul>
				Air conditioning sensor OFF		B+	
1F		○	Self-Diagnosis checker (code number)	Buzzer sounded for 3 sec. after ignition switch OFF → ON		Below 2.5V	<ul style="list-style-type: none"> <li>• With Self-Diagnosis checker and System Selector</li> <li>• With System Selector test switch at SELF TEST</li> </ul>
				Buzzer not sounded for after 3 sec.		B+	
				Buzzer sounded		Below 2.5V	
				Buzzer not sounded		B+	
1G		○	Igniter (Trailing) Front rotor	Ignition switch ON		0V	—
				Idle		0.2–0.5V (Reference)	
				Oscilloscope			
			Engine speed: above 2,500 rpm		0.5–0.8V (Reference)	Initial acceleration	
1H		○	Igniter (Leading)	Ignition switch ON		0V	—
				Idle		0.2–0.5V (Reference)	
				Oscilloscope			
						Engine speed: above 2,500 rpm	



B+: Battery positive voltage

Incorrect voltage		Possible cause
Always 0V		<ul style="list-style-type: none"> <li>● ROOM 10A fuse burnt</li> <li>● Open circuit in wiring from ROOM 10A fuse to PCME terminal 1A</li> </ul>
Always 0V		<ul style="list-style-type: none"> <li>● Main relay malfunction (Refer to page F-174)</li> <li>● Open or short circuit in wiring from main relay to PCME terminal 1B</li> </ul>
Always 0V (starter turns)		<ul style="list-style-type: none"> <li>● Open or short circuit in wiring from ignition switch to PCME terminal 1C</li> <li>● Ignition switch malfunction (Refer to section T)</li> </ul>
Always 0V		<ul style="list-style-type: none"> <li>● Main relay (FUEL INJ relay) malfunction (Refer to page F-174)</li> <li>● Open circuit in wiring from ignition switch to data link connector terminal +B</li> <li>● Open or short circuit in wiring from data link connector terminal MEN to PCME terminal 1D</li> </ul>
Always B+		<ul style="list-style-type: none"> <li>● Poor connection at PCME connector</li> <li>● PCME malfunction</li> </ul>
Always approx. 5V		PCME malfunction
Always below 1.0V		<ul style="list-style-type: none"> <li>● Short circuit in wiring from air conditioning sensor to PCME terminal 1E</li> <li>● Air conditioning sensor malfunction (Refer to section T)</li> </ul>
Always B+		<ul style="list-style-type: none"> <li>● Open circuit in wiring from air conditioning sensor to PCME terminal 1E</li> <li>● Air conditioning sensor malfunction (Refer to section T)</li> </ul>
Always below 2.5V	No display on Self-Diagnosis Checker	<ul style="list-style-type: none"> <li>● Main relay (FUEL INJ relay) malfunction (Refer to page F-174)</li> <li>● Open circuit in wiring from ignition switch to data link connector terminal + B</li> </ul>
	"88" displayed and buzzer sounds continuously	Open or short circuit in wiring from data link connector terminal FEN to PCME terminal 1F
Always B+		<ul style="list-style-type: none"> <li>● Poor connection at PCME connector</li> <li>● PCME malfunction</li> </ul>
Always 0V		Refer to page F-16 (Ignition timing adjustment)
Always 0V		Refer to page F-16 (Ignition timing adjustment)

# F

## CONTROL SYSTEM

B+: Battery positive voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark	
1I	○		Data link connector (TEN terminal)	System Selector test switch at O <sub>2</sub> MONITOR	B+	<ul style="list-style-type: none"> <li>With System Selector</li> <li>Ignition switch ON</li> </ul>	
				System Selector test switch at SELF TEST	0V		
1J		○	Igniter (Trailing) Rear rotor	Ignition switch ON	0V	—	
				Idle	0.2–0.5V (Reference)		
				Oscilloscope			
			Engine speed: above 2500 rpm	0.5–0.8V (Reference)	Initial acceleration		
1K		○	Fuel pump relay (Speed)	Ignition switch ON	Below 1.0V	—	
				While cranking	Below 1.0V		
				Idle	Solenoid valve (PRC) does not operate		B+
					Solenoid valve (PRC) operates		Below 1.0V
1L		○	A/C relay	While cranking	B+	Air conditioning sensor, Blower switch ON	
				Idle	Below 1.0V		
				During acceleration (Running)	B+		
1M	○		Vehicle speed sensor	Ignition switch ON	0V or 4.0–5.0V	—	
				Driving	2.0–2.5V		
1N	○		Steering pressure sensor	P/S OFF at idle	B+	—	
				P/S ON at idle	Below 1.0V		
			Mileage switch	Over 20,000 miles {34,000 km}	Below 1.5V	Ignition switch ON after 2 seconds	
				Under 20,000 miles {34,000 km}	B+		
1O	○		Manifold absolute pressure sensor	Ignition switch ON	Approx. 2.6V	—	
				Idle	Approx. 1.5V 		
1P	—	—	—	—	—	—	

B+: Battery positive voltage

Incorrect condition	Possible cause
Always below 1.0V	Short circuit in wiring from data link connector terminal TEN to PCME terminal 1I
Always B+	<ul style="list-style-type: none"> <li>● Open circuit in wiring from data link connector terminal TEN to PCME terminal 1I</li> <li>● Open circuit in wiring from data link connector terminal GND to ground</li> </ul>
Always 0V	Refer to page F-16 (Ignition timing adjustment)
Always below 1.0V	Refer to Code No.51 Troubleshooting (Refer to page F-60)
Always B+	<ul style="list-style-type: none"> <li>● Poor connection at PCME connector</li> <li>● Fuel pump relay (speed) malfunction (Refer to page F-110)</li> <li>● PCME malfunction</li> </ul>
Always B+	<ul style="list-style-type: none"> <li>● A/C relay malfunction (Refer to page F-142)</li> <li>● Open circuit in wiring from ignition switch to A/C relay</li> <li>● Open circuit in wiring from A/C relay to PCME terminal 1L</li> </ul>
Always below 1.0V	<ul style="list-style-type: none"> <li>● Short circuit in wiring from A/C relay to PCME terminal 1L</li> <li>● A/C relay malfunction (Refer to page F-142)</li> </ul>
Always 0V	<ul style="list-style-type: none"> <li>● Open or short circuit in wiring from vehicle speed sensor to PCME terminal 1M</li> <li>● Vehicle speed sensor malfunction (Refer to section T)</li> </ul>
Always below 1.0V	<ul style="list-style-type: none"> <li>● Steering pressure sensor malfunction (Refer to page F-172)</li> <li>● Short circuit in wiring from steering pressure sensor to PCME terminal 1N</li> <li>● PCME malfunction</li> </ul>
Always B+	<ul style="list-style-type: none"> <li>● Steering pressure sensor malfunction (Refer to page F-172)</li> <li>● Open circuit in wiring from steering pressure sensor to PCME terminal 1N</li> <li>● Open circuit in wiring from steering pressure sensor to ground</li> </ul>
Always B+ under 20,000 miles	<ul style="list-style-type: none"> <li>● Mileage switch malfunction (Refer to page F-175)</li> <li>● PCME malfunction</li> </ul>
Always below 1.5V over 20,000 miles	<ul style="list-style-type: none"> <li>● Mileage switch malfunction (Refer to page F-175)</li> <li>● PCME malfunction</li> </ul>
Always 0V or 5V	Refer to Code No.13 Troubleshooting (Refer to page F-33)



B+: Battery positive voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
1Q	○		Clutch switch (MT)	Clutch pedal: released	B+	Ignition switch ON
				Clutch pedal: depressed	Below 1.0V	
			Powertrain control module (Transmission) (AT)	Idle	B+	Reduce torque signal
				When shifting from 1st to 2nd or from 2nd to 3rd with the throttle opening above 1.5/8	Below 1.0V	
				Idle	B+	Slip lock up signal
				When slip lockup with the throttle opening below 0.5/8	Below 1.0V	
1R	○		Neutral switch (MT)	Neutral	Below 1.0V	Ignition switch ON
				In gear	B+	
			Powertrain control module (Transmission) (AT)	Por N range	Below 1.0V	<ul style="list-style-type: none"> <li>● Park/Neutral signal</li> <li>● Ignition switch ON</li> </ul>
				Other	B+	
1S	○		Stoplight switch	Brake pedal released	Below 1.0V	Ignition switch ON
				Brake pedal depressed	B+	
1T		○	Fuel pump relay	Ignition switch ON	B+	—
				Idle	Below 1.0V	
1U	○		Fuel thermosensor	Idle (after warm up)	1.5–3.0V	—
1V	—	—	—	—	—	—
2A	—	—	—	—	—	—
2B		○	Data link connector (IG-terminal)	Ignition switch ON	0V	—
				Idle	0.3–0.8 (Reference)	
				Engine speed: 3,000 rpm	1.8–2.2V (Reference)	
2C		○	Powertrain control module (Transmission) (AT)	Idle	B+	Slip lock up OFF signal
				Engine speed: hold 3,000 rpm (after 8 seconds)	Below 1.0V	Initial acceleration
2D		○	Powertrain control module (Transmission) (AT)	Ignition switch ON	2–4.5V	Barometric absolute pressure signal
2E		○	Powertrain control module (Transmission) (AT)	Idle	Below 1.0V	Idle signal
				Other	Approx 5V	
2F	—	—	—	—	—	—
2G		○	Powertrain control module (Transmission) (AT)	Idle	B+	Torque reduced signal
				Throttle opening above 1/8 (Engine coolant temp. below 40°C {104°F})	Below 1.0V	
2H	—	—	—	—	—	—
2I	○		Heat Hazard Sensor	Ignition switch ON	Below 2.0V	—
				Idle (Temp.: Below 100°C {212°F})	B+	
				Idle (Temp.: Above 100°C {212°F})	Below 1.0V	
2J		○	A/P relay	Engine speed Idle-Below 3,250 rpm	Below 1.0V	—
				Engine speed above 3,250 rpm	B+	

B+: Battery positive voltage

Incorrect voltage	Possible cause
Always B+	<ul style="list-style-type: none"> <li>● Clutch switch malfunction (Refer to page F-173)</li> <li>● Open circuit in wiring from clutch switch to PCME terminal 1Q</li> </ul>
Always below 1.0V	<ul style="list-style-type: none"> <li>● Clutch switch malfunction (Refer to page F-173)</li> <li>● Short circuit in wiring from clutch switch to PCME terminal 1Q</li> </ul>
Always B+	<ul style="list-style-type: none"> <li>● Open circuit in wiring from PCME terminal 1Q to PCMT terminal 2P</li> </ul>
Always below 1.0V	<ul style="list-style-type: none"> <li>● Short circuit in wiring from PCME terminal 1Q to PCMT terminal 2P</li> </ul>
Always below 1.0V	<ul style="list-style-type: none"> <li>● Neutral switch malfunction (Refer to page F-172)</li> <li>● Short circuit in wiring from neutral switch to PCME terminal 1R</li> </ul>
Always B+	<ul style="list-style-type: none"> <li>● Neutral switch malfunction (Refer to page F-172)</li> <li>● Open circuit in wiring from neutral switch to PCME terminal 1R</li> </ul>
Always below 1.0V	<ul style="list-style-type: none"> <li>● Park/neutral switch malfunction (Refer to section K)</li> <li>● Short circuit in wiring from PCMT terminal 1C to PCME terminal 1R</li> </ul>
Always B+	<ul style="list-style-type: none"> <li>● Park/neutral switch malfunction (Refer to section K)</li> <li>● Open circuit in wiring from PCMT terminal 1C to PCME terminal 1R</li> </ul>
Always below 1.0V (Stoplight OK)	Open circuit in wiring from stoplight switch to PCME terminal 1S
Always below 1.0V or B+	<ul style="list-style-type: none"> <li>● Open or short circuit in wiring from fuel pump relay to PCME terminal 1T</li> <li>● Fuel pump relay malfunction (Refer to page F-174)</li> </ul>
Always Approx. 0V or approx 5V	Refer to Code No.23 Troubleshooting (Refer to page F-40)
—	—
—	—
Always 0V	<ul style="list-style-type: none"> <li>● Open circuit in wiring from data link connector IG-terminal to PCME terminal 2B</li> <li>● Crankshaft position sensor malfunction (Refer to page F-166)</li> <li>● PCME malfunction</li> </ul>
Always B+	Open circuit in wiring from PCMT terminal 2G to PCME terminal 2C
Always below 1.0V	Short circuit in wiring from PCMT terminal 2G to PCME terminal 2C
Always 0V or 4V	<ul style="list-style-type: none"> <li>● Refer to Code No.14 Troubleshooting (Refer to page F-34)</li> <li>● Open or short circuit in wiring from PCMT terminal 2C to PCME terminal 2D</li> </ul>
Always below 1.0V	Short circuit in wiring from PCMT terminal 2M to PCME terminal 2E
Always B+	Open circuit in wiring from PCMT terminal 2M to PCME terminal 2E
—	—
Always below 1.0V	Short circuit in wiring from PCMT terminal 2P to PCME terminal 2G
Always B+	Open circuit in wiring from PCMT terminal 2P to PCME terminal 2G
—	—
Always below 1.0V	<ul style="list-style-type: none"> <li>● Short circuit in wiring from heat hazard sensor to PCME terminal 2I</li> <li>● Heat hazard sensor malfunction (Refer to page F-175)</li> </ul>
Always B+	<ul style="list-style-type: none"> <li>● Open circuit in wiring from heat hazard sensor to PCME terminal 2I</li> <li>● Heat hazard sensor malfunction (Refer to page F-175)</li> </ul>
Always below 1.0V or B+	Refer to Code No.54 Troubleshooting (Refer to page F-61)

B+: Battery positive voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark	
2K	○		1-2 switch (MT)	1st and 2nd position	B+	Ignition switch ON	
				Other	Below 1.0V		
			PCMT	2nd or 3rd position	Below 1.0V	While running	
				Other	B+		
2L	○		1-2 switch (MT)	2nd position	Below 1.0V	Ignition switch ON	
				Other	B+		
			PCMT	3rd or O/D position	Below 1.0V	While running	
				Other	B+		
3A	○		Metering oil pump position sensor	Ignition switch ON	1.0-4.2V	Voltage increase when accelerating	
				Idle	Approx. 1.1V		
				Accelerator pedal depressed	1.1-4.2V		
3B	○		E/L unit	Headlight switch position I, II,	Below 4.0V	-	
				Blower motor position III, IV,			
				Rear defroster switch ON			
				Headlight switch, Blower motor, rear defroster switch are OFF	4.5-5.5V		
3C	○		Oxygen sensor	Driving	Cold engine	Approx 0V	-
					After warm up	0.0-1.0V	
				Oscilloscope		<p>VOLTAGE (V)</p> <p>0.5 s/div</p>	
				Acceleration (after warm up)	0.5-1.0V		
				Deceleration (after warm up)	0.0-0.4V		
3D		○	Coolant fan relay	Idle	Electrical coolant fan does not operating	B+	-
					During electrical coolant fan operating	Below 1.0V	
				TFA terminal of data link connector is grounded		Below 1.0V	Ignition switch ON
3E	○		Engine coolant temperature sensor	Engine coolant temperature 20°C {68°F}	Approx. 2.5V	Ignition switch ON	
				After warm up	Below 0.5V		
3F	○		Throttle position sensor (Narrow range)	Accelerator pedal released	0.75-1.25	<ul style="list-style-type: none"> <li>● Ignition switch ON</li> <li>● After warm-up</li> </ul>	
				Accelerator pedal fully depressed	4.8-5.0		
3G	○		Throttle position sensor (Full range)	Accelerator pedal released	0.1-0.7	<ul style="list-style-type: none"> <li>● Ignition switch ON</li> <li>● After warm-up</li> </ul>	
				Accelerator pedal fully depressed	4.2-4.6		
3H		○	Solenoid valve (purge control)	Ignition switch ON	B+	-	
				Idle			
				Engine speed: 1,500-3,300 rpm	4-10V	While running	



B+: Battery positive voltage

Incorrect voltage	Possible cause
Always below 1.0V	<ul style="list-style-type: none"> <li>● Short circuit in wiring from 1-2 switch to PCME terminal 2K</li> <li>● 1-2 switch malfunction (Refer to page F-173)</li> </ul>
Always B+	<ul style="list-style-type: none"> <li>● Open circuit in wiring from 1-2 switch to PCME terminal 2K</li> <li>● 1-2 switch malfunction (Refer to page F-173)</li> </ul>
Always below 1.0V	Short circuit in wiring from PCMT terminal 1D to PCME terminal 2K
Always B+	Open circuit in wiring from PCMT terminal 1D to PCME terminal 2K
Always below 1.0V	<ul style="list-style-type: none"> <li>● Short circuit in wiring from 1-2 switch to PCME terminal 2L</li> <li>● 1-2 switch malfunction (Refer to page F-173)</li> </ul>
Always B+	<ul style="list-style-type: none"> <li>● Open circuit in wiring from 1-2 switch to PCME terminal 2L</li> <li>● 1-2 switch malfunction (Refer to page F-173)</li> </ul>
Always below 1.0V	● Short circuit in wiring from PCMT terminal 1B to PCME terminal 2L
Always B+	● Open circuit in wiring from PCMT terminal 1B to PCME terminal 2L
Always approx 0V or approx 5V	Refer to Code No.27 Troubleshooting (Refer to page F-43)
Always below 1.0V	<ul style="list-style-type: none"> <li>● Short circuit in wiring from switches ~ E/L unit ~ PCME terminal 3B</li> <li>● Switches malfunction (Refer to section T)</li> </ul>
Always B+	<ul style="list-style-type: none"> <li>● Open circuit in wiring from switches ~ E/L unit ~ PCME terminal 3B</li> <li>● Switches malfunction (Refer to section T)</li> </ul>
0V after warm-up	Refer to Code No.15 Troubleshooting (Refer to page F-34)
Always approx. 1V after warm-up	Refer to Code No.17 Troubleshooting (Refer to page F-36)
Always below 1.0V or Always B+	<ul style="list-style-type: none"> <li>● Open or short circuit in wiring from coolant fan relay to PCME terminals 3D</li> <li>● Fan relay malfunction (Refer to page F-146)</li> <li>● PCME malfunction</li> </ul>
Always approx. 0V or approx. 5V	Refer to Code No.09 Troubleshooting (Refer to page F-30)
Always approx. 0V	Refer to Code No.12 Troubleshooting (Refer to page F-32)
Always approx. 5V	
Always approx. 0V	Refer to Code No.18 Troubleshooting (Refer to page F-38)
Always approx. 5V	
Always 0V or B+	Refer to Code No.40 Troubleshooting (Refer to page F-53)

# F

## CONTROL SYSTEM

B+: Battery positive voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark	
3I	○		Throttle position sensor	Constant	Approx. 5.0V	Ignition switch ON	
3J	○		EGR function sensor	EGR valve operates	B+	—	
				EGR valve does not operate	Below 1.0V		
3K		○	Solenoid valve (Relief2)	Ignition switch ON	B+	—	
				Idle	Before warm up approx. 40°C {104°F}		Below 1.0V
					After warm up		B+
3L	○		Intake air temperature sensor	Ambient air temperature 20°C {68°F}	Approx. 2.5V	Ignition switch ON	
				After warm up	Approx. 0.6V		
3M	○		Knock sensor	Ignition switch ON	Approx. 2.5V	—	
				Knocking occur (Tap the engine hanger with hammer)	2.6–2.8V (Reference)	Ignition switch ON (Measure the terminal voltage by using the digital type voltmeter)	
3N		○	Solenoid valve (Port air bypass)	Ignition switch ON	B+	—	
				After warm up Engine speed: 1,500–3,000 rpm	Below 1.0V	While running	
3O		○	Solenoid valve (Double throttle control)	Engine coolant temperature below 80°C {176°F}	Below 1.0V	Ignition switch ON	
				After warm up	B+		
3P		○	Secondary air bypass valve	Idle	B+	● After warm up	
				Engine speed: 3,250–3,750 rpm for 0.5 sec.	Below 1.0V		
4A	—	—	Ground (Output)	Constant	0V	—	
4B	—	—	Ground (Output)	Constant	0V	—	
4C	—	—	Ground (CPU)	Constant	0V	—	
4D	—	—	Ground (Input)	Constant	0V	—	
4E	○		Crankshaft position sensor [NE + signal]	Ignition switch ON	Below 1.0V	Engine signal monitor: Red lamp flash	
				Idle	Oscilloscope		
					Voltmeter		
4F		○	Solenoid valve (Split air bypass)	Idle	B+	● After warm up ● While running	
				5th position (MT) / OD (AT)	Below 1.0V		
4G	○		Crankshaft position sensor [G signal]	Ignition switch ON	Below 1.0V	—	
				Idle	Oscilloscope		
					Voltmeter		


B+: Battery positive voltage

Incorrect voltage	Possible cause
Always 0V	<ul style="list-style-type: none"> <li>● Short circuit in wiring from main relay to PCME terminal 3I</li> <li>● Main relay malfunction (Refer to page F-174)</li> </ul>
Always 0V or B+	<ul style="list-style-type: none"> <li>● EGR function sensor malfunction (Refer to page F-127)</li> <li>● Open or short circuit in wiring from EGR function sensor to PCME terminal 3J</li> </ul>
Always below 1.0V or B+	Refer to Code No.39 Troubleshooting (Refer to page F-52)
Always 0V or approx. 5V	Refer to Code No.11 Troubleshooting (Refer to page F-31)
Always 0V	Refer to Code No.05 Troubleshooting (Refer to page F-28)
Always below 1.0V or B+	Refer to Code No.33 Troubleshooting (Refer to page F-48)
Always below 1.0V or B+	Refer to Code No.50 Troubleshooting (Refer to page F-59)
Always below 1.0V or B+	Refer to Code No.31 Troubleshooting (Refer to page F-46)
Above 0V	<ul style="list-style-type: none"> <li>● Poor connection at ground terminal</li> <li>● Open circuit in wiring from PCME</li> </ul>
Always approx. 0V or approx. 5V	Refer to Code No.03 Troubleshooting (Refer to page F-27)
Always below 1.0V or B+	Refer to Code No.30 Troubleshooting (Refer to page F-45)
Always approx 0V or approx. 5V	Refer to Code No.02 Troubleshooting (Refer to page F-26)

# F

## CONTROL SYSTEM

B+: Battery positive voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
4H	○		Crankshaft position sensor	Constant	Below 1.0V	—
4I		○	Stepping motor (Metering oil pump)	Ignition switch ON	B+	
4J		Idle		3 terminals / 4 terminals B+ Other terminal 5-9V		
4K						
4L						
4M		○	Solenoid valve (Pressure regulator control)	Idle	B+	approx. 90 seconds
				Idle after hot start	Below 1.0V	
4N		○	Secondary air switching valve	Ignition switch ON/Idle	B+	Initial acceleration
				Engine speed: above 3,200 rpm (After warm up)	Below 1.0V	
4O		○	Solenoid valve (EGR)	Idle	B+	While running
				5th position (MT)/OD (AT)	Below 1.0V	
4P		○	Solenoid valve (AWS)	Before warm up approx. 40°C {104°F}	Below 1.0V	Idle
				After warm up	B+	
4Q		○	Idle air control valve (ISC)	Ignition switch ON	8.0-11.0V	Reference value ● Cranking 99% ● Idle 32-65% ● Initial set 38%
				Idle	5.0-11.0 (Reference) 5V/div Oscilloscope  20 msec/div	
4R		○	Solenoid valve (Turbo control)	Idle	B+	Initial acceleration
				Engine speed: above 5,500 rpm (MT)	Below 1.0V	
				Engine speed: above 5,250 rpm (AT)		
4S		○	Solenoid valve (Charge relief)	Idle	B+	Initial acceleration
				Engine speed: 4,000-5,500 rpm (MT) for 4-8 sec. 3,500-5,000 (AT) for 4-8 sec.	Below 1.0V	
				Engine speed: above 5,500 rpm (MT) above 5,250 rpm (AT)		
4T		○	Solenoid valve (Charge control)	Idle	Below 1.0V	Initial acceleration
				Engine speed: above 5,500 rpm (MT)	B+	
				Engine speed: above 5,250 rpm (AT)		
4U		○	Solenoid valve (Wastegate control)	Ignition switch ON	B+	Reference value ● Idle 5% ● Solenoid valve (Turbo control) before operates 95%
				Idle	B+	
				Initial acceleration	5.0-11.0 V	
4V		○	Solenoid valve (Turbo precontrol)	Ignition switch ON	B+	Reference value ● Idle 5% ● Solenoid valve (Turbo control) after operates 5%
				Idle	B+	
				Initial acceleration	5.0-11.0 V	
				Engine speed: above 3,000 rpm	4.0-10.0V (Reference)	Initial acceleration

# CONTROL SYSTEM

# F

B+: Battery positive voltage


Incorrect voltage	Possible cause
Always above 1.0V	Refer to Code No.02 Troubleshooting (Refer to page F-26)
Always 0V or B+	Refer to Code No.26 Troubleshooting (Refer to page F-42)
Always below 1.0V or B+	Refer to Code No.25 Troubleshooting (Refer to page F-41)
Always below 1.0V or B+	Refer to Code No.32 Troubleshooting (Refer to page F-47)
Always below 1.0V or B+	Refer to Code No.28 Troubleshooting (Refer to page P-44)
Always below 1.0V or B+	Refer to Code No.38 Troubleshooting (Refer to page F-51)
Always below 1.0V or B+	Refer to Code No. 34 Troubleshooting (Refer to page F-49)
Always below 1.0V or B+	Refer to Code No.44 Troubleshooting (Refer to page F-56)
Always below 1.0V or B+	Refer to Code No.46 Troubleshooting (Refer to page F-58)
Always below 1.0V or B+	Refer to Code No.45 Troubleshooting (Refer to page F-57)
Always below 1.0V or B+	Refer to Code No.43 Troubleshooting (Refer to page F-55)
Always below 1.0V or B+	Refer to Code No.42 Troubleshooting (Refer to page F-54)



# F

## CONTROL SYSTEM

B+: Battery positive voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
4W		○	Injector (Front primary)	Ignition switch ON idle*  Oscilloscope	B+ 12-14V 	<ul style="list-style-type: none"> <li>• Secondary injector not working at no load condition</li> <li>* Engine Signal Monitor: Green lamp flash</li> </ul>
4X		○	Injector (Front secondary)			
4Y		○	Injector (Rear primary)			
4Z		○	Injector (Rear secondary)			

### PCME Connector (PCME Side)


4Y	4W	4U	4S	4Q	4O	4M	4K	4I	4G	4E	4C	4A	3O	3M	3K	3I	3G	3E	3C	3A	2K	2I	2G	2E	2C	2A	U	S	Q	O	M	K	I	G	E	C	A
4Z	4X	4V	4T	4R	4P	4N	4L	4J	4H	4F	4D	4B	3P	3N	3L	3J	3H	3F	3D	3B	2L	2J	2H	2F	2D	2B	V	T	R	P	N	L	J	H	F	D	B

<b>Incorrect voltage</b>	<b>Possible cause</b>
Always 0V	<ul style="list-style-type: none"><li>● Open or short circuit in wiring from injector to PCME terminal 4W, 4X, 4Y, or 4Z</li><li>● Main relay malfunction (Refer to page F-174)</li><li>● Refer to Code No.71, 73 (Refer to page F-62, 63) troubleshooting</li></ul>


### CRANKSHAFT POSITION SENSOR

#### Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation Note**.



- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. Battery cable</li> <li>2. Drive belt</li> <li>3. Eccentric shaft pulley</li> <li>4. Crankshaft position sensor plate</li> <li>5. Bracket</li> </ol> | <ol style="list-style-type: none"> <li>6. Connectors</li> <li>7. Crankshaft position sensor (NE-signal)<br/>Inspection ..... below</li> <li>8. Crankshaft position sensor (G-signal)<br/>Inspection ..... below</li> </ol> |
|---|--|




#### Inspection

1. Remove the crankshaft position sensor.
2. Measure the resistance of the sensor.

**Resistance: 0.95–1.25 kΩ (20°C [68°F])**



3. If not as specified, replace the crankshaft position sensor.



#### Installation Note

Measure the crankshaft position sensor to crankshaft position sensor plate clearance by using feeler gauge.

**Clearance: 1.0–2.0 mm (0.039–0.078 in)**

**MANIFOLD ABSOLUTE PRESSURE SENSOR****Inspection**

1. Warm up the engine to normal operating temperature and run it at idle.
2. Turn all electrical load off.
3. Connect a voltmeter between the manifold absolute pressure sensor terminal A and B and verify that the voltage is within specification.

**Voltage: 1.3–1.6V**


4. Disconnect vacuum tube and plug the vacuum tube and verify that the voltage is within specification.

**Voltage: 2.38–2.78V**

5. Connect a vacuum pump to the manifold absolute pressure sensor.
6. Apply vacuum and measure the voltage of the manifold absolute pressure sensor.

Vacuum	Voltage
-66 kPa (-500 mmHg-19.7 inHg) (Vacuum)	1.25–1.55V
0 kPa (0 mmHg, 0 inHg)	2.38–2.78V
98.7 kPa (740 mmHg, 29.1 inHg) (Pressure)	4.35–4.65V


7. If not as specified, replace the manifold absolute pressure sensor.
8. Cancel the memory of malfunctions by disconnecting the negative battery cable for at least 20 seconds and depress brake pedal.
9. Reconnect the negative battery cable.



**THROTTLE POSITION SENSOR**

**Inspection**


1. Warm up the engine to normal operating temperature and run it at idle.
2. Verify the first idle cam separates.
3. Stop the engine.
4. Connect the SSTs (Engine Signal Monitor and Adaptor Harness) to PCME.
5. Turn the ignition switch to ON.
6. Rotate the throttle link by hand verify that the voltage is within specification.



**Specification**

PCME Terminal	Throttle valve condition		
	Closed throttle position	closed to open	Wide open throttle
3F (Narrow range)	0.75-1.25V	1.0-5.0V	4.8-5.0V
3G (Full range)	0.1-0.7V	0.4-4.3V	4.2-4.6V

7. If not as specified, adjust or replace the throttle position sensor.




**Adjustment**


1. Warm up the engine to normal operating temperature and run it idle.
2. Verify that the first idle cam separates.
3. Stop the engine.
4. Connect the SSTs (Engine Signal Monitor and Adaptor Harness) to PCME.
5. Turn the ignition switch to ON.
6. Loosen the screws and rotate the throttle position sensor to set the correct closed position voltage. (Refer to "Specification" above)
7. Check the correct open position voltage and close to open voltage. (Refer to "Specification" above)
9. Tighten the screws.

**Tightening Torque**


1.6-2.4 N·m {16-24 kgf·cm, 140-210 in·lbf}



10. Cancel the memory of malfunctions by disconnecting the negative battery cable for at least 20 seconds and depress the brake pedal.
11. Reconnect the negative battery cable.

**Removal / Installation**

1. Turn ignition switch to OFF.
2. Disconnect the throttle position sensor connector.
3. Remove the throttle position sensor.
4. Install the throttle position sensor.
5. Adjust the throttle position sensor. (Refer to page F-168.)

**ENGINE COOLANT TEMPERATURE SENSOR****Removal / Installation****Warning**

- Removing the engine coolant temperature sensor while the engine hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. Turn off the engine and wait until it is cool. Even then, be very careful when removing the engine coolant temperature sensor.

1. Remove the extension manifold. (Refer to page F-76.)
2. Disconnect engine coolant temperature sensor connector.
3. Remove the engine coolant temperature sensor.
4. Install a new gasket and install in the reverse order of removal.

**Tightening torque:**


20–24 N·m {2.0–2.5 kgf·m, 15–18 ft·lbf}

**Inspection**

1. Place the engine coolant temperature sensor in water with a thermometer and heat the water gradually.
2. Measure the resistance of the sensor with an ohmmeter.

Water temperature	Resistance
20°C {68°F}	2.2–2.7 kΩ
80°C {176°F}	0.29–0.35 kΩ

3. Replace the sensor, if necessary.

**INTAKE AIR TEMPERATURE SENSOR****Removal / Installation**

1. Remove the extension manifold. (Refer to page F-76.)
2. Remove the intake air temperature sensor from extension manifold.
3. Install the intake air temperature sensor.

**Tightening torque:**



7.9–11.7 N·m {80–120 kgf·cm, 70–104 in·lbf}






**Inspection**

1. Remove the intake air temperature sensor and heat the sensor as shown in the figure.
2. Measure the resistance of the sensor with an ohmmeter.

Temperature	Resistance
20°C {68°F}	2.2–2.7 kΩ
80°C {176°F}	0.29–0.35 kΩ

3. Replace the sensor, if necessary.





**FUEL THERMOSENSOR  
Removal / Installation**

**Warning**

- Fuel line spills and leaks can be dangerous. Fuel can ignite and cause serious injuries or death and can damage the vehicle. Fuel can also irritate skin and eyes. To prevent this from happening, release the fuel pressure according to "Fuel Line Safety Procedures" on page F-95.

1. Remove the intake air system component parts. (Refer to page F-76.)
2. Disconnect the fuel thermosensor connector.
3. Remove the fuel thermosensor.
4. Install in the reverse order of removal.

**Tightening torque:**

**20-24 N·m {2.0-2.5 kgf·m, 15-18 ft·lbf}**

**Inspection**

1. Place the fuel thermosensor in water with a thermometer and heat the water gradually.
2. Measure the resistance of the sensor with an ohmmeter.

Water temperature	Resistance
20°C {68°F}	2.2-2.7 kΩ
80°C {176°F}	0.29-0.35 kΩ

3. Replace the sensor, if necessary.


**OXYGEN SENSOR**

**Inspection of Terminal Voltage.**

1. Warm up the engine to normal operating temperature and run it at idle.
2. Disconnect the oxygen sensor connector.
3. Connect a high internal resistance voltmeter (more than 40 kΩ) between the oxygen sensor terminal and ground.
4. Measure the voltage while increasing and decreasing the engine speed suddenly several times.


**Specification**

Engine condition	Voltage
While decelerating	0.0-0.4V
While accelerating	0.5-1.0V




### KNOCK SENSOR Inspection (On vehicle)

1. Connect a voltmeter  $\ominus$  terminal to the MEN terminal of the data link connector
2. Connect the data link connector terminals TEN and GND by using a jumper wire.
3. Turn the ignition switch to ON.




4. Lightly tap the engine hanger with a hammer.
5. Verify that the voltmeter indicator moves.
6. Turn the ignition switch to OFF.



### Self-Diagnosis Checker

1. Connect the SSTs (System Selector and Self-Diagnosis Checker) to data link connector.
2. Set switch A to position of Self-Diagnosis Checker.
3. Set SYSTEM SELECT position 1 and TEST SW to SELF-TEST of System Selector.
4. Turn the ignition switch to ON.
5. Lightly tap the engine hanger with a hammer.
6. Verify that the monitor lamp illuminates for approx. 0.5 seconds.
7. Turn the ignition switch to OFF.




### Removal / Installation

1. Disconnect knock sensor connector.
2. Remove the knock sensor.
3. Install in the reverse order of removal.

### Tightning Torque:

20–34 N·m {2.0–3.5 kgf·m, 14–25 ft·lbf}






**STEERING PRESSURE SENSOR**

**Inspection (On the vehicle)**

1. Disconnect the steering pressure sensor connector.
2. Start the engine, and check continuity of the switch.


Steering wheel	Continuity
Turned	Yes
Straight ahead	No



3. Replace the steering pressure sensor if not as specified.

**Removal / Installation**

Refer to section N.




**STOPLIGHT SWITCH**

**Inspection**

1. Disconnect the stoplight switch connector.
2. Connect a circuit tester between the stoplight switch terminals C and D.
3. Check the continuity of the switch.

Pedal	Continuity
Depressed	Yes
Released	No




**Removal / Installation**

1. Disconnect the stoplight switch connector.
2. Remove the stoplight switch.
3. Install the stoplight switch.
4. Connect a circuit tester between the stoplight switch terminals C and D, and verify that the continuity when the brake pedal depressed and no continuity when the brake pedal released.
5. Tighten the adjust nut.

**Tightening Torque:**

14-18 N·m {1.4-1.8 kgf·m, 10-13 ft·lbf}




**NEUTRAL SWITCH (MT)**

**Inspection**

1. Disconnect the neutral switch connector.
2. Connect a circuit tester to the switch.
3. Check the continuity.

Transmission	Continuity
In neutral	Yes
In other ranges	No




**Removal / Installation**

1. Remove the power plant frame (Refer to section J-MT Refer to section K-AT)
2. Disconnect the neutral switch connector.
3. Remove the neutral switch.
4. Install in the reverse order of removal.

**Tightening Torque:**

25-34 N·m {2.5-3.5 kgf·m, 18-25 ft·lbf}




**CLUTCH SWITCH (MT)**

**Inspection**

1. Disconnect the clutch switch connector.
2. Connect a circuit tester to the switch.
3. Check the continuity.

Pedal	Continuity
Depressed	Yes
Released	No




**Removal / Installation**

1. Remove the power plant frame (Refer to section J-MT Refer to section K-AT)
2. Remove the clutch switch.
3. Install the clutch switch.
4. Connect a circuit tester to the switch and verify that the continuity when the clutch pedal depressed and no continuity when the clutch pedal released.
5. Tighten the adjust nut.

**Tightening torque:**

14-18 N·m {1.4-1.8 kgf·m 10-13 ft·lbf}




**1-2 SWITCH (MT)**

**Inspection**

1. Disconnect 1-2 switch.
2. Connect a circuit tester to the switch.
3. Check the continuity.

Terminal	Transmission	Continuity
A-B	In 1st and 2nd range	No
	In other range	Yes
C-D	In 2nd	Yes
	In other range	No




**Removal / Installation**

1. Remove the extension housing. (Refer to section J.)
2. Remove the 1-2 switch.
3. Install in the reverse order of removal.

**Tightening torque:**


25-34 N·m {2.5-3.5 kgf·m, 18-25 ft·lbf}



### MAIN RELAY (EGI RELAY)

#### Inspection (On vehicle)

Check that a "clicking" sound is heard at the main relay when turning the ignition switch OFF and ON.




#### Inspection

1. Disconnect the main relay.
2. Apply battery positive voltage and ground to terminals A and B of the main relay.
3. Check continuity of the relay.

B+: Battery positive voltage


Operation	C-D terminals
B+ Applied	Continuity
B+ Not applied	No continuity



### FUEL PUMP RELAY

#### Inspection (On vehicle)

Check that a "clicking" sound is heard at the fuel pump relay, when turning the ignition switch OFF and ON.







#### Inspection

1. Disconnect the fuel pump relay.
2. Apply battery positive voltage and ground to terminals A and B of the fuel pump relay.
3. Check continuity of the relay.

B+: Battery positive voltage

Operation	C-D terminals
B+ applied	Continuity
B+ Not applied	No continuity



**HEAT HAZARD SENSOR  
Inspection (Warning system)**

1. Turn the ignition switch to ON and verify that the heat hazard warning light illuminates.
2. Start the engine and verify that the warning lamp goes out.

3. Disconnect the heat hazard sensor connector.
4. Check that the heat hazard warning light illuminates on when a jumper wire is connected to the terminals of the sensor connector (harness side).

**Removal**

1. Remove the right front seat.
2. Lift up the floor mat.
3. Disconnect the heat hazard sensor connector and remove the sensor.

**Installation**

Install in the reverse order of removal.

**Inspection**

1. Wrap the sensor and a thermometer in aluminum foil and place them in a container of oil.
2. Connect a test lamp and battery positive voltage to the terminals of the sensor connector.
3. Gradually heat the oil.
4. Verify that the test lamp comes on when the temperature in the aluminum foil reaches 95–105°C {203–221°F}.
5. Replace the sensor if necessary.

**MILEAGE SWITCH**

**Inspection**


1. Connect the SST (Engine Signal Monitor) to the PCME.
2. Turn the ignition switch to ON.
3. Measure the voltage at PCME terminal 1N within the first two seconds after the ignition switch is turned to ON.

B+: Battery positive voltage

Under 20,000 miles	B+
Over 20,000 miles	Below 1.5V


### SOLENOID VALVES Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Battery cable
2. Pressure chamber
3. Accelerator cable  
removal / installation ..... page F-80  
Inspection / adjustment ..... page F-80
4. Water hose
5. Vacuum hoses

6. Connector
7. Extension manifold
8. Solenoid valves  
Inspection ..... page F-177




**Inspection**

1. Disconnect the connector.
2. Connect a circuit tester to the solenoid valve.
3. Check the continuity at the terminals.



4. Verify that air flows between each ports as below.

Port	Air flow
A-B	No
A-C	No
B-C	Yes



5. Connect battery positive voltage and a ground to the terminals of the solenoid valve.

6. Verify that air flows between each ports as below.

Port	Air flow
A-B	Yes
A-C	No
B-C	No

7. Replace the solenoid valve, if necessary.

### TROUBLESHOOTING GUIDE

#### QUICK DIAGNOSIS CHART

This Quick Diagnosis Chart shows the relationship between troubleshooting items and inspection points.

Item	Possible parts and reference pag	Intake air system		Fuel system						Ignition system			Turbo charger system		Secondary air Injection system			Emission system																							
		F-16	F-83	F-83	F-137	F-79	F-76	F-105	F-105	F-103	F-100	F-110	F-109	F-110	F-104	F-112	Section G	Section G	Section G	F-16	F-93	F-93	F-93	F-93	F-123	F-119	F-119	F-119	F-123	F-121	F-121	F-123	F-128	F-131	F-131	F-127					
		Air cleaner element	Idle air control valve	Solenoid valve (AWS)	Solenoid valve (Double throttle)	Fast idle cam	Intake air leakage	Injector (Primary)	Injector (Secondary)	Fuel filter	Fuel pump	Fuel pump relay (speed)	Fuel pump resistor	Fuel pump relay	Pressure regulator	Solenoid valve (PRC)	Igniter	Ignition coil	Spark plug	Ignition timing	Turbo precontrol	Wastegate control	Turbo precontrol	Charge control	Charge relief	Secondary air bypass valve	Secondary air switching valve	Split air bypass	Port air bypass	Relief 2	Air pump	Air pump relay	Three-way catalyst	Charcoal canister	Solenoid valve (Purge control)	Solenoid valve (EGR)					
1	Melts main or other fuse																																								
2	Will not crank or cranks slowly																																								
3	Crank normally but will not start	No combustion																																							
4		Partial combustion-when engine cold																																							
5		Partial combustion-after warm-up																																							
7	Crank normally but hard to start	Any engine temp.																																							
8		When engine cold																																							
9		After warm-up																																							
10	Engine stalls	Idle at any engine temp.																																							
11		During fast idle																																							
12		Idle after warm-up																																							
13		Idle with A/C, P/S, and/or E/L ON																																							
14		Idle when shifted from N or P to other ranges																																							
15		Driveaway																																							
16		On acceleration																																							
17		While cruising																																							
18	On deceleration																																								
19	Engine rough	Idle at any engine temp																																							
20		During fast idle																																							
21		Idle after warm-up																																							
22		Idle with A/C, P/S, and/or E/L ON																																							
23		Idle when shifted from N or P to other ranges																																							
24	On deceleration																																								
25	Poor acceleration	Driveaway																																							
26		On acceleration																																							
27	High idle speed after warm-up																																								





TROUBLESHOOTING GUIDE

Item	Possible parts and reference pag	Intake air system		Fuel system						Ignition system			Turbo charger system				Secondary air Injection system			Emission system																			
		F-16	F-83	F-83	F-83	F-137	F-79	F-76	F-105	F-105	F-103	F-100	F-110	F-109	F-110	F-104	F-112	Section G	Section G	Section G	F-16	F-93	F-93	F-93	F-93	F-123	F-123	F-119	F-119	F-119	F-123	F-121	F-123	F-128	F-131	F-131	F-127		
		Air cleaner element	Idle air control valve	Solenoid valve (AWS)	Solenoid valve (Double throttle)	Fast idle cam	Intake air leakage	Injector (Primary)	Injector (Secondary)	Fuel filter	Fuel pump	Fuel pump relay (speed)	Fuel pump resistor	Fuel pump relay	Pressure regulator	Solenoid valve (PRC)	Igniter	Ignition coil	Spark plug	Ignition timing	Turbo precontrol	Wastegate control	Turbo precontrol	Charge control	Charge relief	Secondary air bypass valve	Secondary air switching valve	Split air bypass	Port air bypass	Relief 2	Air pump	Air pump relay	Three-way catalyst	Charcoal canister	Solenoid valve (Purge control)	Solenoid valve (EGR)			
28	Idle fluctuates / idle hunts		<input type="radio"/>					<input type="radio"/>											<input type="radio"/>																				
29	Hesitates / Stumbles on acceleration		<input type="radio"/>		<input type="radio"/>				<input type="radio"/>			<input type="radio"/>							<input type="radio"/>				<input type="radio"/>	<input type="radio"/>															
30	Surges while cruising								<input type="radio"/>										<input type="radio"/>																				
31	Lack of power		<input type="radio"/>						<input type="radio"/>		<input type="radio"/>								<input type="radio"/>				<input type="radio"/>	<input type="radio"/>															
32	Poor fuel economy		<input type="radio"/>					<input type="radio"/>											<input type="radio"/>																				
33	A/C does not work																																						
34	Knocking / Pinging							<input type="radio"/>	<input type="radio"/>										<input type="radio"/>																			<input type="radio"/>	
35	Fuel odor																																						
36	Exhaust sulfur smell									<input type="radio"/>																													
37	High oil consumption																																						
38	Self-Diagnosis Checker flashes 88																																						
39	Self-Diagnosis Checker will not work																																						

# TROUBLESHOOTING GUIDE

F

DECIL- ERA- TION system	CONTROL SYSTEM (INPUT SIGNAL)	OTHERS	Possible parts and reference page
F-134	Dashboard		
F-77	Air bypass valve		
F-166	Crankshaft position sensor (NE)		
F-166	Crankshaft position sensor (G)		
F-169	Engine coolant temperature sensor		
F-169	Intake air temperature sensor		
F-170	Fuel thermosensor		
F-167	Manifold absolute pressure sensor		
F-168	Narrow range Throttle position sensor		
F-168	Full range sensor		
F-170	Oxygen sensor		
F-171	Knock sensor		
Section T	Vehicle speed sensor		
Section D	Metering oil pump position sensor		
F-172	P/S manifold absolute pressure sensor		
Section U	Air conditioning sensor		
Section E	Water thermoswitch		
F-172	Stoplight switch		
F-175	Mileage switch		
F-173	Heat hazard sensor		
F-162	Starter signal		
F-134	E/L unit		
F-173	1-2 switch (MT)		
F-172	Neutral switch (MT)		
F-173	Clutch switch (MT)		
Section K	Solenoid valve (Shift A) (AT)		
Section K	Solenoid valve (Shift B) (AT)		
Section K	Reduce torque signal (AT)		
Section K	Slip lock-up signal (AT)		
Section K	Park / neutral signal (AT)		
Section E	Electrical coolant fan		
Section D	Metering oil pump		
F-143	A/C relay		
Section C	Compression down		
F-150	PCME		
			<b>Item</b>
			Idle fluctuates / idle hunts 28
			Hesitates / Stumbles on acceleration 29
			Surges while cruising 30
			Lack of power 31
			Poor fuel economy 32
			A/C does not work 33
			Knocking / Pinging 34
			Fuel odor 35
			Exhaust sulfur smell 36
			High oil consumption 37
			Self-Diagnosis Checker flashes 88 38
			Self-Diagnosis Checker will not work 39

### RELATIONSHIP CHART

INPUT DEVICE		SOLENOID VALVE																										
		FUEL INJECTION AMOUNT	FUEL INJECTION TIMING	FUEL PUMP RELAY	FUEL PUMP RELAY (SPEED)	IGNITER	IDLE AIR CONTROL	ACCELERATED WARM-UP	DOUBLE THROTTLE CONTROL	PRESSURE REGULATOR CONTROL	TURBO PRECONTROL	WASTEGATE CONTROL	TURBO CONTROL	CHARGE CONTROL	CHARGE RELIEF	SECONDARY AIR BYPASS	SECONDARY AIR SWITCHING	SPLIT AIR BYPASS	PORT AIR BYPASS	RELIEF <sup>2</sup>	PURGE CONTROL	EGR	POWERTRAIN CONTROL MODULE (TRANSMISSION)	METERING OIL PUMP	A/C RELAY	AIR PUMP RELAY	TROUBLE CODE	MONITOR LAMP
CRANKSHAFT POSITION SENSOR	NE SIGNAL	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	G SIGNAL		○			○																						○
THROTTLE POSITION SENSOR	NARROW RANGE	○				○	○		○							○	○	○	○	○	○	○	○				○	○
	FULL RANGE	○	○				○	○			○	○	○	○	○							○				○	○	○
ENGINE COOLANT TEMPERATURE SENSOR		○				○	○	○		○	○					○	○	○	○	○	○	○				○	○	○
INTAKE AIR TEMPERATURE SENSOR		○				○	○																					○
FUEL THERMOSENSOR		○			○	○	○		○												○						○	○
MANIFOLD ABSOLUTE PRESSURE SENSOR		○			○	○	○			○	○	○	○	○	○	○	○	○	○	○	○	○		○		○	○	○
OXYGEN SENSOR		○															○		○	○	○	○					○	○
KNOCK SENSOR						○																					○	○
VEHICLE SPEED SENSOR							○																				○	○
MOP POSITION SENSOR																								○			○	○
E/L UNIT							○	○																				○
AIR CONDITIONING SENSOR		○				○	○																					○
STEERING PRESSURE SENSOR		○				○	○																					○
IGNITION SWITCH (ST SIGNAL)		○		○	○	○	○	○		○			○					○								○	○	○
STOPLIGHT SWITCH							○																					○
NEUTRAL SWITCH (MT)		○				○	○	○		○	○	○	○	○	○	○	○	○	○	○	○	○				○	○	○
CLUTCH SWITCH (MT)		○				○	○	○		○	○	○	○	○	○	○	○	○	○	○	○	○				○	○	○
1-2 SWITCH (MT)										○	○	○	○	○	○											○		○
EGR FUNCTION SENSOR																						○					○	○
MILEAGE SWITCH																○		○	○	○								○
HEAT HAZARD SENSOR																											○	○
SOLENOID VALVE SIGNAL (AT)	SHIFT A					○		○		○	○	○	○	○	○		○	○					○			○	○	○
	SHIFT B					○		○		○	○	○	○	○	○		○	○					○			○	○	○
REDUCE TORQUE SIGNAL (AT)						○																		○				○
SLIP LOCK-UP SIGNAL (AT)						○																			○			○
PARK / NEUTRAL SIGNAL (AT)		○				○	○	○		○	○	○	○	○	○	○	○	○	○	○	○	○				○	○	○
DATA LINK CONNECTOR (TEN-TERMINAL)		○					○																				○	○
BAROMETRIC ABSOLUTE PRESSURE SENSOR (IN PCME)		○				○	○			○	○	○	○	○	○	○	○	○	○	○	○	○					○	○

Output devices and Engine condition

ENGINE CONDITION		CRANKING (COLD ENGINE)	WARMING UP (DURING IDLE)	MEDIUM LOAD		ACCELERATION	HEVY LOAD	DECELERATION	IDLE	IG: ON (ENGINE NOT RUNNING)	REMARK	
				COLD	WARM							
OUTPUT DEVICE												
INJECTOR	FUEL INJECTION AMOUNT	Rich		Normal		Rich		FUEL CUT	Rich	No Injection		
	Primary	Operate						Not operate	Operate			
	Secondary	Not operate			Operate		Not operate					
FUEL PUMP RELAY		ON								OFF		
FUEL PUMP REAY (SPEED)		OFF (Low speed)			ON (High speed)		OFF (Low speed)					
IGNITER		Fixed at BTDC 5°	Advanced: depends on engine condition					Fixed at ATDC 5° (L) ATDC 20° (T)	—			
SOLENOID VALVE	ACELERATED WARM-UP (AWS)	ON		OFF								
	IDLE AIR CONTROL (IAC)	ON (Feedback duty)		ON (Fixed duty)				ON (Feedback duty)				
	DOUBLE THROTTLE CONTROL	ON (Closed)		OFF (Open)	ON (AT onry)	OFF (Open)						
	TURBO PRE-CONTROL	OFF (Closed)		Depends on engine condition				OFF (Closed)				
	WASTEGATE CONTROL	OFF (Closed)			Depends on engine condition		OFF (Closed)					
	TURBO CONTOROL	OFF (Closed)			ON (Open)		OFF (Closed)					
	CHARGE CONTROL	ON (Closed)			OFF (Open)		ON (Closed)					
	CHARGE RELIEF CONTROL	OFF (Open)			ON (Closed)		OFF (Closed)					
	SECONDARY AIR BYPASS	OFF (Closed)		ON (Open)	OFF (Closed)							
	SECONDARY AIR SWITCHING	OFF (Port)		ON (Split)		OFF (Port)						
	SPLIT AIR BYPASS	OFF (Closed)		ON (Open)		OFF (Closed)						
	PORT AIR BYPASS	OFF (Closed)		ON (Open)		OFF (Closed)						
	RELIEF 2	ON (Open)		OFF (Closed)								
	PRESSURE REGULATOR CONTROL (PRC)	OFF (Vacuum to pressure regulator)							ON*	OFF	* During hot start only	
	PURGE CONTROL (PURGE)	OFF			ON (Purge)	OFF						
	EXHAUST GAS RECIRCULATION (EGR)	OFF (EGR Cut)			ON* (EGR)	OFF (EGR Cut)					* Engine speed: 1,700-3,850 rpm	
	A/C RELAY	OFF (A/C cut)	ON			OFF (A/C cut)	ON					
COOLANT FAN RELAY	OFF			Depends on engine coolant temperature								
METERING OIL PUMP (MOP)	OFF	ON							OFF			

# F


## TROUBLESHOOTING GUIDE

### USING THIS SECTION

#### Introduction

Most of the fuel and emission control systems are electronically controlled, often making it difficult to diagnose problems, especially intermittent problems. Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a drivability complaint. The customer is often a good source of information on such problems, especially the intermittent ones. Through a talk with the customer, you will usually find out what the symptoms are and under what conditions they occur.

#### Work flow



#### Diagnostic index

**DESCRIPTION:**  
Describes each troubleshooting item.

F TROUBLESHOOTING GUIDE			
DIAGNOSTIC INDEX			
No.	TROUBLESHOOTING ITEM		DESCRIPTION
No.	TROUBLE		
1	Melts main or other fuse		Starter does not work
2	Will not crank or cranks slowly		Starter cranks engine at slow speed
3	Canks normally but will not start	No combustion	Starter cranks engine at normal speed but engine shows no indication of firing
4		Partial combustion - when engine cold	Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is cold or at initial starting Engine will not continue running when cold when ignition switch is returned from STA to IG position
5		Partial combustion - when warm-up	Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is warm Engine will not continue running when warm when IGN switch is returned from STA to IG position
6	Will start in other than P and N ranges		Engine starts in P, N and other ranges
7	Canks normally but hard to start	Any engine temp.	Starter cranks engine at normal speed but engine requires excessive cranking time before starting at any engine temperature Engine starts after stalling a few times at any engine temperature
8		When engine cold	Starter cranks engine at normal speed but engine requires excessive cranking time before starting when engine is cold Engine starts after stalling a few times when engine is cold
9		After warm-up	Starter cranks engine at normal speed but engine requires excessive cranking time before starting after warm-up
10	Engine stalls		Engine stalls at any engine temp.
11			Engine stalls during operation

**No.:**  
Each troubleshooting item is assigned a number.

**PAGE:**  
Shows the reference page or section

**TROUBLESHOOTING ITEM:**  
There are 58 troubleshooting items. Choose the item that most closely corresponds to the actual symptom.

Troubleshooting chart

7, 8, 9	CRANKS NORMALLY BUT HARD TO START		<ul style="list-style-type: none"> <li>• ANY ENGINE TEMPERATURE</li> <li>• WHEN ENGINE COLD</li> <li>• AFTER WARM-UP</li> </ul>
DESCRIP-TION	<ul style="list-style-type: none"> <li>• Starter cranks engine at normal speed but engine requires excessive cranking time before starting</li> <li>• Engine starts after stalling a few times</li> <li>• Battery in normal condition</li> <li>• Engine runs normally at idle (if idle condition not OK, refer to "Engine rough" [Nos. 19, 20, 21, 22, or 23])</li> </ul>		
[TROUBLESHOOTING HINTS]			
<ul style="list-style-type: none"> <li>① Injector                             <ul style="list-style-type: none"> <li>• Fuel leakage from injector(s)</li> </ul> </li> <li>② Fuel pump                             <ul style="list-style-type: none"> <li>• Poor connection of pump connector</li> <li>• Poor connection of fuel pump relay connector</li> </ul> </li> <li>③ Pressure regulator                             <ul style="list-style-type: none"> <li>• Malfunction of pressure regulator</li> </ul> </li> <li>④ Fast idle cam                             <ul style="list-style-type: none"> <li>• Malfunction of fast idle cam (when engine cold)</li> </ul> </li> <li>⑤ Spark plug                             <ul style="list-style-type: none"> <li>• Dirty or worn spark plug(s)</li> </ul> </li> </ul>		<ul style="list-style-type: none"> <li>⑥ Intake air system                             <ul style="list-style-type: none"> <li>• Air leakage</li> </ul> </li> <li>⑦ Engine coolant temperature sensor                             <ul style="list-style-type: none"> <li>• Poor connection of engine coolant temperature sensor</li> <li>• Malfunction of engine coolant temperature sensor</li> </ul> </li> <li>⑧ Solenoid valve (Purge control)                             <ul style="list-style-type: none"> <li>• Air leakage</li> </ul> </li> <li>⑨ Metering oil pump                             <ul style="list-style-type: none"> <li>• Malfunction of pump</li> </ul> </li> <li>⑩ Crankshaft position sensor                             <ul style="list-style-type: none"> <li>• Ground circuit open</li> </ul> </li> </ul>	
STEP	INSPECTION		ACTION
1	Is "00" displayed on SST with ignition switch ON? → page F-20	Yes "00" displayed Go to next step	No Trouble Code No. displayed Check for cause (Refer to specified check sequence)
2	Is air leakage felt or heard at intake air system components at idle?	Yes	Repair or replace
3			

**DESCRIPTION:**

Further describes the system. Confirm that the chart addresses the actual symptom before beginning troubleshooting.

**TROUBLESHOOTING HINTS:**

This describes the possible point of malfunction.

**STEP:**

This shows the order of troubleshooting. Proceed with troubleshooting as indicated.

**INSPECTION:**

This describes an inspection to quickly determine the malfunction of parts. If a detailed procedure is necessary to perform the INSPECTION, refer to the page specified by the "→" mark.

**ACTION:**

This recommends the appropriate action to take as a result (Yes/No) of the INSPECTION. How to perform the actions is described on the reference page specified by the "→" mark.

### DIAGNOSTIC INDEX

TROUBLESHOOTING ITEM		DESCRIPTION	PAGE
No.	TROUBLE		
1	Melts main or other fuse	—	F-190
2	Will not crank or cranks slowly	Starter does not work Starter cranks engine at slow speed	Section G
3	Crank normally but will not start	No combustion	Starter cranks engine at normal speed but engine shows no indication of firing
4		Partial combustion - when engine cold	Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is cold or at initial starting Engine will not continue running when cold when ignition switch is returned from STA to IG position
5		Partial combustion - when warm-up	Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is warm Engine will not continue running when warm when IGN switch is returned from STA to IG position
6	Will start in other than P and N ranges	Engine starts in P, N and other ranges	Section K
7	Crank normally but hard to start	Any engine temperature	Starter cranks engine at normal speed but engine requires excessive cranking time before starting at any engine temperature Engine starts after stalling a few times at any engine temperature
8		when engine cold	Starter cranks engine at normal speed but engine requires excessive cranking time before starting when engine is cold Engine starts after stalling a few times when engine is cold
9		After warm-up	Starter cranks engine at normal speed but engine requires excessive cranking time before starting after warm-up
10	Engine stalls	Idle at any engine temperature	Engine stops unexpectedly at any engine temperature
11		During fast idle	Engine stops unexpectedly during fast-idle operation
12		Idle after warm-up	Engine stops unexpectedly at idle after warm-up
13		Idle with A/C, P/S, and/or E/L ON	Engine stops unexpectedly when A/C, P/S, and/or E/L is turned ON at idle
*14		Idle when shifted from N or P to other ranges	Engine stops unexpectedly when shifted from N or P to other ranges at idle
15		Driveaway	Engine stops unexpectedly upon driveaway
16		On acceleration	Engine stops unexpectedly at beginning of acceleration or during acceleration
17		While cruising	Engine stops unexpectedly while cruising
*18		On deceleration	Engine stops unexpectedly at beginning of deceleration or recovery from deceleration Exhaust afterburn
19	Engine rough	Idle at any engine temperature	Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at any engine temperature Idle speed too slow and excessive engine shake at any engine temperature
20		During fast idle	Fast idle speed too slow and excessive engine shake during fast idle, but returns to normal after warm-up
21		Idle after warm-up	Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle after warm-up

\* Refer to section F before referring to section K.

# TROUBLESHOOTING GUIDE

# F

TROUBLESHOOTING ITEM		DESCRIPTION	PAGE
No.	TROUBLE		
22	Engine rough	Idle with A/C, P/S, and/or E/L ON	F-205
23		Idle when shifted from N or P to other range	
24*		On deceleration	Engine shakes at beginning of deceleration, during deceleration, or recovery from deceleration Exhaust afterburn
25*	Poor acceleration	Driveaway	F-207 Section K
26*		On acceleration	
27	High idle speed after warm-up	Idle speed continues at fast idle after warm-up Engine returns slowly to idle after accelerator is released	F-209
28	Idle fluctuates / Idle hunts	Engine speed hunts between specified idle speed and higher speed	F-211
29	Hesitates / Stumbles on acceleration	Momentary pause at beginning of acceleration or during acceleration	F-212
30*	Surges while cruising	Momentary minor irregularity in engine power at steady vehicle speed	F-214 Section K
31*	Lack of power	Performance poor under load (i.e., power down when climbing hills)	F-215 Section K
32*	Poor fuel economy	Fuel economy unsatisfactory	F-215 Section K
33	A/C does not work	A/C compressor magnetic clutch does not engage when Air conditioning sensor ON	F-215
34	Knocking / Pinging	Sound produced as air/fuel mixture is ignited by something other than spark plug (i.e., hot spot in combustion chamber)	F-216
35	Fuel odor	Gasoline fuel smell or visible leaks	F-216
36	Exhaust sulfur smell	Rotten egg (sulfur) smell from exhaust	F-216
37	High oil consumption	Oil consumption excessive	F-216
38	Self-Diagnosis Checker flashes 88	Checker flashes 88 with test connector grounded	F-217
39	MIL never ON	Self-Diagnosis Checker indicates Trouble Code No. of input device but MIL never ON	F-217
40	Vehicle does not move in D, S, L and/or R ranges	No creep at all Vehicle does not move when accelerator pedal is depressed after shifted to D, S, L and/or R ranges	Section K
41	Vehicle moves in N range	Vehicle creeps in N ranges Vehicle moves with accelerator pedal not depressed	Section K
42	Vehicle moves in P range	Vehicle rolls in P range	Section K
43	Excessive creep	Vehicle moves quickly in D, S, L and R range (with accelerator pedal not depressed) Excessive N to R range and N to D range shift shock felt.	Section K

\* Refer to section F before referring to section K.



# F

## TROUBLESHOOTING GUIDE




TROUBLESHOOTING ITEM		DESCRIPTION	PAGE	
No.	TROUBLE			
44	No shift	Single range shift (1st → 2nd, 2nd → 3rd or 3rd → O/D) only Sometimes shifts correctly Gear position held in hold mode	Section K	
45	Abnormal shift	Shifts incorrectly (incorrect shift pattern) (ex) Vehicle shifts 1st → O/D directly when accelerating with accelerator pedal depressed slightly	Section K	
46	Frequent shifting	Downshift occurs when accelerated slightly in D, S and L ranges (except hold mode)	Section K	
47	Shift point high or low	Shift points do not match shift diagram Shift delayed when accelerating Shift occur too fast when accelerating and engine speed does not increase	Section K	
48	No lockup	No lockup when vehicle speed reaches lockup range	Section K	
49	No kickdown	Does not downshift when accelerator pedal depressed more than 7/8 within kickdown range	Section K	
50	Engine speed flares up	When accelerating	Engine speed flares up on acceleration	Section K
51		When upshifting and/or downshifting	Engine flares up when accelerator pedal depressed before upshifting Engine flares up suddenly when accelerator pedal depressed before downshifting	Section K
52	Excessive shift shock	P, N to R and/or N to D	Strong shift shock felt at idle when shifting from N to D or R range	Section K
53		When upshitting and/or downshifting	Excessive shift shock felt when accelerating at upshitting Excessive shift shock felt when accelerator pedal depressed at downshifting during cruising	Section K
54	No engine braking	Engine speed drops to idle but vehicle does not slow when accelerator pedal released during cruising at medium to high speed Engine speed drops to idle but vehicle does not slow when accelerator pedal released when in L range at low vehicle speed	Section K	
55	No mode change	Mode does not change to/from normal mode in D range Hold mode not engaged or not cancelled	Section K	
56	Transmission noise	All ranges	Transmission noisy in all ranges when vehicle is idling	Section K
57		D, S, L, R ranges	Abnormal noise from transmission in D, S, L, R	Section K
58	Transmission overheats	ATF smells burnt and/or is discolored	Section K	

**Description of Drivability Problems**

**STUMBLE** : Mild jerking during acceleration.

**HESITATION** : Flat spot occurring just after the accelerator pedal is depressed.

**SURGE** : Continuous soft jerking while cruising.

**PRECAUTION****Fuel Pressure Release and Servicing Fuel System**

a) Fuel in the fuel system remains under high pressure when the engine is not running.

Before disconnecting any fuel line, release the fuel pressure from the fuel system as described to reduce the possibility of injury or fire.

1. Start the engine.
2. Remove the fuel pump relay.
3. After the engine stalls, turn OFF the Ignition switch.
4. Install the fuel pump relay.

b) Use a rag as protection from fuel spray when disconnecting the hoses.

Plug the hoses after removal.

c) When inspecting the fuel system, use a suitable fuel pressure gauge.


**Caution**

- Install hose clamps to secure the fuel pressure gauge to prevent fuel leakage.

### SYMPTOM TROUBLESHOOTING

1	MELTS MAIN OR OTHER FUSE
---	--------------------------


**[TROUBLESHOOTING HINTS]**  
 Check the condition of the fuse






Damaged Fuse	Related Wiring Harness													
MAIN (120A)	Main fuse	Alternator												
BTN (60A)	BTN fuse	ROOM fuse												
ROOM (10A)	ROOM fuse	PCME terminal 1A												
EGI INJ (30A)	Main relay	<table border="0" style="margin-left: 20px;"> <tr><td>_____</td><td>Injectors</td></tr> <tr><td>_____</td><td>PCME terminal 1B</td></tr> <tr><td>_____</td><td>Oxygen sensor</td></tr> <tr><td>_____</td><td>Solenoid valves</td></tr> <tr><td>_____</td><td>E/L unit</td></tr> <tr><td>_____</td><td>Air pump relay</td></tr> </table>	_____	Injectors	_____	PCME terminal 1B	_____	Oxygen sensor	_____	Solenoid valves	_____	E/L unit	_____	Air pump relay
_____	Injectors													
_____	PCME terminal 1B													
_____	Oxygen sensor													
_____	Solenoid valves													
_____	E/L unit													
_____	Air pump relay													
ENGINE (15A)	ENGINE fuse	Main relay												
METER (15A)	METER fuse	Data link connector terminal + B												
FUEL PUMP (20A)	FUEL PUMP fuse Fuel pump relay	Fuel pump relay Fuel pump												

<b>3</b>	<b>CRANK NORMALLY BUT WILL NOT START</b>	<b>• NO COMBUSTION</b>
<b>DESCRIP- TION</b>	<ul style="list-style-type: none"> <li>• Starter cranks engine at normal speed but engine shows no indication of firing</li> </ul>	
<p><b>[TROUBLESHOOTING HINTS]</b></p> <ul style="list-style-type: none"> <li>① Crankshaft position sensor             <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>② Main relay             <ul style="list-style-type: none"> <li>• Poor connection of connector</li> <li>• Malfunction of relay</li> </ul> </li> <li>③ Fuel pump             <ul style="list-style-type: none"> <li>• No fuel in tank</li> <li>• Poor connection of fuel pump connector</li> </ul> </li> <li>④ PCME             <ul style="list-style-type: none"> <li>• Poor connection of connector (Especially 1H, 1O, 1T, 3I, 4D, 4E, 4G, 4H)</li> </ul> </li> <li>⑤ Igniter             <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>⑥ Injector             <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> </ul>		

<b>4</b>	<b>CRANKS NORMALLY BUT WILL NOT START</b>	<b>• PARTIAL COMBUSTION - WHEN ENGINE COLD</b>
<b>DESCRIP- TION</b>	<ul style="list-style-type: none"> <li>• Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is cold at initial starting</li> <li>• Engine will not continue running when cold when ignition switch is returned from STA to IG position</li> <li>• Refer to "ENGINE STALLS" if this symptom initially appears after engine stalls</li> <li>• Fuel in tank</li> <li>• Battery in normal condition</li> </ul>	
<p><b>[TROUBLESHOOTING HINTS]</b></p> <ul style="list-style-type: none"> <li>① Igniter             <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>② Ignition coil             <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>③ Spark plug             <ul style="list-style-type: none"> <li>• Dirty or worn spark plug(s)</li> </ul> </li> <li>④ Injector (primary)             <ul style="list-style-type: none"> <li>• Poor connection of connector</li> <li>• Fuel leakage from injector(s)</li> </ul> </li> <li>⑤ Intake air system             <ul style="list-style-type: none"> <li>• Air leakage</li> </ul> </li> <li>⑦ Engine coolant temperature sensor             <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>⑧ Engine compression</li> <li>⑨ PCME             <ul style="list-style-type: none"> <li>• Poor connection of connector (Especially 1B, 1G, 1H, 1J, 1N, 1O, 1T, 3E, 4E, 4G, 4H)</li> </ul> </li> <li>⑩ Solenoid valve (Purge control)             <ul style="list-style-type: none"> <li>• Short circuit (Solenoid valve fully opened)</li> </ul> </li> </ul>		

STEP	INSPECTION	ACTION	
1	Is "00" displayed on SST with ignition switch ON? ⇨ page F-20 	Yes	"00" displayed Go to next step
		No	Trouble Code No. displayed Check for cause (Refer to specified check sequence)



STEP	INSPECTION		ACTION
2	<p>Is strong blue spark visible at each disconnected high-tension lead while cranking engine?</p>  <p>HIGH-TENSION LEAD</p>	Yes	Go to next step
		No	Check ignition system <span style="float: right;">⇨ Section G</span>
3	<p>Are spark plugs OK?</p> <p style="text-align: right;">⇨ Page G</p>	Yes	Go to next step
		No	Clean or replace
4	<p>Connect jumper wire between F/P and GND terminals of data link connector; will engine start?</p>  <p>GND F/P DATA LINK CONNECTOR JUMPER WIRE</p>	Yes	<p>Check as follows:</p> <ul style="list-style-type: none"> <li>● 1T terminal voltage at PCME</li> <li>● Continuity between 1T terminal and fuel pump relay connector terminal</li> <li>● Condition of PCME and fuel pump relay connector female terminals</li> </ul> <p style="text-align: right;">⇨ page F-156</p>
		No	<p>Check if fuel pump operating sound is heard</p> <ul style="list-style-type: none"> <li>● If yes, go to next step</li> <li>● If no, check fuel pump and wiring harness</li> </ul> <p style="text-align: right;">⇨ Page F-100</p>
5	<p>Are PCME terminal voltages OK?</p> <p style="text-align: right;">⇨ page F-152</p> <p>Terminal: 1B, 1G, 1H, 1J, 1N, 1O, 1T, 3E, 4E, 4G, 4H</p>	Yes	Go to next step
		No	Check for cause <span style="float: right;">⇨ page F-153</span>
6	<p>Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON?</p> <p style="text-align: right;">⇨ page F-98</p> <p><b>Fuel line pressure:</b> 250-260 kPa {2.5-2.7 kgf/cm<sup>2</sup>, 36-38 psi}</p>  <p>JUMPER WIRE F/P GND DATA LINK CONNECTOR PRESSURE GAUGE INSALL CLAMP</p>	Yes	Go to next step
		No	<p><b>Low pressure</b></p> <p>Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> <li>● If pressure <b>quickly</b> increases, check pressure regulator</li> <li>● If pressure <b>gradually</b> increases, check for clogging between fuel pump and pressure regulator</li> </ul> <p>If hose not clogged, check fuel pump maximum pressure</p> <p style="text-align: right;">⇨ page F-104</p> <p style="text-align: right;">⇨ page F-101</p>


STEP	INSPECTION	ACTION	
7	Are injectors OK? <span style="float: right;">⇨ Page F-107</span> • Fuel leakage • Primary injector(s) clogged	Yes	Go to next step
		No	Replace injector(s) <span style="float: right;">⇨ Page F-105</span>
8	Is engine compression OK? <span style="float: right;">⇨ Section C</span> <b>Compression</b> 690 kPa (7.0 kg/cm <sup>2</sup> , 100 psi) – 250 rpm <b>Differential limit of chambers</b> 150 kPa (1.5 kg/cm <sup>2</sup> , 21psi) – 250 rpm	Yes	Go to next step
		No	Check for cause <span style="float: right;">⇨ Section C</span>
9	Try known good PCME; does condition improve? <span style="float: right;">⇨ page F-150</span>		

5	CRANKS NORMALLY BUT WILL NOT START	• PARTIAL COMBUSTION – AFTER WARM UP
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>• Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is warm</li> <li>• Engine will not continue running when ignition switch is returned from STA to IG position</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b>		
<ul style="list-style-type: none"> <li>① Solenoid valve (PRC)                             <ul style="list-style-type: none"> <li>• Poor connection of solenoid valve connector or PCME 4M terminal</li> </ul> </li> <li>② Fuel                             <ul style="list-style-type: none"> <li>• High RVP (winter) fuel used in warm weather</li> </ul> </li> <li>③ Engine coolant temperature sensor                             <ul style="list-style-type: none"> <li>• Malfunction of engine coolant temperature sensor</li> </ul> </li> <li>④ Evaporative emission control                             <ul style="list-style-type: none"> <li>• Malfunction of check valve (two-way)</li> </ul> </li> <li>⑤ Fuel pump                             <ul style="list-style-type: none"> <li>• Malfunction of fuel pump relay</li> </ul> </li> </ul>		

# F

## TROUBLESHOOTING GUIDE



7, 8, 9	<b>CRANKS NORMALLY BUT HARD TO START</b>	<ul style="list-style-type: none"> <li>● ANY ENGINE TEMPERATURE</li> <li>● WHEN ENGINE COLD</li> <li>● AFTER WARM-UP</li> </ul>				
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>● Starter cranks engine at normal speed but engine requires excessive cranking time before starting</li> <li>● Engine starts after stalling a few times</li> <li>● Battery in normal condition</li> <li>● Engine runs normally at idle (if idle condition not OK, refer to "Engine rough" [Nos. 19, 20, 21, 22, or 23])</li> </ul>					
<p><b>[TROUBLESHOOTING HINTS]</b></p> <table border="0"> <tr> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>① Injector                             <ul style="list-style-type: none"> <li>● Fuel leakage from injector(s)</li> </ul> </li> <li>② Fuel pump                             <ul style="list-style-type: none"> <li>● Poor connection of pump connector</li> <li>● Poor connection of fuel pump relay connector</li> </ul> </li> <li>③ Pressure regulator                             <ul style="list-style-type: none"> <li>● Malfunction of pressure regulator</li> </ul> </li> <li>④ Fast idle cam                             <ul style="list-style-type: none"> <li>● Malfunction of fast idle cam (when engine cold)</li> </ul> </li> <li>⑤ Spark plug                             <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> </li> </ul> </td> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>⑥ Intake air system                             <ul style="list-style-type: none"> <li>● Air leakage</li> </ul> </li> <li>⑦ Engine coolant temperature sensor                             <ul style="list-style-type: none"> <li>● Poor connection of engine coolant temperature sensor</li> <li>● Malfunction of engine coolant temperature sensor</li> </ul> </li> <li>⑧ Solenoid valve (Purge control)                             <ul style="list-style-type: none"> <li>● Air leakage</li> </ul> </li> <li>⑨ Metering oil pump                             <ul style="list-style-type: none"> <li>● Malfunction of pump</li> </ul> </li> <li>⑩ Crankshaft position sensor                             <ul style="list-style-type: none"> <li>● Ground circuit open</li> </ul> </li> </ul> </td> </tr> </table>			<ul style="list-style-type: none"> <li>① Injector                             <ul style="list-style-type: none"> <li>● Fuel leakage from injector(s)</li> </ul> </li> <li>② Fuel pump                             <ul style="list-style-type: none"> <li>● Poor connection of pump connector</li> <li>● Poor connection of fuel pump relay connector</li> </ul> </li> <li>③ Pressure regulator                             <ul style="list-style-type: none"> <li>● Malfunction of pressure regulator</li> </ul> </li> <li>④ Fast idle cam                             <ul style="list-style-type: none"> <li>● Malfunction of fast idle cam (when engine cold)</li> </ul> </li> <li>⑤ Spark plug                             <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>⑥ Intake air system                             <ul style="list-style-type: none"> <li>● Air leakage</li> </ul> </li> <li>⑦ Engine coolant temperature sensor                             <ul style="list-style-type: none"> <li>● Poor connection of engine coolant temperature sensor</li> <li>● Malfunction of engine coolant temperature sensor</li> </ul> </li> <li>⑧ Solenoid valve (Purge control)                             <ul style="list-style-type: none"> <li>● Air leakage</li> </ul> </li> <li>⑨ Metering oil pump                             <ul style="list-style-type: none"> <li>● Malfunction of pump</li> </ul> </li> <li>⑩ Crankshaft position sensor                             <ul style="list-style-type: none"> <li>● Ground circuit open</li> </ul> </li> </ul>		
<ul style="list-style-type: none"> <li>① Injector                             <ul style="list-style-type: none"> <li>● Fuel leakage from injector(s)</li> </ul> </li> <li>② Fuel pump                             <ul style="list-style-type: none"> <li>● Poor connection of pump connector</li> <li>● Poor connection of fuel pump relay connector</li> </ul> </li> <li>③ Pressure regulator                             <ul style="list-style-type: none"> <li>● Malfunction of pressure regulator</li> </ul> </li> <li>④ Fast idle cam                             <ul style="list-style-type: none"> <li>● Malfunction of fast idle cam (when engine cold)</li> </ul> </li> <li>⑤ Spark plug                             <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>⑥ Intake air system                             <ul style="list-style-type: none"> <li>● Air leakage</li> </ul> </li> <li>⑦ Engine coolant temperature sensor                             <ul style="list-style-type: none"> <li>● Poor connection of engine coolant temperature sensor</li> <li>● Malfunction of engine coolant temperature sensor</li> </ul> </li> <li>⑧ Solenoid valve (Purge control)                             <ul style="list-style-type: none"> <li>● Air leakage</li> </ul> </li> <li>⑨ Metering oil pump                             <ul style="list-style-type: none"> <li>● Malfunction of pump</li> </ul> </li> <li>⑩ Crankshaft position sensor                             <ul style="list-style-type: none"> <li>● Ground circuit open</li> </ul> </li> </ul>					
<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>				
1	<p>Is "00" displayed on SST with ignition switch ON?  <small>☞ page F-20</small></p> 	<table border="0"> <tr> <td style="vertical-align: top;">Yes</td> <td style="vertical-align: top;"> <p><b>"00" displayed</b></p> <p>Go to next step</p> </td> </tr> <tr> <td style="vertical-align: top;">No</td> <td style="vertical-align: top;"> <p><b>Trouble Code No. displayed</b></p> <p>Check for cause (Refer to specified check sequence)</p> </td> </tr> </table>	Yes	<p><b>"00" displayed</b></p> <p>Go to next step</p>	No	<p><b>Trouble Code No. displayed</b></p> <p>Check for cause (Refer to specified check sequence)</p>
Yes	<p><b>"00" displayed</b></p> <p>Go to next step</p>					
No	<p><b>Trouble Code No. displayed</b></p> <p>Check for cause (Refer to specified check sequence)</p>					
2	Is air leakage felt or heard at intake air system components at idle?	<table border="0"> <tr> <td style="vertical-align: top;">Yes</td> <td style="vertical-align: top;">Repair or replace</td> </tr> <tr> <td style="vertical-align: top;">No</td> <td style="vertical-align: top;">Go to next step</td> </tr> </table>	Yes	Repair or replace	No	Go to next step
Yes	Repair or replace					
No	Go to next step					
3	<p>Is fast idle cam OK?  <small>☞ page F-79</small></p>	<table border="0"> <tr> <td style="vertical-align: top;">Yes</td> <td style="vertical-align: top;">Go to next step</td> </tr> <tr> <td style="vertical-align: top;">No</td> <td style="vertical-align: top;">Adjust <small>☞ page F-79</small></td> </tr> </table>	Yes	Go to next step	No	Adjust <small>☞ page F-79</small>
Yes	Go to next step					
No	Adjust <small>☞ page F-79</small>					
4	<p>Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON?  <small>☞ page F-98</small></p> <p><b>Fuel line pressure:</b>  <b>250–260 kPa {2.5–2.7 kgf/cm<sup>2</sup>, 36–38 psi}</b></p> 	<table border="0"> <tr> <td style="vertical-align: top;">Yes</td> <td style="vertical-align: top;">Go to next step</td> </tr> <tr> <td style="vertical-align: top;">No</td> <td style="vertical-align: top;"> <p><b>Low pressure</b></p> <p>Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> <li>● If pressure <b>quickly</b> increases, check pressure regulator <small>☞ page F-104</small></li> <li>● If pressure <b>gradually</b> increases, check for clogging between fuel pump and pressure regulator</li> </ul> <p>If hose not clogged, check fuel pump maximum pressure <small>☞ page F-101</small></p> </td> </tr> </table>	Yes	Go to next step	No	<p><b>Low pressure</b></p> <p>Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> <li>● If pressure <b>quickly</b> increases, check pressure regulator <small>☞ page F-104</small></li> <li>● If pressure <b>gradually</b> increases, check for clogging between fuel pump and pressure regulator</li> </ul> <p>If hose not clogged, check fuel pump maximum pressure <small>☞ page F-101</small></p>
Yes	Go to next step					
No	<p><b>Low pressure</b></p> <p>Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> <li>● If pressure <b>quickly</b> increases, check pressure regulator <small>☞ page F-104</small></li> <li>● If pressure <b>gradually</b> increases, check for clogging between fuel pump and pressure regulator</li> </ul> <p>If hose not clogged, check fuel pump maximum pressure <small>☞ page F-101</small></p>					


STEP	INSPECTION	ACTION	
5	Is fuel line pressure held after ignition switch is turned OFF? ☞ page F-97 Fuel pressure: More than 150 kPa {1.5 kg/cm <sup>2</sup> , 21 psi}	Yes	Go to next step
	 <p>Diagram showing a fuel line connected to a pressure gauge. Labels include 'PRESSURE GAUGE' and 'INSTALL CLAMP'.</p>	No	Plug outlet of pressure regulator, Is fuel line pressure held after ignition switch is turned OFF? ● If yes, replace pressure regulator ● If no, check fuel pump hold pressure If fuel pump OK, check injectors for fuel leakage ☞ page F-100 ☞ page F-104 ☞ page F-101 ☞ page F-106
6	Are spark plugs OK? ☞ Section G	Yes	Go to next step
		No	Repair or replace
7	Is EGR control system OK? ☞ page F-126	Yes	Go to next step
		No	Check as follows: ● Solenoid valve (EGR) for sticking ● Condition of solenoid valve connector female terminal(s)
8	Try known good PCME; does condition improve? ☞ page F-150		



# F


## TROUBLESHOOTING GUIDE



10,11,12	ENGINE STALLS	<ul style="list-style-type: none"> <li>● IDLE AT ANY ENGINE TEMP</li> <li>● DURING FAST IDLE</li> <li>● IDLE AFTER WARM-UP</li> </ul>			
DESCRIPTION	<ul style="list-style-type: none"> <li>● Engine stops unexpectedly at idle and/or during fast idle operation</li> </ul>				
<p><b>[TROUBLESHOOTING HINTS]</b></p> <table border="0"> <tr> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>① Injector                             <ul style="list-style-type: none"> <li>● Fuel leakage from injector(s)</li> <li>● Injector(s) clogged</li> </ul> </li> <li>② Fuel pump                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>③ Fuel pump relay                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>④ Spark plug                             <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> </li> <li>⑤ Manifold absolute pressure sensor                             <ul style="list-style-type: none"> <li>● Poor connection of manifold absolute pressure sensor connector</li> </ul> </li> </ul> </td> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>⑥ EGR control valve                             <ul style="list-style-type: none"> <li>● EGR control valve stuck</li> </ul> </li> <li>⑦ Idle air control valve                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑧ Crankshaft position sensor                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑨ PCME                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑩ Igniter                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑪ Metering oil pump                             <ul style="list-style-type: none"> <li>● Malfunction of oil pump</li> </ul> </li> </ul> </td> </tr> </table>				<ul style="list-style-type: none"> <li>① Injector                             <ul style="list-style-type: none"> <li>● Fuel leakage from injector(s)</li> <li>● Injector(s) clogged</li> </ul> </li> <li>② Fuel pump                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>③ Fuel pump relay                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>④ Spark plug                             <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> </li> <li>⑤ Manifold absolute pressure sensor                             <ul style="list-style-type: none"> <li>● Poor connection of manifold absolute pressure sensor connector</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>⑥ EGR control valve                             <ul style="list-style-type: none"> <li>● EGR control valve stuck</li> </ul> </li> <li>⑦ Idle air control valve                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑧ Crankshaft position sensor                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑨ PCME                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑩ Igniter                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑪ Metering oil pump                             <ul style="list-style-type: none"> <li>● Malfunction of oil pump</li> </ul> </li> </ul>
<ul style="list-style-type: none"> <li>① Injector                             <ul style="list-style-type: none"> <li>● Fuel leakage from injector(s)</li> <li>● Injector(s) clogged</li> </ul> </li> <li>② Fuel pump                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>③ Fuel pump relay                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>④ Spark plug                             <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> </li> <li>⑤ Manifold absolute pressure sensor                             <ul style="list-style-type: none"> <li>● Poor connection of manifold absolute pressure sensor connector</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>⑥ EGR control valve                             <ul style="list-style-type: none"> <li>● EGR control valve stuck</li> </ul> </li> <li>⑦ Idle air control valve                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑧ Crankshaft position sensor                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑨ PCME                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑩ Igniter                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑪ Metering oil pump                             <ul style="list-style-type: none"> <li>● Malfunction of oil pump</li> </ul> </li> </ul>				
STEP	INSPECTION		ACTION		
1	<p>Is "00" displayed on SST with ignition switch ON?  <small>☞ page F-20</small></p> 	Yes	<p><b>"00" displayed</b></p> <ul style="list-style-type: none"> <li>● If symptom occurs at idle at any engine temp., go to next step</li> <li>● If symptom occurs during fast idle operation, go to next step</li> <li>● If symptom occurs at idle after warm-up, go to Step 6</li> </ul>		
2	<p>Is fast idle cam OK?  <small>☞ page F-79</small></p>	Yes	Go to next step		
3	<p>Is strong blue spark visible at each disconnected high-tension lead while cranking engine?</p> 	Yes	Go to next step		
		No	<p>Check ignition system <small>☞ Section G</small></p>		

STEP	INSPECTION	ACTION	
4	Are following PCME terminal voltages OK? ⇨ page F-152 <ul style="list-style-type: none"> <li>● 1B (PCME power)</li> <li>● 1G, 1H, 1J (Igniter)</li> <li>● 1O (Manifold absolute pressure sensor)</li> <li>● 1T (Fuel pump relay)</li> <li>● 3E (Engine coolant temperature sensor)</li> <li>● 3F (Throttle position sensor narrow range)</li> <li>● 4E, 4G, 4H (Crankshaft position sensor)</li> <li>● 4O (Solenoid valve (EGR))</li> <li>● 4P (Solenoid valve (AWS))</li> <li>● 4Q (Idle air control valve)</li> <li>● 4W, 4Y (Primary fuel injector)</li> </ul>	Yes	Go to next step
		No	Check for cause ⇨ page F-153
5	Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON? ⇨ page F-98  <b>Fuel line pressure:</b> 250-260 kPa {2.5-2.7 kgf/cm <sup>2</sup> , 36-38 psi}  	Yes	Go to next step
		No	<b>Low pressure</b> Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> <li>● If pressure <b>quickly</b> increases, check pressure regulator ⇨ page F-104</li> <li>● If pressure <b>gradually</b> increases, check for clogging between fuel pump and pressure regulator</li> </ul> If hose not clogged, check fuel pump maximum pressure ⇨ page F-101
6	Is engine compression correct? ⇨ Section C  <b>Compression</b> 690 kPa {7.0 kgf/cm <sup>2</sup> , 100 psi} - 250 rpm <b>Differential limit of chambers</b> 150 kPa {1.5 kgf/cm <sup>2</sup> , 21 psi} - 250 rpm	Yes	Go to next step
		No	Check for cause
7	Are spark plugs OK? ⇨ Section G	Yes	Go to next step
		No	Check for cause
8	Try known good PCME; does condition improved? ⇨ page F-150		

# F

## TROUBLESHOOTING GUIDE



13, 14	<b>ENGINE STALLS</b>	<ul style="list-style-type: none"> <li>● IDLE WITH A/C, P/S, and/or E/L ON</li> <li>● IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGES</li> </ul>	
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● Engine stops unexpectedly when A/C, P/S, and/or E/L turned ON at idle</li> <li>● Engine stops unexpectedly when shifted from N or P to other ranges at idle</li> <li>● Idle condition is normal when A/C, P/S, and E/L are OFF and in N and P</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b> ① Monitor switch functions (SST) <ul style="list-style-type: none"> <li>● Air conditioning sensor</li> <li>● Headlight switch</li> <li>● Rear window defroster switch</li> <li>● Blower switch</li> </ul> ② Idle air control valve <ul style="list-style-type: none"> <li>● Solenoid valve stuck</li> </ul> ③ Air control valve <ul style="list-style-type: none"> <li>● Malfunction of air control valve</li> </ul>			
<b>STEP</b>	<b>INSPECTION</b>		<b>ACTION</b>
1	Are switches correct when checked by using SST monitor switch function while ignition switch ON? <b>☞ page F-44</b> <ul style="list-style-type: none"> <li>● Blower switch</li> <li>● Headlight switch</li> <li>● Rear window defroster switch</li> <li>● Electric coolant fan</li> <li>● Electrical load unit</li> <li>● Air conditioning sensor</li> </ul>		Yes: Go to next step  No: Lamp not ON/OFF with specified switch Check for cause (Refer to specified check sequence) <b>☞ page F-45</b>
2	Is "00" displayed on SST with ignition switch ON? <b>☞ page F-20</b> 		Yes: "00" displayed Go to next step  No: <b>Trouble Code No. displayed</b> Check for cause (Refer to specified check sequence) <b>☞ page F-22</b>
3	Is terminal voltage at PCME correct at idle? <b>☞ page F-150</b>  <b>4Q terminal: Approx. 5-11V (at idle)</b>		Yes: Check idle air control valve and replace it if necessary If OK, go to "ENGINE STALLS-IDLE WHEN SHIFTED FROM N or P TO OTHER RANGES" in Section K of this manual <b>☞ page F-83</b>  No: Try known good PCME and check if condition improves <b>☞ page F-150</b>

15	ENGINE STALLS	• DRIVEAWAY							
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>• Engine stops unexpectedly upon driveaway</li> <li>• Idle condition normal</li> </ul>								
<b>[TROUBLESHOOTING HINTS]</b> <ul style="list-style-type: none"> <li>① Injector                             <ul style="list-style-type: none"> <li>• Fuel leakage from injector(s)</li> <li>• Injector(s) clogged</li> </ul> </li> <li>② Pressure regulator                             <ul style="list-style-type: none"> <li>• diaphragm damaged</li> </ul> </li> <li>③ Fuel filter                             <ul style="list-style-type: none"> <li>• Fuel filter clogged</li> </ul> </li> <li>④ Metering oil pump                             <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>⑤ Engine coolant temperature sensor                             <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>⑥ Crankshaft position sensor                             <ul style="list-style-type: none"> <li>• Malfunction of sensor</li> </ul> </li> </ul>									
STEP	INSPECTION	ACTION							
1	Is "00" displayed on SST with ignition switch ON? ☞ page F-20	Yes "00" displayed Go to next step							
		No <b>Trouble Code No. displayed</b> Check for cause (Refer to specified check sequence) ☞ page F-22							
2	Using Engine Signal Monitor, do voltage reading and lamp operation change as follows upon driveaway?	Yes Go to next step							
	<table border="1"> <thead> <tr> <th>Terminal</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td>1O</td> <td>Voltage gradually increase</td> </tr> <tr> <td>4E, 4G</td> <td>Voltage not suddenly change</td> </tr> <tr> <td>4W, 4Y</td> <td>Flashing of green and red lamps becomes quicker</td> </tr> </tbody> </table>	Terminal	Condition	1O	Voltage gradually increase	4E, 4G	Voltage not suddenly change	4W, 4Y	Flashing of green and red lamps becomes quicker
Terminal	Condition								
1O	Voltage gradually increase								
4E, 4G	Voltage not suddenly change								
4W, 4Y	Flashing of green and red lamps becomes quicker								
3	Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON? ☞ page F-98	Yes Go to next step							
	<b>Fuel line pressure:</b> 250-260 kPa {2.5-2.7 kgf/cm <sup>2</sup> , 36-38 psi}  	No <b>Low pressure</b> Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> <li>• If pressure <b>quickly</b> increases, check pressure regulator ☞ page F-104</li> <li>• If pressure <b>gradually</b> increases, check for clogging between fuel pump and pressure regulator</li> </ul> If hose not clogged, check fuel pump maximum pressure ☞ page F-101							
4	Are injectors OK? • No fuel leakage ☞ page F-106 • Injectors not clogged (Perform volume test) ☞ page F-67	Yes Go to next step							
		No Replace injector ☞ page F-105							

# F


## TROUBLESHOOTING GUIDE



STEP	INSPECTION	ACTION	
5	Is engine compression OK? <b>⇒ Section G</b>  Compression 690 kPa {7.0 kg/cm <sup>2</sup> , 100 psi} – 250 rpm Differential limit of chambers 150 kPa {1.5 kg/cm <sup>2</sup> , 21 psi} – 250 rpm	Yes	Go to next step
		No	Check for cause
6	Are spark plugs OK? <b>⇒ Section G</b>	Yes	Go to next step
		No	Clean or replace
7	Try known good PCME; does condition improved? <b>⇒ page F-150</b>		

16, 17	ENGINE STALLS	● ON ACCELERATION / WHILE CRUISING			
<b>DESCRIP-TION</b>		<ul style="list-style-type: none"> <li>● Engine stops unexpectedly at beginning of acceleration or during acceleration</li> <li>● Engine stops unexpectedly while cruising</li> </ul>			
<p><b>[TROUBLESHOOTING HINTS]</b></p> <table border="0"> <tr> <td style="vertical-align: top;"> <p>① Fuel pump</p> <ul style="list-style-type: none"> <li>● Poor connection</li> </ul> <p>② Pressure regulator</p> <ul style="list-style-type: none"> <li>● Diaphragm damaged</li> </ul> <p>③ Crankshaft position sensor</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </td> <td style="vertical-align: top;"> <p>④ Manifold absolute pressure sensor</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> <p>⑤ Spark plug</p> <ul style="list-style-type: none"> <li>● Misfire</li> </ul> <p>⑥ Main relay</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </td> </tr> </table>				<p>① Fuel pump</p> <ul style="list-style-type: none"> <li>● Poor connection</li> </ul> <p>② Pressure regulator</p> <ul style="list-style-type: none"> <li>● Diaphragm damaged</li> </ul> <p>③ Crankshaft position sensor</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul>	<p>④ Manifold absolute pressure sensor</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> <p>⑤ Spark plug</p> <ul style="list-style-type: none"> <li>● Misfire</li> </ul> <p>⑥ Main relay</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul>
<p>① Fuel pump</p> <ul style="list-style-type: none"> <li>● Poor connection</li> </ul> <p>② Pressure regulator</p> <ul style="list-style-type: none"> <li>● Diaphragm damaged</li> </ul> <p>③ Crankshaft position sensor</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul>	<p>④ Manifold absolute pressure sensor</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> <p>⑤ Spark plug</p> <ul style="list-style-type: none"> <li>● Misfire</li> </ul> <p>⑥ Main relay</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul>				
STEP	INSPECTION		ACTION		
1	<p>Is "00" displayed on SST with ignition switch ON?                      ⇨ page F-20</p> 	Yes	<p><b>"00" displayed</b></p> <p>Go to next step</p>		
	No	<p><b>Trouble Code No. displayed</b></p> <p>Check for cause (Refer to specified check sequence)</p>			
2	<p>Ground terminal F/P of data link connector within ignition switch ON; does condition improve?</p> 	Yes	<p>Check as follows;</p> <ul style="list-style-type: none"> <li>● Poor connection of fuel pump relay</li> <li>● Poor connection of PCME 1T terminal</li> </ul>		
	No	Go to next step			
3	<p>Is pressure regulator OK?                      ⇨ page F-104</p>	Yes	Go to next step		
	No	Replace			
4	<p>Try known good PCME; does condition improved?                      ⇨ page F-150</p>				

# F

## TROUBLESHOOTING GUIDE

18	ENGINE STALLS	• ON DECELERATION
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine stops unexpectedly at beginning of deceleration or recovery from deceleration</li> <li>• Exhaust afterburn</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b> <ul style="list-style-type: none"> <li>① Fuel pump               <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>② Idle speed               <ul style="list-style-type: none"> <li>• Idle speed too low</li> </ul> </li> <li>③ Crankshaft position sensor               <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>④ Manifold absolute pressure sensor               <ul style="list-style-type: none"> <li>• Malfunction of manifold absolute pressure sensor</li> </ul> </li> <li>⑤ Idle air control valve               <ul style="list-style-type: none"> <li>• Solenoid valve stuck</li> </ul> </li> <li>⑥ EGR control valve               <ul style="list-style-type: none"> <li>• Solenoid valve stuck open</li> </ul> </li> <li>⑦ PCME               <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>⑧ Fuel cut control</li> </ul>		
STEP	INSPECTION	ACTION
1	Is "00" displayed on SST with ignition switch ON <small>⇨ page F-20</small> 	Yes <b>"00" displayed</b> Go to next step
		No <b>Trouble Code No. displayed</b> Check for cause (Refer to specified check sequence)
2	Are following PCME terminal voltage correct? When checking voltages, tap, move, and wiggle the harness and the connector. <ul style="list-style-type: none"> <li>• 1B (Main relay)</li> <li>• 1G, 1H, 1J (Igniter)</li> <li>• 1T (Fuel pump relay)</li> <li>• 4D (Ground)</li> <li>• 4W, 4Y (Primary injector)</li> </ul>	Yes <b>MT</b> Check neutral switch and clutch switch <small>⇨ page F-173</small> <b>AT</b> Go to "ENGINE STALLS ON DECELERATION" in Section K of this manual
		No Check for cause

19, 20, 21	ENGINE ROUGH	● IDLE AT ANY ENGINE TEMP / DURING FAST IDLE / IDLE AFTER WARM-UP	
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at any engine temperature</li> <li>● Idle speed too low and excessive engine shake at any engine temperature</li> <li>● Fast idle speed too low and excessive engine shake during fast idle, but returns to normal after warm-up</li> <li>● Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle after warm-up</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
<div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p>① Injector</p> <ul style="list-style-type: none"> <li>● Fuel leakage from injector(s)</li> <li>● Injector(s) clogged</li> </ul> <p>② Air pump</p> <ul style="list-style-type: none"> <li>● Malfunction of air pump</li> </ul> <p>③ Fuel pump relay</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> <p>④ Spark plug</p> <ul style="list-style-type: none"> <li>● Misfire</li> </ul> <p>⑤ Engine</p> <ul style="list-style-type: none"> <li>● Compression low</li> </ul> </div> <div style="width: 48%;"> <p>⑥ Fast idle cam</p> <ul style="list-style-type: none"> <li>● Malfunction of fast idle cam</li> </ul> <p>⑦ Manifold absolute pressure sensor</p> <ul style="list-style-type: none"> <li>● Malfunction of manifold absolute pressure sensor</li> </ul> <p>⑧ Engine coolant temperature sensor</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> <p>⑨ EGR control valve</p> <ul style="list-style-type: none"> <li>● EGR control valve stuck</li> </ul> <p>⑩ Idle air control valve</p> <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> <p>⑪ Fuel thermosensor</p> </div> </div>			
STEP	INSPECTION		ACTION
1	Is "00" displayed on SST with ignition switch ON ? ⇨ page F-20 	Yes	<b>"00" displayed</b>  Go to next step
		No	<b>Trouble Code No. displayed</b> Check for cause (Refer to specified check sequence) ⇨ page F-22
2	Are spark plugs OK?	Yes	Go to next step
		No	Clean or replace
3	Is strong blue spark visible at each disconnected high-tension lead at idle?	Yes	Go to next step
		No	Check ignition system ⇨ Section G
4	Connect data link connector terminals F/P and GND with a jumper wire; is fuel line pressure correct with ignition switch ON? ⇨ page F-98 	Yes	<ul style="list-style-type: none"> <li>● If symptom occurs at idle at any engine temperature, go to next step</li> <li>● If symptom occurs during fast idle operation, go to Step 6</li> <li>● If symptom occurs at idle after warm-up, go to Step 10</li> </ul>
		No	<b>Low pressure</b> Check fuel line pressure while pinching fuel return hose <ul style="list-style-type: none"> <li>● If pressure <b>quickly</b> increases, check pressure regulator ⇨ page F-104</li> <li>● If pressure <b>gradually</b> increases, check for clogging between fuel pump and pressure regulator</li> </ul> If hose not clogged, check fuel pump maximum pressure ⇨ page F-101
5	Is air pump OK? ⇨ page F-121	Yes	Go to next step
		No	Repair or replace




# F

## TROUBLESHOOTING GUIDE

STEP	INSPECTION	ACTION	
6	Is idle air control valve OK? ☞ page F-83	Yes	Go to next step
		No	Repair or replace
7	Is fast idle cam OK? ☞ page F-79	Yes	Go to next step
		No	Adjust
8	Is accelerated warm-up system OK? ☞ page F-83	Yes	Go to next step
		No	Repair or replace
9	Is engine compression correct? ☞ Section C Compression 690 kPa (7.0 kgf/cm <sup>2</sup> , 100 psi) – 250 rpm Differential limit of chambers 150 kPa (1.5 kgf/cm <sup>2</sup> , 21 psi) – 250 rpm	Yes	Go to next step
		No	Check for cause ☞ Section G
10	Are following PCME terminal voltages correct? ☞ page F-152 ● 1O (Manifold absolute pressure sensor) ● 3E (Engine coolant temperature sensor) ● 3L (Intake air temperature sensor) ● 4I, 4J, 4K, 4L (Metering oil pump) ● 4Y (Rear primary injector) ● 4W (Front primary injector)	Yes	Go to next step
		No	Check for cause
11	Is EGR control system OK? ☞ page F-126	Yes	Try known good PCME; does condition improve? ☞ page F-150
		No	Repair or replace



# TROUBLESHOOTING GUIDE



# F

<b>22, 23</b>	<b>ENGINE ROUGH</b>	<ul style="list-style-type: none"> <li>● IDLE WITH A/C, P/S AND/OR E/L ON</li> <li>● IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGES</li> </ul>	
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>● Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle when A/C, P/S and/or E/L ON</li> <li>● Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle when shifted from P or N to other range</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b> ① Idle speed <ul style="list-style-type: none"> <li>● Idle speed too low</li> </ul> ② Monitor switch function (SST) <ul style="list-style-type: none"> <li>● Air conditioning sensor</li> <li>● Headlight switch</li> <li>● Rear window defroster switch</li> <li>● Blower switch</li> </ul> ③ Idle air control valve <ul style="list-style-type: none"> <li>● Solenoid valve stuck</li> </ul>			
<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>	
1	Is idle speed correct?  <span style="float: right;">☞ page F-16</span>	Yes	Go to next step
		No	Adjust  <span style="float: right;">☞ page F-16</span>
2	Is "00" displayed on SST with ignition switch ON? <span style="float: right;">☞ page F-20</span>	Yes	"00" displayed  Go to next step
		No	<b>Trouble Code No. displayed</b> Check for cause (Refer to specified check sequence)  <span style="float: right;">☞ page F-22</span>
3	Are following terminal voltage at PCME correct? <span style="float: right;">☞ page F-1</span>	Yes	Go to next step
	<ul style="list-style-type: none"> <li>● 1E (Air conditioning sensor)</li> <li>● 1N (Steering pressure sensor)</li> <li>● 1R (PCMT) [AT]</li> <li>● 3B (Electrical load unit)</li> <li>● 3D (Electrical coolant fan)</li> </ul>	No	Check for cause
5	Warm-up engine Does idle speed decrease when idle air control valve connector disconnected?	Yes	<ul style="list-style-type: none"> <li>● If symptom occurs at idle with A/C ON, check A/C system in section U of this manual</li> <li>● If symptom occurs at idle with E/L ON, check E/L unit</li> <li>● If symptom occurs at idle with P/S ON, check P/S pump in section N of this manual</li> <li>● If symptom occurs at idle when shifted from N or P to other range, go to "ENGINE ROUGH-IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGE" in Section K of this manual (AT)</li> </ul> <span style="float: right;">☞ page F-135</span>
		No	Check fast idle cam  <span style="float: right;">☞ page F-79</span>

# F


## TROUBLESHOOTING GUIDE


24		ENGINE ROUGH	• ON DECELERATION
<b>DESCRIP-TION</b>		<ul style="list-style-type: none"> <li>• Engine shakes at beginning of deceleration, or recovery from deceleration</li> <li>• Exhaust afterburn.</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b> <ul style="list-style-type: none"> <li>① Fuel pump               <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>② Injector               <ul style="list-style-type: none"> <li>• Fuel leakage from injector(s)</li> </ul> </li> <li>③ Dashpot               <ul style="list-style-type: none"> <li>• Dashpot misadjusted</li> </ul> </li> <li>④ Throttle position sensor               <ul style="list-style-type: none"> <li>• Poor connection of connector</li> </ul> </li> <li>⑤ Secondary air injection</li> <li>⑥ Idle air control valve               <ul style="list-style-type: none"> <li>• Solenoid valve stuck</li> </ul> </li> </ul>			
STEP	INSPECTION		ACTION
1	Is "00" displayed on SST with ignition switch ON? <b>☞ page F-20</b> 	Yes	<b>"00" displayed</b> Go to next step
		No	<b>Trouble Code No. displayed</b> Check for cause (Refer to specified check sequence) <b>☞ page F-22</b>
2	Is strong blue spark visible at each disconnected high-tension lead? 	Yes	Check spark plugs If OK, go to next step If not OK, clean or replace spark plug
		No	Check ignition system <b>☞ Section G</b>
3	Is dashpot OK? <b>☞ page F-134</b>	Yes	Go to next step
		No	Adjust
4	Is intake manifold vacuum correct at idle? <b>Vacuum:</b> <b>More than 60.0 kPa {450 mmHg, 17.7 inHg}</b>	Yes	Go to next step
		No	Check as follows: <ul style="list-style-type: none"> <li>• Intake air system components for proper installation</li> <li>• Vacuum hoses for disconnection and damage</li> <li>• Engine compression</li> </ul> <b>☞ Section C</b>
5	Are injectors OK? <b>☞ page F-106</b>	Yes	Go to next step
		No	Replace
6	Is engine compression OK? <b>☞ Section C</b> <b>Compression</b> <b>690 kPa {7.0 kgf/cm<sup>3</sup>, 100 psi} – 250 rpm</b> <b>Differential limit of chambers</b> <b>150 kPa {1.5 kgf/cm<sup>2</sup>, 21 psi} – 250 rpm</b>	Yes	Go to next step
		No	Check for cause <b>☞ Section C</b>
7	Try known good PCME; does condition improved? <b>☞ page F-150</b>		

25, 26	POOR ACCELERATION	<ul style="list-style-type: none"> <li>● DRIVEAWAY</li> <li>● ON ACCELERATION</li> </ul>
<b>DESCRIPTION</b>		● Engine speed increases normally but vehicle speed slowly increases during driveaway or acceleration
<b>[TROUBLESHOOTING HINTS]</b>		
<ul style="list-style-type: none"> <li>① Injector                             <ul style="list-style-type: none"> <li>● Fuel leakage from injector(s)</li> <li>● Injector nozzle clogged</li> </ul> </li> <li>② Pressure regulator                             <ul style="list-style-type: none"> <li>● Pressure regulator malfunction</li> </ul> </li> <li>③ Fuel filter                             <ul style="list-style-type: none"> <li>● Filter clogged</li> </ul> </li> <li>④ Spark plug                             <ul style="list-style-type: none"> <li>● Misfire</li> </ul> </li> <li>⑤ Igniter                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑥ Air leakage in intake air system</li> <li>⑦ Manifold absolute pressure sensor                             <ul style="list-style-type: none"> <li>● Manifold absolute pressure sensor filter or hose clogged</li> <li>● Poor connection of connector</li> </ul> </li> <li>⑧ Crankshaft position sensor                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> <li>⑨ Metering oil pump                             <ul style="list-style-type: none"> <li>● Malfunction of oil pump (Fuel injection amount and ignition timing fixed)</li> </ul> </li> <li>⑩ Solenoid valve (Turbo control, Charge control)                             <ul style="list-style-type: none"> <li>● Malfunction of solenoid valve (Fuel injection amount and ignition timing fixed)</li> </ul> </li> <li>⑪ EGR control system                             <ul style="list-style-type: none"> <li>● FOR control valve stuck (open)</li> </ul> </li> <li>⑫ Engine coolant temperature sensor                             <ul style="list-style-type: none"> <li>● Malfunction of thermosensor</li> </ul> </li> <li>⑬ Double throttle control system</li> <li>⑭ Check valve (Turbo control, Charge control, Charge relief)</li> </ul>		
STEP	INSPECTION	ACTION
1	Is "00" displayed on SST with ignition switch ON? <small>☞ page F-20</small>	Yes <b>"00" displayed</b>  Go to next step
		No <b>Trouble Code No. displayed</b> Check for cause (Refer to specified check sequence) <small>☞ page F-22</small>
2	Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?	Yes Check spark plugs If OK, go to next step If not OK, clean or replace spark plug
		No Check ignition system <small>☞ Section G</small>
3	Is intake manifold vacuum correct at idle?  <b>Vacuum:</b> <b>More than 60.0 kPa {450 mmHg, 17.7 inHg}</b>	Yes Go to next step
	No Check as follows <ul style="list-style-type: none"> <li>● Intake air system components and installation</li> <li>● Vacuum hoses for disconnection and damage</li> <li>● Engine compression</li> </ul> <small>☞ Section C</small>	
4	Is air leakage felt or heard at intake air system components?	Yes Repair or replace
	No Go to next step	

# F

## TROUBLESHOOTING GUIDE



STEP	INSPECTION	ACTION	
5	<p>Is fuel line pressure correct at idle? <b>page F-98</b></p> <p><b>Fuel line pressure:</b> 190–220 kPa {1.9–2.3 kgf/cm<sup>2</sup>, 28–32 psi}</p>  <p>The diagram shows a fuel line assembly. A circular pressure gauge is connected to the line. A clamp, labeled 'INSTALL CLAMP', is shown securing the line to a component.</p>	Yes	Go to next step
		No	<p><b>Low pressure</b> Check as follows:</p> <ul style="list-style-type: none"> <li>● Fuel filter for clogging</li> <li>● Operation of pressure regulator</li> </ul>
6	<p>Are injectors OK? <b>page F-106</b></p>	Yes	<p><b>MT</b> Go to next step <b>AT</b> Go to "POOR ACCELERATION – DRIVEAWAY / ON ACCELERATION" in section K of this manual</p>
		No	Replace
7	<p>Try known good PCME; does condition improved? <b>page F-150</b></p>		

27	HIGH IDLE SPEED AFTER WARM-UP					
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● Idle speed continues at fast idle after warm-up</li> <li>● Engine returns slowly to idle after accelerator is released</li> </ul>					
<b>[TROUBLESHOOTING HINTS]</b> <ul style="list-style-type: none"> <li>① Fast idle cam                             <ul style="list-style-type: none"> <li>● Malfunction of fast idle cam</li> </ul> </li> <li>② Accelerated warm-up system                             <ul style="list-style-type: none"> <li>● Solenoid valve (AWS) open</li> </ul> </li> <li>③ Engine coolant temperature sensor                             <ul style="list-style-type: none"> <li>● Malfunction of engine coolant temperature sensor</li> </ul> </li> <li>④ Idle air control valve                             <ul style="list-style-type: none"> <li>● Idle air control valve stuck (open)</li> <li>● A/C, P/S, or E/L signal always ON</li> </ul> </li> <li>⑤ Throttle valve                             <ul style="list-style-type: none"> <li>● Valve not closed throttle position</li> </ul> </li> <li>⑥ Dashpot</li> </ul>						
STEP	INSPECTION	ACTION				
1	Is "00" displayed on SST with ignition switch ON? ⇨ page F-20 	<table border="1"> <tr> <td data-bbox="898 470 989 625">Yes</td> <td data-bbox="989 470 1534 625">                             "00" displayed                              Go to next step                         </td> </tr> <tr> <td data-bbox="898 625 989 891">No</td> <td data-bbox="989 625 1534 891"> <b>Trouble Code No. displayed</b>                              Check for cause (Refer to specified check sequence)                              ⇨ page F-22                         </td> </tr> </table>	Yes	"00" displayed Go to next step	No	<b>Trouble Code No. displayed</b> Check for cause (Refer to specified check sequence) ⇨ page F-22
Yes	"00" displayed Go to next step					
No	<b>Trouble Code No. displayed</b> Check for cause (Refer to specified check sequence) ⇨ page F-22					
2	Connect data link connector terminals TEN and GND with a jumper wire; does idle speed decrease?	<table border="1"> <tr> <td data-bbox="898 891 989 1025">Yes</td> <td data-bbox="989 891 1534 1025">                             Check following terminal voltage at PCME ⇨ page F-152                             <ul style="list-style-type: none"> <li>● 1E (Air conditioning sensor)</li> <li>● 1N (Steering pressure sensor)</li> <li>● 3B (Electrical load unit)</li> </ul> </td> </tr> <tr> <td data-bbox="898 1025 989 1108">No</td> <td data-bbox="989 1025 1534 1108">Go to next step</td> </tr> </table>	Yes	Check following terminal voltage at PCME ⇨ page F-152 <ul style="list-style-type: none"> <li>● 1E (Air conditioning sensor)</li> <li>● 1N (Steering pressure sensor)</li> <li>● 3B (Electrical load unit)</li> </ul>	No	Go to next step
Yes	Check following terminal voltage at PCME ⇨ page F-152 <ul style="list-style-type: none"> <li>● 1E (Air conditioning sensor)</li> <li>● 1N (Steering pressure sensor)</li> <li>● 3B (Electrical load unit)</li> </ul>					
No	Go to next step					
3	Are following terminal voltage at PCME correct? ⇨ page F-152 <ul style="list-style-type: none"> <li>● 1E (Air conditioning sensor)</li> <li>● 1O (Manifold absolute pressure sensor)</li> <li>● 3B (Electric load unit)</li> <li>● 3E (Engine coolant temperature sensor)</li> <li>● 3F (Throttle position sensor-Narrow range)</li> <li>● 3L (Intake air temperature sensor)</li> <li>● 4P (Solenoid valve (AWS))</li> <li>● 4Q (Idle air control valve)</li> </ul>	<table border="1"> <tr> <td data-bbox="898 1108 989 1300">Yes</td> <td data-bbox="989 1108 1534 1300">Go to next step</td> </tr> <tr> <td data-bbox="898 1300 989 1534">No</td> <td data-bbox="989 1300 1534 1534">                             Check for cause                              ⇨ page F-153                         </td> </tr> </table>	Yes	Go to next step	No	Check for cause ⇨ page F-153
Yes	Go to next step					
No	Check for cause ⇨ page F-153					
4	Is throttle valve closed throttle position?	<table border="1"> <tr> <td data-bbox="898 1534 989 1596">Yes</td> <td data-bbox="989 1534 1534 1596">Go to next step</td> </tr> <tr> <td data-bbox="898 1596 989 1740">No</td> <td data-bbox="989 1596 1534 1740">                             Check following devices                             <ul style="list-style-type: none"> <li>● Accelerator cable linkage</li> <li>● Throttle lever</li> <li>● Accelerator pedal</li> <li>● Fast idle cam</li> </ul> </td> </tr> </table>	Yes	Go to next step	No	Check following devices <ul style="list-style-type: none"> <li>● Accelerator cable linkage</li> <li>● Throttle lever</li> <li>● Accelerator pedal</li> <li>● Fast idle cam</li> </ul>
Yes	Go to next step					
No	Check following devices <ul style="list-style-type: none"> <li>● Accelerator cable linkage</li> <li>● Throttle lever</li> <li>● Accelerator pedal</li> <li>● Fast idle cam</li> </ul>					




# F

## TROUBLESHOOTING GUIDE

STEP	INSPECTION		ACTION
5	Is solenoid valve (AWS) OK? ⇨ page F-83	Yes	Go to next step
		No	Repair
6	Is engine coolant temperature sensor OK? ⇨ page F-183	Yes	Go to next step
		No	Replace
7	Try known good PCME; does condition improved? ⇨ page F-150		

28	<ul style="list-style-type: none"> <li>● IDLE FLUCTUATES</li> <li>● IDLE HUNTS</li> </ul>	
DESCRIP-TION	<ul style="list-style-type: none"> <li>● Engine speed changes back and forth between specified idle speed and higher speed</li> </ul>	
<p><b>[TROUBLESHOOTING HINTS]</b></p> <p>① PCV valve</p> <ul style="list-style-type: none"> <li>● PCV valve stuck</li> </ul> <p>② Spark plug</p> <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> <p>③ Throttle position sensor</p> <ul style="list-style-type: none"> <li>● Incorrect adjustment</li> </ul> <p>④ Idle air control valve</p> <ul style="list-style-type: none"> <li>● Solenoid valve stuck</li> </ul> <p>⑤ Intake air system</p> <ul style="list-style-type: none"> <li>● Air leakage</li> </ul>		
STEP	INSPECTION	ACTION
1	<p>Is "00" displayed on SST with ignition switch ON?</p> <p>☞ page F-20</p> 	<p>Yes "00" displayed</p> <p>Go to next step</p> <p>No <b>Trouble Code No. displayed</b></p> <p>Check for cause (Refer to specified check sequence)</p> <p>☞ page F-22</p>
2	<p>Is a strong blue spark visible at each disconnected high-tension lead while cranking engine?</p> 	<p>Yes Check spark plug(s)</p> <p>If OK, go to next step</p> <p>If not OK clean or, replace spark plug(s)</p> <p>No Check as follows:</p> <ul style="list-style-type: none"> <li>● Ignition coils</li> <li>● Igniter</li> <li>● High-tension leads</li> <li>● PCME 1G, 1H, 1J terminal voltage</li> </ul> <p>☞ Section G</p>
3	<p>Is air leakage felt or heard at intake air system components?</p>	<p>Yes Repair or replace</p> <p>No Go to next step</p>
4	<p>Is PCV valve stuck?</p> <p>☞ page F-124</p>	<p>Yes Replace PCV valve</p> <p>No Go to next step</p>
5	<p>Is idle air control valve OK?</p> <p>☞ page F-83</p>	<p>Yes Go to next step</p> <p>No Replace</p>
6	<p>Is fuel line pressure correct at idle?</p> <p>☞ page F-98</p> <p><b>Fuel line pressure:</b> 190-220 kPa {1.9-2.3 kgf/cm<sup>2</sup>, 28-32 psi}</p>	<p>Yes Go to next step</p> <p>No <b>Low pressure</b></p> <p>Check as follows:</p> <ul style="list-style-type: none"> <li>● Fuel filter for clogging</li> <li>● Operation of pressure regulator</li> </ul>
7	<p>Try known good PCME; does condition improved?</p> <p>☞ page F-150</p>	



29	<ul style="list-style-type: none"> <li>● HESITATES</li> <li>● STUMBLES ON ACCELERATION</li> </ul>	
DESCRIPTION	<ul style="list-style-type: none"> <li>● Momentary pause at beginning of acceleration or during acceleration</li> </ul>	
<p><b>[TROUBLESHOOTING HINTS]</b></p> <p>① Injector</p> <ul style="list-style-type: none"> <li>● Fuel leakage from injector(s)</li> </ul> <p>② Pressure regulator</p> <ul style="list-style-type: none"> <li>● Pressure regulator stuck</li> </ul> <p>③ High-tension lead</p> <ul style="list-style-type: none"> <li>● Lead damaged</li> </ul> <p>④ Spark plug</p> <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> <p>⑤ Manifold absolute pressure sensor</p> <ul style="list-style-type: none"> <li>● Malfunction of manifold absolute pressure sensor</li> </ul> <p>Ⓞ EGR control valve</p> <ul style="list-style-type: none"> <li>● EGR control valve stuck</li> </ul> <p>⑦ Double throttle control</p> <ul style="list-style-type: none"> <li>● Double throttle valve stuck</li> </ul>		
STEP	INSPECTION	ACTION
1	<p>Is "00" displayed on SST with ignition switch ON?  <small>☞ page F-20</small></p> 	<p>Yes "00" displayed Go to next step</p> <p>No <b>Trouble Code No. displayed</b> Check for cause (Refer to specified check sequence)  <small>☞ page F-22</small></p>
2	<p>Is strong blue spark visible at each disconnected high-tension lead at idle?</p> 	<p>Yes Check spark plug(s) If OK, go to next step If not OK, clean or replace spark plug(s)</p> <p>No Check ignition system  <small>☞ Section G</small></p>
3	<p>Is fuel line pressure correct at idle?  <small>☞ page F-104</small></p> <p><b>Fuel line pressure</b>  <b>190-220 kPa (1.9-2.3 kgf/cm<sup>2</sup>, 28-32 psi)</b></p> 	<p>Yes Go to next step</p> <p>No <b>Low pressure</b> Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> <li>● If pressure <b>quickly</b> increases, check pressure regulator <small>☞ page F-104</small></li> <li>● If pressure <b>gradually</b> increases, check for clogging between fuel pump and pressure regulator</li> </ul> <p>If hose not clogged, check fuel pump maximum pressure  <small>☞ page F-101</small></p>

STEP	INSPECTION	ACTION	
4	Does fuel pressure increase when throttle valve opened? (engine running)	Yes	Go to next step
		No	Check pressure regulator ⇨ page F-104
5	Are following terminal voltage at PCME correct? ⇨ page F-154 1O (Manifold absolute pressure sensor) 3F (Throttle position sensor-Full range) 3G (Throttle position sensor-Narrow range) 3K (Solenoid valve (Relief 2)) 3O (Solenoid valve (Double throttle)) 3P (Secondary air bypass valve) 4E (Crankshaft position sensor (NE)) 4I, 4J, 4K, 4L (Metering oil pump) 4O (Solenoid valve (EGR)) 4R (Solenoid valve (Turbo control)) 4S (Solenoid valve (Charge relief)) 4T (Solenoid valve (Charge control)) 4V (Solenoid valve (Turbo precontrol)) 4W, 4X, 4Y, 4Z (Fuel injector)	Yes	Go to next step
		No	Check for cause ⇨ page F-155
6	Are injectors OK? ⇨ page F-106	Yes	Go to next step
		No	Repair or replace
7	Is EGR control system OK? ⇨ page F-126		
8	Try known good PCME; does condition improved? ⇨ page F-150		



<b>31</b>	<b>LACK OF POWER</b>		
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● Performance poor under load (i.e., power down when climbing hills)</li> </ul>		
<p><b>[TROUBLESHOOTING HINTS]</b></p> <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; vertical-align: top;"> <ul style="list-style-type: none"> <li>① Manifold absolute pressure sensor                             <ul style="list-style-type: none"> <li>● Malfunction of manifold absolute pressure sensor</li> </ul> </li> <li>② Secondary injector                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> <li>● Nozzle clogged</li> </ul> </li> <li>③ Air leakage                             <ul style="list-style-type: none"> <li>● Turbo boost leakage</li> </ul> </li> <li>④ Spark plug                             <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> </li> <li>⑤ Throttle position sensor (Full range)                             <ul style="list-style-type: none"> <li>● Malfunction of throttle position sensor</li> </ul> </li> <li>⑥ Fuel filter                             <ul style="list-style-type: none"> <li>● Filter clogged</li> </ul> </li> <li>⑦ Pressure regulator                             <ul style="list-style-type: none"> <li>● Malfunction of pressure regulator</li> </ul> </li> </ul> </td> <td style="width: 50%; vertical-align: top;"> <ul style="list-style-type: none"> <li>⑧ Double throttle control system                             <ul style="list-style-type: none"> <li>● Double throttle valve not open</li> </ul> </li> <li>⑨ Sequential twin turbo control system                             <ul style="list-style-type: none"> <li>● Secondary port not open</li> <li>● Malfunction of check valve(s)</li> </ul> </li> <li>⑩ EGR control system                             <ul style="list-style-type: none"> <li>● EGR control valve stuck (open)</li> </ul> </li> <li>⑪ Air cleaner housing                             <ul style="list-style-type: none"> <li>● Clogged element</li> </ul> </li> <li>⑫ Three-way catalyst                             <ul style="list-style-type: none"> <li>● Clogged three-way catalyst</li> </ul> </li> <li>⑬ Fuel                             <ul style="list-style-type: none"> <li>● Low octane fuel used</li> </ul> </li> <li>⑭ Metering oil pump                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> </ul> </td> </tr> </table>		<ul style="list-style-type: none"> <li>① Manifold absolute pressure sensor                             <ul style="list-style-type: none"> <li>● Malfunction of manifold absolute pressure sensor</li> </ul> </li> <li>② Secondary injector                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> <li>● Nozzle clogged</li> </ul> </li> <li>③ Air leakage                             <ul style="list-style-type: none"> <li>● Turbo boost leakage</li> </ul> </li> <li>④ Spark plug                             <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> </li> <li>⑤ Throttle position sensor (Full range)                             <ul style="list-style-type: none"> <li>● Malfunction of throttle position sensor</li> </ul> </li> <li>⑥ Fuel filter                             <ul style="list-style-type: none"> <li>● Filter clogged</li> </ul> </li> <li>⑦ Pressure regulator                             <ul style="list-style-type: none"> <li>● Malfunction of pressure regulator</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>⑧ Double throttle control system                             <ul style="list-style-type: none"> <li>● Double throttle valve not open</li> </ul> </li> <li>⑨ Sequential twin turbo control system                             <ul style="list-style-type: none"> <li>● Secondary port not open</li> <li>● Malfunction of check valve(s)</li> </ul> </li> <li>⑩ EGR control system                             <ul style="list-style-type: none"> <li>● EGR control valve stuck (open)</li> </ul> </li> <li>⑪ Air cleaner housing                             <ul style="list-style-type: none"> <li>● Clogged element</li> </ul> </li> <li>⑫ Three-way catalyst                             <ul style="list-style-type: none"> <li>● Clogged three-way catalyst</li> </ul> </li> <li>⑬ Fuel                             <ul style="list-style-type: none"> <li>● Low octane fuel used</li> </ul> </li> <li>⑭ Metering oil pump                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> </ul>
<ul style="list-style-type: none"> <li>① Manifold absolute pressure sensor                             <ul style="list-style-type: none"> <li>● Malfunction of manifold absolute pressure sensor</li> </ul> </li> <li>② Secondary injector                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> <li>● Nozzle clogged</li> </ul> </li> <li>③ Air leakage                             <ul style="list-style-type: none"> <li>● Turbo boost leakage</li> </ul> </li> <li>④ Spark plug                             <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> </li> <li>⑤ Throttle position sensor (Full range)                             <ul style="list-style-type: none"> <li>● Malfunction of throttle position sensor</li> </ul> </li> <li>⑥ Fuel filter                             <ul style="list-style-type: none"> <li>● Filter clogged</li> </ul> </li> <li>⑦ Pressure regulator                             <ul style="list-style-type: none"> <li>● Malfunction of pressure regulator</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>⑧ Double throttle control system                             <ul style="list-style-type: none"> <li>● Double throttle valve not open</li> </ul> </li> <li>⑨ Sequential twin turbo control system                             <ul style="list-style-type: none"> <li>● Secondary port not open</li> <li>● Malfunction of check valve(s)</li> </ul> </li> <li>⑩ EGR control system                             <ul style="list-style-type: none"> <li>● EGR control valve stuck (open)</li> </ul> </li> <li>⑪ Air cleaner housing                             <ul style="list-style-type: none"> <li>● Clogged element</li> </ul> </li> <li>⑫ Three-way catalyst                             <ul style="list-style-type: none"> <li>● Clogged three-way catalyst</li> </ul> </li> <li>⑬ Fuel                             <ul style="list-style-type: none"> <li>● Low octane fuel used</li> </ul> </li> <li>⑭ Metering oil pump                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> </ul> </li> </ul>		

<b>32</b>	<b>POOR FUEL ECONOMY</b>
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● Fuel economy unsatisfactory</li> </ul>
<p><b>[TROUBLESHOOTING HINTS]</b></p> <ul style="list-style-type: none"> <li>① Engine compression             <ul style="list-style-type: none"> <li>● Compression low</li> </ul> </li> <li>② Spark plug(s)             <ul style="list-style-type: none"> <li>● Dirty or worn spark plug(s)</li> </ul> </li> <li>③ Ignition coil             <ul style="list-style-type: none"> <li>● Malfunction of ignition coil</li> </ul> </li> <li>④ Pressure regulator             <ul style="list-style-type: none"> <li>● Malfunction of pressure regulator</li> </ul> </li> <li>⑤ Intake air leakage             <ul style="list-style-type: none"> <li>● Air hose damaged or disconnected</li> </ul> </li> </ul>	

<b>33</b>	<b>A/C DOES NOT WORK</b>		
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● A/C compressor magnetic clutch does not engage when Air conditioning sensor ON</li> </ul>		
<p><b>[TROUBLESHOOTING HINTS]</b></p> <table style="width: 100%; border: none;"> <tr> <td style="width: 80%; vertical-align: top;"> <ul style="list-style-type: none"> <li>① A/C relay                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> <li>● Relay malfunction</li> </ul> </li> <li>② Air conditioning sensor                             <ul style="list-style-type: none"> <li>● Does not send signal to PCME terminal 1E</li> </ul> </li> <li>③ PCME                             <ul style="list-style-type: none"> <li>● PCME 1L terminal circuit open</li> </ul> </li> </ul> </td> <td style="width: 20%; vertical-align: top; padding-left: 20px;"> <ul style="list-style-type: none"> <li>➤ Section U</li> <li>➤ page F-152</li> <li>➤ page F-154</li> </ul> </td> </tr> </table>		<ul style="list-style-type: none"> <li>① A/C relay                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> <li>● Relay malfunction</li> </ul> </li> <li>② Air conditioning sensor                             <ul style="list-style-type: none"> <li>● Does not send signal to PCME terminal 1E</li> </ul> </li> <li>③ PCME                             <ul style="list-style-type: none"> <li>● PCME 1L terminal circuit open</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>➤ Section U</li> <li>➤ page F-152</li> <li>➤ page F-154</li> </ul>
<ul style="list-style-type: none"> <li>① A/C relay                             <ul style="list-style-type: none"> <li>● Poor connection of connector</li> <li>● Relay malfunction</li> </ul> </li> <li>② Air conditioning sensor                             <ul style="list-style-type: none"> <li>● Does not send signal to PCME terminal 1E</li> </ul> </li> <li>③ PCME                             <ul style="list-style-type: none"> <li>● PCME 1L terminal circuit open</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>➤ Section U</li> <li>➤ page F-152</li> <li>➤ page F-154</li> </ul>		

**F****TROUBLESHOOTING GUIDE**

<b>34</b>	<ul style="list-style-type: none"> <li>● <b>KNOCKING</b></li> <li>● <b>PINGING</b></li> </ul>
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● Sound produced when air/fuel mixture is ignited by something other than spark plug (i.e., hot spot in combustion chamber)</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b> Knock sensor <ul style="list-style-type: none"> <li>● Open or short in harness (Code No.05 output)</li> </ul> <div style="text-align: right;">➤ page F-171</div>	

<b>35</b>	<b>FUEL ODOR</b>
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● Gasoline smell or visible leaks</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b> ① Solenoid valve (purge control) <ul style="list-style-type: none"> <li>● Open harness (Code No.26 output)</li> </ul> ② Charcoal canister <ul style="list-style-type: none"> <li>● Canister full of fuel and leaking</li> </ul> <div style="text-align: right;">➤ page F-131</div>	

<b>36</b>	<b>EXHAUST SULFUR SMELL</b>
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● Rotten egg smell (sulfur) from exhaust</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b> High sulfur content fuel used	

<b>37</b>	<b>HIGH OIL CONSUMPTION</b>
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● Oil consumption excessive</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b> ① Metering oil pump <ul style="list-style-type: none"> <li>● Malfunction of metering oil pump</li> <li>● Open or short in wiring harness</li> </ul> ② PCV valve <ul style="list-style-type: none"> <li>● PCV valve stuck open</li> </ul> <div style="text-align: right;">➤ Section D</div> <div style="text-align: right;">➤ page F-124</div>	

<b>38</b>	<b>SELF-DIAGNOSIS CHECKER FLASHES 88</b>
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Checker flashes 88 with test connector (TEN) grounded</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b> ① Short circuit in wiring between data link connector terminal FEN and PCME terminal 1F ② PCME malfunction	

<b>39</b>	<b>MIL NEVER ON</b>
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Self-Diagnosis Checker indicates Trouble Code No. of input device but MIL never ON</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b> ① Bulb burnt ② Electrical load unit 1K terminal circuit open	

**SERVICE POINTS****OUTLINE****[Power and Ground]****Main relay (Battery power)**

- If the circuit is shorted, the EGI INJ fuse (30A) will burn out.

**PCME ground (Injector)**

- An open circuit will not produce any symptom.
- If the PCME ground (Output devices) circuit also has an open, the engine will not start.

**PCME ground (Output devices)**

- An open circuit will not produce any symptom.
- If PCME ground (Injector) circuit also has an open, the engine will not start.

**PCME ground (System)**

- An open circuit will not produce any symptom.

**PCME ground (Analogue)**

- If the circuit has an open, engine hard starting and rough idle will be caused and Trouble Code Nos. 09,11,12,13, 20 and 23 will be output.

**Room fuse (PCME memory power)**

- If the circuit is open, the PCME memory function will not operate, and trouble codes for intermittent malfunctions will not be indicated. Also, the learning control will be canceled, but will not produce any particular symptom.
- If the circuit is shorted, the ROOM fuse (15A) will burn out.

**[Input Device]****1-2 switch (MT)**

- If the circuit has an open or short, no symptom will be noticed.

**Air conditioning sensor**

- The switch monitor function can confirm the presence of an open or short circuit.
- If the circuit is open, the air conditioner (the magnetic clutch) will not operate.
- If the circuit is shorted, the air conditioner will constantly operate when the blower is ON.

**Barometric absolute pressure sensor**

- The sensor is contained in the PCME.
- If the sensor has an open or short circuit, Trouble Code No. 14 is output, and the PCME will use a preprogrammed pressure of sea level.
- A malfunction in the sensor causes engine roughness at high elevation.

**Clutch switch (MT)**

- Refer to "Neutral / clutch switches" on page F-173.

**Crankshaft position sensor (NE, G signal)**

- If the NE signal circuit has an open or short, Trouble Code No. 02 is output.
- If the G signal circuit has an open or short, Trouble Code No. 03 is output.
- If the NE or G signal circuit has an open or short, the engine will not start (No fuel injection and no ignition).

**E/L unit**

- If the circuit has an open, the switch monitor function can confirm that the blower fan, headlight, rear window defroster, signals are not input to the PCME.
- If the circuit is short, the Idle speed will be increased slightly.

**EGR function sensor**

- If the EGR function sensor or circuit has an open or short, Trouble Code No. 16 is output.

**Engine coolant temperature sensor**

- If the thermosensor or circuit has an open or short, Trouble Code No. 09 is output, and PCME uses a preprogrammed temperature value of 82°C {180°F}.
- A malfunction in the engine coolant temperature sensor or its circuit will cause hard starting or engine stall when engine is cold.
- In the above condition, the electric coolant fan will constantly operate when the ignition switch is ON.

**Fuel thermosensor**

- If the thermosensor circuit has an open or short, Trouble Code No. 23 is output.
- In the above conditions, the PCME will use a preprogrammed temperature value of 50°C {122°F} and no symptom will be noticed.

**Heat hazard sensor**

- If the circuit has open, no symptom will be noticed.
- If the sensor or circuit has a short, the heat hazard warning light will illuminate and the air pump will not operate, causing rough idle.

**Intake air temperature sensor**

- If the thermosensor or circuit has an open or short, Trouble Code No. 11 is output.
- In the above conditions, no symptom will be noticed.

**Knock sensor**

- If the knock sensor or circuit has an open or short, Trouble Code No. 05 is output.
- In the above conditions, ignition timing is retarded.

**Manifold absolute pressure sensor**

- If the sensor or circuit has an open or short, Trouble Code No. 13 is output.
- In the above condition, the PCME uses a preprogrammed fuel injection amount, causing rough idle and poor acceleration with afterburn.

**Metering oil pump position sensor**

- If the sensor or circuit has an open or short, Trouble Code 20 is output.
- In the above conditions, the fuel injection amount is fixed, causing poor acceleration and hesitation.

**Mileage switch / Steering pressure sensor**

- If the sensor circuit has an open circuit, no particular symptom will be noticed.
- If the sensor circuit has a short circuit, idle speed will be increased.

**Neutral switches (MT)**

- The switch monitor function of the Self-Diagnosis Checker can confirm the presence of an open or short circuit.
- If the circuit is open, the idle speed drops when the A/C, P/S, or electrical load is ON.

**Oxygen sensor**

- If the sensor output voltage continues below 0.55V for 100 sec. after the engine exceeds 1,500 rpm because of an open or short circuit, Trouble Code No. 15 is output.
- If the sensor output voltage continues unchanged 50 Sec, after the engine exceeds 1,500 rpm, Trouble Code No. 17 is output.
- In the above conditions, no fuel injection closed loop control will be present and no symptom will be noticed.

**Park / Neutral signal (AT; Refer to section K)**

- If the circuit is open or shorted, the idle speed will be slightly low in R, D, S, and L ranges.



**Reduce torque signal (AT; Refer to section K)**

- If a malfunction occurs in the reduce torque signal, the torque reduction control system is inhibited and line pressure will be high at shifting. Shift shock may be slightly increased.

**Slip lock-up signal (AT; Refer to section K)**

- If a malfunction occurs in the slip lock-up signal, line pressure will be high at shifting and shift shock may be slightly increased.

**Solenoid valve (Shift A) (AT)**

- Refer to section K.

**Solenoid valve (Shift B) (AT)**

- Refer to section K.

**Start signal**

- A lack of engine cranking signal will cause hard starting when engine is cold.

**Steering pressure sensor**

- Refer to "Mileage switch".

**Stoplight switch**

- The switch monitor function can confirm the presence of an open or short circuit.
- An open or short circuit will produce no symptom.
- A short circuit will cause the STOP fuse (20A) burn out.

**TEN terminal (Data link connector)**

- If the circuit is open, the Self-Diagnosis Checker can not perform trouble code checks.
- If the circuit is shorted, the opening amount of the idle air control valve will not change, causing hard starting and rough idle. The Self-Diagnosis Checker cannot perform sensor monitoring checks.

**Throttle position sensor (Narrow range)**

- If the sensor or circuit has an open or short, Trouble Code No. 18 is output.
- In the above condition, rough idle, and engine stall on deceleration will be caused.

**Throttle position sensor (Full range)**

- If the sensor or circuit has an open or short, Trouble Code No. 12 is output.
- In the above condition, poor acceleration will be caused.

**Vehicle speed sensor**

- If the vehicle speed signal circuit has an open or short, Trouble Code No. 06 is output.
- If the circuit has open or short, hold mode will not operate.

**[Output Device]****A/C relay**

- If the circuit is open, the air conditioner (Magnetic clutch) will not operate.
- If the circuit is shorted, the air conditioner will constantly operate when blower is ON, causing rough idle.

**Air pump relay**

- If the relay or circuit has an open or short, Trouble Code No. 54 is output.
- If the circuit is short, air pump will always operate, causing three-way catalyst melted.
- If the circuit is open, the air pump will never operate, causing rough idle.

**Fan relay**

- If the circuit is shorted, the coolant fan will always operate while the ignition switch ON.
- If the circuit is open, the coolant fan will not operate until the engine temperature exceeds 108°C {226°F}.

**FEN terminal (Data link connector)**

- If the circuit between the data link connector and E/L unit is open, the Self-Diagnosis Checker buzzer will not sound during the trouble code check.
- If the circuit between PCME 1F terminal and E/L unit is open, the Self-Diagnosis Checker buzzer will constantly sound during the trouble code check.
- If the circuit is shorted, code "88" will keep flashing and the buzzer will continue sounding (Self-Diagnosis Checker), preventing a trouble code check.

**Fuel injector**

- If a secondary injector or circuit has an open or short, Trouble Code No. 71 (Front) or 73 (Rear) is output, causing poor acceleration and lack of engine power.
- If a primary injector or circuit has an open, engine will stall and will not start.

**Fuel pump relay**

- If the circuit is open, the engine will not start.
- If the circuit is shorted, the fuel pump will operate whenever the ignition switch is ON.

**Fuel pump relay (speed)**

- If the relay or circuit has an open or short, Trouble Code No. 51 is output.
- If the circuit is open, engine will hesitate or engine power will lack.

**Idle air control valve**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 34 is output.
- If the circuit is open, the valve will always closed throttle position, causing rough idle and hard starting.
- If the circuit is shorted, the valve will always wide open throttle, causing high idle speed. (After warm-up, engine hunts at approx. 1500 rpm.)

**Igniter**

- If a trailing igniter or circuit has an open or short, idle speed will be slightly decreased and poor acceleration will be caused.
- If the leading igniter or circuit has an open or short, hard starting and rough idle will be caused.

**MEN Terminal (Data Link Connector)**

- If the circuit is open, the monitor lamp will not illuminate.
- If the circuit is shorted, the monitor lamp will stay on.

**Metering oil pump**

- If the pump or circuit has an open or short, Trouble Code No. 26 and 27 are output.
- In the above conditions, PCME fixes ignition timing and fuel injection amount, causing engine poor acceleration.

**PCMT (AT)**

- Refer to section K.

**Secondary air bypass valve**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 31 is output.
- If the circuit is open, no symptom will be noticed.
- If the circuit is shorted, solenoid / valve will be always open and CO and HC will be increased.

**Secondary air switching valve**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 32 is output.
- If the circuit is open, no symptom will be noticed.
- If the circuit is shorted, rough idle will result.

**Solenoid valve (Accelerated warm-up system)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 38 is output.
- If the circuit is open, the fast idle speed just after engine starting will not exceed 2,000 rpm.
- If the circuit is shorted, the idle speed will be increased and then hunted at the specified speed (approx. 1500 rpm after warm-up).

**Solenoid valve (Charge control)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 45 is output.
- In the above conditions, the PCME fixes the ignition timing and fuel injection amount, causing poor acceleration and lack of power.

**Solenoid valve (Charge relief)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 46 is output.
- If the circuit is open, the charge relief valve will always open, causing poor acceleration.
- If the circuit is shorted, the charge relief valve will always closed, causing momentarily intake air noise on acceleration.

**Solenoid valve (Double throttle control)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 50 is output.
- If the circuit is open, the double throttle valve will always closed, causing poor acceleration and lack of power.
- If the circuit is shorted, the double throttle valve will always open, causing hesitation when the engine is cold.

**Solenoid valve (EGR)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 28 is output.
- If the circuit is open, no symptom will be noticed.
- If the circuit is shorted, the EGR valve will always open, causing engine stalling and hard starting.

**Solenoid valve (Port air bypass)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 33 is output.
- In the above conditions, no symptom will be noticed.

**Solenoid valve (Pressure regulator control)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 25 is output.
- If the circuit is open, hard starting may result when the engine is hot.
- If the circuit is shorted, fuel pressure will always be approx. 280 kPa {2.9 kgf/cm<sup>2</sup>, 41 psi} and no symptom will be noticed.

**Solenoid valve (Purge control)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 40 is output.
- If the circuit is open, no symptom will be noticed.
- If the circuit is shorted, the engine stalls at low speed.

**Solenoid valve (Relief 2)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 39 is output.
- If the circuit is open, no symptom will be noticed.
- If the circuit is shorted, secondary air noise will be heard while the air pump operates.

**Solenoid valve (Split air bypass)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 30 is output.
- In the above conditions, no symptom will be produced.

**Solenoid valve (Turbo control 1, Turbo control 2)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 44 is output.
- If the circuit is open, the turbo control valve will not open, causing poor acceleration and lack of power.
- If the circuit is shorted, turbo control valve will open earlier on acceleration, causing poor acceleration.

**Solenoid valve (Turbo precontrol)**


- If the solenoid valve or circuit has an open or short, Trouble Code No. 42 is output.
- If the circuit is open, the precontrol valve will open earlier, causing slightly hesitation and poor acceleration.
- If the circuit is short, precontrol valve will never open, causing hesitation and poor acceleration.

**Solenoid valve (Wastegate control)**

- If the solenoid valve or circuit has an open or short, Trouble Code No. 43 is output.
- If the circuit is open, wastegate valve will open earlier, causing poor acceleration and lack of power.
- If the circuit is shorted, wastegate valve will not open easily and no symptom will be noticed. (To prevent engine damage, the overboost fuel cut will be operated.)


**WIRING DIAGRAM**

**B-1a ENGINE CONTROL SYSTEM ■ FUEL CONTROL SYSTEM ■ IGNITION SYSTEM**




B1-01 POWERTRAIN CONTROL MODULE (ENGINE) (F)	B1-02 EGI MAIN RELAY (F)	B1-03 FUEL PUMP RELAY (F)	B1-04 FUEL PUMP RELAY (F)	B1-05 FUEL PUMP RESISTOR (F)	B1-06 FUEL PUMP (FP)	B1-07 MAGNETIC CLUTCH (A/P) (EM)	B1-08 AIR PUMP RELAY (F)	B1-09 IGNITER (F)	B1-10 CONDENSER (F)	B1-11 IGNITION COIL-TR (IG)
1U 1S 1Q 10 1H 1K 11 1G 1E 1C 1A 2K 2I 2G 2E 2C 2A	L G 1B 2D 1G/Y G/R L/W LG/Y BR G/Y/R B/R L/R	L G 1B 2D 1G/Y G/R L/W LG/Y BR G/Y/R B/R L/R	L G 1B 2D 1G/Y G/R L/W LG/Y BR G/Y/R B/R L/R	L G 1B 2D 1G/Y G/R L/W LG/Y BR G/Y/R B/R L/R	L G 1B 2D 1G/Y G/R L/W LG/Y BR G/Y/R B/R L/R	L G 1B 2D 1G/Y G/R L/W LG/Y BR G/Y/R B/R L/R	L G 1B 2D 1G/Y G/R L/W LG/Y BR G/Y/R B/R L/R	L G 1B 2D 1G/Y G/R L/W LG/Y BR G/Y/R B/R L/R	L G 1B 2D 1G/Y G/R L/W LG/Y BR G/Y/R B/R L/R	L G 1B 2D 1G/Y G/R L/W LG/Y BR G/Y/R B/R L/R
1V 1T 1R 1P 1N 1L 1J 1H 1F 1D 1B 1A	* L/B G/Y *	* L/B G/Y *	* L/B G/Y *	* L/B G/Y *	* L/B G/Y *	* L/B G/Y *	* L/B G/Y *	* L/B G/Y *	* L/B G/Y *	* L/B G/Y *
B1-06 FUEL PUMP (FP)	B1-07 MAGNETIC CLUTCH (A/P) (EM)	B1-08 AIR PUMP RELAY (F)	B1-09 IGNITER (F)	B1-10 CONDENSER (F)	B1-11 IGNITION COIL-TR (IG)	B1-12 IGNITION COIL-TF (IG)	B1-13 IGNITION COIL-L (IG)	B1-14 CONNECTOR BETWEEN ENGINE (E) AND IGNITION (IG)		
W/G L B W/R	B/G B/L	G B B/W *	L G/B LG L/G/W B/W BR/B G/R BR	L B/LG L/R L/B	R Y/L L/W B/R	R Y/L L/W B/R	R Y/L L/W B/R	R Y/L L/W B/R		
B1-12 IGNITION COIL-TF (IG)										
R B/R										

**B-1b ■ ENGINE CONTROL SYSTEM ■ FUEL CONTROL SYSTEM**




B1-01 POWERTRAIN CONTROL MODULE (ENGINE)		B1-15 INJECTOR (PRIMARY FRONT)		B1-16 INJECTOR (PRIMARY REAR)		B1-17 INJECTOR (SECONDARY FRONT)		B1-18 INJECTOR (SECONDARY REAR)		B1-19 HEAT HAZARD SENSOR (FR)		B1-20 ELECTRICAL LOAD CONTROL UNIT (D)		B1-21 STEERING PRESSURE SENSOR (E)	
1U	1S	1G	1H	1K	1I	1G	1E	1C	1A	2K	2I	2G	2E	2C	2A
1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	3K	3M	3K	3I	3G	3E
1W	1Q	1O	1M	1K	1I	1G	1E	1C	1A	4Y	4W	4U	4S	4O	4K
1X	1Y	1Z	1V	1T	1R	1P	1N	1L	1J	5Y	5W	5U	5S	5O	5K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	6Y	6W	6U	6S	6O	6K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	7Y	7W	7U	7S	7O	7K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	8Y	8W	8U	8S	8O	8K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	9Y	9W	9U	9S	9O	9K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	10Y	10W	10U	10S	10O	10K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	11Y	11W	11U	11S	11O	11K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	12Y	12W	12U	12S	12O	12K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	13Y	13W	13U	13S	13O	13K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	14Y	14W	14U	14S	14O	14K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	15Y	15W	15U	15S	15O	15K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	16Y	16W	16U	16S	16O	16K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	17Y	17W	17U	17S	17O	17K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	18Y	18W	18U	18S	18O	18K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	19Y	19W	19U	19S	19O	19K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	20Y	20W	20U	20S	20O	20K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	21Y	21W	21U	21S	21O	21K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	22Y	22W	22U	22S	22O	22K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	23Y	23W	23U	23S	23O	23K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	24Y	24W	24U	24S	24O	24K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	25Y	25W	25U	25S	25O	25K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	26Y	26W	26U	26S	26O	26K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	27Y	27W	27U	27S	27O	27K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	28Y	28W	28U	28S	28O	28K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	29Y	29W	29U	29S	29O	29K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	30Y	30W	30U	30S	30O	30K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	31Y	31W	31U	31S	31O	31K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	32Y	32W	32U	32S	32O	32K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	33Y	33W	33U	33S	33O	33K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	34Y	34W	34U	34S	34O	34K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	35Y	35W	35U	35S	35O	35K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	36Y	36W	36U	36S	36O	36K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	37Y	37W	37U	37S	37O	37K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	38Y	38W	38U	38S	38O	38K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	39Y	39W	39U	39S	39O	39K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	40Y	40W	40U	40S	40O	40K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	41Y	41W	41U	41S	41O	41K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	42Y	42W	42U	42S	42O	42K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	43Y	43W	43U	43S	43O	43K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	44Y	44W	44U	44S	44O	44K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	45Y	45W	45U	45S	45O	45K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	46Y	46W	46U	46S	46O	46K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	47Y	47W	47U	47S	47O	47K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	48Y	48W	48U	48S	48O	48K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	49Y	49W	49U	49S	49O	49K
1AA	1AB	1AC	1AD	1AE	1AF	1AG	1AH	1AI	1AJ	50Y	50W	50U	50S	50O	50K

**B-1c** ■ **ENGINE CONTROL SYSTEM**



B1-01 POWERTRAIN CONTROL MODULE (ENGINE)	B1-02 TURBO CONTROL 1 SOLENOID VALVE (EM)	B1-03 TURBO CONTROL 2 SOLENOID VALVE (EM)	B1-04 TURBO PRE-CONTROL SOLENOID VALVE (EM)	B1-05 IDLE AIR CONTROL SOLENOID VALVE (EM)	B1-06 CHARGE RELIEF SOLENOID VALVE (EM)	B1-07 DOUBLE THROTTLE SOLENOID VALVE (EM)	B1-08 CHARGE CONTROL SOLENOID VALVE (EM)	B1-09 TURBO CONTROL 1 SOLENOID VALVE (EM)	B1-10 TURBO CONTROL 2 SOLENOID VALVE (EM)	B1-11 THROTTLE POSITION SENSOR (EM)	B1-12 EGR FUNCTION SENSOR (EM)	B1-13 INTAKE AIR TEMPERATURE SENSOR (EM)	B1-14 FUEL THERMOSENSOR (SECTION B-1b)	B1-15 MANIFOLD ABSOLUTE PRESSURE SENSOR (EM)	B1-16 KNOCK SENSOR (EM)	B1-17 OXYGEN SENSOR (EM)	B1-18 SHIELD WIRE (SECTION B-1a)
B1-19 PURGE SOLENOID VALVE (EM)	B1-20 WASTE GATE SOLENOID VALVE (EM)	B1-21 PRE-TURBO SOLENOID VALVE (EM)	B1-22 IDLE AIR SOLENOID VALVE (EM)	B1-23 CHARGE RELIEF SOLENOID VALVE (EM)	B1-24 DOUBLE THROTTLE SOLENOID VALVE (EM)	B1-25 CHARGE CONTROL SOLENOID VALVE (EM)	B1-26 TURBO CONTROL 1 SOLENOID VALVE (EM)	B1-27 TURBO CONTROL 2 SOLENOID VALVE (EM)	B1-28 THROTTLE POSITION SENSOR (EM)	B1-29 EGR FUNCTION SENSOR (EM)	B1-30 INTAKE AIR TEMPERATURE SENSOR (EM)	B1-31 FUEL THERMOSENSOR (SECTION B-1b)	B1-32 MANIFOLD ABSOLUTE PRESSURE SENSOR (EM)	B1-33 KNOCK SENSOR (EM)	B1-34 OXYGEN SENSOR (EM)	B1-35 SHIELD WIRE (SECTION B-1a)	B1-36 METERING OIL PUMP
B1-37 WASTEGATE SOLENOID VALVE (EM)	B1-38 PRE-TURBO SOLENOID VALVE (EM)	B1-39 IDLE AIR SOLENOID VALVE (EM)	B1-40 CHARGE RELIEF SOLENOID VALVE (EM)	B1-41 DOUBLE THROTTLE SOLENOID VALVE (EM)	B1-42 CHARGE CONTROL SOLENOID VALVE (EM)	B1-43 TURBO CONTROL 1 SOLENOID VALVE (EM)	B1-44 TURBO CONTROL 2 SOLENOID VALVE (EM)	B1-45 THROTTLE POSITION SENSOR (EM)	B1-46 EGR FUNCTION SENSOR (EM)	B1-47 INTAKE AIR TEMPERATURE SENSOR (EM)	B1-48 FUEL THERMOSENSOR (SECTION B-1b)	B1-49 MANIFOLD ABSOLUTE PRESSURE SENSOR (EM)	B1-50 KNOCK SENSOR (EM)	B1-51 OXYGEN SENSOR (EM)	B1-52 SHIELD WIRE (SECTION B-1a)	B1-53 METERING OIL PUMP	

B-1d ENGINE CONTROL SYSTEM



Terminal	Wire Color	Component	Notes
1U	B	POWERTRAIN CONTROL MODULE (ENGINE)	
1S	G	CRANKSHAFT POSITION SENSOR (G)	
10	G/Y	CRANKSHAFT POSITION SENSOR (NE)	
1G	L/W	CRANKSHAFT POSITION SENSOR (NE)	
1K	G/Y	CRANKSHAFT POSITION SENSOR (NE)	
1I	L/W	CRANKSHAFT POSITION SENSOR (NE)	
1G	L/W	CRANKSHAFT POSITION SENSOR (NE)	
1E	G	CRANKSHAFT POSITION SENSOR (NE)	
1C	B	CRANKSHAFT POSITION SENSOR (NE)	
1A	B	CRANKSHAFT POSITION SENSOR (NE)	
2K	W	1-2 SWITCH	
2J	GY	1-2 SWITCH	
2H	W	1-2 SWITCH	
2F	W	1-2 SWITCH	
2E	W	1-2 SWITCH	
2C	W	1-2 SWITCH	
2A	W	1-2 SWITCH	
4Y	LG/B	CLUTCH SWITCH (D)	(MT ONLY)
4U	L/W	CLUTCH SWITCH (D)	(MT ONLY)
4S	P	CLUTCH SWITCH (D)	(MT ONLY)
40	L/G	CLUTCH SWITCH (D)	(MT ONLY)
4M	L/Y	CLUTCH SWITCH (D)	(MT ONLY)
4K	L/O	CLUTCH SWITCH (D)	(MT ONLY)
4I	B/O	CLUTCH SWITCH (D)	(MT ONLY)
4G	W	CLUTCH SWITCH (D)	(MT ONLY)
4E	B	CLUTCH SWITCH (D)	(MT ONLY)
4C	B	CLUTCH SWITCH (D)	(MT ONLY)
4A	B/W	CLUTCH SWITCH (D)	(MT ONLY)
4Z	LG	CLUTCH SWITCH (D)	(MT ONLY)
4X	W	CLUTCH SWITCH (D)	(MT ONLY)
4V	L/G	CLUTCH SWITCH (D)	(MT ONLY)
4W	L/Y	CLUTCH SWITCH (D)	(MT ONLY)
4R	L/B	CLUTCH SWITCH (D)	(MT ONLY)
4P	Y/L	CLUTCH SWITCH (D)	(MT ONLY)
4N	BR/Y	CLUTCH SWITCH (D)	(MT ONLY)
4L	B/Y	CLUTCH SWITCH (D)	(MT ONLY)
4J	B/R	CLUTCH SWITCH (D)	(MT ONLY)
4F	B/W	CLUTCH SWITCH (D)	(MT ONLY)
4D	B/W	CLUTCH SWITCH (D)	(MT ONLY)
4B	B/W	CLUTCH SWITCH (D)	(MT ONLY)
44	L/G	CRUISE CONTROL UNIT	
43	R/W	CRUISE CONTROL UNIT	
42	G/Y	CRUISE CONTROL UNIT	
41	G/R	CRUISE CONTROL UNIT	
40	G/W	CRUISE CONTROL UNIT	
39	Y	CRUISE CONTROL UNIT	
26	L/G	POWERTRAIN CONTROL MODULE (TRANSMISSION)	
25	O/B	POWERTRAIN CONTROL MODULE (TRANSMISSION)	
20	L	POWERTRAIN CONTROL MODULE (TRANSMISSION)	
2C	Y/G	POWERTRAIN CONTROL MODULE (TRANSMISSION)	
2D	L	POWERTRAIN CONTROL MODULE (TRANSMISSION)	
2E	O/B	POWERTRAIN CONTROL MODULE (TRANSMISSION)	
2G	L/G	POWERTRAIN CONTROL MODULE (TRANSMISSION)	
2K	V/W	POWERTRAIN CONTROL MODULE (TRANSMISSION)	
2L	R	POWERTRAIN CONTROL MODULE (TRANSMISSION)	
19	G	STOPLIGHT SWITCH	
1M	G/R	INSTRUMENT CLUSTER	
1L	Y/B	A/C RELAY	
1E	GY/R	REFRIGERANT PRESSURE SWITCH	
1C	B/R	STARTER INTERLOCK SWITCH	
4E	B	CRANKSHAFT POSITION SENSOR (G)	
4H	R	CRANKSHAFT POSITION SENSOR (G)	
4G	V	CRANKSHAFT POSITION SENSOR (G)	
4F	B	CRANKSHAFT POSITION SENSOR (G)	
4D	B	CRANKSHAFT POSITION SENSOR (G)	
4C	B	CRANKSHAFT POSITION SENSOR (G)	
4B	B	CRANKSHAFT POSITION SENSOR (G)	
4A	B	CRANKSHAFT POSITION SENSOR (G)	
37	G	STOPLIGHT SWITCH	
36	G/R	INSTRUMENT CLUSTER	
35	Y/B	A/C RELAY	
34	GY/R	REFRIGERANT PRESSURE SWITCH	
33	B/R	STARTER INTERLOCK SWITCH	
32	B	CRANKSHAFT POSITION SENSOR (G)	
31	B	CRANKSHAFT POSITION SENSOR (G)	
30	B	CRANKSHAFT POSITION SENSOR (G)	
29	B	CRANKSHAFT POSITION SENSOR (G)	
28	B	CRANKSHAFT POSITION SENSOR (G)	
27	B	CRANKSHAFT POSITION SENSOR (G)	
26	B	CRANKSHAFT POSITION SENSOR (G)	
25	B	CRANKSHAFT POSITION SENSOR (G)	
24	B	CRANKSHAFT POSITION SENSOR (G)	
23	B	CRANKSHAFT POSITION SENSOR (G)	
22	B	CRANKSHAFT POSITION SENSOR (G)	
21	B	CRANKSHAFT POSITION SENSOR (G)	
20	B	CRANKSHAFT POSITION SENSOR (G)	
19	B	CRANKSHAFT POSITION SENSOR (G)	
18	B	CRANKSHAFT POSITION SENSOR (G)	
17	B	CRANKSHAFT POSITION SENSOR (G)	
16	B	CRANKSHAFT POSITION SENSOR (G)	
15	B	CRANKSHAFT POSITION SENSOR (G)	
14	B	CRANKSHAFT POSITION SENSOR (G)	
13	B	CRANKSHAFT POSITION SENSOR (G)	
12	B	CRANKSHAFT POSITION SENSOR (G)	
11	B	CRANKSHAFT POSITION SENSOR (G)	
10	B	CRANKSHAFT POSITION SENSOR (G)	
9	B	CRANKSHAFT POSITION SENSOR (G)	
8	B	CRANKSHAFT POSITION SENSOR (G)	
7	B	CRANKSHAFT POSITION SENSOR (G)	
6	B	CRANKSHAFT POSITION SENSOR (G)	
5	B	CRANKSHAFT POSITION SENSOR (G)	
4	B	CRANKSHAFT POSITION SENSOR (G)	
3	B	CRANKSHAFT POSITION SENSOR (G)	
2	B	CRANKSHAFT POSITION SENSOR (G)	
1	B	CRANKSHAFT POSITION SENSOR (G)	



# F

## SERVICE POINTS

### ELECTRICAL DIAGNOSIS SUPPORT

#### [Power and Ground]

#### Main relay (Battery power)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1B)–Main relay	Engine hard starting	EGI INJ fuse (30A) burns out when ignition switch ON	NA

#### Room fuse (Memory power)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1A)–Room fuse	No symptom	ROOM fuse (15A) burns out	NA

#### PCME ground (Output device, Injector, System, Analogue)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4A)–Ground (Output device)	(One side open circuit) No symptom (Both sides open circuit) Engine will not start	NA	(One side poor ground) No symptom
PCME (4B)–Ground (Injector)			(Both sides poor ground) Engine will not start
PCME (4C)–Ground (System)			No symptom
PCME (4D)–Ground (Analogue)			Code Nos. 09, 11, 12, 13, 20, and 23 Engine hard starting Rough idle

#### [Input Device]

#### Air conditioning sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME(1E)–A/C amplifier	Air conditioner (magnetic clutch) will not operate	Air conditioner will constantly operate with blower ON	NA

#### Clutch switch (MT)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1Q)–Clutch switch	No symptom	No symptom	NA

#### Crankshaft position sensor (NE, G signal)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4E)–Crankshaft position sensor (NE)	Code No. 02 output Engine will not start	Code No. 02 output Engine will not start	NA
PCME (4G)–Crankshaft position sensor (G)	Code No. 03 output Engine will not start	Code No. 03 output Engine will not start	
PCME (4H)–Crankshaft position sensor (Ground)	Code Nos. 02 and 03 output Engine will not start	NA	Engine will not start Engine suddenly stalls

NA: Not applicable

# SERVICE POINTS

# F

## E/L unit

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1F)-E/L unit (H)	MIL will never ON	MIL will always ON Self-Diagnosis Checker buzzer sounds constantly	NA
PCME (3B)-E/L unit (N)	Idle speed will be low when E/L ON*1	Idle speed will be high	
Main relay-E/L unit (A)	Idle speed will be low when E/L ON*1	EGI INJ fuse (30A) burns out when ignition switch ON	
Headlight switch-E/L unit (B)	Idle speed may be low when headlight switch ON	Parking lights will always ON	
Rear window defroster switch-E/L unit (D)	Idle speed may be low when defroster switch ON	Rear window defroster al- ways ON when ignition switch ON	
Heater control unit-E/L unit (E)	Idle speed may be low when blower fan operate high speed	High idle speed when blower fan not operate	
MIL-E/L unit (K)	MIL will never ON	MIL will always ON	
Ground-E/L unit (M)	Idle speed drops when E/L ON*1 MIL will never ON	NA	Idle speed hunts or drops when E/L ON*1 MIL will never ON

\*1 E/L ON: Headlight switch ON, rear window defroster switch ON, or blower switch at 3rd or 4th position.

## EGR function sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3J)-EGR function sensor	Code No. 16 output No symptom	Code No. 16 output No symptom	NA
PCME (4D)-EGR function sensor		No symptom	

## Fuel thermosensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1U)-Fuel thermosensor	Code No. 23 output No symptom	Code No. 23 output No symptom	NA
PCME (4D)-Fuel thermosensor		No symptom	

## Heat hazard sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (2I)-Heat hazard sensor	No symptom	Heat hazard warning light il- luminates Rough idle	NA
Ground-Heat hazard sensor		No symptom	

NA: Not applicable

# F

## SERVICE POINTS

### Park / Neutral signal (AT)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1R)-PCMT (1C)	Idle speed drops when shifted to L, S, D or R range		NA

### Intake air temperature sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3L)-Thermosensor	Code No. 11 output No symptom	Code No. 11 output No symptom	NA
PCME (4D)-Thermosensor		No symptom	

### Knock sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3M)-Knock sensor	Code No. 05 output Lack of power Knocking	Code No. 05 output Lack of power Knocking	NA

### Metering oil pump position sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3A)-Metering oil pump (J)	Code No. 20 output Poor acceleration Hesitation	Code No. 20 output Poor acceleration Hesitation	NA
PCME (4D)-Metering oil pump (H)		No symptom	
PCME (3I)-Metering oil pump (I)		Code No. 20 output Poor acceleration Hesitation	

### Mileage switch

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1N)-Mileage switch	No symptom	Idle speed slightly high	NA

### Neutral switch (MT)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1R)-Neutral switch	Idle speed slightly high	Idle speed drops when A/C, P/S, or E/L ON	NA

### 1-2 switch (MT)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (2K)-1-2 switch	No symptom	No symptom	NA
PCME (2L)-1-2 switch			
Ground-1-2 switch			No symptom

NA: Not applicable

**Oxygen sensor**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3C)–Oxygen sensor	Code No. 15 output No symptom	Code No. 15 output No symptom	NA

**Manifold absolute pressure sensor**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1O)–Manifold absolute pressure sensor	Code No. 13 output Poor acceleration Rough idle	Code No. 13 output Poor acceleration Rough idle	NA
PCME (3I)–Manifold absolute pressure sensor			
PCME (4D)–Manifold absolute pressure sensor		No symptom	

**Steering pressure sensor**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1N)–Steering pressure sensor	No symptom	Idle speed slightly high	NA

**Reduced torque signal, slip lock-up signal (AT)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1Q)–PCMT (2P)	Shift shock slightly increased		NA

**Solenoid valve (Shift A) (AT)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (2K)–PCMT (1D)	Shift shock slightly increased		NA

**Solenoid valve (Shift B) (AT)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (2L)–PCMT (1B)	Shift shock slightly increased		NA

**Stoplight signal (Stoplight switch)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1S)–Stoplight switch	No symptom	STOP fuse (20A) burns out	NA

**Throttle position sensor (Narrow range, Full range)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3F)–Throttle position sensor (Narrow range)	Code No. 18 output Rough idle Strong shift shock (AT)	Code No. 18 output Rough idle Strong shift shock (AT)	NA
PCME (3G)–Throttle position sensor (Full range)	Code No. 12 output Poor acceleration Strong shift shock (AT)	Code No. 12 output Poor acceleration Strong shift shock (AT)	
PCME (3I)–Throttle position sensor	Code Nos. 12,18 output Rough idle Code No. 12 output	Code Nos. 12 and 18 output Rough idle	
PCME (4D)–Throttle position sensor	Rough idle	No symptom	

NA: Not applicable

# F

## SERVICE POINTS

### TEN terminal (Data link connector)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1I)–Data link connector	Cannot perform trouble code checks and switch monitor checks	Hard starting Rough idle	NA

### Engine coolant temperature sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3E)–Engine coolant temperature sensor	Code No. 09 output Rough idle and hard starting when engine cold	Code No. 09 output Rough idle and hard starting when engine cold	NA
PCME (4D)–Engine coolant temperature sensor		No symptom	

### Vehicle speed sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1M)–Vehicle speed sensor	Code No. 06 output Hold mode will not operate (AT)		NA

### [Output Device] A/C relay

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1L)–A/C relay	A/C will not operate	A/C constantly operate when blower ON Rough idle	NA

### Air pump relay

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (2J)–Air pump relay	Code No. 54 output Rough idle	Code No. 54 output Three-way catalyst melted	NA

### Fan relay

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3D)–fan relay	Coolant fan will not operate until coolant temperature exceeds 108°C {226°F}	Coolant fan always operate when ignition switch ON	NA

### Fuel injector

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4X, 4Z)–Secondary injector	Code No. 71 or 73 output Lack of power	Code No. 71 or 73 output Engine will not start	NA
PCME (4W, 4X)–Primary injector		Engine stalls Engine will not start	

NA: Not applicable

**Fuel pump relay (speed)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1K)–Fuel pump relay (speed)	Code No. 51 output Hesitation Lack of power	Code No. 51 output No symptom	NA

**FEN terminal (Data link connector)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1F)–Data link connector	Self-Diagnosis Checker buzzer will not sound during trouble code check	Code "88" will keep flashing and buzzer will continue sounding during trouble code check	NA

**Idle air control valve**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4Q)–Solenoid valve	Code No. 34 output Rough idle Hard start	Code No. 34 output Idle speed stays or fluctuates at approx. 1,500 rpm after warm-up	NA
Solenoid valve–Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

**Igniter**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1G)–Igniter (Trailing Front) PCME (1J)–Igniter (Trailing Rear)	Poor acceleration Hard starting when engine cold		NA
PCME (1H)–Igniter (Leading)	Rough idle Poor acceleration Hard starting when engine cold		

**Metering oil pump**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4I, 4J, 4K, 4L)–Metering oil pump	Code No. 26 and 27 output Poor acceleration		NA

**MEN terminal (Data link connector)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (1D)–MEN terminal	Monitor lamp will not illuminate	Monitor lamp stays on	NA

**Secondary air bypass valve**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3P)–Solenoid valve	Code No. 31 output No symptom	Code No. 31 output CO and HC increased	NA
Solenoid valve–Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

NA: Not applicable

# F

## SERVICE POINTS

### Secondary air switchig valve

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4N)-Solenoid valve	Code No. 32 output No symptom	Code No. 32 output Rough idle	NA
Solenoid valve-Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

### Solenoid valve (Accelerated warm-up system)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4P)-Solenoid valve	Code No. 38 output Fast idle speed just after en- gine starting will not exceed 2,000 rpm	Code No. 38 output Idle speed stays stays or fluctu- ates at approx. 1,500 rpm af- ter warm-up	NA
Solenoid valve-Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

### Solenoid valve (Charge control)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4T)-Solenoid valve	Code No. 45 output Lack of power Poor acceleration	Code No. 45 output Lack of power Poor acceleration	NA
Solenoid valve-Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

### Solenoid valve (Charge relief)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4S)-Solenoid valve	Code No. 46 output Poor acceleration	Code No. 46 output Momentarily Intake air noise on acceleration	NA
Solenoid valve-Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

### Solenoid valve (Double throttle control)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3O)-Solenoid valve	Code No. 50 output Poor acceleration Lack of power	Code No. 50 output Hesitation when engine cold	NA
Solenoid valve-Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

### Solenoid valve (EGR)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4O)-Solenoid valve	Code No. 28 output No symptom	Code No. 28 output Engine stall Hard starting	NA
Solenoid valve-Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

NA: Not applicable

**Solenoid valve (Port air bypass)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3N)–Solenoid valve	Code No. 33 output No symptom	Code No. 33 output No symptom	NA
Solenoid valve–Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

**Solenoid valve (Pressure regulator control)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4M)–Solenoid valve	Code No. 25 output Hard starting when engine warm-up	Code No. 25 output No symptom	NA
Solenoid valve–Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

**Solenoid valve (Purge control)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3H)–Solenoid valve	Code No. 40 output No symptom	Code No. 40 output Hard starting Engine stalls at low speed	NA
Solenoid valve–Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

**Solenoid valve (Relief 2)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (3K)–Solenoid valve	Code No. 39 output No symptom	Code No. 39 output Secondary air noise heard while air pump operates	NA
Solenoid valve–Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

**Solenoid valve (Split air bypass)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4F)–Solenoid valve	Code No. 30 output No symptom	Code No. 30 output No symptom	NA
Solenoid valve–Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

**Solenoid valve (Turbo control 1, Turbo control 2)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4R)–Solenoid valve (s)	Code No. 44 output Poor acceleration	Code No. 44 output Poor acceleration	NA
Solenoid valve (s)–Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

NA: Not applicable



**F****SERVICE POINTS****Solenoid valve (Turbo precontrol)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4V)-Solenoid valve	Code No. 42 output Hesitation Poor acceleration	Code No. 42 output Hesitation Poor acceleration	NA
Solenoid valve-Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

**Solenoid valve (Wastegate control)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
PCME (4U)-Solenoid valve	Code No. 43 output Lack of power Poor acceleration	Code No. 43 output No symptom	NA
Solenoid valve-Main relay		EGI INJ fuse (30A) burns out when ignition switch ON	

NA: Not applicable

Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.


G

# ENGINE ELECTRICAL SYSTEM

<b>INDEX</b> .....	G - 2
<b>OUTLINE</b> .....	G - 3
SPECIFICATIONS .....	G - 3
<b>TROUBLESHOOTING GUIDE</b> .....	G - 4
DIAGNOSTIC INDEX .....	G - 4
SYMPTOM TROUBLESHOOTING .....	G - 4
<b>CHARGING SYSTEM</b> .....	G - 7
PREPARATION .....	G - 7
CIRCUIT DIAGRAM .....	G - 7
TROUBLESHOOTING .....	G - 8
BATTERY .....	G - 9
ALTERNATOR .....	G -12
DRIVE BELT .....	G -15
<b>IGNITION SYSTEM</b> .....	G -16
PREPARATION .....	G -16
CIRCUIT DIAGRAM .....	G -16
IGNITION TIMING .....	G -17
SPARK PLUGS .....	G -18
IGNITION COIL .....	G -20
HIGH-TENSION LEAD .....	G -21
IGNITER .....	G -22
<b>STARTING SYSTEM</b> .....	G -24
PREPARATION .....	G -24
CIRCUIT DIAGRAM .....	G -24
STARTER .....	G -24
INTERLOCK SWITCH .....	G -32

G

**INDEX**



- 1. Battery
  - Removal / Installation ..... page G- 9
  - Inspection .... page G- 9
  - Recharging ... page G-10
- 2. Alternator
  - Removal / Installation ..... page G-12
  - Disassembly / Assembly ..... page G-13
  - Inspection .... page G-14
- 3. Drive belt
  - Inspection .... page G-15
  - Adjustment ... page G-15

- 4. Spark plug
  - Removal / Installation ..... page G-18
  - Spark test .... page G-18
  - Inspection .... page G-19
- 5. Ignition coil
  - Removal / Installation ..... page G-20
  - Inspection .... page G-21
- 6. High-tension leads
  - Removal / Installation ..... page G-21
  - Inspection .... page G-21
- 7. Igniter
  - Removal / Installation ..... page G-22
  - Inspection .... page G-23

- 8. Stator
  - Inspection (On-Vehicle) ..... page G-24
  - Removal / Installation ..... page G-25
  - Performance inspection ..... page G-27
  - Disassembly / Assembly ..... page G-28
  - Inspection .... page G-30
- 9. Interlock switch
  - Inspection .... page G-32

OUTLINE

SPECIFICATIONS

Item		Transmission		MT	AT	
Battery	Voltage	V		12, negative ground		
	Type and Capacity (5-hour rate)			65D23L (43Ah)	75D26L (52Ah)	
Dark current*1		mA		20 or less		
Ignition system	Spark timing (TEN terminal grounded)		Leading : ATDC 5° (BTDC -5°) Trailing : ATDC 20° (BTDC -20°) at idle (AT: P range)			
	Spark advance		Electronic spark advance (ESA)			
	Spark plug	Type	Leading	NGK : BUR7EQP*2, BUR6EQP, BUR7EQ, BUR6EQ		
			Trailing	NGK : BUR9EQ*2, BUR8EQP, BUR9EQP, BUR8EQ		
	Plug gap	mm {in}	1.1-1.7 {0.044-0.066}			
Alternator	Output	V-A		12-100		
	Regulated voltage	V		14.1-14.7 (with temperature gradient characteristics)		
	Brush length	Standard	mm {in}	21.5 {0.846}		
Minimum		mm {in}	8.0 {0.32}			
Stater	Type			Direct	Reduction	
	Output	V-KW		12-1.2	12-2.0	
	Output (no load)	Voltage	V		11	
		Current	A		Max 90	
		Speed	rpm		Min 3000	Min 2200
	Brush length	Standard	mm {in}	17.5 {0.689}	18 {0.71}	
Minimum		mm {in}	12 {0.47}	11{0.43}		

\*1 Dark current is the constant flow of current while the ignition is OFF (i.e., audio unit, clock, etc)

\*2 Standard plug

G



### TROUBLESHOOTING GUIDE


#### DIAGNOSTIC INDEX



No.	Troubleshooting items	Page
1	Will not crank-starter motor does not operate	Below
2	Will not crank-starter motor spins	Below
3	Cranks slowly	G-5
4	Alternator warning light illuminates while engine running	G-5
5	Discharged battery	G-5
6	Misfire	G-6

#### SYMPTOM TROUBLESHOOTING

B+: Battery positive voltage

1		Will not crank-starter motor does not operate	
STEP	INSPECTION	ACTION	
1	Does engine crank with fully charged battery?	Yes	Check charging system <b>☛ page G-8</b>
		No	Go to next step
2	Is B+ present at terminal B? 	Yes	Go to next step
		No	Check wiring harness
3	Is B+ present at terminal S with ignition switch in START position? 	Yes	<ul style="list-style-type: none"> <li>• Check magnetic switch</li> <li>• Check armature</li> </ul> <b>☛ page G-30</b> <b>☛ page G-30</b>
		No	<ul style="list-style-type: none"> <li>• Check park/neutral switch</li> <li>• Check ignition switch</li> <li>• Check wiring harness</li> </ul> <b>☛ Section K</b> <b>☛ 1994 RX-7</b> <b>Body Electrical Troubleshooting Manual Section Z4</b>


2		Will not crank-starter motor spins	
STEP	INSPECTION	ACTION	
1	Is drive pinion pushed out when energized? (Is click heard?) 	Yes	Remove starter and check ring gear teeth and starter drive pinion teeth
		No	Check magnetic switch <b>☛ page G-30</b>

3		Crank slowly	
STEP	INSPECTION	ACTION	
1	Does engine crank normally with fully charged battery?	Yes	Check charging system <span style="float: right;">☞ page G-8</span>
		No	Go to next step
2	Are starter cable connections loose or corroded?  <div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p style="text-align: center;">AT                      MT</p>	Yes	Repair connection
		No	Check starter for binding (brush, armature, etc.) <span style="float: right;">☞ page G-30</span>

G

B+: Battery Positive Voltage

4		Alternator warning light illuminates while engine running	
STEP	INSPECTION	ACTION	
1	Is B+ correct at idle?  Specification: 14.1-14.7V	Yes	Check wiring harness (Alternator terminal L-Alternator warning light)
		No	Check charging system <span style="float: right;">☞ page G-8</span>


5		Discharged battery	
STEP	INSPECTION	ACTION	
1	Is charging system OK? <span style="float: right;">☞ page G-8</span>	Yes	Turn ignition switch OFF and measure dark current as shown  <div style="text-align: center;">  </div> <p style="text-align: center;">Dark current: 20 mA max</p>
		No	Repair or replace parts as necessary

B+: Battery positive voltage


6		Misfire	
STEP	INSPECTION	ACTION	
1	Are "02" or "03" displayed on SST while ignition switch ON?	Yes	Check for cause <span style="float: right;">☞ Section F</span>
		No	Go to next step
2	Are connector and wiring harness connections OK? (High-tension leads, igniter, ignition coils, PCME)	Yes	Go to next step
		No	Repair connection
3	Remove each High-tension lead; is there strong blue spark while engine is cranking?	Yes	Go to step 10
		No	Go to next step
4	Is resistance of High-tension leads OK? Specification: 16 kΩ per 1m {3.28 ft} (at 20°C [68°F])	Yes	Go to next step
		No	Replace High-tension lead(s)
5	Is there B+ at ignition coils terminal A and igniter terminal D with ignition switch in ON position? (Disconnect each connection) <span style="float: right;">☞ page G-16</span>	Yes	Go to next step
		No	Check wiring harness <span style="float: right;">☞ Page G-16</span> (Ignition coils terminal A, Igniter terminal D-Ignition switch)
6	Are ignition coils OK? <span style="float: right;">☞ page G-21</span>	Yes	Go to next step
		No	Replace ignition coil <span style="float: right;">☞ page G-20</span>
7	Is wiring harness from ignition coils to igniter OK? <span style="float: right;">☞ page G-16</span>	Yes	Go to next step
		No	Repair or replace
8	Is igniter OK? <span style="float: right;">☞ page G-23</span>	Yes	Go to next step
		No	Replace igniter <span style="float: right;">☞ page G-22</span>
9	Is wiring harness from igniter to PCME terminals OK? <span style="float: right;">☞ page G-16</span>	Yes	Go to next step
		No	Repair or replace
10	Is input sensor OK? ● Crankshaft position sensor ● Manifold absolute pressure sensor <span style="float: right;">☞ Section F</span>	Yes	Replace PCME <span style="float: right;">☞ page F-150</span>
		No	Check input sensor

CHARGING SYSTEM

PREPARATION  
SST

<p>49 9200 020 Tension gauge V-ribbed belt</p> 	<p>For inspection of drive belt tension</p>
--	---

CIRCUIT DIAGRAM





The alternator has a self-diagnosis function to warn of the following problems in the charging system. If a problem arises, the alternator warning light illuminates.

1. Terminal S circuit open
2. No voltage output
3. Field coil circuit open
4. Terminal B circuit open
5. Voltage output too high (above 16.2V)




### TROUBLESHOOTING

B+: Battery positive voltage

STEP	INSPECTION	ACTION													
1	Check battery positive voltage, is it correct?  <b>Specification: Above 12.4V</b>	Yes	Go to next step												
		No	Check battery <span style="float: right;">page G-9</span>												
2	Does alternator warning light illuminate with ignition switch ON?	Yes	Go to next step												
		No	Check warning light bulb and wiring harness (Alternator warning light-Terminal L)												
3	Does alternator warning light go out after engine started?	Yes	Go to step 5												
		No	Go to next step												
4	Is voltage at alternator terminals correct?  <b>Specification:</b> <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Terminal</th> <th>Ign: ON (V)</th> <th>Idle (V)</th> </tr> </thead> <tbody> <tr> <td>B</td> <td>B+</td> <td>14.1-14.7</td> </tr> <tr> <td>L</td> <td>Approx. 1</td> <td>12.9-13.5</td> </tr> <tr> <td>S</td> <td>B+</td> <td>14.1-14.7</td> </tr> </tbody> </table> 	Terminal	Ign: ON (V)	Idle (V)	B	B+	14.1-14.7	L	Approx. 1	12.9-13.5	S	B+	14.1-14.7	Yes	Check wiring harness (Battery-Terminal L)
		Terminal	Ign: ON (V)	Idle (V)											
B	B+	14.1-14.7													
L	Approx. 1	12.9-13.5													
S	B+	14.1-14.7													
No	<ul style="list-style-type: none"> <li>Check and repair wiring harness as necessary <span style="float: right;">page G-12</span></li> <li>Replace or repair alternator</li> </ul>														
5	1. Connect ammeter (100A min.) between terminal B and harness 2. Start engine 3. Turn all electrical loads ON and depress brake pedal 4. Is output current 100A or more at 2,500-3,000 rpm?  <b>Caution</b> <ul style="list-style-type: none"> <li>Do not ground terminal B</li> </ul> 	Yes	Charging system normal												
		No	Go to next step												
6	Is drive belt tension OK? <span style="float: right;">page G-15</span>	Yes	Replace or repair alternator <span style="float: right;">page G-12</span>												
		No	<ul style="list-style-type: none"> <li>Adjust drive belt tension</li> <li>Replace drive belt</li> </ul> <span style="float: right;">page G-15</span>												

**BATTERY  
Removal / Installation**



1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Battery negative cable
2. Battery positive cable

3. Battery clamp
4. Battery box

5. Battery  
Inspection .... page G- 9  
Recharging ... page G-10



**Inspection  
Electrolyte level**

**Warning**

- Hydrogen gas is produced during normal battery operation. A battery-related explosion can cause serious injury. Keep all flames (including cigarettes), heat, and sparks away from the top and surrounding area of open battery cells.

**Caution**

- To prevent damage to electrical components or the battery, turn all accessories off and stop the engine before performing maintenance or recharging the battery.

**Caution**

- When disconnecting the battery, remove the negative cable first and install it last to prevent damage to electrical components or the battery.

**Electrolyte level and specific gravity**



1. Verify that the electrolyte level is between the "Upper" and "Lower" level marks.

2. Add distilled water if necessary, but do not over fill.

3. Check the specific gravity with a hydrometer.


**Specific Gravity: 1.27-1.29 (at 20°C {68°F})**

**Battery Discharge Test**



**Terminal and cable**

1. Remove any corrosion on the clamps or battery posts, and coat them with grease.
2. Verify that the battery top is clean. If necessary, clean with baking soda and water.
3. Verify that cables are not frayed or corroded. Repair or replace if necessary.
4. Verify that cable clamps are tight.
5. Verify that the rubber protector completely covers the positive terminal and clamp.




**Recharging**

Battery	Slow charge (A)	Quick charge (A)
65D23L	Under 5	Max. 25
75D26L	Under 8	Max. 30

**Slow charging**

It is not necessary to remove the vent caps to perform a slow charge.



### Quick charging

1. Remove the battery from the vehicle and remove the vent caps to perform a quick charge.

### Caution

- Obtain the code number and deactivate the audio anti-theft system before disconnecting the battery. (Refer to the 1994 RX-7 Body Electrical Troubleshooting Manual section J1)

### Caution

- To avoid damaging the battery, do not quick charge for over 30 minutes.

2. Place the battery in a pan of water to prevent it from overheating, but keep water away from the top of the battery.

### ALTERNATOR

#### Caution

- Reversing the battery connections or using high-voltage testers will damage the rectifier.

#### Caution


- Do not start the engine while the connector is disconnected from terminals L and S. It can damage the alternator.

#### Note

- Positive voltage is always present at alternator terminal B.

#### Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



N·m {kgf·m, ft·lbf}

1. Battery negative cable
2. Air-intake hose
3. Air-relief hose
4. Accelerator cable
5. Pressure chamber
6. Air pipe

7. Bracket
8. Terminal B and connector
9. Air pump hose
10. Air pump
11. Drive belt

Inspection .... page G-15  
Adjustment ... page G-15

12. Water hose
13. Alternator


Disassembly / Assembly

..... page G-13


Inspection .... page G-14

**Disassembly / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assembly in the reverse order of disassembly, referring to **Assembly Note**.




- |   |  |   |
|---|--|---|
| <p>1. Nut, washer<br/>2. Pulley<br/>3. Front bracket<br/>4. Rotor<br/>    Inspection .... page G-14<br/>5. Stator<br/>    Disassembly / Assembly<br/>    Note ..... page G-13<br/>    Inspection .... page G-14</p> | <p>6. Regulator<br/>    Disassembly / Assembly<br/>    Note ..... page G-13<br/>7. Rectifier<br/>    Disassembly / Assembly<br/>    Note ..... page G-13<br/>    Inspection .... page G-14</p> | <p>8. Rear bracket<br/>    Disassembly / Assembly<br/>    Note ..... page G-13<br/>9. Bearing<br/>    Inspection .... page G-14<br/>10. Brush<br/>    Inspection .... page G-14</p> |
|---|--|---|



**Disassembly / Assembly Note**


**Rear bracket, stator wire**

Melt the solder quickly, the diodes (rectifier) and regulator will be damaged by excessive heat.



**Brush holder, regulator assembly and rectifier**

Melt the solder quickly, the diodes (rectifier) and regulator will be damaged by excessive heat.




### Inspection

#### Rotor

Check the continuity as shown.


Inspection point	Continuity
Core-Slip ring	No
Slip ring-Slip ring	Yes



### Stator

Check the continuity as shown.


Inspection point	Continuity
Core-Stator coil leads	No
Between leads	Yes



### Rectifier

Check the continuity as shown.

Negative	Positive	Continuity
E	P <sub>n</sub> , P <sub>1</sub> , P <sub>2</sub> , P <sub>3</sub>	Yes
B		No
T		No
P <sub>n</sub> , P <sub>1</sub> , P <sub>2</sub> , P <sub>3</sub>	E	No
	B	Yes
P <sub>1</sub> , P <sub>2</sub> , P <sub>3</sub>	T	Yes
		No




### Brush

If a brush is worn almost to or beyond the limit, replace the brushes.




**Standard : 21.5 mm {0.846 in}**

**Minimum : 8.0 mm {0.32in}**



### Bearing

1. Check for abnormal noise, looseness, and sticking.
2. Replace the bearing(s) as necessary.



**DRIVE BELT**

**Inspection**

1. Check the drive belts and pulleys for wear, cracks and fraying. Replace as necessary.
2. Measure the drive belt tension by using a tension gauge, and measure the deflection by applying moderate pressure midway between the pulleys. Adjust the belt if necessary.

**Specification Tension**

Drive belt	N (kgf, lbf)		
	New	Used	Limit
Alternator	690-780 {70-80, 160-170}	590-680 {60-70, 140-150}	320 {33-73}

**Deflection**

Drive belt	mm (in)		
	New	Used	Limit
Alternator	6.0-7.0 {0.24-0.27}	7.0-7.5 {0.28-0.29}	9.0 {0.35}

**Adjustment**

1. Loosen the alternator mounting bolts and turn the adjusting bolt.
2. Move the alternator to set the specified deflection.
3. Tighten all bolts and recheck the tension.

**Tightening torque:**

**Mounting bolt:**

38-51 N·m {3.8-5.3 kgf·m, 28-38 ft·lbf}





**Adjusting bolt:**

19-25 N·m {1.9-2.6 kgf·m, 14-18 ft·lbf}









### IGNITION SYSTEM

#### PREPARATION SST

<p>49 B019 9A0 System selector</p> 	<p>For self-diagnosis and inspection of ignition timing</p>	<p>49 F018 002 Igniter Checker</p> 	<p>For inspection of igniter</p>
<p>49 F018 003 Adapter Harness</p> 	<p>For inspection of igniter</p>	<p>49 H018 9A1 Self-Diagnosis Checker</p> 	<p>For self-diagnosis inspection</p>

#### CIRCUIT DIAGRAM





## IGNITION TIMING

The ignition timing is set at the factory and must not be adjusted. Any adjustment will negatively effect the engine performance.

### Preparation

1. Warm up the engine to normal operating temperature.
2. Run the engine at idle and verify the following.
  - Shift selector lever to P range (AT) / Neutral (MT).
  - Set steering wheel straight ahead.
  - Turn all electrical loads OFF.
  - Wait for electric coolant fan to stop.

### Inspection

1. Connect a timing light to the high-tension lead of the front trailing side.
2. Connect a tachometer.

### Note

- Some timing lights will not illuminate even if the ignition is working properly.

3. Connect the SST to the data link connector.
4. Set switch A to position 1.
5. Set TEST SW to SELF-TEST.
6. Verify that the idle speed is within specification.

**Idle speed: 550–950 rpm**

7. Verify that the timing mark (white) on the crankshaft position sensor plate is aligned with the indicator pin.

**Ignition timing: Trailing side: 20°ATDC (–20°BTDC)  
Leading side: 5°ATDC (–5°BTDC)**

8. If the timing is incorrect, check the following.

- Verify that no diagnostic trouble code number is present. If present, check for the cause referring to the specified check sequence. (Refer to Section F)
- 05 Knock sensor
- 13 Manifold absolute pressure sensor


### Input devices

- E/L, P/S, A/C, electric coolant fan
- Crankshaft position sensor (NE, G-Signal)
- Manifold absolute pressure sensor
- Throttle position sensor
- Neutral SW / Clutch SW (MT)
- Park/neutral signal (AT)

### Others

- PCME terminal 3I voltage

8. Disconnect the SST.
9. Verify that the ignition timing advances when the engine is above 1,500 rpm.




### SPARK PLUGS

#### Removal / Installation

1. Remove and install the high-tension leads carefully.

#### Caution

- Pulling on the wire part of the spark plug lead may break it. To remove the lead, pull only on the boot.



2. Remove and install the spark plugs by using a plug socket.

#### Caution

- To avoid breaking the spark plug, be sure to fit the socket squarely over it.


3. Apply anti-seize compound or molybdenum-based lubricant to the spark plug threads before installing.
4. Tighten the spark plugs to the specified torque.


#### Tightening torque:

13–17 N·m {1.3–1.8 kgf·m, 9.5–13 ft·lbf}

#### Spark test

1. Remove the spark plug.
2. Connect the spark plug to a high-tension lead.
3. Hold the high-tension lead and spark plug with insulated pliers 5–10 mm {0.20–0.39 in} from a ground.
4. Check the engine and verify that there is a strong blue spark.
5. Replace the spark plug or high tension lead as necessary if not as specified.





**Inspection**

Check the following points. If a problem is found, replace the spark plug.

- Damaged insulation
- Worn electrodes
- Carbon deposits

If cleaning is necessary, use a plug cleaner. Clean the upper insulator, also.

- Damaged gasket
- Burnt

**Plug gap: 1.1–1.7 mm {0.044–0.066 in}**

Plug position	NGK	Color
Leading side	BUR7EQP*, (BUR7EQ) (BUR6EQP) (BUR6EQ)	—
Trailing side	BUR9EQ*, (BUR9EQP) (BUR8EQP) (BUR8EQ)	Blue

\* Standard plug

**Caution**


- The electrode is platinum coated. The following can scratch its platinum coating and impair its performance.

- (1) Adjusting the plug gap.
- (2) Using a wire brush to clean the electrode.
- (3) Using a plug cleaner for more than twenty (20) seconds, or at more than 588 kPa {6 kgf/cm<sup>2</sup>, 85 psi}

**IGNITION COIL**

**Removal / Installation**


1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Battery negative cable
2. Pressure chamber
3. Accelerator cable
4. Extension manifold

5. high-tension lead  
Inspection .... page G-21
6. Connector
7. Ignition coil bracket
8. Ignition coil (Trailing No.1)  
Inspection .... page G-21

9. Ignition coil (Leading)  
Inspection .... page G-21
10. Ignition coil (Trailing No.2)  
Inspection .... page G-21




**Inspection**

**T (Trailing) side**

1. Measure resistance of the coil.

Inspection point	Resistance
A-B (primary coil winding)	below 1.0 $\Omega$
A-T (secondary coil winding)	$\infty$ (infinity)

2. If not within specification, replace the ignition coil.




**L (Leading) side**

1. Measure resistance of the coil.

Inspection point	Resistance
A-B (primary coil winding)	below 1.0 $\Omega$
L <sub>1</sub> -L <sub>2</sub> (secondary coil winding)	9.6-16.0 k $\Omega$

2. If not within specification, replace the ignition coil.



**HIGH-TENSION LEAD**

**Removal / Installation**

**Caution**

- Reinstall the high-tension leads to their original positions. Incorrect installation can damage the leads and cause power loss, and negatively effect electronic components.

**Inspection**

1. Measure resistance of the high-tension leads.


**Specification: 16 k $\Omega$  per 1m {3.28 ft}**

2. If not as specified, replace the high-tension leads.

### IGNITER





#### Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Battery negative cable
2. Connector

3. Igniter  
Inspection ..... page G-23



## Inspection

Before this inspection, check the specific gravity of the battery, and that it is at or near full charge.

1. Disconnect the negative battery cable.
2. Disconnect the igniter connector.
3. Connect the SST.
4. Reconnect the negative battery cable.
5. Turn the ON ignition switch.

## Note

- Switch 1 may be in either position.

## Trailing side

1. Insert the voltmeter probe into the brown (Front rotor trailing) or gray (Rear rotor trailing) lead of the SST (adapter harness) and verify that the voltage is as specified.

## Voltage: Battery positive voltage

2. Press switch 2 to ON when certify to shake a hand of voltmeter.
3. Replace the igniter, if necessary.

## Leading side

1. Insert the voltmeter probe into the black lead of the SST (adapter harness) and verify that the voltage is as specified.


## Voltage: Battery positive voltage

2. Press switch 2 to ON when certify to shake a hand of voltmeter.
3. Replace the igniter, if necessary.





### STARTING SYSTEM

#### PREPARATION SST

<p>49 E301 144 Plate, removing</p>		<p>For installation of overrunning clutch</p>
--	---	---

#### CIRCUIT DIAGRAM



#### STARTER

##### Inspection (on-vehicle)

1. Measure the battery positive voltage.


##### Specification: Above 12.4V

2. Crank the engine, and verify that the starter turns smoothly.
3. If the starter does not turn, measure the voltage at terminal S.
4. If the voltage is **more than 8V**, remove and inspect the starter. If the voltage is **less than 8V**, check the wiring harness, ignition switch, and park/neutral switch (AT).

**Removal / Installation**

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.


MT



1. Battery negative cable
2. Under cover
3. Terminal S and B wire


4. Stator
  - Performance inspection ..... page G-27
  - Disassembly / Assembly ..... page G-28
  - Inspection ..... page G-30

AT



- 1. Battery negative cable
- 2. Under cover
- 3. Terminal S and B wire

- 4. Stator
  - Performance inspection ..... page G-27
  - Disassembly / Assembly ..... page G-29
  - Inspection ..... page G-30



**Performance Inspection**

**Magnetic switch**


Disconnect terminal M wire, and perform the following tests. Replace the magnetic switch if necessary.

**Pull-in test**

Connect battery positive voltage as shown and verify that the pinion is ejected.


**Caution**

- Applying power for more than 10 seconds can damage the starter.



**Hold-in test**

After completing the pull-in test, disconnect the wire from terminal M (with pinion ejected) and verify that the pinion does not return.




**Adjustment of pinion gap**

1. Disconnect the wire from terminal M.
2. Apply battery positive voltage between terminal S and the starter body.
3. Measure the clearance (pinion gap) between the pinion and the stopper.

**Caution**

- Applying power for more than 10 seconds can damage the starter.

**Pinion gap: 0.5–2.0 mm {0.020–0.078 in}**



4. If the pinion gap is not within specification, increase or decrease the number of washers between the magnetic switch and the drive housing.

**Note**

- The gap becomes smaller as the number of washers is increased.

**No load test**


1. Connect a circuit as shown.
2. Measure voltage, current, and speed as shown below.

Voltage	(V)	11.0
Current	(A)	Max 90
Speed	(rpm)	Min 2,200 (AT), Min 3,000 (MT)

### Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly.


MT



- |                              |           |
|------------------------------|-----------|
| 1. Magnetic switch           |           |
| Performance inspection ..... | page G-27 |
| Inspection .....             | page G-30 |
| 2. Front bracket             |           |
| 3. Drive pinion              |           |
| Inspection .....             | page G-31 |

- |                           |           |
|---------------------------|-----------|
| 4. Armature               |           |
| Inspection .....          | page G-30 |
| 5. Field coil             |           |
| Inspection .....          | page G-30 |
| 6. Brush and Brush holder |           |
| Inspection .....          | page G-31 |
| 7. Rear bracket           |           |


AT



- 1. Magnetic switch  
Performance  
Inspection .... page G-27  
Inspection .... page G-30
- 2. Spring set
- 3. Lever set
- 4. Rear bracket

- 5. Field coil  
Inspection .... page G-30
- 6. Brush and Brush holder  
Inspection .... page G-31
- 7. Armature  
Inspection .... page G-30
- 8. Cover


- 9. Center bracket
- 10. Reduction gear
- 11. Pinion shaft assembly  
(Overrunning clutch)  
Inspection .... page G-31
- 12. Bearing
- 13. Front bracket



**Inspection  
Magnetic switch**

Check the continuity as shown.


Inspection point	Continuity
Terminal S-M	Yes
Terminal M-B	No
Terminal S-Body	Yes



**Field coil**

Check the continuity as shown.


Inspection point	Continuity
Brush - Connector	Yes
Body - Connector	No



**Armature**

1. Check the continuity as shown.


Inspection point	Continuity
Commutator - Core	Yes
Commutator - Shaft	No
Core - Shaft	No



2. Replace the armature if the outer diameter of the commutator is almost at or less than the minimum.

3. If the commutator surface is dirty, wipe it with a cloth; if it is rough, repair it with a lathe or fine sandpaper.


**Minimum diameter  
32.0 mm {1.26 in}**



4. Place the armature on V-blocks, and measure the runout by using a dial indicator.


5. If the runout is not within specification, repair the armature by using a lathe or replace it.

**Runout: 0.05 mm {0.002 in}**



**Brush and Brush holder**


1. Check for continuity between the insulated brush and the plate. Repair or replace if there is continuity. Also check that the brush slides smoothly inside the brush holder.



2. Measure the force of the brush spring by using a spring balance.


**Standard: 18.6–22.6 N {1.89–2.31 kgf, 4.16–5.08 lbf}**  
**Maximum: 6.9 N {0.7 kgf, 1.5 lbf}**

3. Replace the spring if not as specified.



4. If a brush is worn almost to or beyond the wear limit, replace all of the brushes.

Specification		MT	AT
Standard	mm {in}	17 {0.67}	18 {0.71}
Minimum	mm {in}	11 {0.43}	11 {0.43}



**Overrunning Clutch**


1. Turn the pinion shaft by hand while holding the overrunning clutch.
2. Replace the overrunning clutch if the pinion turns in both or in neither direction.

**Caution**


- Using cleaning fluids or a steam cleaner to clean the overrunning clutch can dissolve the grease inside it.



### INTERLOCK SWITCH



This system is similar to that of the park/neutral switch on at AT vehicle. If the clutch pedal is not depressed during starting, battery power will not be supplied to the starter and the starter will not operate.



#### Inspection

1. Disconnect the interlock switch connector.
2. Connect a circuit tester to the switch.
3. Check the continuity.

Pedal	Continuity
Depressed	Yes
Released	No

4. If not as specified, replace the switch.

Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.


H

# CLUTCH

<b>INDEX</b> .....	H - 2
<b>OUTLINE</b> .....	H - 3
<b>SPECIFICATIONS</b> .....	H - 3
<b>TROUBLESHOOTING GUIDE</b> .....	H - 3
<b>CLUTCH FLUID</b> .....	H - 4
<b>PREPARATION</b> .....	H - 4
<b>INSPECTION</b> .....	H - 4
<b>REPLACEMENT</b> .....	H - 4
<b>CLUTCH PEDAL</b> .....	H - 6
<b>ADJUSTMENT</b> .....	H - 6
<b>REMOVAL/INSTALLATION</b> .....	H - 7
<b>OVERHAUL</b> .....	H - 8
<b>CLUTCH MASTER CYLINDER</b> .....	H - 9
<b>PREPARATION</b> .....	H - 9
<b>REMOVAL/INSTALLATION</b> .....	H - 9
<b>AIR BLEEDING</b> .....	H -11
<b>OVERHAUL</b> .....	H -12
<b>CLUTCH RELEASE CYLINDER</b> .....	H -14
<b>PREPARATION</b> .....	H -14
<b>REMOVAL/INSTALLATION</b> .....	H -14
<b>OVERHAUL</b> .....	H -15
<b>CLUTCH UNIT</b> .....	H -16
<b>PREPARATION</b> .....	H -16
<b>REMOVAL/INSTALLATION</b> .....	H -17
<b>CLUTCH COVER</b> .....	H -20
<b>INSPECTION</b> .....	H -20
<b>CLUTCH DISC</b> .....	H -21
<b>INSPECTION</b> .....	H -21
<b>CLUTCH RELEASE FORK ASSEMBLY</b> ....	H -21
<b>INSPECTION</b> .....	H -21
<b>OVERHAUL</b> .....	H -22
<b>CLUTCH RELEASE COLLAR</b> .....	H -23
<b>INSPECTION</b> .....	H -23
<b>PILOT BEARING</b> .....	H -23
<b>INSPECTION</b> .....	H -23
<b>FLYWHEEL</b> .....	H -23
<b>INSPECTION</b> .....	H -23

H

## INDEX



- |   |  |   |
|---|--|---|
| <p>1. Clutch pedal<br/>                     Adjustment ... page H- 6<br/>                     Removal/<br/>                     Installation ... page H- 7<br/>                     Overhaul ..... page H- 8</p> <p>2. Clutch master cylinder<br/>                     Removal/<br/>                     Installation ... page H- 9<br/>                     Air bleeding ... page H-11<br/>                     Overhaul ..... page H-12</p> <p>3. Clutch release cylinder<br/>                     Removal/<br/>                     Installation ... page H-14<br/>                     Air bleeding ... page H-11<br/>                     Overhaul ..... page H-15</p> | <p>4. Clutch release collar<br/>                     Removal/<br/>                     Installation ... page H-17<br/>                     Inspection .... page H-23</p> <p>5. Clutch release fork assembly<br/>                     Removal/<br/>                     Installation ... page H-17<br/>                     Inspection .... page H-21<br/>                     Overhaul ..... page H-22</p> <p>6. Clutch cover<br/>                     Removal/<br/>                     Installation ... page H-17<br/>                     Inspection .... page H-20</p> | <p>7. Clutch disc<br/>                     Removal/<br/>                     Installation ... page H-17<br/>                     Inspection .... page H-21</p> <p>8. Pilot bearing<br/>                     Removal/<br/>                     Installation ... page H-17<br/>                     Inspection .... page H-23</p> <p>9. Flywheel<br/>                     Removal/<br/>                     Installation ... page H-17<br/>                     Inspection .... page H-23</p> |
|---|--|---|

OUTLINE

SPECIFICATIONS

Transmission model		R15M-D (R5M-D)	
Clutch control		Hydraulic	
Clutch pedal	Type	Suspended	
	Pedal ratio	6.35	
	Full stroke mm {in}	135 {5.32}	
	Height (with carpet) mm {in}	165.5-177.0 {6.516-6.968}	
Clutch disc	Outer diameter mm {in}	236 {9.29}	
	Inner diameter mm {in}	160 {6.30}	
	Facing thickness	Flywheel side mm {in}	3.5 {0.14}
		Pressure plate side mm {in}	3.5 {0.14}
Clutch cover	Type	Diaphragm spring	
	Set load N {kgf, lbf}	7,220 {736,1619}	
Clutch master cylinder	Inner diameter mm {in}	15.87 {0.625}	
Clutch release cylinder	Inner diameter mm {in}	19.05 {0.750}	
Clutch fluid		FMVSS116 DOT-3	

H


TROUBLESHOOTING GUIDE



Problem	Possible Cause	Action	Page
<b>Slipping</b>	Clutch disc facing worn excessively	Replace	H-17
	Clutch disc facing surface hardened or oil soaked	Repair or replace	H-17
	Pressure plate damaged	Replace	H-17
	Flywheel damaged	Replace	H-17
	Diaphragm spring damaged or weak	Replace	H-17
	Insufficient clutch pedal play	Adjust	H-6
	Clutch pedal sticking	Repair or replace	H-7, 8
<b>Faulty disengagement</b>	Clutch disc damaged or excessive runout	Replace	H-17
	Clutch disc splices rusted or worn	Repair or replace	H-17
	Oil on clutch disc facing	Repair or replace	H-17
	Diaphragm spring damaged or weak	Replace	H-17
	Excessive clutch pedal play	Adjust	H-6
	Leakage of clutch fluid	Locate and repair or replace	—
<b>Clutch vibrates when accelerating</b>	Oil on clutch disc facing	Repair or replace	H-17
	Clutch disc facing hardened or damaged	Repair or replace	H-17
	Diaphragm spring weak	Replace	H-17
	Clutch disc facing rivets loose	Replace	H-17
	Pressure plate damaged or excessive runout	Replace	H-17
	Flywheel surface hardened or damaged	Repair or replace	H-17
	Loose or worn engine mount	Tighten or replace	—
<b>Clutch pedal sticks</b>	Pedal shaft not properly lubricated	Lubricate or replace	H-8
<b>Abnormal noise</b>	Clutch release collar damaged	Replace	H-17
	Release collar not properly lubricated	Lubricate or replace	H-17
	Torsion spring weak	Replace	H-17
	Pilot bearing worn or damaged	Replace	H-17
	Worn pivot points of release fork	Repair or replace	H-17
	Release fork contact points not properly lubricated	Lubricate or replace	H-17
<b>Clutch pedal vibrates when engine running</b>	Improper installation of or damage to wedge collar and wire ring assembly	Replace	H-17

## CLUTCH FLUID

## PREPARATION

## SST

<p>49 0259 770B</p> <p>Wrench flare nut</p> 	<p>For air bleeding</p>
---	-----------------------------



## INSPECTION

1. Make sure that the fluid level in the reservoir is between the MAX and MIN mark.
2. If the fluid level is extremely low, check the clutch and brake systems for leakage.

## REPLACEMENT

## Note

- A common reservoir is used for the clutch and brake system fluids.


## Caution

- Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.


1. Remove the brake fluid from the reservoir by using a suction pump, and fill the reservoir with new fluid of the specified type.
2. Remove the bleeder cap from the clutch release cylinder and attach a vinyl hose to the bleeder plug.
3. Insert the other end of the vinyl hose into a clear container.
4. Working with another person, have the person depress the clutch pedal several times, then hold it down.
5. With the clutch pedal depressed, loosen the bleeder screw by using the SST to let the fluid escape. Close the bleeder screw.
6. Repeat steps 4 and 5 until only clean fluid is seen make sure the reservoir is always 3/4 full or more during this procedure.
7. Modify the bleeder screw tightening torque to allow for a torque wrench-SST combination. (Refer to section GI "Torque Formulas".)
8. Tighten the bleeder screw by using the SST.

## Tightening torque:

5.9–8.8 N·m{60–90 kgf·cm,53–78 in·lbf}



9. Fill the reservoir to MAX with new fluid of the specified type.
10. Slowly pump the clutch pedal several times.  
Verify that there is no fluid leakage.
11. Check operation of the clutch system.
12. Check operation of the brake system.



## CLUTCH PEDAL

### ADJUSTMENT

#### Height

#### Inspection

1. Measure the distance from the upper surface of the pedal to the carpet.

**Pedal height: 165.5–177.0 mm {6.516–6.968 in}  
(with carpet)**

2. If necessary, adjust the pedal height.

#### Adjustment

1. Disconnect the clutch switch connector.
2. Loosen locknut A and turn clutch switch B until the pedal height is correct.
3. Tighten locknut A.

#### Tightening torque:

**13.8–17.6 N·m {140–180 kgf·cm 122–156 in·lbf}**

4. After adjustment, measure the pedal free play.

#### Free Play

#### Inspection

1. Depress the clutch pedal by hand until clutch resistance is felt.

**Free play: 0.6–3.2 mm {0.02–0.13 in}**

**Total free play: 5.1–14 mm {0.20–0.55 in}**

2. If necessary, adjust the pedal free play.

#### Adjustment

1. Loosen locknut C and turn push rod D until pedal free play is correct.
2. Verify that the disengagement height (from the upper surface of the pedal to the carpet) is correct when the pedal is fully depressed.

**Minimum disengagement height: 48 mm {1.9 in}  
(with carpet)**

3. Tighten locknut C.


#### Tightening torque:

**11.8–16.6 N·m {120–170 kgf·cm, 105–147 in·lbf}**

4. After adjustment, measure the pedal height.

## REMOVAL / INSTALLATION

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



N·m {kgf·m, ft·lbf}

1. Starter interlock switch connector
2. Clutch switch connector


3. Nut

4. Clutch pedal assembly  
 Adjustment ..... page H-6  
 Overhaul ..... page H-8



### OVERHAUL

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



1. Starter interlock switch
2. Clutch switch
3. Retaining ring
4. Wave washer


5. Pin
6. Push rod assembly  
Inspect for damage and  
bending.
7. Nut

8. Push rod
9. Fork
10. Spacer
11. Clutch pedal assembly

CLUTCH MASTER CYLINDER

PREPARATION

SST


49 0259 770B		For disconnecting and connecting clutch pipe
Wrench, flare nut		

REMOVAL / INSTALLATION


Caution

- Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.

1. Remove in the order shown in the figure, referring to Removal Note.
2. Install in the reverse order of removal, referring to Installation Note.
3. After installation, bleed the clutch system. (Refer to page H-11.)
4. Inspect and adjust the clutch pedal height and free play. (Refer to page H-6.)




- |  |  |   |
|--|--|---|
| <ol style="list-style-type: none"> <li>1. Cruise control actuator assembly</li> <li>2. Clutch pipe<br/>Removal Note ..... page H-10<br/>Installation Note ..... page H-10</li> </ol> | <ol style="list-style-type: none"> <li>3. Clamp</li> <li>4. Clutch hose<br/>Installation Note ..... page H-10</li> <li>5. Nut</li> </ol> | <ol style="list-style-type: none"> <li>6. Clutch master cylinder<br/>Overhaul ..... page H-12<br/>Inspect for fluid leakage from the cylinder bore<br/>Air bleeding ... page H-11</li> <li>7. Gasket</li> </ol> |
|--|--|---|



### Removal Note


#### Clutch pipe

1. Disconnect the clutch pipe by using the SST.



2. Disconnect the clutch hose from the reservoir.


3. Plug the outlet of the reservoir.



### Installation Note

#### Clutch hose

Install the clutch hose with the mark facing upward, as shown in figure A. If reusing the clutch hose, install the new hose clamp exactly into the mark left by the previous hose clamp, as shown in figure B.






### Clutch pipe

1. Modify the clutch pipe tightening torque to allow for use of a torque wrench-SST combination. (Refer to section GI "Torque Formulas".)

2. Tighten the clutch pipe by using the SST.

### Tightening torque:

12.8–21.5 N·m{130–220 kgf·cm, 113–190 in·lbf}

**AIR BLEEDING**

The clutch hydraulic system must be bled to remove air introduced whenever a hydraulic line is disconnected.

**Caution**

- Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.

1. Remove the bleeder cap from the clutch release cylinder and attach a vinyl hose to the bleeder plug.
2. Insert the other end of the vinyl hose into a fluid-filled clear container.
3. Working with another person, have the person depress the clutch pedal several times, then hold it down.
4. With the clutch pedal depressed, loosen the bleeder screw by using the SST to let fluid and air escape. Close the bleeder screw.
5. Repeat steps 3 and 4 until no air bubbles are seen. Make sure the reservoir is always 3/4 full or more during this procedure.
6. Modify the bleeder screw tightening torque to allow for use of a torque wrench-SST combination. (Refer to section GI "Torque Formulas".)
7. Tighten the bleeder screw by using the SST.

**Tightening torque:**

5.9–8.8 N·m{60–90 kgf·cm, 53–78 in·lbf}

8. Fill the reservoir to MAX with new fluid of the specified type.
9. Slowly pump the clutch pedal several times. Verify that there is no fluid leakage.
10. Check operation of the clutch system.
11. Check operation of the brake system.


### OVERHAUL

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.


#### Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eyewear whenever using compressed air.


3. Wipe all parts, and clean all ports, passages, and inner parts with compressed air.
4. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Hose clamp</li> <li>2. Clutch hose</li> <li>3. Joint</li> <li>4. Bushing</li> <li>5. Snap ring<br/>Disassembly Note ..... below<br/>Assembly Note ..... page H-13</li> <li>6. Piston and secondary cup assembly<br/>Disassembly Note ..... page H-13<br/>Inspect for wear, scoring, and cracks<br/>Assembly Note ..... page H-13</li> <li>7. Spacer</li> </ol> | <ol style="list-style-type: none"> <li>8. Primary cup<br/>Inspect for wear and cracks</li> <li>9. Return spring</li> <li>10. Joint bolt</li> <li>11. Packing</li> <li>12. One-way valve piston<br/>Disassembly Note ..... page H-13</li> <li>13. Return spring</li> <li>14. Master cylinder body<br/>Inspect for scoring and corrosion.<br/>Replace master cylinder assembly if any<br/>scoring or corrosion is found.</li> </ol> |
|--|---|


**Disassembly Note****Snap ring**

While holding the piston down with a cloth-wrapped pin punch, remove the snap ring.

**Piston and secondary cup assembly****Warning**


- Applying compressed air to the cylinder assembly can make the contents suddenly pop out, possibly causing injury. Hold a rag over the cylinder opening when using compressed air.

Remove the piston-and-secondary-cup assembly, spacer, primary cup, and the return spring by applying compressed air through the clutch pipe installation hole.


**One-way valve piston****Warning**

- Applying compressed air to the cylinder assembly can make the contents suddenly pop out, possibly causing injury. Hold a rag over the cylinder opening when using compressed air.

Remove the piston by applying compressed air through the cylinder bore.

**Assembly Note****Piston and secondary cup assembly**

1. Apply new fluid of the specified type to the cylinder bore and all internal parts.
2. Verify that all parts are completely free of dirt, dust, and other small particles.
3. Install the spring, primary cup, spacer, and piston-and-secondary-cup assembly into the master cylinder body.


**Snap ring**

While holding the piston down with a cloth-wrapped pin punch, install the snap ring.

### CLUTCH RELEASE CYLINDER

#### PREPARATION

##### SST


49 0259 770B		For disconnecting and connecting clutch pipe
Wrench, flare nut		

#### REMOVAL / INSTALLATION

##### Caution


- Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, bleed the clutch system. (Refer to page H-11.)



1. Clutch pipe  
Removal Note ..... below  
Installation Note ..... page H-15


2. Bolt
3. Clutch release cylinder  
Remove boot and check for fluid leakage  
Overhaul ..... page H-15



##### Removal Note

##### Clutch pipe

Disconnect the clutch pipe by using the SST, and plug the clutch pipe immediately.



**Installation Note**  
**Clutch pipe**

1. Modify the clutch pipe tightening torque to allow for use of a torque wrench-SST combination. (Refer to section GI "Torque Formulas".)
2. Tighten the clutch pipe onto the clutch release cylinder by using the SST.

**Tightening torque:**

12.8–21.5 N·m{130–220 kgf·cm, 113–190 in·lbf}


**OVERHAUL**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.

**Warning**

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eyewear whenever using compressed air.


3. Wipe all parts, and clean all ports, passages, and inner parts with compressed air.
4. Assemble in the reverse order of disassembly.



1. Boot
2. Push rod
3. Piston and cup assembly  
Disassembly Not ..... page H-16  
Inspect for wear, scoring and cracks
4. Return spring

5. Bleeder cap
6. Bleeder screw  
5.9–8.8 N·m  
(60–90 kgf·cm, 53–78 in·lbf)
7. Steel ball
8. Release cylinder body  
Inspect cylinder bore for scoring and corrosion  
Replace cylinder assembly if any is found





### Disassembly Note Piston and cup assembly










#### Warning

- Applying compressed air to the cylinder assembly can make the contents suddenly pop out, possibly causing injury. Hold a rag over the cylinder opening when using compressed air.

Remove the piston and cup assembly by applying compressed air through the clutch pipe installation hole.

## CLUTCH UNIT


### PREPARATION SST

<p>49 F011 101 Brake, ring gear</p> 	<p>For prevention of engine rotation</p>	<p>49 0820 035 Box wrench, flywheel</p> 	<p>For removal and installation of flywheel</p>
<p>49 0839 305A Puller, counterweight</p> 	<p>For removal of flywheel</p>	<p>49 SE01 310A Clutch disc centering tool</p> 	<p>For support of clutch disc</p>
<p>49 1285 071 Puller, bearing</p> 	<p>For removal of pilot bearing and oil seal</p>	<p>49 1285 073 Chuck (Part of 49 1285 071)</p> 	<p>For removal of pilot bearing and oil seal</p>
<p>49 F011 1A1 Installer set, bearing</p> 	<p>For installation of pilot bearing and oil seal</p>	<p>49 G030 795 Installer, oil seal</p> 	<p>For installation of pilot bearing and oil seal</p>
<p>49 G030 797 Handle (Part of 49 G030 795)</p> 	<p>For installation of pilot bearing and oil seal</p>		


## REMOVAL / INSTALLATION

### Note

- The clutch release cylinder can be removed from the trans with the clutch pipe connected.
1. Remove in the order shown in the figure, referring to **Removal Note**.
  2. Install in the reverse order of removal, referring to **Installation Note**.




1. Clutch release cylinder	6. Wedge collar	10. Pilot bearing
2. Transmission	Removal Note	Removal Note
Service . . . . . section J	. . . . . page H-18	. . . . . page H-18
3. Clutch release fork assembly	Installation Note	Inspection . . . . . page H-23
Removal Note . . . . . below	. . . . . page H-19	Installation Note
Inspection . . . . . page H-21	7. Wire ring	. . . . . page H-19
Overhaul . . . . . page H-22	8. Clutch disc	11. Flywheel
4. Clutch release collar	Removal Note	Removal Note
Removal Note . . . . . below	. . . . . page H-18	. . . . . page H-18
Inspection . . . . . page H-23	Inspection . . . . . page H-21	Inspection . . . . . page H-23
5. Clutch cover	Installation Note	Installation Note
Removal Note	. . . . . page H-20	. . . . . page H-19
. . . . . page H-18	9. Oil seal	
Inspection . . . . . page H-20	Removal Note	
Installation Note	. . . . . page H-18	
. . . . . page H-20	Installation Note	
	. . . . . page H-19	




### Removal Note

#### Clutch release fork assembly and clutch release collar


1. Remove the release fork assembly bolts.
2. Remove the release fork assembly and release collar together as shown in the figure.

**Clutch cover and clutch disc**

1. Install the SSTs.
2. Loosen each bolt one turn at a time in a crisscross pattern until spring tension is released.
3. Remove the clutch cover and disc.


**Wedge collar**

1. Remove the wire ring from the wedge collar.
2. Remove the wedge collar from the clutch cover.


**Oil seal and pilot bearing****Note**

- The pilot bearing and oil seal do not need to be removed unless you are replacing them.


Remove the pilot bearing together with the oil seal by using the SST.

**Flywheel**


1. Hold the flywheel by using the SST or equivalent.
2. Using the SST (box wrench), loosen the looknut to the end of the eccentric shaft.




3. Loosen the flywheel from the eccentric shaft by using the SST (puller).
4. Remove the locknut and Flywheel.
5. Remove the key from the eccentric shaft.
6. Inspect for oil leakage past the crankshaft rear oil seal. If there is any such leakage or if the oil seal is damaged, refer to section C and replace the crankshaft rear oil seal.

**Installation Note****Flywheel**

1. Set the key in the eccentric shaft.
2. Align the groove with the eccentric shaft key and slide the flywheel into place.




3. Apply a small amount of sealant and thread-locking compound to the flywheel locknut as shown.



4. Install the SST to the flywheel.
5. Tighten the locknut by using the SST (box wrench).

**Tightening torque:**

393-490 N·m {40.0-50.0 kgf·m, 290-361 ft·lbf}


**Pilot bearing and oil seal**

1. Install the new bearing by using the SST.

**Bearing outer diameter: 20 mm {0.79 in}**


**Insertion depth: 11.5-12.3 mm {0.453-0.482 in}**

2. Install the new oil seal by using the SST.


**Wedge collar****Caution**

- If the wire ring or wedge collar is bent, it can separate from the release collar, disconnecting the clutch. When installing the wire ring and wedge collar, fit them onto the clutch cover without bending them.


1. Install a new wedge collar to the clutch cover.
2. Apply a small amount of grease to a new wire ring and install into exact position.

**Clutch disc**

1. Clean the clutch disc splines and main drive gear splines. Apply molybdenum sulfide grease to the splines.



2. Hold the flywheel by using the SST or equivalent.
3. Hold the clutch disc in position by using the SSTs.

**Clutch cover**

1. Align the dowel holes with the flywheel dowels and set the clutch cover in place, being careful not to dent or scratch the wedge collar and wire ring.
2. Tighten the bolts evenly and gradually in a crisscross pattern, while securing the flywheel by using the SST.

**Tightening torque:**



18–26 N·m {1.8–2.7 kgf·m, 14–19 ft·lbf}


**CLUTCH COVER****INSPECTION**

1. Inspect for wear or damage to the wire ring contact surface of the diaphragm spring plate.
2. Inspect for loosening of the diaphragm spring plate support.
3. If the diaphragm spring plate is loose or damaged, replace the clutch covers.
4. Measure the flatness of the pressure plate/clutch disc contact surface in a crisscross pattern with a straight-edge and a feeler gauge.

**Maximum: 0.20 mm {0.008 in}**

5. Check for discoloration of the pressure plate/clutch disc contact surface.
6. Remove minor discoloration with emery paper. Replace if discoloration is major.







## CLUTCH DISC

### INSPECTION


1. Inspect the lining surface for burning or oil contamination. Remove minor scratches or discoloration with sandpaper.
2. Inspect for loose facing rivets and torsion springs. Replace the clutch disc if any are loose.
3. Measure the thickness of the lining at a rivet head on both sides with vernier calipers. Replace if thickness is less than minimum.

**Thickness: 0.3 mm {0.012 in} min.**



4. Measure the clutch disc runout with a dial indicator. Replace the clutch disc if runout is excessive.


**Runout: 0.6 mm {0.024 in} max.**



## CLUTCH RELEASE FORK ASSEMBLY

### INSPECTION

1. Remove the return spring.
2. Swing the release fork back and forth, and make sure it moves smoothly.




3. Inspect for wear and damage to the push rod contact surface.
4. Inspect for wear and damage to the release collar contact surfaces.
5. Replace parts as necessary.

# H

## CLUTCH RELEASE FORK ASSEMBLY

### OVERHAUL


1. Disassemble in the order shown.
2. Inspect all parts and replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



1. Return spring  
Inspect for damage and bending
2. Fork shaft  
Assembly Note ..... below


3. Clutch release fork  
Inspect for wear and damage
4. Release fork support

5. Bushing  
Inspect bushing bore for wear and damage



### Assembly Note Fork shaft

1. Install the roll pin with the split facing as shown.
2. Make sure the roll pin is installed flush with the release fork surface.





## CLUTCH RELEASE COLLAR

### INSPECTION

#### Caution

- Cleaning the clutch release collar with cleaning fluids or a steam cleaner can wash the grease out of the sealed bearing.


1. Turn the collar while applying force in the axial direction. If the collar sticks or has excessive resistance, replace it.
2. Inspect for wear and damage to the release collar groove. Replace if worn or damaged.



## PILOT BEARING

### INSPECTION

Without removing the pilot bearing from the flywheel, inspect the pilot bearing for wear and damage, and check the rotating condition. Replace the pilot bearing if worn or damaged, or if rotating condition is poor.




## FLYWHEEL

### INSPECTION

1. Inspect the contact surface for scoring, cracks, and burning.
2. Remove minor scoring and burning with emery paper. Replace if scoring or burning is major, or if flywheel is cracked.
3. Inspect the ring gear teeth for wear and damage.
4. Measure the flywheel runout with a dial indicator. Replace the flywheel if runout is excessive.

Runout: 0.2 mm {0.008 in} max.





Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.


J

## MANUAL TRANSMISSION (R15M-D)

INDEX .....	J - 2
OUTLINE .....	J - 3
SPECIFICATIONS .....	J - 3
STRUCTURAL VIEW .....	J - 3
POWERFLOW .....	J - 4
TROUBLESHOOTING GUIDE .....	J - 5
TRANSMISSION OIL .....	J - 6
INSPECTION .....	J - 6
REPLACEMENT .....	J - 6
OIL SEAL (EXTENSION HOUSING) .....	J - 7
PREPARATION .....	J - 7
ON-VEHICLE REPLACEMENT .....	J - 7
TRANSMISSION .....	J - 8
PREPARATION .....	J - 8
REMOVAL .....	J -10
DISASSEMBLY .....	J -13
INSPECTION .....	J -29
ASSEMBLY .....	J -33
INSTALLATION .....	J -55
SHIFT MECHANISM .....	J -58
OVERHAUL .....	J -58

J

## INDEX



### OIL SPECIFICATION

GRADE : API SERVICE GL-4 OR GL-5  
 ALL SEASON : SAE 75W-90  
 ABOVE 10°C (50°F) : SAE 80W-90  
 CAPACITY : 2.5 L {2.6 US qt, 2.2 Imp qt}

### 1. Transmission oil

Inspection ..... page J-6  
 Replacement .... page J-6

### 2. Oil seal (extension housing)

On-vehicle  
 replacement ... page J-7

### 3. Transmission

Removal ..... page J-10  
 Disassembly .. page J-13  
 Inspection .... page J-29  
 Assembly ..... page J-33  
 Installation .... page J-55

### 4. Shift mechanism

Overhaul ..... page J-58


OUTLINE

SPECIFICATIONS

Item		Model	R15M-D
Synchronization mechanism			Forward: Synchromesh Reverse: Synchromesh
Shift type			5-speed, floor shift
Shift pattern			<pre>           ①  ②  ③   ④  ⑤  ⑥                     </pre>
Gear ratio	1st		3.483
	2nd		2.015
	3rd		1.391
	4th		1.000
	5th		0.719
	Reverse		3.288
Oil	Grade		API service GL-4 or GL-5
	Viscosity	All-season	SAE 75W-90
		Above 10°C (50°F)	SAE 80W-90
	Capacity	L {US qt, Imp qt}	2.5 {2.6, 2.2}

J







STRUCTURAL VIEW



- 1. Main drive gear (4th gear)
- 2. 3rd gear
- 3. 2nd gear
- 4. 1st gear
- 5. 5th gear
- 6. Countershaft

- 7. Counter 5th gear
- 8. Mainshaft
- 9. Reverse gear
- 10. Reverse idler gear
- 11. Counter reverse gear


## POWERFLOW



**TROUBLESHOOTING GUIDE**

Problem	Possible Cause	Action	Page
<b>Abnormal noise</b>	Insufficient oil	Add oil	J-6
	Deterioration of oil quality	Replace with specified oil	J-6
	Worn bearing	Replace	—
	Worn contact surface of countershaft gear	Replace	J-24
	Worn contact surface of gears	Replace	J-16, 20, 24
	Excessive gear backlash	Replace	J-16, 20, 24
	Damaged gear teeth	Replace	J-16, 20, 24
<b>Difficult to shift</b>	Object caught in gears	Repair or replace	J-16, 20, 24
	Bent shift rod	Replace	J-16
	Insufficient oil	Add oil	J-6
	Deterioration of oil quality	Replace with specified oil	J-6
	Wear or play of shift fork or shift rod	Replace	J-16, 20
	Worn or damaged synchronizer ring (1st, 4th, 5th, Reverse)	Replace	J-16, 24
	Worn or damaged synchronizer assembly (2nd and 3rd)	Replace	J-24
	Worn synchronizer gear cone	Replace	J-16, 20, 24
	Poor contact of synchronizer ring and gear cone	Replace	J-16, 20, 24
	Excessive longitudinal play of gears	Replace	J-16, 20, 24
	Worn bearing	Replace	—
	Improper disengagement of clutch	Refer to section H	—
	Weak synchronizer key spring	Replace	J-16, 24
<b>Jumps out of gear</b>	Weak detent ball spring	Replace	J-16
	Worn shift fork	Replace	J-16, 20
	Worn clutch hub	Replace	J-16, 24
	Worn clutch hub sleeve	Replace	J-16, 24
	Worn gears	Replace	J-16, 20, 24
	Excessive gear backlash	Replace	J-16, 20, 24
	Worn bearing	Replace	—
	Loose engine mounts or transmission mounts	Tighten	—

J



## TRANSMISSION OIL

### INSPECTION

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the transmission cover.
3. Remove the filler plug.
4. Verify that the oil is up to the bottom of the filler plug hole.
5. If the oil level is low, add the specified oil through the filler plug port.
6. Install a new filler plug.


### Tightening torque:

25–39 N·m {2.5–4.0 kgf·m, 19–28 ft·lbf}

7. Install the transmission cover.

### Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




### REPLACEMENT

1. Remove the transmission cover.
2. Remove plug A (with washer) and B, and drain the oil into a suitable container.
3. Wipe both plugs clean.
4. Apply sealant to the B plug threads.
5. Install plug A (with new washer) and B.

### Tightening torque:

A: 40–58 N·m {4.0–6.0 kgf·m, 29–43 ft·lbf}

B: 21–31 N·m {2.1–3.2 kgf·m, 16–23 ft·lbf}



6. Remove the filler plug and add the specified oil through the filler plug port until the level rises to the bottom of the port.


### Specified oil:

Grade: API service GL-4 or GL-5

All-season: SAE 75W-90

Above 10°C {50°F}: SAE 80W-90

Capacity: 2.5 L {2.6 US qts, 2.2 Imp qts}



7. Install a new filler plug.


### Tightening torque:

25–39 N·m {2.5–4.0 kgf·m, 19–28 ft·lbf}

8. Install the transmission cover.




### Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




OIL SEAL (EXTENSION HOUSING)

PREPARATION  
SST


<p>49 G030 795</p> <p>Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 G030 796</p> <p>Body (Part of 49 G030 795)</p> 	<p>For installation of oil seal</p>
<p>49 G030 797</p> <p>Handle (Part of 49 G030 795)</p> 	<p>For installation of oil seal</p>		

J



**ON-VEHICLE REPLACEMENT**

1. Remove the transmission cover.
2. Remove the propeller shaft. (Refer to section L.)
3. Remove the oil seal.



















4. Apply the specified oil to the new oil seal.
5. Install the oil seal by using the SST.
6. Install the propeller shaft. (Refer to section L.)
7. Inspect the oil level. (Refer to page J-6)
8. Install the transmission cover.

**Tightening torque:**






7.9-10.7 N·m{80-110 kgf·cm,70-95.4 in·lbf}

**TRANSMISSION**

**PREPARATION  
SST**

<p>49 G017 5A0 Support, engine</p> 	<p>For support of engine</p>	<p>49 G017 501 Bar (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>
<p>49 G017 502 Support (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>	<p>49 G017 503 Hook (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>
<p>49 S120 440 Holder, mainshaft</p> 	<p>For holding mainshaft</p>	<p>49 0839 425C Puller set, bearing</p> 	<p>For removal of bearing</p>
<p>49 G030 795 Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 G030 796 Body (Part of 49 G030 795)</p> 	<p>For installation of oil seal</p>
<p>49 G030 797 Handle (Part of 49 G030 795)</p> 	<p>For installation of oil seal</p>	<p>49 0500 330 Installer, transmission bearing</p> 	<p>For installation of bearing</p>
<p>49 0636 145 Puller, fan pulley boss</p> 	<p>For removal of clutch hub assembly</p>	<p>49 0862 350 Guide, shift fork</p> 	<p>For installation of interlock pin</p>
<p>49 1243 465A Wrench, mainshaft locknut</p> 	<p>For removal of locknut</p>	<p>49 H017 101 Hook</p> 	<p>For removal of bearing</p>
<p>49 0710 520 Puller, bearing</p> 	<p>For removal of bearing</p>	<p>49 F017 101 Holder, synchronizer ring</p> 	<p>For installation of bearing</p>




<p><b>49 F401 330B</b> Installer set, bearing</p> 	<p>For installation of bearing</p>	<p><b>49 F401 331</b> Body (Part of 49 F401 330B)</p> 	<p>For installation of clutch hub assembly</p>
<p><b>49 F401 335A</b> Attachment A (Part of 49 F401 330B)</p> 	<p>For installation of bearing race</p>	<p><b>49 0813 235</b> Replacer, main bearing</p> 	<p>For installation of main bearing</p>
<p><b>49 S017 401</b> Retaining ring replacer</p> 	<p>For removal/installation of retaining ring</p>		


**J**

**REMOVAL**

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.



- |  |   |   |
|--|---|---|
| <ol style="list-style-type: none"> <li>1. Shift lever knob</li> <li>2. Console panel assembly</li> <li>3. Insulator assembly</li> <li>4. Shift lever assembly</li> <li>5. Transmission cover</li> <li>6. Right undercover</li> <li>7. Left undercover</li> <li>8. Clutch release cylinder<br/>Removal Note<br/>..... page J-11</li> <li>9. Starter</li> <li>10. Tunnel reinforcement<br/>(center)</li> </ol> | <ol style="list-style-type: none"> <li>11. Secondary air injection<br/>pipe</li> <li>12. Catalytic converter<br/>assembly</li> <li>13. Tunnel reinforcement<br/>(front)</li> <li>14. Tunnel reinforcement<br/>(rear)</li> <li>15. Cover</li> <li>16. Propeller shaft<br/>Removal ..... section L</li> </ol> | <ol style="list-style-type: none"> <li>17. Power Plant Frame (PPF)<br/>Removal Note<br/>..... page J-11</li> <li>18. Connectors</li> <li>19. Service hole A cover</li> <li>20. Service hole B cover</li> <li>21. Back-up light switch</li> <li>22. Transmission<br/>Removal Note<br/>..... page J-11</li> <li>23. Dust cover</li> </ol> |
|--|---|---|




### Removal Note Clutch release cylinder

#### Caution


- Bending the clutch pipe can cause kinks or cracks.

1. Loosen the clutch release cylinder installation bolts.
2. Loosen the clutch pipe bracket bolt.
3. Secure the clutch release cylinder/clutch pipe assembly in a place where it will not interfere with transmission removal.




### Power plant frame (PPF)

1. Hold the engine by using the SST (engine supports).




2. Hold the differential with a transmission jack.
3. Remove the PPF.
4. Remove the back-up light switch from the transmission.



### Transmission

1. The clutch cover and clutch release collar are joined as shown in the figure.


- A: Clutch cover
- B: Clutch release collar
- C: Wedge collar
- D: Wire ring




2. Remove the covers from service holes A and B.
3. Through service hole A, swing the release fork so that the release collar is pushed and held toward the clutch cover (engine side).

# J


## TRANSMISSION




4. Insert a screwdriver through service hole B, into the space between the wedge collar and the release collar. Pry and separate the release collar from the clutch cover.




5. Swing the release fork back and forth to make sure that the release collar and clutch cover are separated.



6. If the above procedure does not work, then separate the clutch cover from the flywheel, following the procedure below.
  - (1) Through service hole B, gradually loosen the 6 clutch cover installation bolts in a crisscross pattern.
  - (2) Remove the clutch cover installation bolts, and separate the clutch cover from the flywheel.



7. Support the transmission with a transmission jack.
8. Loosen the transmission installation bolts.
9. Remove the transmission.



10. Remove the clutch cover.
  - (1) Remove the clutch cover from the flywheel. (Refer to section H.)
  - (2) If the transmission was removed by following step 6, remove the wire ring from the release collar and separate the release collar from the clutch cover.

## DISASSEMBLY

### Precaution

1. Clean the transmission exterior thoroughly with a steam cleaner or cleaning solvents before disassembly.

### Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eyewear whenever using compressed air.

### Caution


- Cleaning sealed bearings with cleaning fluids or a steam cleaner can wash the grease out of the bearing.
2. Clean the removed parts (except sealed bearings) with cleaning solvent, and dry with compressed air. Clean out all holes and passages with compressed air, and check that there are no obstructions.
  3. Use a plastic hammer when disassembling the transmission case and other light alloy metal parts.

### Clutch Housing and Extension Housing Components

**Note**


- The front and rear oil seals do not need to be removed unless you are replacing them.

Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- |                             |   |                            |
|-----------------------------|---|----------------------------|
| 1. Release fork assembly    | 10. Oil seal (clutch housing)                       | 16. Speedometer drive gear |
| 2. Release collar           | 11. Adjustment shim                                 | 17. Key                    |
| 3. Front cover              | 12. Back-up light switch                            | 18. Snap ring              |
| 4. Dust cover               | 13. Speedometer sensor<br>(Speedometer driven gear) | 19. Undercover             |
| 5. Service hole A cover     | 14. Extension housing                               | 20. Oil baffle             |
| 6. Service hole B cover     | 15. Snap ring                                       | 21. Magnet                 |
| 7. Vent cover               |   |                            |
| 8. Release cylinder support |   |                            |
| 9. Clutch housing           |   |                            |

Disassembly Note  
 ..... page J-15

**Disassembly note****Extension Housing**

1. Temporarily reinstall the shifter lever, and move the control rod end to the neutral position.
2. Remove the shift lever.
3. Remove the extension housing installation bolts.


**Caution**

- When removing the extension housing, be careful that the control lever is not pulled into or pushed against the shift rod gates.

4. Lift up on and remove the extension housing from the center housing.


### 5th/Reverse Gear and Housing Components

Disassemble in the order shown in the figure, referring to Disassembly Note.





- |  |  |   |
|--|--|---|
| 1. 5th/Reverse shift rod end<br>Inspection .... page J-30            | 16. Center housing<br>Disassembly Note<br>..... page J-18        | 34. 1st/2nd shift rod<br>Disassembly Note<br>..... page J-19                  |
| 2. 3rd/4th shift rod end<br>Inspection .... page J-30                | 17. Oil guide  | 35. Thrust washer   |
| 3. 1st/2nd shift rod end<br>Inspection .... page J-30                | 18. Blind cover  | 36. Reverse idler gear shaft<br>Inspection .... page J-31                     |
| 4. Bearing housing<br>Disassembly Note<br>..... below                | 19. Cap plug, spring, and<br>detent ball                         | 37. Reverse idler gear<br>Inspection .... page J-31                           |
| 5. Snap ring   | 20. Thrust lock washer   | 38. Thrust washer   |
| 6. Thrust washer   | 21. Steel ball   | 39. Counter reverse gear<br>Inspection .... page J-29                         |
| 7. C-washers   | 22. Bearing<br>Inspect for damage                                | 40. Locknut<br>Disassembly Note<br>..... page J-19                            |
| 8. Retaining ring  | 23. 5th gear<br>Inspection .... page J-29                        | 41. 5th/Reverse clutch hub<br>assembly<br>Disassembly Note<br>..... page J-19 |
| 9. Mainshaft rear bearing<br>Disassembly Note<br>..... below         | 24. Retaining ring   | 42. Reverse synchronizer ring<br>Inspection .... page J-30                    |
| 10. C-washers and<br>retaining ring                                  | 25. 5th synchronizer ring<br>Inspection .... page J-30           | 43. Reverse gear<br>Inspection .... page J-29                                 |
| 11. Locknut<br>Disassembly Note<br>..... page J-18                   | 26. Retaining ring   | 44. Bearing<br>Inspect for damage   |
| 12. Countershaft rear bearing<br>Disassembly Note<br>..... page J-18 | 27. 5th/Reverse shift rod<br>Disassembly Note<br>..... page J-18 | 45. Bearing race  |
| 13. Counter 5th gear<br>Inspection .... page J-29                    | 28. Spring<br>Inspection .... page J-31                          | 46. Thrust washer   |
| 14. Spacer   | 29. 5th/Reverse shift fork                                       | 47. Bearing cover   |
| 15. Set bolt and washer  | 30. Interlock pin (large)  | 48. Oil guide   |
|  | 31. 3rd/4th shift rod<br>Disassembly Note<br>..... page J-19     |   |
|  | 32. Interlock pin (small)  |   |
|  | 33. Interlock pin (large)  |   |



**Disassembly note**  
**Bearing housing**


**Caution**


- The bearing housing is made of aluminum, and is therefore easily dented and scratched by metal tools. When removing the bearing housing, do not use metal tools.

Hit down and outward on the bearing housing with a plastic hammer to remove.


**Mainshaft rear bearing**

1. Remove the snap ring, washer, retaining ring, and rear C-washers. Keep the rear C-washers together for correct reassembly.
2. Remove the mainshaft rear bearing by using the SST.
3. Remove the retaining ring and the front C-washers. Keep the front C-washers together for correct reassembly.




**Locknut and countershaft rear bearing**


1. Shift the 1st/2nd shift rod to 1st gear.
2. Uncrimp the tab of the locknut.
3. Hold the mainshaft by using the SST and a vise.
4. Remove the locknut.




5. Remove the countershaft rear bearing by using the SST.

**Center housing**


1. Remove the set bolt and washer from the center housing.
2. Remove the center housing by tapping around its edge with a plastic hammer.

**5th/Reverse shift rod**


1. Remove the three cap plugs, packings, detent balls, and springs.



2. Drive the roll pin from the 5th/Reverse shift fork.




3. Remove the retaining ring from the 5th/Reverse shift rod by using the SST.
4. Slide the 5th/Reverse shift rod out of the transmission case, and remove the spring.




**1st/2nd and 3rd/4th shift rods**

1. Shift the transmission into 4th gear to gain access to the roll pin. Drive the roll pin from the 3rd/4th shift fork.
2. Slide the 3rd/4th shift rod and interlock pin (small) out from the rear of the transmission case.
3. Drive the roll pin from the 1st/2nd shift fork. Slide the 1st/2nd shift rod out from the rear of the transmission case, and remove the interlock pin (large).




**Locknut**

1. Uncrimp the tab of the locknut.
2. Shift into 1st and 4th gears to lock the rotation of the main shaft.



3. Remove the locknut by using the SST.




**5th/Reverse clutch hub assembly**


1. Remove the bearing cover installation bolts.
2. Attach the SST to the bearing cover and remove the assembly, which consists of the following parts:
  - 5th/Reverse clutch hub assembly
  - Synchronizer ring
  - Needle bearing
  - Bearing race
  - Reverse gear
  - Thrust washer

### Transmission Case Components

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- |  |   |  |
|--|---|--|
| <p>1. Snap rings<br/>Disassembly Note<br/>..... page J-21</p> <p>2. Main drive gear bearing<br/>Disassembly Note<br/>..... page J-21<br/>Inspect for damage</p> <p>3. Countershaft front bearing<br/>Disassembly Note<br/>..... page J-21<br/>Inspect for damage</p> | <p>4. Mainshaft front bearing<br/>Disassembly Note<br/>..... page J-22<br/>Inspect for damage</p> <p>5. Thrust washer</p> <p>6. Countershaft center bearing<br/>Disassembly Note<br/>..... page J-22<br/>Inspect for damage</p> <p>7. Countershaft assembly</p> | <p>8. Main drive gear<br/>Inspection .... page J-29</p> <p>9. Bearing</p> <p>10. Mainshaft gear assembly<br/>Disassembly Note<br/>..... page J-22</p> <p>11. 3rd/4th shift fork</p> <p>12. 1st/2nd shift fork</p> <p>13. Transmission case</p> |
|--|---|--|



**Disassembly note**


**Snap rings**

Remove the snap rings from the mainshaft and the countershaft by using snap ring pliers.




**Main drive gear bearing**


1. Install the SST between the 4th gear synchronizer ring and main drive synchromesh gear.



2. Turn the bearing snap rings so that the ends are 90° to the transmission case grooves.




3. Install the SST, making sure to hand tighten the side screws as tightly as possible, and remove the main drive gear bearing.




**Countershaft front bearing**

1. Turn the bearing snap rings so that the ends are 90° to the transmission case grooves.




2. Remove the countershaft front bearing by using the SST.




**Mainshaft front bearing**

Remove the mainshaft front bearing by using the SST.




**Countershaft center bearing**

1. Remove the countershaft center bearing by using the SST.




2. Remove the countershaft.



**Mainshaft gear assembly**

1. Remove the main drive gear from the transmission case.  
2. Remove the needle bearing from the mainshaft joint of the main drive gear.




3. Remove the mainshaft gear assembly from the transmission case.

### Mainshaft and Countershaft Components

#### Note


- The countershaft center bearing race does not need to be removed unless you are replacing it.

Disassemble in the order shown, referring to Disassembly Note.






- |  |  |   |
|--|--|---|
| <p>1. 1st gear<br/>Inspection . . . . page J-29</p> <p>2. Bearing<br/>Inspect for damage</p> <p>3. Bearing race</p> <p>4. 1st synchronizer ring<br/>Inspection . . . . page J-30</p> <p>5. 4th synchronizer ring<br/>Inspection . . . . page J-30</p> <p>6. 3rd/4th clutch hub assembly<br/>Disassembly Note<br/>..... below<br/>Inspection . . . . page J-30</p> <p>7. 3rd/4th clutch hub</p> <p>8. Synchronizer key</p> <p>9. Clutch hub sleeve</p> <p>10. Synchronizer key spring</p> <p>11. 3rd synchronizer assembly<br/>Inspection . . . . page J-31</p> | <p>12. Inner cone</p> <p>13. Double cone</p> <p>14. Synchronizer ring</p> <p>15. Bearing<br/>Inspect for damage</p> <p>16. 3rd gear<br/>Inspection . . . . page J-29</p> <p>17. 1st/2nd clutch hub assembly<br/>Disassembly Note<br/>..... below<br/>Inspection . . . . page J-30</p> <p>18. 1st/2nd clutch hub</p> <p>19. Synchronizer key</p> <p>20. Clutch hub sleeve</p> <p>21. Synchronizer key springs</p> <p>22. 2nd synchronizer assembly<br/>Inspection . . . . page J-31</p> | <p>23. Inner cone</p> <p>24. Double cone</p> <p>25. Synchronizer ring</p> <p>26. 2nd gear<br/>Inspection . . . . page J-29</p> <p>27. Bearing<br/>Inspect for damage</p> <p>28. Mainshaft<br/>Inspection . . . . page J-29</p> <p>29. Countershaft front bearing spacer</p> <p>30. Countershaft center bearing race<br/>Disassembly Note<br/>..... page J-26</p> <p>31. Countershaft<br/>Inspection . . . . page J-29</p> |
|--|--|---|




**Disassembly note**

**3rd/4th clutch hub assembly**

1. Remove the snap ring from the front of the mainshaft.




2. Position the SST between 2nd and 3rd gears, and hold the mainshaft from underneath.
3. Press the mainshaft out from the 3rd gear, 3rd synchronizer ring assembly, and the 3rd/4th clutch hub assembly.



**1st/2nd clutch hub assembly**

- Hold the mainshaft, and press the 1st/2nd clutch hub assembly, 2nd synchronizer ring assembly, and 2nd gear from the mainshaft.

**Countershaft center bearing race**


Hold the countershaft from underneath, and remove the countershaft bearing race by using the SST.

Extension Housing Components


Note

- The extension housing oil seal does not need to be removed unless you are replacing it.


Disassemble in the order shown, referring to Disassembly Note.




- |   |                                |                           |
|---|--------------------------------|---------------------------|
| 1. Stopper                              | 9. Wave washer                 | 15. Control rod           |
| 2. Power plant frame installation bolts | Inspect for wear and damage    | Disassembly Note          |
| 3. Oil guide                            | 10. Blind cover                | ..... page J-28           |
| 4. Neutral switch                       | 11. Select spindle assembly    | Inspectio ..... page J-30 |
| 5. 1-2 switch                           | 12. Spring cap                 | 16. Control rod end       |
| 6. Bracket                              | 13. Select lock spindle spring | 17. Selector              |
| 7. Control case                         | Inspection .... page J-31      | 18. Shift guide assembly  |
| 8. Bushing                              | 14. Select lock spindle        | 19. Oil seal              |
| Inspect for wear and damage             |                                | Disassembly Note          |
|   |                                | ..... page J-28           |
|   |                                | 20. Extension housing     |
|   |                                | Inspection .... page J-32 |

**Disassembly note****Control rod**

1. Slide the control rod end to the point where the roll pin is directly above the recess in the extension housing.
2. Remove the roll pin from the control rod end by using a pin punch and hammer.




3. Remove the roll pin from the selector by using a pin punch and hammer.
4. Slide the control rod from the extension housing, and remove the control rod end and selector.

**Oil seal (extension housing)**


Remove the oil seal from the extension housing by using a screwdriver.

**INSPECTION**

Inspect all parts, and repair or replace as necessary.

**Each Gear and Main Drive Gear**


1. Inspect synchronizer cones for wear.
2. Inspect individual gear teeth for damage, wear, and cracks.
3. Inspect synchronizer ring matching teeth for damage and wear.
4. Inspect main drive gear splines for damage and wear.

**Mainshaft**

1. Measure the mainshaft runout.


**Runout: 0.03 mm {0.0012 In} max.**

2. Inspect splines for damage and wear.




3. Measure the clearance between mainshaft and gear (or bushing).

**Clearance: 0.15 mm {0.006 In} max.**

**Countershaft**


1. Inspect gear teeth for damage, wear, and cracks.
2. Inspect splines for damage and wear.



**Control Rod Lever and Shift Rod**


Measure the clearance between the control rod lever and the shift rod gate.

**Clearance: 0.8 mm {0.031 in} max.**



**Each Clutch Hub Assembly**

1. Inspect clutch hub sleeve and hub operation.
2. Inspect individual gear teeth for damage, wear, and cracks.
3. Inspect synchronizer keys for damage, wear, and cracks.




4. Measure the clearance between the hub sleeve groove and shift fork.

**Clearance:**


**0.2–0.3 mm {0.008–0.012 in}**

**Maximum: 0.5 mm {0.020 in}**



**1st, 4th, 5th, Reverse Synchronizer Rings**


1. Inspect individual synchronizer ring teeth for damage, wear, and cracks.
2. Inspect taper surface for wear and cracks.



3. Set the synchronizer ring squarely in the gear.
4. Measure the clearance between the synchronizer ring and flank surface of gear all around the circumference.


**Clearance: 1.5 mm {0.059 in}**

**Minimum: 0.8 mm {0.031 in}**




### 2nd/3rd Synchronizer Assembly

1. Inspect individual synchronizer ring gear teeth for damage, wear, and cracks. Replace the synchronizer assembly if any such damage is found.
2. Inspect for wear and damage to the tapered surfaces of the inner cone, double cone, and synchronizer ring. Replace the synchronizer assembly if any such damage is found.




3. Set the synchronizer assembly squarely in the gear.
4. Measure the clearance between the synchronizer ring and flank surface of gear.

**Clearance: 1.5 mm {0.059 in}**  
**Minimum: 0.8 mm {0.031 in}**




### Reverse Idler Gear and Shaft

1. Inspect gear teeth for damage, wear, and cracks.



2. Measure the clearance between the reverse idler gear bushing and shaft.

**Clearance:**  
**0.02–0.05 mm {0.0008–0.0020 in}**  
**Maximum: 0.15 mm {0.006 in}**




### Spring

Measure the free length of the spring.

#### Standard free length

**Detent ball spring: 22.5 mm {0.886 in}**  
**5th/Reverse retaining spring: 73.00 mm {2.874 in}**  
**Select lock spindle spring: 43.25 mm {1.703 in}**

**Extension Housing**

1. Inspect the indicated bearings for damage.
2. Replace the extension housing if necessary.




**ASSEMBLY**

**Precaution**


1. Make sure each part is cleaned before assembling.
2. Coat all movable parts with the specified oil.
3. Replace parts wherever required.
4. Remove old sealant from contact surfaces before applying new sealant.
5. Assemble the parts within 10 minutes after applying sealant. Allow all sealant to cure at least 30 minutes after assembly before filling the transmission with transmission oil.

**Extension Housing Components**

Assemble in the order shown, referring to **Assembly Note**.




- |  |                                   |   |
|--|-----------------------------------|---|
| 1. Extension housing                             | 7. Select lock spindle            | 13. Wave washer                             |
| 2. Oil seal (extension housing)<br>Assembly Note | 8. Select lock spindle spring     | 14. Bushing                                 |
| ..... page J-34                                  | 9. Spring cap                     | 15. Bracket                                 |
| 3. Shift guide assembly                          | 10. Select spindle assembly       | 16. 1-2 switch                              |
| 4. Selector                                      | 11. Blind cover                   | 17. Neutral switch                          |
| 5. Control rod end                               | Assembly Note                     | 18. Oil guide                               |
| 6. Control rod<br>Assembly Note                  | ..... page J-34                   | 19. Power plant frame<br>installation bolts |
| ..... page J-34                                  | 12. Control case<br>Assembly Note | 20. Stopper                                 |
|  | ..... page J-34                   |   |



**Assembly note**


**Oil seal (extension housing)**

1. Apply clean oil to the lip and outer edge of a new oil seal.
2. Install the oil seal evenly and gradually by using the SST.



**Control rod**

1. Install the control rod through the selector and the control rod end, into the extension housing.
2. Install new roll pins into the selector and control rod ends as shown in the figure.




**Blind cover**

1. Apply sealant to the contact surfaces of the blind cover and extension housing.
2. Install the blind cover.

**Tightening torque:**

**19–25 N·m{1.9–2.6 kgf·m,14–18 ft·lbf}**



**Control case**

1. Apply sealant to the contact surfaces of the extension housing and control case.
2. Install the control case to the extension housing.

**Tightening torque:**

**19–25 N·m{1.9–2.6 kgf·m,14–18 ft·lbf}**


MEMO

# J


## TRANSMISSION

### Mainshaft and Countershaft Components

Assemble in the order shown, referring to Assembly Note.




- |                                 |                                 |                                       |
|---------------------------------|---------------------------------|---------------------------------------|
| 1. Mainshaft                    | 13. 3rd gear                    | 25. 1st synchronizer ring             |
| 2. Bearing                      | 14. Bearing                     | 26. Bearing race                      |
| 3. 2nd gear                     | 15. Inner cone                  | 27. Bearing                           |
| 4. Inner cone                   | 16. Double cone                 | 28. 1st gear                          |
| 5. Double cone                  | 17. Synchronizer ring           | 29. Countershaft                      |
| 6. Synchronizer ring            | 18. 3rd synchronizer assembly   | 30. Countershaft center bearing race  |
| 7. 2nd synchronizer assembly    | Assembly Note . . . . . below   | Assembly Note . . . . . page J-39     |
| 8. 1st/2nd clutch hub           | 19. 3rd/4th clutch hub          |                                       |
| 9. Synchronizer key             | 20. Synchronizer key            |                                       |
| 10. Clutch hub sleeve           | 21. Clutch hub sleeve           |                                       |
| 11. Synchronizer key springs    | 22. Synchronizer key springs    |                                       |
| 12. 1st/2nd clutch hub assembly | 23. 3rd/4th clutch hub assembly |                                       |
| Assembly Note . . . . . below   | Assembly Note . . . . . below   |                                       |
|                                 | 24. 4th synchronizer ring       |                                       |
|                                 |                                 | 31. Countershaft front bearing spacer |
|                                 |                                 | Assembly Note . . . . . page J-39     |




**Assembly note**  
**2nd, 3rd synchronizer assemblies**

Install the inner cone, double cone, and synchronizer ring as shown in the figure. The 1st synchronizer ring has two teeth fused together at three places around its outer edge.




**1st/2nd, 3rd/4th clutch hub assemblies**

1. For the 2nd and 3rd synchronizer assemblies, align the synchronizer ring grooves and keys, and fit the inner cone tabs into the clutch hub slots.




2. For the 1st and 4th synchronizer rings, align the synchronizer ring grooves and synchronizer keys.




### Standard key dimensions

mm {in}


	1	2	3
1st and 2nd	18.00 {0.709}	5.45 {0.215}	6.00 {0.236}
3rd and 4th	17.00 {0.669}	4.25 {0.167}	5.00 {0.197}




3. When installing the gears and clutch hub assemblies in the following procedure, make sure that they are installed in the direction shown in the figure.




4. Set the needle bearing, 2nd gear, 2nd synchronizer assembly, and the 1st/2nd clutch hub assembly on the mainshaft. Press the parts onto the mainshaft while keeping the parts from becoming crooked or misaligned.



5. Set the needle bearing, 3rd gear, 3rd synchronizer assembly, and 3rd/4th clutch hub assembly on the mainshaft. Press the parts onto the mainshaft by using the SST, while keeping the parts from becoming crooked or misaligned.




6. Install a new snap ring on the front of the mainshaft.



**Countershaft center bearing race**

Press the countershaft center bearing race onto the countershaft by using the SST.




**Countershaft front bearing spacer**

Install the countershaft front bearing spacer. If the countershaft front bearing or countershaft front bearing spacer is being replaced, replace them as an assembly.

**Transmission Case Components**


Assemble in the order shown, referring to **Assembly Note**.



N·m {kgf·m, ft·lbf}

- |  |  |  |
|--|--|--|
| 1. Transmission case<br>Assembly Note<br>..... page J-41 | 7. Countershaft assembly   | 12. Main drive gear bearing<br>Assembly Note<br>..... page J-42    |
| 2. Mainshaft gear assembly                               | 8. Thrust washer   | 13. Countershaft front bearing<br>Assembly Note<br>..... page J-43 |
| 3. 1st/2nd shift fork                                    | 9. Mainshaft front bearing<br>Assembly Note<br>..... page J-42         | 14. Snap rings   |
| 4. 3rd/4th shift fork                                    | 10. Countershaft center<br>bearing<br>Assembly Note<br>..... page J-42 |  |
| 5. Bearing   | 11. Bearing cover  |  |
| 6. Main drive gear                                       |  |  |






**Assembly note**  
**Transmission case**

1. Measure the mainshaft front bearing thrust play as follows.

- (1) Measure the depth of the mainshaft front bearing bore in the rear of the transmission case.



(2) Measure the mainshaft front bearing height.


The difference between the two measurements indicates the required thickness of the adjustment shim.

**Standard thrust play:**

0–0.05 mm {0–0.002 in}


**Adjustment shim thicknesses:**

0.1mm {0.004 in}, 0.3 mm {0.012 in}



2. Measure the countershaft front bearing thrust play as follows.

- (1) Measure depth B of the countershaft front bearing bore in the transmission case.



(2) Measure the countershaft front bearing snap ring height A.

- (3) Choose an adjustment shim that will allow the difference between the two measurements to be equal to the standard bearing height.


**A-B + Adjustment shim(s) = 0.9–1.0 mm**  
**{0.035–0.039 in}**

**Standard bearing height on installing:**

0.9–1.0 mm {0.035–0.039 in}

**Adjustment shim thicknesses:**

0.1mm {0.004 in}, 0.3 mm {0.012 in}




3. Position the 1st/2nd and 3rd/4th shift forks into the grooves of the clutch hub and sleeve assemblies.

4. Apply molybdenum grease to the needle bearing and install it in the main drive gear.

5. Install the main drive gear onto the front of the mainshaft.



- |                                  |                            |                               |
|----------------------------------|----------------------------|-------------------------------|
| 1. Counter reverse gear          | 20. 1st/2nd shift rod      | 35. Counter 5th gear          |
| 2. Thrust washer                 | Assembly Note              | 36. Countershaft rear bearing |
| 3. Reverse idler gear            | ..... page J-47            | Assembly Note                 |
| 4. Reverse idler gear shaft      | 21. Interlock pin (large)  | ..... page J-49               |
| 5. Thrust washer                 | 22. Interlock pin (small)  | 37. Locknut                   |
| 6. Thrust washer                 | 23. 3rd/4th shift rod      | 38. Mainshaft rear bearing    |
| 7. Bearing race                  | Assembly Note              | Assembly Note                 |
| 8. Bearing                       | ..... page J-47            | ..... page J-49               |
| 9. Reverse gear                  | 24. Interlock pin (large)  | 39. Retaining ring            |
| 10. Reverse synchronizer ring    | 25. 5th/Reverse shift fork | 40. C-washers                 |
| Assembly Note ..... below        | Assembly Note              | 41. Thrust washer             |
| 11. 5th/Reverse clutch hub       | ..... page J-47            | 42. Snap ring                 |
| assembly                         | 26. Spring                 | 43. Bearing housing           |
| Assembly Note ..... below        | 27. 5th/Reverse shift rod  | Assembly Note                 |
| 12. Locknut                      | Assembly Note              | ..... page J-50               |
| Assembly Note ..... below        | ..... page J-47            | 44. 1st/2nd shift rod end     |
| 13. 5th synchroniser ring        | 28. Retaining ring         | Assembly Note                 |
| Assembly Note ..... below        | 29. Cap plug, spring, and  | ..... page J-50               |
| 14. Retaining ring               | detent ball                | 45. 3rd/4th shift rod end     |
| 15. 5th gear                     | 30. Blind cover            | Assembly Note                 |
| Assembly Note                    | 31. Oil guide              | ..... page J-50               |
| ..... page J-46                  | 32. Center housing         | 46. 5th/Reverse shift rod end |
| 16. Bearing                      | Assembly Note              | Assembly Note                 |
| 17. Steel ball                   | ..... page J-48            | ..... page J-50               |
| 18. Thrust lock washer           | 33. Set bolt and washer    | 47. Oil guide                 |
| 19. C-washers and retaining ring | 34. Spacer                 |                               |




**Assembly note**

**Synchronizer ring (5th/Reverse)**


The 5th and Reverse synchronizer rings are differentiated as follows.

- (1) The 5th synchronizer ring has 3 places on its circumference with one tooth missing in each place.
- (2) The Reverse synchronizer ring has no distinguishing marks.



**5th/Reverse clutch hub assembly and locknut**


1. Align the 5th/Reverse synchronizer grooves and the synchronizer keys.




Standard key dimensions

mm {in}

	1	2	3
5th/Reverse	17.00 {0.669}	4.250 {0.167}	5.00 {0.197}



2. Install the 5th/Reverse clutch hub assembly onto the mainshaft in the direction shown.




3. Shift the clutch hubs into 1st and 4th gears to lock the rotation of the mainshaft.

4. Install a new locknut and tighten it with the SST.

Tightening torque:

157-235 N·m {16.0-24.0 kgf·m, 116-173 ft·lbf}



5. Check the clearance between the synchronizer key and the exposed edge of the synchronizer ring.


If the clearance is not as specified, adjust it by changing the thrust washers on the front and rear of the mainshaft front bearing. The total combined thickness of the front and rear thrust washers must equal 6.0 mm {0.236 in}

Clearance: 0.66-2.00 mm {0.026-0.079 in}


Available thrust washer thicknesses:

2.5 mm {0.098 in}, 3.0 mm {0.118 in}

3.5 mm {0.138 in}




6. Stake the locknut into the mainshaft groove.



**5th gear**


1. Install a new retaining ring to the 5th gear.



2. Install the synchronizer ring, 5th gear, and needle bearing.

3. Install the steel ball and thrust lock washer.

4. Install the 3.0 mm {0.118 in} C-washers and hold them with a retaining ring.



5. Push the C-washers toward 5th gear and measure the clearance between the C-washers and thrust lock washer. If the clearance is not as specified, select the proper thrust lock washer.


**Standard: 0.1–0.2 mm {0.004–0.008 in}**

**Available thrust lock washer thicknesses:**

6.2 mm {0.244 in}, 6.3 mm {0.248 in}


6.4 mm {0.252 in}, 6.5 mm {0.256 in}

6.6 mm {0.260 in}, 6.7 mm {0.264 in}




**Shift forks and rods**

1. Refer to the figure to identify each shift rod. When installing the shift rods in the following procedure, install them so that the detent grooves are facing the detent balls.




2. Slide the 1st/2nd shift rod into the case.


3. Secure the 1st/2nd shift fork to the rod with a new roll pin. The split in the roll pin must be facing in the direction shown in the figure.




4. Install the interlock pins as shown in the figure when doing steps 4 through 8.




5. Slide the two SST into the transmission case to guide the interlock pins, and insert the first pin.  
 6. Remove the 3rd/4th shift fork guide from the case.  
 7. Slide the 3rd/4th shift rod containing the interlock pin (small) into the case.  
 8. Secure the 3rd/4th shift rod onto the fork with the new roll pin.  
 9. Insert the remaining interlock pin and remove the SST.



10. Install the 5th/Reverse shift fork onto the clutch hub.  
 11. Install the 5th/Reverse shift rod in the transmission case through the spring.  
 12. Push back the spring, and install a new clip to the 5th/Reverse shift rod by using the SST.



13. Install a new roll pin into the 5th/Reverse shift fork.




14. Install the two blind covers and two new gaskets.

**Tightening torque:**  
 7.9–10.7 N·m{80–110 kgf·cm, 70.0–95.4 in·lbf}

15. Install the packings, detent balls, springs, and cap bolts.


**Tightening torque:**  
 A: 40–58 N·m{4.0–6.0 kgf·m, 29–43 ft·lbf}  
 B: 19–25 N·m{1.9–2.6 kgf·m, 14–18 ft·lbf}

**Center housing**


1. Apply sealant to the contact surfaces of the transmission case and center housing.
2. Install the oil guide.
3. Install the center housing.
4. Align the reverse idler gear shaft with the set bolt hole, and install the set bolt and washer.

**Tightening torque:**


8.9–13.7 N·m{90–140 kgf·cm, 79–121 in·lbf}



5. Install the spacer and counter 5th gear.

**Countershaft rear bearing**


1. Install the countershaft rear bearing by using the SST.




2. Connect the SST to the mainshaft and mount it securely in a vise.
3. Shift into 1st gear to lock the countershaft.
4. Install the new countershaft locknut.

**Tightening torque:**

128–196 N·m{13.0–20.0 kgf·m, 95–144 ft·lbf}




5. Stake the locknut into the countershaft groove.

**Mainshaft rear bearing**

1. Drive on the mainshaft rear bearing with a suitable pipe.

**Bearing diameter (inner): 22 mm {0.87 in}**

**Bearing diameter (outer): 56 mm {2.2 in}**




2. Install the C-washers and hold them in place with a new retaining ring.
3. With points A and B pressed tightly together, measure the clearance between the C-washers and the groove. If the clearance is not as specified, select the proper C-washers.

**Standard: 0–0.1 mm {0–0.004 in}**


**Available C-washer thicknesses:**

**2.9 mm {0.114 in}, 3.0 mm {0.118 in}**

**3.1 mm {0.122 in}, 3.2 mm {0.126 in}**

**Bearing housing**


1. Apply sealant to the contact surfaces of the center housing and bearing housing.
2. Install the bearing housing onto the center housing.

**Shift rod ends**


- Install the shift rod ends onto the proper shift rods, and secure them with new roll pins facing as shown in the figure.



## Clutch Housing and Extension Housing Components Assemble in the order shown, referring to Assembly Note.



- |  |   |   |
|--|---|---|
| 1. Magnet  | 9. Speedometer sensor<br>(Speedometer driven gear)                | 15. Vent cover  |
| 2. Oil baffle  | 10. Back-up light switch  | 16. Service hole B cover                                      |
| 3. Undercover<br>Assembly Note<br>..... page J-52        | 11. Assist shim   | 17. Service hole A cover                                      |
| 4. Snap ring   | 12. Oil seal (clutch housing)<br>Assembly Note<br>..... page J-52 | 18. Dust cover  |
| 5. Key   | 13. Clutch housing<br>Assembly Note<br>..... page J-52            | 19. Front cover   |
| 6. Speedometer drive gear                                | 14. Release cylinder support                                      | 20. Release collar<br>Assembly Note<br>..... page J-53        |
| 7. Snap ring   |   | 21. Release fork assembly<br>Assembly Note<br>..... page J-53 |
| 8. Extension housing<br>Assembly Note<br>..... page J-52 |   |   |



**Assembly note**

**Undercover**

1. Install the magnet to the undercover.


**Tightening torque:**

**7.9–10.7 N·m{80–110 kgf·cm,70.0–95.4 in·lbf}**

2. Install the oil baffle to the undercover.

**Tightening torque:**

**7.9–10.7 N·m{80–110 kgf·cm,70.0–95.4 in·lbf}**




3. Apply sealant to the contact surfaces of the undercover and the transmission case.

4. Install the undercover.

**Tightening torque:**

**19–25 N·m{1.9–2.6 kgf·m,14–18 ft·lbf}**



**Extension housing**

1. Apply sealant to the contact surfaces of the extension housing and bearing housing.
2. Install the extension housing.

**Bolt length (measured from below the head):**


**A: 135 mm {5.31 in}**

**B: 48 mm {1.89 in}**

**C: 165 mm {6.50 in}**


**Tightening torque:**

**42–54 N·m{4.2–5.6 kgf·m,31–40 ft·lbf}**




**Oil seal (clutch housing)**

1. Apply the specified oil to the lip of a new oil seal.
2. Install the oil seal evenly by using the SST.



**Clutch housing**

1. Measure the depth of the main drive gear bearing bore in the clutch housing by using vernier calipers.



2. Measure the main drive gear bearing height.
3. The difference between the measurements in steps 1 and 2 indicates the required thickness of the adjustment shim.


**Standard thrust play: 0–0.1 mm {0–0.004 in}**

**Adjustment shim thicknesses:**


0.3 mm {0.012 in}, 0.4 mm {0.016 in}

0.5 mm {0.020 in}, 0.6 mm {0.024 in}

0.7 mm {0.028 in}




4. Apply sealant to the contact surfaces of the clutch housing and transmission case.
5. Install the correct adjustment shim on the main drive gear bearing as determined in steps 1 and 2.



6. Install the clutch housing.

**Tightening torque:**


42–54 N·m{4.2–5.6 kgf·m, 31–40 ft·lbf}



7. Install the front cover to the clutch housing.


**Tightening torque:**

19–25 N·m{1.9–2.6 kgf·m, 14–18 ft·lbf}



### Release collar and release fork assembly


1. Apply molybdenum grease to the shaded areas of the release bearing and release fork.



2. Install the release bearing and release fork assembly.


**Tightening torque:**  
**32–46 N·m {3.2–4.7 kgf·m, 24–33 ft·lbf}**






**Installation Note**  
**Transmission**

1. Coat the main drive gear splines with grease as shown in the figure.



2. Set the transmission on a transmission jack.



3. Raise the transmission into place and install it to the engine, being careful not to dent or scratch the wedge collar and wiring.

4. Tighten the installation bolts.


**Bolt length:**

**A: 55 mm {2.2 in}**


**B: 90 mm {3.5 in}**

**Tightening torque:**

**38-51 N·m{3.8-5.3 kgf·m,28-38 ft·lbf}**




5. Through service hole A, push the release-cylinder end of the clutch release fork toward the transmission, and connect the clutch release collar to the clutch cover. The clutch release collar should snap into the clutch cover when installed properly.




6. Swing the clutch release fork back and forth to verify that the clutch release collar is connected to the clutch cover.

7. Push the release-cylinder end of the clutch release fork toward the engine, and verify that it does not move past the dotted line.




**Power plant frame (PPF)**

1. Hold the differential at a 0° angle by using the transmission jack.



2. Hold the PPF in place with a new bolt and 8 new nuts.




3. Tighten the differential-side PPF installation bolt and nuts in the order shown.

**Tightening torque:**

**A, C: 148–176 N·m**

**{15.0–18.0 kgf·m, 109–130 ft·lbf}**

**B: 75–93 N·m {7.6–9.5 kgf·m, 55–68 ft·lbf}**




4. Tighten the transmission-side PPF installation nuts in the order shown.

**Tightening torque:**

**148–176 N·m {15.0–18.0 kgf·m, 109–130 ft·lbf}**

5. Remove the transmission jack.
6. Lower the vehicle to the ground, and remove the SST (engine supports).



7. Place a straightedge on the flat area on the front/left edge of the tunnel mount (A) so that it passes under the PPF installation bolts. Measure from the top of the straightedge to the PPF.

**Standard: 75.1 mm {2.96 in}**


**Acceptable range: 70–77 mm {2.76–3.03 in}**

8. If the clearance is not within specification, readjust the PPF.

**SHIFT MECHANISM**

**OVERHAUL**

1. Disassemble as shown in the figure.
2. Inspect each part, and replace if necessary.
3. Assemble in the reverse order of disassembly.
4. After assembly, pump the clutch pedal and verify that the shift lever moves smoothly.



1. Shift lever knob
2. Console panel assembly
3. Bushing pad
4. Insulator boot pads
5. Insulator boot ring
6. Insulator boot
7. Dust boot


8. Gasket
  9. Wave washer
  10. Bushing
  11. Shift lever
- Assembly Note

12. Shift seat
  13. Bushing
  14. Wave washer
- Assembly Note

..... page J-59

..... page J-59






### Assembly Note

#### Shift seat

Apply grease to both the inside and outside of the shift seat.




#### Shift lever


The change control case must be filled with oil after the transmission has been reassembled and installed.

1. Fill the change control case with the specified oil.

**Capacity: 80–95 cm<sup>3</sup> {4.9–5.8 cu in}**



2. Apply grease to the shift lever ball joint.



3. Align the control case pin with the slots in the change bushings and the shift lever, and install.

Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.


**K**

# AUTOMATIC TRANSMISSION (Electronically Controlled)

<b>INDEX</b> .....	K- 2	<b>EXTENSION HOUSING /</b>	
<b>OUTLINE</b> .....	K- 4	<b>PARKING MECHANISM</b> .....	K- 97
<b>SPECIFICATIONS</b> .....	K- 4	<b>OIL SEAL (EXTENSION HOUSING)</b> .....	K-104
<b>CROSS-SECTIONAL VIEW</b> .....	K- 5	<b>CONTROL VALVE BODY</b>	
<b>POWERFLOW DIAGRAM</b> .....	K- 6	<b>(DISASSEMBLY / INSPECTION)</b> .....	K-108
<b>OPERATION OF COMPONENTS</b> .....	K- 6	<b>UPPER CONTROL VALVE BODY</b> .....	K-112
<b>FLUID PASSAGE LOCATION</b> .....	K- 7	<b>LOWER CONTROL VALVE BODY</b> .....	K-120
<b>MECHANICAL SYSTEM TEST</b> .....	K- 9	<b>CONTROL VALVE BODY (ASSEMBLY)</b> .....	K-125
<b>PREPARATION</b> .....	K- 9	<b>CONTROL VALVE BODY (ON-VEHICLE</b>	
<b>STALL TEST</b> .....	K- 9	<b>REMOVAL / INSTALLATION)</b> .....	K-128
<b>TIME LAG TEST</b> .....	K- 12	<b>TRANSMISSION UNIT (ASSEMBLY)</b> .....	K-132
<b>LINE PRESSURE TEST</b> .....	K- 14	<b>TRANSMISSION UNIT (INSTALLATION)</b> .....	K-149
<b>ROAD TEST</b> .....	K- 16	<b>OIL COOLER</b> .....	K-154
<b>D RANGE TEST</b> .....	K- 16	<b>OIL COOLER</b> .....	K-154
<b>S RANGE TEST</b> .....	K- 20	<b>DRIVE PLATE</b> .....	K-156
<b>L RANGE TEST</b> .....	K- 21	<b>PREPARATION</b> .....	K-156
<b>P RANGE TEST</b> .....	K- 23	<b>DRIVE PLATE</b> .....	K-156
<b>AUTOMATIC TRANSMISSION FLUID (ATF)</b> .....	K- 25	<b>SHIFT MECHANISM</b> .....	K-158
<b>ATF</b> .....	K- 25	<b>SHIFT-LOCK SYSTEM COMPONENTS</b> .....	K-158
<b>ELECTRONIC SYSTEM COMPONENTS</b> .....	K- 27	<b>TROUBLESHOOTING</b> .....	K-159
<b>HOLD SWITCH</b> .....	K- 27	<b>SHIFT-LOCK</b> .....	K-161
<b>PARK/NEUTRAL SWITCH</b> .....	K- 28	<b>EMERGENCY OVERRIDE BUTTON</b> .....	K-161
<b>VEHICLE SPEED SENSOR</b>		<b>KEY INTERLOCK</b> .....	K-161
<b>(REVOLUTION SENSOR)</b> .....	K- 29	<b>KEY INTERLOCK SOLENOID</b> .....	K-162
<b>VEHICLE SPEEDOMETER SENSOR</b> .....	K- 29	<b>SHIFT-LOCK CONTROL SYSTEM</b> .....	K-162
<b>VEHICLE SPEED PULSE GENERATOR</b> .....	K- 30	<b>SELECTOR LEVER</b> .....	K-164
<b>ATF THERMOSENSOR</b> .....	K- 31	<b>TROUBLESHOOTING GUIDE</b> .....	K-171
<b>SOLENOID VALVES</b> .....	K- 32	<b>GENERAL NOTES</b> .....	K-171
<b>DROPPING RESISTOR</b> .....	K- 33	<b>QUICK DIAGNOSIS CHART</b> .....	K-172
<b>WATER THERMOSWITCH</b> .....	K- 34	<b>OUTLINE</b> .....	K-172
<b>HOLD INDICATOR</b> .....	K- 34	<b>QUICK DIAGNOSIS CHART (I)</b> .....	K-172
<b>POWERTRAIN CONTROL MODULE</b>		<b>QUICK DIAGNOSIS CHART (II)</b> .....	K-174
<b>(TRANSMISSION)</b> .....	K- 35	<b>SYMPTOM TROUBLESHOOTING</b> .....	K-178
<b>SELECTOR INDICATOR LIGHT</b> .....	K- 41	<b>USING THIS SECTION</b> .....	K-178
<b>TRANSMISSION</b> .....	K- 42	<b>DIAGNOSTIC INDEX</b> .....	K-180
<b>TRANSMISSION UNIT (REMOVAL)</b> .....	K- 42	<b>SYMPTOM TROUBLESHOOTING CHART</b> .....	K-183
<b>TRANSMISSION UNIT</b>		<b>SELF-DIAGNOSIS FUNCTION</b> .....	K-214
<b>(DISASSEMBLY)</b> .....	K- 45	<b>DESCRIPTION</b> .....	K-214
<b>TORQUE CONVERTER</b> .....	K- 57	<b>PREPARATION</b> .....	K-214
<b>ACCUMULATORS</b> .....	K- 58	<b>DIAGNOSTIC TROUBLE CODE</b> .....	K-216
<b>OIL PUMP</b> .....	K- 60	<b>SERVICE POINTS</b> .....	K-235
<b>REVERSE CLUTCH</b> .....	K- 64	<b>OUTLINE</b> .....	K-235
<b>HIGH CLUTCH AND</b>		<b>WIRING DIAGRAM</b> .....	K-238
<b>FRONT SUN GEAR</b> .....	K- 70	<b>ELECTRICAL DIAGNOSIS SUPPORT</b> .....	K-241
<b>BAND SERVO</b> .....	K- 76	<b>SYSTEM INSPECTION</b> .....	K-246
<b>FRONT INTERNAL GEAR, REAR INTERNAL</b>		<b>LINE PRESSURE SOLENOID VALVE</b>	
<b>GEAR, FORWARD CLUTCH HUB,</b>		<b>OUTPUT DUTY</b> .....	K-246
<b>OVERRUNNING CLUTCH HUB</b> .....	K- 80	<b>LOCKUP SOLENOID VALVE</b>	
<b>FORWARD CLUTCH DRUM</b>		<b>OUTPUT DUTY</b> .....	K-247
<b>(FORWARD CLUTCH, OVEBRUNNING</b>		<b>MANUAL OPERATION TEST</b> .....	K-247
<b>CLUTCH, LOW ONE-WAY CLUTCH)</b> .....	K- 83	<b>HYDRAULIC CIRCUIT</b> .....	K-249
<b>LOW AND REVERSE BRAKE</b> .....	K- 91		

**K**

## INDEX



- |  |            |   |            |
|--|------------|---|------------|
| 1. Automatic transmission fluid (ATF)        |            | 15. Extension housing / Parking mechanism |            |
| Inspection .....                             | page K- 25 | Disassembly / Inspection /                |            |
| 2. Hold switch                               |            | Assembly .....                            | page K- 97 |
| Inspection .....                             | page K- 27 | On-vehicle Removal /                      |            |
| Replacement .....                            | page K- 27 | Installation .....                        | page K-101 |
| 3. Park/Neutral switch                       |            | 16. Oil seal (extension housing)          |            |
| Inspection .....                             | page K- 28 | On-vehicle Removal /                      |            |
| Adjustment .....                             | page K- 28 | Installation .....                        | page K-104 |
| Replacement .....                            | page K- 28 | 17. Control valve body                    |            |
| 4. Vehicle speed sensor                      |            | Disassembly /Inspection .....             | page K-108 |
| (revolution sensor)                          |            | Assembly .....                            | page K-125 |
| Inspection .....                             | page K- 29 | On-vehicle Removal .....                  | page K-128 |
| Replacement .....                            | page K- 29 | On-vehicle Installation .....             | page K-130 |
| 5. Vehicle speedometer sensor                |            | 18. Oil cooler                            |            |
| Inspection .....                             | page K- 29 | Removal / Inspection /                    |            |
| Replacement .....                            | page K- 30 | Installation .....                        | page K-154 |
| 6. Vehicle speed pulse generator             |            | 19. Drive plate                           |            |
| Inspection .....                             | page K- 30 | Removal / Inspection /                    |            |
| Replacement .....                            | page K- 31 | Installation .....                        | page K-156 |
| 7. ATF thermosensor                          |            | 20. Shift-lock                            |            |
| Replacement .....                            | page K- 31 | Inspection .....                          | page K-161 |
| Inspection .....                             | page K- 32 | 21. Emergency override button             |            |
| 8. Solenoid valves                           |            | Inspection .....                          | page K-161 |
| Inspection .....                             | page K- 32 | 22. Key interlock                         |            |
| Replacement .....                            | page K- 33 | Inspection .....                          | page K-161 |
| 9. Dropping resistor                         |            | 23. Key interlock solenoid                |            |
| Inspection .....                             | page K- 33 | Inspection .....                          | page K-162 |
| Replacement .....                            | page K- 33 | Replacement .....                         | page K-162 |
| 10. Water thermoswitch                       |            | 24. Shift-lock control system             |            |
| Replacement .....                            | page K- 34 | Inspection .....                          | page K-162 |
| Inspection .....                             | page K- 34 | Replacement .....                         | page K-163 |
| 11. Hold indicator                           |            | 25. Selector lever                        |            |
| Inspection .....                             | page K- 34 | Inspection .....                          | page K-164 |
| 12. Powertrain control module (Transmission) |            | Adjustment .....                          | page K-164 |
| Inspection .....                             | page K- 35 | Removal / Installation .....              | page K-166 |
| Replacement .....                            | page K- 41 | Disassembly / Inspection /                |            |
| 13. Selector indicator light                 |            | Assembly .....                            | page K-168 |
| Inspection .....                             | page K- 41 |   |            |
| 14. Transmission unit                        |            |   |            |
| Removal .....                                | page K- 42 |   |            |
| Disassembly .....                            | page K- 45 |   |            |
| Assembly .....                               | page K-132 |   |            |
| Installation .....                           | page K-149 |   |            |


### OUTLINE

### SPECIFICATIONS


Item		Model	RB4A-EL
Gear ratio	1st gear		3.027
	2nd gear		1.619
	Third gear		1.000
	Fourth gear		0.694
	Reverse		2.272
Final gear ratio			3.909
Automatic transmission fluid (ATF)	Type		Dexron®II or M-III
	Capacity L {US qt, Imp qt}	Total	8.6 {9.1, 7.6}
		Oil pan	4.0 {4.2, 3.5}
Torque converter stall torque ratio			2.200
Number of drive / driven plates	Reverse clutch		2/2
	High clutch		4/7
	Forward clutch		6/6
	Overrunning clutch		3/5
	Low and reverse brake		7/7
Band servo mm {in}	Servo piston outer / inner diameter		80.0/50.0 {3.15/1.97}
	4GR servo piston outer diameter		72.0 {2.83}
Number of teeth on front planetary gear unit	Sun gear		33
	Pinion gear		21
	Internal gear		75
Number of teeth on front planetary gear unit	Sun gear		37
	Pinion gear		19
	Internal gear		75

CROSS-SECTIONAL VIEW

OUTLINE



### POWERFLOW DIAGRAM



### OPERATION OF COMPONENTS

Range	Mode	Gear	Shift	Reverse clutch	High clutch	Forward clutch	Overrunning clutch	Band servo piston			Forward OWC	Low OWC	Low and reverse brake
								2nd applied	3GR released	4GR applied			
P	—	—	—										
R	—	Reverse	—	○									○
N	—	—	—										
D	Except hold	1	↕			○	■				●	●	
		2	↕			○	*3 ■	○			●		
		3	↕			○	○	*3 ■	*1 ⊗	⊗		●	
	hold	4	↕			○	⊗		*2 ⊗	⊗	○		
		2	↑				○	*3 ⊙	○			●	
		3	↑			○	○	*3 ⊙	*1 ⊗	⊗		●	
		*4 4	↑		○	⊗		*2 ⊗	⊗	○			
S	Except hold	1	↕			○	△				●	●	
		2	↕			○	*3 △	○			●		
		3	↕			○	○	*3 △	*1 ⊗	⊗		●	
	hold	2	↑			○	○	*3 △	○			●	
		*4 3	↑			○	○	*3 △	*1 ⊗	⊗		●	
L	Except hold	1	↕			○	*3 ○				●	●	○
		2	↕			○	*3 ○	○			●		
	hold	1	↑			○	○	*3 ○				●	○
		*4 2	↑			○	○	*3 ○	○			●	

OWC: one-way clutch

\*1: Hydraulic pressure is applied to both 2nd gear applied side and Third gear released side of band servo piston.

However, because area of Third gear released side is larger than 2nd gear applied side, the brake band does not engage.

\*2: Hydraulic pressure is applied to Fourth gear applied side in the above conditions (\*1) and brake band engages.

\*3: Indicates that engine braking is available as a result of operation of overrunning clutch.

\*4: Prevents engine overspeed.

○: Constantly engaged.

●: Operates when accelerated.


△: Engaged when throttle opening is below approximately 1.3/8.

⊙: Engaged when vehicle speed is above approximately 10 km/h {6.2 MPH} and throttle opening is below approximately 1.3/8.

■: Engaged when vehicle speed is above approximately 10 km/h {6.2 MPH} and throttle opening is below approximately 1.3/8 (NORMAL A/C OFF mode)

⊗: Engaged, but does not transmit power.


**FLUID PASSAGE LOCATION**  
**Transmission Case**




K




### Oil Pump



### Input Shaft









### Output Shaft



MECHANICAL SYSTEM TEST

PREPARATION  
SST

<p>49 0378 400A Gauge set, oil pressure</p> 	<p>For oil pressure test</p>	<p>49 B019 901 Gauge, oil pressure</p> 	<p>For oil pressure test</p>
<p>49 F019 0A0 Adapter set</p> 	<p>For oil pressure test</p>	<p>49 F019 002 Adapter A (Part of 49 F019 0A0)</p> 	<p>For oil pressure test</p>
<p>49 F019 003 Adapter B (Part of 49 F019 0A0)</p> 	<p>For oil pressure test</p>	<p>49 F019 004 Screw (Part of 49 F019 0A0)</p> 	<p>For oil pressure test</p>


K

STALL TEST

This test is performed to determine if there is slippage of the friction elements or malfunction of the hydraulic components.

Preparation

1. Engage the parking brake and use wheel chocks at the front and rear of the wheels.
2. Warm the engine thoroughly to raise the ATF temperature to operating level 60–70°C {140–158°F}.
3. Check, and correct as necessary, the engine coolant, engine oil, and ATF levels before testing.



PARKING BRAKE

WARM UP ENGINE


COOLANT LEVEL

ENGINE OIL LEVEL

WHEEL CHOCK

ATF LEVEL

## Procedure



1. Check the idle speed and ignition timing in P range. (Refer to section F.)

**Caution**

- If the accelerator pedal is pressed for longer than 5 seconds while the brake pedal is pressed, the transmission could be damaged. Therefore, do steps 2 and 3 within 5 seconds of other.

2. Firmly depress the brake pedal with the left foot, shift the selector lever to D range (except hold mode), and gradually depress the accelerator pedal with the right foot until the throttle valve is at wide opened throttle.
3. When the engine speed no longer increases, quickly read the speed and release the accelerator.
4. Shift the selector to N and let the engine idle for 1 minute or more to cool the ATF.

5. Perform a stall test for the following ranges in the same manner. Check the high clutch and brake band for slipping even if the engine speed is within specification.

- (1) D range (hold mode)
- (2) S range (except hold mode)
- (3) S range (hold mode)
- (4) L range (except hold mode)
- (5) L range (hold mode)
- (6) R range

**Engine stall speed: 3,000–3,300 rpm**

**Evaluation of Stall Test**

Condition		Possible Cause	
Above specification	In all ranges	Insufficient line pressure	Worn oil pump
			Oil leakage from oil pump, control valve, and/or transmission case
	Stuck pressure regulator valve		
In D and S ranges (except hold mode)	Forward clutch slipping Forward one-way clutch slipping Low one-way clutch slipping		
		In R range	Low and reverse brake slipping Reverse clutch slipping Perform road test to determine whether problem is low and reverse brake or reverse clutch
a) Engine braking applied in L range 1st ...Reverse clutch slipping	b) Engine braking not applied in L range 1st ...Low and reverse brake slipping		
Below specification		Engine out of tune	
		One-way clutch slipping within torque converter	

## MECHANICAL SYSTEM TEST


### TIME LAG TEST

When the selector lever is shifted while the engine is idling, there will be a certain time lapse, or time lag, before shift shock is felt. This step measures this time lag in order to check conditions of the N-D, 1-2, and 3-4/N-R accumulators; forward, reverse, and one-way clutches; brake band; and low and reverse brake.

#### Preparation

Perform the preparation procedure outlined in STALL TEST. (Refer to page K-9.)

#### Procedure



1. Check the idle speed and ignition timing in P range. (Refer to section F.)
2. Shift from N range to D range (except hold mode).
3. Use a stopwatch to measure the time taken from shifting until shock is felt.
4. Do the time lag test for the following shifts in the same manner.  
Make three measurements for each test and average the results.
  - (1) N → D range (hold mode)
  - (2) N → R range

**Time lag: N → D range ..... Below 1.0 sec.**  
**N → R range ..... Below 1.2 sec.**

If the time lag test result is above specification, check for the following possible causes.

**Evaluation of Time Lag Test**


Condition		Possible Cause
<b>Above specification</b>	N → D shift (except hold mode)	Insufficient line pressure Forward clutch slipping Low one-way clutch slipping N-D accumulator not operating properly
	N → D shift (hold mode)	Insufficient line pressure Brake band slipping 1-2 accumulator not operating properly
	N → R shift	Insufficient line pressure Reverse clutch slipping Low and reverse brake slipping 3-4/N-R accumulator not operating properly

**LINE PRESSURE TEST**

This test measures line pressures as a means of checking the hydraulic components and inspecting for oil leakage.

**Preparation**

Perform the preparation procedure outlined in STALL TEST. (Refer to page K-9.)

**Procedure**

1. Check the idle speed and ignition timing in P range. (Refer to section F.)
2. Remove the front tunnel member and the exhaust pipe bracket.
3. Remove the line pressure inspection bolt, and connect the SST (49 F019 0A0).
4. Replace the gauge of SST (49 0378 400A) with the other SST (49 B019 901).
5. Shift the selector lever to D range and read the line pressure at idle.

**Warning**

- Removing the square-head plug when the ATF is hot can be dangerous. Hot ATF can come out of the opening and badly burn. Before removing the square-head plug, allow the ATF to cool.

6. Remove the SST (49 B019 901) and replace the gauge of it with the other SST (49 0378 400A).
7. Connect the SST (49 0378 400A) to the line pressure inspection port.

**Caution**

- If the accelerator pedal is pressed for longer than 5 seconds while the brake pedal is pressed, the transmission could be damaged. Therefore, do steps 8 and 9 within 5 seconds of other.
8. Depress the brake pedal firmly with the left foot and gradually depress the accelerator pedal with the right foot until the throttle valve is at wide opened throttle.
  9. Read the line pressure as soon as the engine speed becomes constant, then release the accelerator pedal.
  10. Shift the selector to N and let the engine idle for 1 minute or more to cool the ATF.
  11. Read the line pressure at idle and at the engine stall speed for each range in the same manner.

**Specified line pressure:**

Range	Line pressure kPa {kgf/cm <sup>2</sup> , psi}	
	Idle	Stall
D, S, L	500–520 {5.0–54, 72–76}	1,200–1,270 {12.2–13.0, 174–184}
R	620–650 {6.3–6.7, 90–95}	1,510–1,570 {15.3–16.1, 218–228}

**Warning**

- **Removing the square-head plug when the ATF is hot can be dangerous. Hot ATF can come out of the opening and badly burn. Before removing the square-head plug, allow the ATF to cool.**

12. Remove the SST and install a new square head plug in the inspection port.

**Tightening torque: 5.0–9.8 N·m {50–100 kgf·cm, 44–86 in·lbf}**

13. Install the exhaust pipe bracket.

**Tightening torque: 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}**

14. Install the front tunnel member.

**Tightening torque: 18–26 N·m {1.8–2.7 kgf·m, 14–19 ft·lbf}**

If the line pressure test result is out of the specification, check for the following possible causes.

**Evaluation of Line Pressure Test**

Condition		Possible Cause
At idle	Low pressure in every range	Worn oil pump Damaged control piston (in oil pump) Pressure regulator valve or plug sticking Damaged pressure regulator valve spring Fluid leaking between oil strainer, oil pump, and pressure regulator valve
	Low pressure in forward ranges	Fluid leaking from hydraulic circuit of forward clutch
	Low pressure in D and S ranges (hold mode)	Fluid leaking from hydraulic circuit of band servo 2nd apply side
	Low pressure in R range	Fluid leaking from hydraulic circuit of reverse clutch
	Low pressure in R and L ranges	Fluid leaking from hydraulic circuit of low and reverse brake
	Higher than specification	Throttle position sensor out of adjustment Damaged ATF thermosensor Line pressure solenoid valve sticking Short circuit of line pressure solenoid valve circuit Pressure modifier valve sticking Pressure regulator valve or plug sticking
At stall speed	Low pressure	Throttle position sensor out of adjustment Line pressure solenoid valve sticking Short circuit of line pressure solenoid valve circuit Pressure regulator valve or plug sticking Pressure modifier valve sticking Pilot valve sticking Damaged control piston (in oil pump)



## ROAD TEST

A road test is necessary to inspect for problems in the different gear ranges. If a range or function targeted by the road test is found to have any problem, refer to the ELECTRONIC SYSTEM COMPONENT segment or the TRANSMISSION, OIL COOLER, DRIVE PLATE, and SHIFT MECHANISM segments of this section. Do the road test only when the ATF is 60–70°C (140–158°F).

Verify the shift points by using only vehicle speeds shown by the speedometer.

### D RANGE TEST

#### Shift Point, Shift Pattern, and Shift Shock

The power mode and the normal mode are automatically selected by the Powertrain Control Module (Transmission). Once the power mode is selected, the Powertrain Control Module (Transmission) does not switch to normal mode until the ignition switch is turned OFF.

When the ATF temperature is less than 40°C {104°F} in the period shortly after the engine is started, the Powertrain Control Module (Transmission) selects the low ATF temperature mode.

The shift points during the low ATF temperature mode are higher than in the power mode, and lockup is inhibited.

1. Shift the selector lever to D range.

#### Note

- There is no shift to fourth gear in any of the following conditions.
  1. The ATF temperature is below 10°C {50°F}.
  2. The ATF temperature is below 38°C {100°F} and vehicle speed is less than 63 Km/h {39 MPH}.
  3. The cruise control is operating and there is an 8 km/h {5 MPH} difference between the preset cruise speed and the vehicle speed, or the RESUME/ACCEL switch is ON.

2. Accelerate the vehicle with half- and full-throttle opening.
3. Verify that 1-2, 2-3, and 3-4 upshifts are obtained. The shift points must be as shown in the D range shift diagram.
4. Drive the vehicle in Fourth, Third, and 2nd gears and verify that kickdown occurs for 4 → 3, 4 → 2, 4 → 1, 3 → 2, 3 → 1, 2 → 1, and that the shift points are as shown in the D range shift diagram.
5. Decelerate the vehicle and verify that engine braking effect is felt in Third and 2nd gears when normal A/C OFF mode is selected, vehicle speed is more than 10 km/h {6.2 MPH}, and the throttle opening is less than 1.3/8.

#### Note

- When the engine coolant temperature is above 115°C {239°F}, the lockup points are lowered.
- There is no lockup in the following conditions.
  1. The transmission is in Fourth gear position and the ATF temperature is below 20°C {68°F}.
  2. The transmission is in Third gear position and ATF temperature is below 38°C {100°F}.
- There is no slip lockup in the following conditions.
  1. There is no slip lockup when the ATF temperature is below 50°C {122°F}.
  2. There is no slip lockup when the ATF temperature is above 100°C {212°F}.
  3. There is no slip lockup when the slip lockup OFF signal is ON.
  4. There is no slip lockup when the transmission is in Fourth gear position and the idle signal is ON.
  5. There is no slip lockup when the transmission is in Third gear position, the idle signal is ON, and vehicle speed is less than 140 km/h {87 MPH}.
  6. There is no slip lockup when the accelerator pedal is depressed rapidly.


7. Drive the vehicle and verify that lockup is obtained.
8. Select hold mode.
9. Accelerate the vehicle with half-and full-throttle opening, and verify that Third gear is held after 2-3 up-shift is obtained. The shift points must be as shown in the D range (hold mode) shift diagram.
10. Drive the vehicle in Third and 2nd gears and verify that kickdown does not occur.
11. Decelerate the vehicle and verify that engine braking effect is felt in Third and 2nd gears when vehicle speed is more than 10 km/h {6.2 MPH} and the throttle opening is less than 1.3/8.

**Note**


- When the engine coolant temperature is above 115°C {239°F}, the lockup points are lowered.
- There is no lockup when the transmission is in Third gear position and the ATF temperature is below 38°C {100°F}.

12. Drive the vehicle and verify that lockup is obtained.


**D range (power mode) shift diagram**




D range (normal A/C ON mode) shift diagram



D range (normal A/C OFF mode) shift diagram



**D range (hold mode) shift diagram**



**Noise and Vibration**

Drive the vehicle in Fourth gear (lockup), Fourth gear (no lockup), and Third gear (Hold) and listen closely for any out of the ordinary noise or vibration. The torque converter, propeller shaft, and differential can be sources of abnormal noise and vibration if they are not functioning properly. Check these when searching for sources of noise and vibration.

### S RANGE TEST

#### Shift Point, Shift Pattern, and Shift Shock

1. Shift the selector lever to S range.
2. Accelerate the vehicle with half- and full-throttle opening.
3. Verify that 1-2 and 2-3 upshifts are obtained. The shift points must be as shown in the S range shift diagram.
4. Drive the vehicle in Third and 2nd gears and verify that kickdown occurs for 3 → 2, 3 → 1, 2 → 1, and that the shift points are as shown in the S range shift diagram.
5. Decelerate the vehicle and verify that engine braking effect is felt in Third and 2nd gears when the throttle opening is less than 1.3/8.

#### Note

- When the engine coolant temperature is above 115°C {239°F}, the lockup points are lowered.
- There is no lockup when the transmission is in Third gear position and the ATF temperature is below 38°C {100°F}.


6. Drive the vehicle and verify that lockup is obtained.
7. Select hold mode.
8. Accelerate the vehicle with half- and full-throttle opening, and verify that 2nd gear is held.
9. Decelerate the vehicle and verify that engine braking effect is felt when the throttle opening is less than 1.3/8.


#### Note

- When the engine coolant temperature is above 115°C {239°F}, the lockup points are lowered.

10. Drive the vehicle and verify that lockup is obtained.

### S range (normal mode) shift diagram




**S range (hold mode) shift diagram****Noise and Vibration**

Drive the vehicle in 2nd gear (Hold) and listen closely for any out of the ordinary noise or vibration. The torque converter, propeller shaft, and differential can be sources of abnormal noise and vibration if they are not functioning properly. Check these when searching for sources of noise and vibration.


**L RANGE TEST****Shift Point, Shift Pattern, and Shift Shock**

1. Shift the selector lever to L range.
2. Accelerate the vehicle with half- and full-throttle opening.
3. Verify that 1-2 upshift is obtained. The shift points must be as shown in the L range shift diagram.
4. Drive the vehicle in 2nd gear and verify that kickdown occurs for 2 → 1, and that the shift point is as shown in the L range shift diagram.
5. Decelerate the vehicle and verify that engine braking effect is felt in 2nd and 1st gears.
6. Select hold mode.
7. Accelerate the vehicle with half- and full-throttle opening, and verify that 1st gear is held.
8. Decelerate the vehicle and verify that engine braking effect is felt.

### L range (normal mode) shift diagram



### L range (hold mode) shift diagram



**Noise and Vibration**

Drive the vehicle in 1st gear (Hold) and listen closely for any out of the ordinary noise or vibration. The torque converter, propeller shaft, and differential can be sources of abnormal noise and vibration if they are not functioning properly. Check these when searching for sources of noise and vibration.

**P RANGE TEST**

Shift into P range on a gentle slope. Release the brake and verify that the vehicle does not roll.

**Vehicle Speed at Shift Point Table**

Range	Mode	Throttle condition (throttle position sensor voltage)	Shift	Vehicle speed km/h {MPH}
D	POWER	Wide open throttle (4.0-4.5V)	D <sub>1</sub> → D <sub>2</sub>	50-56 {31-35}
			D <sub>2</sub> → D <sub>3</sub>	103-111 {64-69}
			D <sub>3</sub> → D <sub>4</sub>	178-188 {111-117}
		Half throttle	D <sub>1</sub> → D <sub>2</sub>	35-41 {22-25}
			D <sub>2</sub> → D <sub>3</sub>	81-93 {50-58}
			D <sub>3</sub> → D <sub>4</sub>	126-144 {78-89}
			*Lockup ON (D <sub>3</sub> )	94-106 {58-66} (81-93 {50-58})
		Closed throttle position (0.1-1.1V)	*Lockup ON (D <sub>4</sub> )	174-192 {108-119} (126-144 {78-89})
			D <sub>4</sub> → D <sub>3</sub>	39-45 {24-28}
			D <sub>3</sub> → D <sub>2</sub>	13-19 {8-12}
		Kickdown	D <sub>2</sub> → D <sub>1</sub>	5-11 {3-7}
			D <sub>4</sub> → D <sub>3</sub>	142-152 {88-94}
	D <sub>3</sub> → D <sub>2</sub>		91-99 {57-62}	
	NORMAL A/C ON	Wide open throttle (4.0-4.5V)	D <sub>2</sub> → D <sub>1</sub>	38-44 {24-27}
			D <sub>1</sub> → D <sub>2</sub>	50-56 {31-35}
			D <sub>2</sub> → D <sub>3</sub>	103-111 {64-69}
		Half throttle	D <sub>3</sub> → D <sub>4</sub>	178-188 {111-117}
			D <sub>1</sub> → D <sub>2</sub>	32-38 {20-24}
			D <sub>2</sub> → D <sub>3</sub>	80-92 {50-57}
			D <sub>3</sub> → D <sub>4</sub>	126-144 {78-89}
		Closed throttle position (0.1-1.1V)	*Lockup ON (D <sub>3</sub> )	94-106 {58-66} (80-92 {50-57})
			*Lockup ON (D <sub>4</sub> )	174-192 {108-119} (126-144 {78-89})
			D <sub>4</sub> → D <sub>3</sub>	39-45 {24-28}
		Kickdown	D <sub>3</sub> → D <sub>2</sub>	13-19 {8-12}
D <sub>2</sub> → D <sub>1</sub>			5-11 {3-7}	
D <sub>4</sub> → D <sub>3</sub>	142-152 {88-94}			
NORMAL A/C OFF	Wide open throttle (4.0-4.5V)	D <sub>3</sub> → D <sub>2</sub>	91-99 {57-62}	
		D <sub>2</sub> → D <sub>1</sub>	38-44 {24-27}	
		D <sub>1</sub> → D <sub>2</sub>	50-56 {31-35}	
	Half throttle	D <sub>2</sub> → D <sub>3</sub>	103-111 {64-69}	
		D <sub>3</sub> → D <sub>4</sub>	178-188 {111-117}	
		D <sub>1</sub> → D <sub>2</sub>	32-38 {20-24}	
		D <sub>2</sub> → D <sub>3</sub>	80-92 {50-57}	
	Closed throttle position (0.1-1.1V)	D <sub>3</sub> → D <sub>4</sub>	126-144 {78-89}	
		*Lockup ON (D <sub>3</sub> )	94-106 {58-66} (80-92 {50-57})	
		*Lockup ON (D <sub>4</sub> )	174-192 {108-119} (126-144 {78-89})	
	Kickdown	D <sub>4</sub> → D <sub>3</sub>	32-38 {20-24}	
		D <sub>3</sub> → D <sub>2</sub>	13-19 {8-12}	
D <sub>2</sub> → D <sub>1</sub>		5-11 {3-7}		
Kickdown	D <sub>4</sub> → D <sub>3</sub>	142-152 {88-94}		
	D <sub>3</sub> → D <sub>2</sub>	91-99 {57-62}		
	D <sub>2</sub> → D <sub>1</sub>	38-44 {24-27}		

\* complete lockup

( ) indicates lockup points when the engine coolant temperature is above 115°C {239°F}.




Range	Mode	Throttle condition (throttle position sensor voltage)	Shift	Vehicle speed km/h {MPH}
D	HOLD	—	D <sub>4</sub> → D <sub>3</sub>	180–186 {112–116}
			D <sub>3</sub> → D <sub>2</sub>	7–13 {4–8}
			D <sub>2</sub> → D <sub>3</sub>	15–25 {9–16}
			*Lockup ON (D <sub>3</sub> )	94–106 {58–66} (39–51 {24–32})
S	EXCEPT HOLD	Wide open throttle (4.0–4.5V)	S <sub>1</sub> → S <sub>2</sub>	50–56 {31–35}
			S <sub>2</sub> → S <sub>3</sub>	103–111 {64–69}
		Half throttle	S <sub>1</sub> → S <sub>2</sub>	35–41 {22–25}
			S <sub>2</sub> → S <sub>3</sub>	81–93 {50–58}
		Closed throttle position (0.1–1.1V)	*Lockup ON (S <sub>3</sub> )	94–106 {58–66} (81–93 {50–58})
			S <sub>3</sub> → S <sub>2</sub>	13–19 {8–12}
	Kickdown	S <sub>2</sub> → S <sub>1</sub>	5–11 {3–7}	
		S <sub>3</sub> → S <sub>2</sub>	91–99 {57–62}	
	HOLD	—	S <sub>2</sub> → S <sub>1</sub>	38–44 {24–27}
			S <sub>3</sub> → S <sub>2</sub>	112–118 {70–73}
L	EXCEPT HOLD	Wide open throttle (4.0–4.5V)	L <sub>1</sub> → L <sub>2</sub>	50–56 {31–35}
		Half throttle	L <sub>1</sub> → L <sub>2</sub>	35–41 {22–25}
		Closed throttle position (0.1–1.1V)	L <sub>2</sub> → L <sub>1</sub>	5–11 {3–7}
		Kickdown	L <sub>2</sub> → L <sub>1</sub>	38–44 {24–27}
	HOLD	—	L <sub>2</sub> → L <sub>1</sub>	45–51 {28–32}

\* complete lockup

( ) indicates lockup points when the engine coolant temperature is above 115° {239°F}.  
 Input the voltages displayed on the EC-AT Tester into the following formula to calculate the halfthrottle voltage.

$$\frac{\text{wide open throttle voltage} - \text{closed throttle position voltage}}{2} = \text{Half throttle voltage}$$

Condition		Possible cause
Shifting	Starts in 2nd gear or shifts directly from 1st gear to Fourth gear	Stuck shift A solenoid valve Stuck shift valve A
	Starts in fourth gear	Stuck shift B solenoid valve Stuck shift valve B
	No shift	Stuck shift A and B solenoid valve Stuck shift valve A and/or B
	Incorrect shift points	Throttle position sensor out of adjustment Vehicle speed sensor (revolution sensor) not operating properly
Shift shock felt or slipping exists		Stuck line pressure solenoid valve Accumulators not operating properly Throttle position sensor out of adjustment Vehicle speed sensor (revolution sensor) not operating properly ATF thermosensor not operating properly Worn clutches, one-way clutches, and/or brakes
No engine braking		Stuck overrunning clutch solenoid valve Worn clutches and/or brakes
No lockup shift		Stuck lockup solenoid valve Stuck lockup control valve




**AUTOMATIC TRANSMISSION FLUID (ATF)**

**ATF**

**Inspection**

**Level**


1. Park the vehicle on level ground.
2. Apply the parking brake and securely position wheel chocks to prevent the vehicle from rolling.
3. Warm up the engine until the ATF temperature reaches **60–70°C {140–158°F}**.
4. While depressing the brake pedal, shift the selector lever to each range (P–L). Leave it a few seconds in each range.
5. Shift back to P range.



6. Ensure that the ATF level is between the notches of the ATF dipstick. Add ATF to specification, if necessary.

**ATF Type: Dexron®II or M-III**


**Capacity: 8.6 L {9.1US qt, 7.6 Imp qt}**



**Condition**

Determine whether the transmission should be disassembled by noting the following.

1. Is the ATF muddy or varnished?
2. Does the ATF smell strange or unusual?





# K

## AUTOMATIC TRANSMISSION FLUID (ATF)

### Fluid leakage

Check for ATF leakage at the points shown below and repair or replace as necessary.






**ELECTRONIC SYSTEM COMPONENTS**

**HOLD SWITCH**

**Inspection**

**Operation**

1. Turn the ignition switch ON.
2. Press the hold switch ON/OFF and verify that the hold indicator illuminates when the hold mode is selected.
3. If not as specified, measure the hold switch terminal voltage.




**Terminal voltage**

1. Remove the console panel.
2. Turn the ignition switch ON.
3. Press the hold switch ON/OFF, and measure the voltage between terminals D and F.

B+: Battery positive voltage

Terminal Switch condition	Terminal voltage (V)	
	D	F
Released	0	0
Depressed	B+	0

4. If not correct, check the hold switch continuity.




**Continuity**

1. Disconnect the negative battery cable and the shift-lock control unit connector.
2. Press the hold switch ON/OFF, and check continuity between terminals D and F.


Switch condition	Continuity
Released	Yes
Depressed	No

3. If not correct, replace the selector lever knob.
4. Connect the shift-lock control unit connector.
5. Install the console panel.
6. Connect the negative battery cable.



**Replacement**






1. Remove the console panel.
2. Remove the indicator panel screws.
3. Disconnect the shift-lock control unit connector and pull the hold switch terminals out of the connector.
4. Remove the selector lever knob.
5. Install the new selector lever knob.
6. Insert the hold switch terminals into the connector and connect the shift-lock control unit connector.
7. Apply a small amount of locking compound to the screws, and tighten.



**Tightening torque:**

1.5–2.9 N·m {15–30 kgf·cm, 14–26 in·lbf}

8. Install and adjust the indicator panel.  
(Refer to page K–165.)
9. Install the console panel.



### PARK/NEUTRAL SWITCH

#### Inspection

#### Operation

1. Turn the ignition switch to ON.
2. Shift the selector lever and verify that the selected range and selector indicator light (built into combination meter) positions are aligned.
3. Apply the parking brake and securely position wheel chocks to prevent the vehicle from rolling.
4. Verify that the starter operates with the ignition switch at START position and with the selector lever in P and N ranges only.
5. Verify that the back-up lights illuminate when the selector lever is shifted to R range with the ignition switch at the ON position.
6. If not as specified, check the park/neutral switch continuity.

#### Continuity

1. Disconnect the negative battery cable and the park/neutral switch connector.
2. Remove the park/neutral switch connector from the bracket.
3. Check continuity of the park/neutral switch terminals.

Position	1	2	3	4	5	6	7	8	9
P	○						○	○	○
R		○					○		
N			○				○	○	○
D				○			○		
S					○		○		
L						○	○		

○—○ : Indicates continuity

4. If not correct, adjust or replace the park/neutral switch.
5. Install the park/neutral switch connector to the bracket.
6. Connect the park/neutral switch connector and the negative battery cable.

#### Adjustment

1. Remove the selector rod from the manual shaft lever.
2. Move the manual shaft to N range position.
3. Loosen the park/neutral switch mounting bolts.
4. Align the holes of the park/neutral switch and the manual shaft by inserting a 4.0 mm {0.16 in} outer diameter pin.
5. Tighten the park/neutral switch mounting bolts and remove the pin.





#### Tightening torque:

2.5–3.9 N·m {25–40 kgf·cm, 22–34 in·lbf}

6. Recheck the continuity of the park/neutral switch.
7. If not correct, readjust or replace the park/neutral switch.
8. Install the selector rod to the manual shaft lever.

#### Replacement

Refer to "Adjustment" above for replacement of the park/neutral switch.

**VEHICLE SPEED SENSOR (REVOLUTION SENSOR)****Inspection**

1. Disconnect the negative battery cable.
2. Disconnect vehicle speed sensor connector.
3. Measure the resistance between the terminals of the vehicle speed sensor.

ATF temperature: 20–80°C (68–176°F)

Terminal	Resistance ( $\Omega$ )
A and B	500–1,000
B and C	$\infty$
A and C	$\infty$

4. If not correct, replace the vehicle speed sensor.
5. Connect the vehicle speed sensor connector.
6. Connect the negative battery cable.

**Replacement**

1. Disconnect the negative battery cable.
2. Disconnect the vehicle speed sensor connector.
3. Remove the vehicle speed sensor from the extension housing.
4. Apply ATF to a new O-ring and install it on the speed sensor 1.
5. Install the new vehicle speed sensor.





**Tightening torque:**

5.0–6.8 N·m {50–70 kgf·cm, 44–60 in·lbf}

6. Connect the vehicle speed sensor connector.
7. Connect the negative battery cable.

**VEHICLE SPEEDOMETER SENSOR****Speedmeter****Inspection**

1. Remove the combination meter. (Refer to 1994 RX-7 Body Electrical Troubleshooting Manual, section C1.)
2. Disconnect the speedometer connector.
3. Set the voltmeter to the 5V range.
4. Turn the ignition switch to the LOCK position.
5. Measure the voltage between terminals 3A and 3C of the speedometer connector (harness side) while the rear wheels are turning slowly.
6. When the voltmeter pointer moves slightly, replace the speedometer. If the pointer does not move, check the vehicle speedometer sensor and/or wiring.
7. Connect the speedometer connector.
8. Install the combination meter. (Refer to 1994 RX-7 Body Electrical Troubleshooting Manual, section C1.)



### Vehicle Speedometer Sensor Inspection

1. Disconnect the negative battery cable.
2. Remove the vehicle speedometer sensor.
3. Verify that magnetic resistance is felt when turning the vehicle speedometer sensor driven gear by hand.
4. Disconnect the vehicle speedometer sensor connector.
5. Set the voltmeter to the 5V range.
6. Measure the voltage between terminals A and B while the rear wheels are turning slowly.
7. If the pointer does not move, check the vehicle speedometer sensor continuity.
8. Measure the resistance between terminals A and B.

#### Resistance:

Approx. 290  $\Omega$  (at 20–80°C {68–176°F})

9. If not correct, replace the vehicle speedometer sensor.
10. Apply ATF to a new O-ring and install it on the vehicle speedometer sensor.
11. Install the vehicle speedometer sensor.

#### Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95 in·lbf}

12. Connect the vehicle speedometer sensor connector.
13. Connect the negative battery cable.

### Replacement

1. Disconnect the negative battery cable.
2. Disconnect the vehicle speedometer sensor connector.
3. Remove the vehicle speedometer sensor from the extension housing.
4. Apply ATF to a new O-ring and install it on the vehicle speedometer sensor.
5. Install the new vehicle speedometer sensor.

#### Tightening torque:






7.9–10.7 N·m {80–110 kgf·cm, 70–95 in·lbf}

6. Connect the vehicle speedometer sensor connector.
7. Connect the negative battery cable.

### VEHICLE SPEED PULSE GENERATOR

#### Inspection

1. Disconnect the negative battery cable.
2. Disconnect the vehicle speed pulse generator connector.



3. Measure the resistance between the terminals of the vehicle speed pulse generator.

ATF temperature: 20–80°C (68–176°F)

Terminal	Resistance (kΩ)
A and B	2.2–3.5
B and C	∞
A and C	∞

4. If not correct, replace the vehicle speed pulse generator.
5. Connect the vehicle speed pulse generator connector.
6. Connect the negative battery cable.

#### Replacement

1. Remove the transmission assembly. (Refer to page K-42.)
2. Remove the vehicle speed pulse generator from the transmission case.
3. Apply ATF to a new O-ring and install it on the new vehicle speed pulse generator.
4. Install the new gasket and new vehicle speed pulse generator.
5. Install new bolts and tighten.

#### Tightening torque:

5.0–6.8 N·m {50–70 kgf·cm, 44–60 in·lbf}

6. Install the transmission assembly. (Refer to page K-149.)

#### ATF THERMOSENSOR Replacement

##### Warning

- Be careful when draining; the ATF is hot.

1. Disconnect the negative battery cable.
2. Disconnect the solenoid valve connector.
3. Loosen the oil pan mounting bolts and drain the ATF into a suitable container.
4. Remove the oil pan.
5. Remove the ATF thermosensor from the control valve body.
6. Remove the control valve body. (Refer to page K-128.)

##### Note


- The ATF thermosensor is part of the solenoid valve harness.

7. Remove the solenoid valve harness from the transmission case.
8. Apply ATF to a new O-ring and install it on the solenoid valve harness.
9. Install the new solenoid valve harness into the transmission case.
10. Install the control valve body. (Refer to page K-130.)
11. Install the ATF thermosensor onto the control valve body.

#### Tightening torque:

6.9–6.8 N·m {70–90 kgf·cm, 61–78 in·lbf}






12. Clean the oil pan and the magnet, and set the magnet into the oil pan.
13. Remove any old locking compound from the bolt holes.
14. Install a new gasket and the oil pan.

### Tightening torque:

6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}

15. Tighten the new bolts evenly and quickly.
16. Connect the solenoid valve connector.
17. Fill the transmission with the specified amount and type of ATF. (Refer to page K-25.)
18. Connect the negative battery cable.




### Inspection

1. Refer to "Replacement" on the previous page for removal of the ATF thermosensor.
2. Wrap the ATF thermosensor, place it in water with a thermometer as shown, and heat the water gradually.
3. Measure the resistance between the terminals of the thermosensor.

Water temperature	Resistance (kΩ)
10°C {50°F}	2.5
40°C {104°F}	0.6
80°C {176°F}	0.3

4. If not correct, replace the ATF thermosensor.
5. Refer to "Replacement" for installation of the ATF thermosensor.



### SOLENOID VALVES


#### Inspection






1. Disconnect the negative battery cable.
2. Disconnect the solenoid valve connector.
3. Measure the resistance between terminals A through F and a ground.

ATF temperature: 20–80°C {68–176°F}

Terminal	Solenoid valve	Resistance (Ω)
A	Lockup control	20–40
B	Shift A	20–40
C	Shift B	20–40
D	Overrunning clutch	20–40
E	Line pressure	2.5–5.0
F	Lockup	10–20

4. If not correct, replace the solenoid valves.
5. Connect the solenoid valve connector.
6. Connect the negative battery cable.





### Replacement

If the shift A, shift B, overrunning clutch, and line pressure solenoid valves are not correct, replace the solenoids as an assembly.

1. Disconnect the negative battery cable.
2. Loosen the oil pan mounting bolts and drain the ATF into a suitable container.
3. Remove the oil pan.
4. Remove the control valve body. (Refer to page K-128.)
5. Remove the solenoid valve(s).
6. Apply ATF to a new O-ring(s) and install it on the new solenoid valve(s).
7. Install the new solenoid valve(s) to the control valve body.

### Tightening torque

**A: 6.9–9.8 N·m {70–100 kgf·cm, 61–86 in·lbf}**

**B: 9.9–12.7 N·m {100–130 kgf·cm, 86.9–112 in·lbf}**

8. Install the control valve body. (Refer to page K-130.)
9. Clean the oil pan and the magnet, and set the magnet into the oil pan.
10. Remove any old locking compound from the bolt holes.
11. Install a new gasket and the oil pan.
12. Tighten the new bolts evenly and quickly.

### Tightening torque:

**6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}**

13. Fill the transmission with the specified amount and type of ATF. (Refer to page K-25.)
14. Connect the negative battery cable.

### DROPPING RESISTOR

#### Inspection

1. Disconnect the negative battery cable.
2. Disconnect the dropping resistor connector.
3. Measure the resistance between the terminals of the resistor.

**Resistance: 10–14 Ω**

4. If not correct, replace the dropping resistor.
5. Connect the dropping resistor connector.
6. Connect the negative battery cable.


#### Replacement

1. Disconnect the negative battery cable.
2. Disconnect the dropping resistor connector.
3. Remove the dropping resistor.
4. Install the new dropping resistor.

### Tightening torque:

**7.9–11.7 N·m {80–120 kgf·cm, 70–104 in·lbf}**

5. Connect the dropping resistor connector.
6. Connect the negative battery cable.



### WATER THERMOSTAT

#### Replacement

1. Disconnect the negative battery cable.
2. Disconnect the water thermostat connector.
3. Drain the engine coolant.
4. Remove the water thermostat.
5. Install the new water thermostat.

#### Tightening torque:

5.9–6.8 N·m {60–90 kgf·cm, 53–78 in·lbf}

6. Connect the water thermostat connector.
7. Fill the engine with the specified amount and type of engine coolant.
8. Connect the negative battery cable.

#### Inspection

1. Refer to "Replacement" above for removal of water thermostat.
2. Wrap the water thermostat in wrapping vinyl, place it in the ATF with a thermometer as shown, and heat the ATF gradually.
3. Measure the resistance between the terminals of the water thermostat.

ATF temperature	Continuity
Above 115°C {239°F}	Yes
Below 110°C {230°F}	No

4. If not correct, replace the water thermostat.
5. Refer to "Replacement" above for installation of the water thermostat.

### HOLD INDICATOR

#### Inspection

#### Operation

1. Turn the ignition switch ON.

#### Note

- The hold indicator will flash if a malfunction exists in any of the PCMT system components.

2. Press the hold switch ON/OFF and verify that the hold indicator illuminates when the hold mode is selected.
3. If not as specified, inspect the combination meter and/or hold switch.




#### Continuity

1. Disconnect the negative battery cable.
2. Remove the combination meter. (Refer to 1994 RX-7 Body Electrical Troubleshooting Manual, section C1.)
3. Check for continuity between terminals 5C and 5G of the combination meter.

Terminal	5C	5G
Continuity	○	○




○ ○ : Indicates continuity




4. If not correct, replace the bulb or the combination meter.
5. Install the combination meter. (Refer to 1994 RX-7 Body Electrical Troubleshooting Manual, section C1.)
6. Connect the negative battery cable.



**POWERTRAIN CONTROL MODULE (TRANSMISSION)**

**Preparation  
SST**

<p>49 9200 162 Monitor, Engine Signal</p> 	<p>For inspection of Powertrain Control Module (Transmission) terminal voltage</p>	<p>49 G018 904 Sheet</p> 	<p>For inspection of Powertrain Control Module (Transmission) terminal voltage</p>
<p>49 H019 905 Adapter Harness</p> 	<p>For inspection of Powertrain Control Module (Transmission) terminal voltage</p>		



**Inspection**

1. Lift out the Powertrain Control Module (Transmission) by referring to the Powertrain Control Module (Transmission) replacement procedure. (Refer to page K-41.)
2. Disconnect the Powertrain Control Module (Transmission) connectors.
3. Connect the SSTs (Engine Signal Monitor and Adapter Harness) to the Powertrain Control Module (Transmission) as shown.
4. Place the SST (Sheet) on the Engine Signal Monitor.
5. Turn the ignition switch to ON.
6. Measure the terminal voltage at each terminal.
7. If any Powertrain Control Module (Transmission) terminal voltage is incorrect, check the related input or output devices and wiring. If no problem is found, replace the Powertrain Control Module (Transmission).

**Caution**

- Applying voltage to terminals A and B of this SST will damage the SST.

### Terminal Voltage Chart (Reference Data)

2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1O	1M	1K	1I	1G	1E	1C	1A
2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1P	1N	1L	1J	1H	1F	1D	1B

B+: Battery positive voltage

Terminal	Color	Component	Connected to	Voltmeter		Correct voltage	Condition	Check area
				(+) terminal	(-) terminal			
1A	L/R	Battery (backup)	Battery	1A	Ground	B+	Constant	<ul style="list-style-type: none"> <li>Wiring and/or connector from terminal 1A to battery</li> </ul>
1B (Output)	W/G	Shift B solenoid valve	Solenoid valve	1B		B+	P, R, and N ranges or 1st and 2nd gear positions	<ul style="list-style-type: none"> <li>Shift B solenoid valve</li> <li>Wiring and/or connector from 1B terminal to shift B solenoid valve</li> </ul>
						Below 1.0V	Third and Fourth gear positions	
1C (Output)	Y	Inhibitor signal	Engine control unit	1C		Below 1.0V	P and N ranges	<ul style="list-style-type: none"> <li>Park/Neutral switch, vehicle speed pulse generator, and/or powertrain control module (engine)</li> <li>Wiring and/or connector from terminal 1C to powertrain control module (engine) terminal 1R</li> </ul>
						B+	Except P and N ranges	
1D (Output)	W/R	Shift A solenoid valve	Solenoid valve	1D		B+	P, R, and N ranges or 1st and Fourth gear positions	<ul style="list-style-type: none"> <li>Shift A solenoid valve</li> <li>Wiring and/or connector from terminal 1D to shift A solenoid valve</li> </ul>
						Below 1.0V	2nd and Third gear positions	
1E (Input)	R	Park/Neutral switch (R range)	Park/Neutral switch	1E		B+	R range	<ul style="list-style-type: none"> <li>Park/Neutral switch</li> <li>Wiring and/or connector from terminal 1E to park/neutral switch</li> </ul>
						0V	Except R range	
1F (Output)	W/L	Line pressure solenoid valve	Solenoid valve	1F		Above 1.5V	Throttle valve closed throttle position	<ul style="list-style-type: none"> <li>Line pressure solenoid valve</li> <li>Wiring and/or connector from terminal 1F to line pressure solenoid valve</li> </ul>
						Below 1.0V	Throttle valve wide opened throttle	
1G (Input)	Y/L	Engine rpm signal	Engine control unit	1G		0.3-0.8V	Engine running at idle	<ul style="list-style-type: none"> <li>Wiring and/or connector from terminal 1G to powertrain control module (engine) terminal 2B</li> <li>Powertrain control module (engine)</li> </ul>
						0V	Engine stopped	
						1.8-2.2V	Engine running at 3,000 rpm (no load)	
1H (Output)	B/LG	Dropping resistor	Dropping resistor	1H		B+	Throttle valve closed throttle position	<ul style="list-style-type: none"> <li>Dropping resistor and/or solenoid valve (line pressure)</li> <li>Wiring and/or connector between terminal 1H, dropping resistor, and solenoid valve.</li> </ul>
						Below 1.0V	Throttle valve wide opened throttle	

Terminal 1D voltage [shift A solenoid valve] is below 1.0V when in HOLD mode in P, R, and N ranges.

2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1O	1M	1K	1I	1G	1E	1C	1A
2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1P	1N	1L	1J	1H	1F	1D	1B

B+: Battery positive voltage

Terminal	Color	Component	Connected to	Voltmeter		Correct voltage	Condition	Check area
				(+) terminal	(-) terminal			
1I (Input)	G/R	Vehicle speedometer sensor	Speedometer	1I	Ground	2-3V	Vehicle moving	<ul style="list-style-type: none"> <li>Vehicle speedometer sensor and/or speedometer</li> <li>Wiring and/or connector between terminal 1I speedometer, and vehicle speedometer sensor.</li> </ul>
						0V or 4.5-5.5V	Vehicle stopped	
1J (Ground)	B/L	Ground (Powertrain control module (Transmission))	—	1J	Ground	0V	Constant	<ul style="list-style-type: none"> <li>Wiring condition.</li> </ul>
1K (Output)	Y	Hold indicator / FAT terminal (data link connector)	Combination meter (hold indicator light) and FAT terminal (data link connector)	1K	Ground	Below 1.0V	Hold mode	<ul style="list-style-type: none"> <li>Wiring and/or connector from terminal 1K to hold indicator light (combination meter)</li> <li>Hold indicator light</li> </ul>
						B+	Except hold mode	
1L (Input)	V/P	A/C signal	A/C relay	1L	Ground	Below 3.0V	A/C ON	<ul style="list-style-type: none"> <li>Powertrain control module (engine) and/or Air conditioning sensor</li> <li>Wiring and/or connector from terminal 1L to Air conditioning sensor</li> </ul>
						B+	A/C OFF	
1M (Output)	W	Lockup solenoid valve	Solenoid valve	1M	Ground	B+	Lockup	<ul style="list-style-type: none"> <li>Lockup solenoid valve</li> <li>Wiring and/or connector from terminal 1M to lockup solenoid valve</li> </ul>
						Below 1.0V	No lockup	
1N	B/Y	Battery (main)	Ignition switch	1N	Ground	B+	Ignition switch ON	<ul style="list-style-type: none"> <li>Meter fuse and/or ignition switch</li> <li>Wiring and/or connector from terminal 1N to ignition switch (IG1)</li> </ul>
						0V	Ignition switch OFF	
1O (Output)	W/Y	Overrunning clutch solenoid valve	Solenoid valve	1O	Ground	Below 1.0V	Throttle valve wide opened throttle (D range)	<ul style="list-style-type: none"> <li>Overrunning clutch solenoid valve</li> <li>Wiring and/or connector from terminal 1O to overrunning clutch solenoid valve</li> </ul>
						B+	Throttle valve closed (D range)	
1P	B/Y	Battery (main)	Ignition switch	1P	Ground	B+	Ignition switch ON	<ul style="list-style-type: none"> <li>Meter fuse and/or ignition switch</li> <li>Wiring and/or connector from terminal 1P to ignition switch (IG1)</li> </ul>
						0V	Ignition switch OFF	
2A (Input)	BR/W	Throttle sensor (V <sub>REF</sub> )	Throttle position sensor	2A	Ground	4.5-5.5V	Ignition switch ON	<ul style="list-style-type: none"> <li>Wiring and/or connector from terminal 2A to powertrain control module (engine) terminal 3I</li> <li>Throttle position sensor</li> </ul>
						0V	Ignition switch OFF	

2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1O	1M	1K	1I	1G	1E	1C	1A
2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1P	1N	1L	1J	1H	1F	1D	1B

B+: Battery positive voltage

Terminal	Color	Component	Connected to	Voltmeter		Correct voltage	Condition	Check area
				(+) terminal	(-) terminal			
2B (Input)	Y/G	Park/Neutral switch (D range)	Park/Neutral switch	2B	Ground	B+	D range	<ul style="list-style-type: none"> <li>• Park/Neutral switch</li> <li>• Wiring and/or connector from terminal 2B to park/neutral switch</li> </ul>
						0V	Except D range	
2C (Input)	G/Y	Barometric absolute pressure sensor	Powertrain control module (engine)	2C	Ground	2.0–4.5V	Ignition switch ON	<ul style="list-style-type: none"> <li>• Wiring and/or connector from terminal 2C to powertrain control module (engine) terminal 2D</li> </ul>
						0V	Ignition switch OFF	
2D (Input)	L/Y	Park/Neutral switch (P and N ranges)	Park/Neutral switch	2D	Ground	0V	P and N ranges	<ul style="list-style-type: none"> <li>• Park/Neutral switch and/or ignition switch</li> <li>• Wiring and/or connector between terminal 2D park/neutral switch, and ignition switch (STA)</li> </ul>
						B+	Except P and N ranges	
2E (Input)	O	Vehicle speed pulse generator	Vehicle speed pulse generator	2E*1	2L	Approx. above 0.5V AC	Vehicle speed above 25 km/h {16 MPH}	<ul style="list-style-type: none"> <li>• Vehicle speed pulse generator</li> <li>• Wiring and/or connector from terminal 2E to vehicle speed pulse generator</li> </ul>
						Approx. 0V (AC)	Vehicle stopped (Ignition switch ON)	
2P (Output)	G/W	Lockup control solenoid valve	Solenoid valve	2F	Ground	B+	lockup	<ul style="list-style-type: none"> <li>• Lockup control solenoid valve</li> <li>• Wiring and/or connector from terminal 2F to lockup control solenoid valve</li> </ul>
						Below 1.0V	No lockup	
2G (Input)	G/R	Slip lockup OFF signal	Powertrain control module (engine)	2G	Ground	Below 1.0V	Engine running at 3.000 rpm	<ul style="list-style-type: none"> <li>• Wiring and/or connector from terminal 2G to powertrain control module (engine) terminal 2C</li> <li>• Powertrain control module (engine)</li> </ul>
						B+	Engine running at idle	
2H (Input)	L/G	Torque reduced signal	Powertrain control module (engine)	2H*2	Ground	B+	Engine running at idle	<ul style="list-style-type: none"> <li>• Wiring and/or connector from terminal 2H to powertrain control module (engine) terminal 2G</li> <li>• Throttle position sensor, vehicle speed sensor vehicle speed pulse generator, and/or powertrain control module (engine)</li> </ul>
						Below 1.0V	Throttle opening above 1/8 (Engine coolant temp below 40°C {104°F})	
2I (Input)	W/Y	Hold switch	Hold switch	2I	Ground	B+	Switch depressed	<ul style="list-style-type: none"> <li>• Hold switch</li> <li>• Wiring and/or connector from terminal 2I to hold switch</li> </ul>
						0V	Switch released	

\*1 Check terminal 2E (vehicle speed pulse generator) voltage by using the AC range.

\*2 2H (Torque reduced signal) : Some kinds of testers may give incorrect values. This is because the voltage output period is very short.

2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1O	1M	1K	1I	1G	1E	1C	1A
2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1P	1N	1L	1J	1H	1F	1D	1B

B+: Battery positive voltage

Terminal	Color	Component	Connected to	Voltmeter		Correct voltage	Condition	Check area
				(+) terminal	(-) terminal			
2J (Input)	Y/G	Vehicle speed sensor (revolution sensor)	Vehicle speed sensor (revolution sensor)	2J*	2L	Approx. above 1.0V (AC)	Vehicle speed above 25 km/h {16 MPH}	<ul style="list-style-type: none"> <li>Vehicle speed sensor (revolution sensor)</li> <li>Wiring and/or connector from terminal 2J to vehicle speed sensor</li> </ul>
						Approx. 0V (AC)	Vehicle stopped	
2K	L/W	TAT terminal(data link connector) / 4GR inhibit signal (auto speed control signal)	TAT terminal (data link connector) and cruise control unit	2K	Ground	4.5-5.5	Ignition switch ON	<ul style="list-style-type: none"> <li>Terminal 1N and 1P voltage</li> <li>Wiring and/or connector from terminal 2K to data link connector TAT terminal</li> <li>Wiring and/or connector from terminal 2K to cruise control unit terminal G</li> </ul>
						0V	TAT terminal grounded	
						0V	Constant	
2L (Ground)	W	Ground (input signals)	—	2L		0V	Constant	<ul style="list-style-type: none"> <li>Wiring condition</li> </ul>
2M (Input)	R/W	Idle signal	Powertrain control module (engine)	2M	Ground	4.5-5.5V	Throttle valve opened	<ul style="list-style-type: none"> <li>Throttle position sensor and/or powertrain control module (engine)</li> <li>Wiring and/or connector from terminal 2M to powertrain control module (engine) terminal 2E</li> </ul>
						Below 1.0V	Throttle valve closed throttle position	
2N (Input)	B	Water thermo-switch / mileage switch	Water thermo-switch and mileage switch	2N	Ground	0V	Engine coolant temp. above 115°C {239°F} or vehicle total mileage above 625 km {388 miles} and vehicle stopped	<ul style="list-style-type: none"> <li>Water thermo-switch and/or mileage switch</li> <li>Wiring and/or connector from terminal 2N to water thermo-switch</li> </ul>
						B+	Engine coolant temp. below 110°C {230°F} or vehicle total mileage below 625 km {388 miles} and vehicle stopped	
2O (Input)	LG/R	Stoplight switch	Stoplight switch	2O		B+	Brake pedal depressed	<ul style="list-style-type: none"> <li>Stoplight switch</li> <li>Wiring and/or connector from terminal 2O to stoplight switch</li> </ul>
						0V	Brake pedal released	

\* Check terminal 2J (speed sensor 1) voltage by using the AC range.







2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1O	1M	1K	1I	1G	1E	1C	1A
2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1P	1N	1L	1J	1H	1F	1D	1B

B+: Battery positive voltage

Terminal	Color	Component	Connected to	Voltmeter		Correct voltage	Condition	Check area
				(+) terminal	(-) terminal			
2P (Output)	G/W	Reduce torque signal / slip lockup signal	Powertrain control module (engine)	2P*	Ground	Below 1.0V	When shifting from 1st to 2nd or from 2nd to Third with the throttle opening above 1.5/8. When slip lockup with the throttle opening below 0.5/8.	<ul style="list-style-type: none"> <li>Wiring and/or connector from terminal 2P to powertrain control module (engine) terminal 1Q</li> <li>Throttle position sensor, vehicle speed pulse generator, lockup, lockup control solenoid valve, and/or powertrain control module (engine)</li> </ul>
						B+		
2Q (Input)	BR/W	Park/Neutral switch (L range)	Park/Neutral switch	2Q	Ground	B+	L range	<ul style="list-style-type: none"> <li>Park/Neutral switch</li> <li>Wiring and/or connector from terminal 2Q to park/neutral switch</li> </ul>
						0V	Except L range	
2R (Input)	R	ATF thermosensor	ATF thermosensor	2R	2L	Approx. 2.4–0.4V	While warming up ATF Note <ul style="list-style-type: none"> <li>Approx. 1.8V: ATF temperature 10°C {50°F}</li> <li>Approx. 1.1V: ATF temperature 40°C {104°F}</li> </ul>	<ul style="list-style-type: none"> <li>ATF thermosensor</li> <li>Wiring and/or connector from terminal 2R to ATF thermosensor</li> </ul>
2S (Input)	L/R	Park/Neutral switch (S range)	Park/Neutral switch	2S	Ground	B+	S range	<ul style="list-style-type: none"> <li>Park/Neutral switch</li> <li>Wiring and/or connector from terminal 2S to park/neutral switch</li> </ul>
						0V	Except S range	
2T (Input)	B/G	Throttle position sensor (TVO)	Throttle position sensor	2T	Ground	0.1–1.1V	Throttle valve closed throttle position	<ul style="list-style-type: none"> <li>Throttle position sensor</li> <li>Wiring and/or connector from terminal 2T to throttle position sensor</li> </ul>
						4.0–4.5V	Throttle valve wide opened throttle	

\* 2P (Reduce torque signal/ lockup signal): Some kinds of testers may give incorrect values. This is because the voltage output period is very short.



**Replacement**

1. Disconnect the negative battery cable.
2. Remove the front side trim (passenger side).
3. Remove the Powertrain Control Module (Engine). (Refer to section F.)
4. Remove the nuts shown in the figure and disconnect the Powertrain Control Module (Transmission) connectors.
5. Install the new Powertrain Control Module (Transmission).

**Tightening torque:**

7.9-10.7 N·m {80-110 kgf·cm, 70-95 in·lbf}

6. Connect the Powertrain Control Module (Transmission) connectors.
7. Install the Powertrain Control Module (Engine). (Refer to section F.)

**Tightening torque:**

7.9-10.7 N·m {80-110 kgf·cm, 70-95 in·lbf}

8. Install the front side trim (passenger side).
9. Connect the negative battery cable.

**SELECTOR INDICATOR LIGHT**

**Inspection**

**Operation**

1. Verify that the selected range and selector indicator light (built into combination meter) positions are aligned.
2. If not as specified, check the park/neutral switch and/or selector indicator light.

**Continuity**

1. Disconnect the negative battery cable.
2. Remove the combination meter. (Refer to 1994 RX-7 Body Electrical Troubleshooting Manual, section C1.)
3. Check for continuity between the terminals.

Terminal Position	5K	5I	5L	5J	5H	5F	5D	5B
P	○		○					
R	○			○				
N		○			○			
D		○				○		
S		○					○	
L		○						○







○—○ : Indicates Continuity

4. If not correct, replace the bulb or combination meter.
5. Install the combination meter. (Refer to 1994 RX-7 Body Electrical Troubleshooting Manual, section C1.)
6. Connect the negative battery cable.

### TRANSMISSION

#### TRANSMISSION UNIT (REMOVAL)


##### Preparation SST

<p>49 J019 002 Cap</p> 	<p>For prevention of ATF leakage</p>	<p>49 0877 435 Special wrench</p> 	<p>For loosening of torque converter installation bolts</p>
<p>49 G017 5A0 Support, engine</p> 	<p>For support of engine</p>	<p>49 G017 50 1 Bar (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>
<p>49 G017 502 Support (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>	<p>49 G017 503 Hook (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>


##### Removal

The oil pan could contain small chips, shavings, and other particles helpful in checking the condition of the transmission and diagnosing certain problems. To ensure that all foreign particles stay in the oil pan, make sure that the transmission is never tipped completely over while the oil pan is still installed.


1. Disconnect the negative battery cable.
2. On level ground, jack up the vehicle and support it evenly on safety stands.
3. Remove in the order shown in the figure, referring to **Removal Note**.



- |  |  |
|--|--|
| <p>1. ATF dipstick</p> <p>2. Undercover (right and left)</p> <p>3. Starter</p> <p>4. Tunnel member (center)</p> <p>5. Secondary air injection pipe</p> <p>6. Three-way catalyst assembly</p> <p>7. Front tunnel member</p> <p>8. Rear tunnel member</p> <p>9. Cover</p> <p>10. Propeller shaft<br/>Removal ..... section L</p> <p>11. Power plant frame (PPF)<br/>Removal Note ..... page K-44</p> <p>12. Front exhaust pipe</p> | <p>13. Park/neutral switch connector</p> <p>14. Vehicle speed sensor connector</p> <p>15. Vehicle speed pulse generator connector</p> <p>16. Solenoid valve connector</p> <p>17. Vehicle speedometer sensor connector</p> <p>18. Selector rod (selector lever side)</p> <p>19. Service hole cover</p> <p>20. Torque converter bolts<br/>Removal Note ..... page K-44</p> <p>21. Oil filler tube (upper)</p> <p>22. Oil filler tube (lower)</p> <p>23. Oil cooler hose</p> <p>24. Transmission<br/>Removal Note ..... page K-45</p> |
|--|--|


**Removal note****Power plant frame (PPF)**

1. Hold the engine by using the SST.




2. Hold the differential with a transmission jack.

3. Remove the PPF.

**Torque converter bolts**

1. Lock the drive plate by using a screwdriver.






2. Remove the torque converter bolts by using the SST.

**Transmission**

Set the transmission onto the transmission jack, paying special attention not to damage the oil pipes. Make sure that the torque converter side of the transmission is tilted slightly upward during removal. Carefully lower the transmission from the vehicle.

TRANSMISSION UNIT (DISASSEMBLY)

Preparation  
SST

<p>49 0107 680A Engine stand</p> 	<p>For disassembly of transmission</p>	<p>49 U019 0A0A Hanger set, transmission</p> 	<p>For disassembly of transmission</p>
<p>49 H075 495B Body (Part of 49 U019 0A0A)</p> 	<p>For disassembly of transmission</p>	<p>49 U019 003 Holder (Part of 49 U019 0A0A)</p> 	<p>For disassembly of transmission</p>
<p>49 0378 390 Puller, oil pump</p> 	<p>For disassembly of transmission</p>		

Precaution

General Notes:

1. Disassemble the transmission in a clean area (clean work space) to prevent contaminants from entering into the mechanisms.
2. Inspect the individual transmission components in accordance with the QUICK DIAGNOSIS CHART during disassembly.
3. Use only plastic hammers when applying force to separate the light alloy case joints.
4. Never use rags during disassembly; they may leave particles that can clog fluid passages.
5. Several parts resemble one another; organize them so that they do not get mixed up.
6. Disassemble the control valve assembly and thoroughly clean it when the clutch or brake band has burned out or when the ATF has degenerated.

Cleaning Notes:

1. Clean the transmission exterior thoroughly with a steam cleaner or cleaning solvents, or both, before disassembly.


Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.
2. Clean the removed parts with cleaning solvent, and dry with compressed air. Clean out all holes and passages with compressed air, and verify that there are no obstructions.

### Disassembly


Disassemble in the order shown in the figure, referring to **Disassembly Procedure**.

### Components 1



- |                                  |            |   |            |
|----------------------------------|------------|---|------------|
| 1. Park/neutral switch           |            | 6. Converter housing                      |            |
| Inspection .....                 | page K- 28 | 7. Oil pan                                |            |
| Adjustment .....                 | page K- 28 | 8. Oil strainer                           |            |
| Replacement .....                | page K- 28 | 9. Control valve body                     |            |
| 2. Vehicle speed sensor          |            | Disassembly / Inspection .....            | page K-108 |
| Inspection .....                 | page K- 29 | Assembly .....                            | page K-125 |
| Replacement .....                | page K- 29 | On-Vehicle Removal .....                  | page K-128 |
| 3. Vehicle speedometer sensor    |            | On-Vehicle Installation .....             | page K-130 |
| Inspection .....                 | page K- 30 | 10. Solenoid valve harness                |            |
| Replacement .....                | page K- 30 | 11. Anchorend bolt and nut                |            |
| 4. Vehicle speed pulse generator |            | 12. Extension housing / Parking mechanism |            |
| Inspection .....                 | page K- 30 | Disassembly / Inspection /                |            |
| Replacement .....                | page K- 31 | Assembly .....                            | page K- 97 |
| 5. Torque converter              |            | On-Vehicle Removal /                      |            |
| Inspection .....                 | page K- 57 | Installation .....                        | page K-101 |

Components 2




- 1. Oil pump  
Disassembly / Inspection /  
Assembly ..... page K-60
- 2. Input shaft
- 3. Brake band and strut
- 4. Reverse clutch  
Preinspection ..... page K-64  
Disassembly / Inspection /  
Assembly ..... page K-65
- 5. High clutch and front sun gear  
Preinspection ..... page K-70  
Disassembly / Inspection /  
Assembly ..... page K-71
- 6. Front planetary carrier
- 7. Rear sun gear
- 8. Snap ring
- 9. Speedometer drive gear

- 10. Steel ball
- 11. Snap ring
- 12. Parking gear and bearing
- 13. Snap ring
- 14. Output shaft
- 15. Front internal gear, rear internal gear, forward  
clutch hub, overrunning clutch hub  
Preinspection ..... page K-80  
Disassembly / Inspection /  
Assembly ..... page K-80
- 16. Forward clutch drum (forward clutch, overrunning  
clutch, low one-way clutch)  
Preinspection ..... page K-83  
Disassembly / Inspection /  
Assembly ..... page K-84




### Components 3



- 1. Accumulators  
Disassembly / Inspection /  
Assembly ..... page K-58
- 2. Band servo  
Preinspection ..... page K-76  
Disassembly / Inspection /  
Assembl ..... page K-76




- 3. Low and reverse brake  
Preinspection ..... page K-91  
Disassembly / Inspection /  
Assembly ..... page K-92




**Disassembly procedure**

1. Support the transmission by placing wooden blocks under the converter housing and the extension housing.
2. Remove the oil pan and gasket.  
If large amounts of material are found in the oil pan, replace the torque converter and inspect the transmission for the cause.
3. Examine any material found in the pan or on the magnet to determine the condition of the transmission.
 


Clutch facing material	.....	Drive plate and brake band wear
Steel (magnetic)	.....	Bearing gear, and driven plate wear
Aluminum(non-magnetic)	...	Bushings or cast aluminum parts wear
4. Install the oil pan with a few bolts to protect the control valve body.
5. Remove the harness from the connector bracket.
6. Remove the park/neutral switch.




7. Remove the harness from the connector bracket.
8. Remove the connector bracket from the converter housing.
9. Remove the vehicle speedometer sensor.
10. Remove the O-ring from the vehicle speedometer sensor.




11. Remove the vehicle speed sensor.
12. Remove the O-ring from the vehicle speed sensor.




13. Remove the vehicle speed pulse generator and gasket from the transmission case.
14. Remove the O-ring from the vehicle speed pulse generator.




15. Remove the torque converter, and immediately turn it so that the hole faces upward. This will help to keep any remaining fluid from spilling.



16. Assemble the SSTs as shown.




17. Mount the transmission to the SSTs.
18. Remove the oil pan, gasket, and magnet.




19. Remove the extension housing and gasket.

**Bolt length (measured from below bolt head)**  
**A: 30 mm {1.181 in}**  
**B: 45 mm {1.772 in}**




20. Remove the clip by carefully prying with a small flathead screwdriver.

21. Remove the lockup solenoid valve connector.



22. Remove the ATF thermosensor.


**Bolt length (measured from below bolt head):**  
45 mm {1.772 in}




23. Remove the oil strainer.

**Bolt length (measured from below bolt head):**  
50 mm {1.969 in}

24. Remove the O-ring from the oil strainer.



25. Separate the solenoid valve harness from the harness clip.




26. Remove bolts A, B, and the brackets shown in the figure.

**Bolt length (measured from below bolt head)**


**A: 33 mm {1.299 in}**

**B: 45 mm {1.772 in}**




27. Remove the clip by carefully prying with a small flathead screwdriver.


28. Disconnect the solenoid valve connectors.




29. Remove the control valve body.



30. Remove the accumulator springs.



31. Remove the solenoid connector from the transmission case.
32. Remove the O-ring from the solenoid valve harness.




33. Remove the converter housing from the transmission case.


**Caution**

- The converter housing is made of aluminum, and is therefore easily dented and scratched by metal tools. When removing old sealant, do not gouge or strike the sealing surface of the converter housing.


34. Clean the sealant from the converter housing.




35. Remove the O-ring from the input shaft.




36. Install the SST to the oil pump.
37. Slowly remove the oil pump from the transmission case by evenly sliding the weights of the SST.
38. Remove the SST from the oil pump.




39. Clean the sealant from the oil pump housing, being careful not to scratch or dent the machined surfaces.




- 40. Remove the oil pump gasket.
- 41. Pull out the input shaft while holding the reverse clutch drum.




- 42. While holding the anchor end bolt, loosen the locknut.
- 43. Remove the anchor end bolt.
- 44. Clean the sealant from the case threads.




- 45. Remove the brake band and hold it together with a piece of wire as shown in the figure.
- 46. Remove the band strut.




- 47. Remove the reverse clutch, high clutch, and front sun gear assembly from the transmission case.




- 48. Remove the front planetary carrier, bearings, and rear sun gear. Inspect the following and replace as necessary.
  - 1) Front planetary carrier  
Inspect gear teeth for damage, wear, and cracks. Check for rough rotation of pinion gears.
  - 2) Rear sun gear  
Inspect gear teeth for damage, wear, and cracks.
  - 3) Bearing  
Inspect for damage and rough rotation.




49. Remove the snap ring and the speedometer drive gear.  
50. Remove the steel ball.




51. Remove the snap ring from the output shaft.  
52. Remove the parking gear.



53. Remove the bearing from the rear of the transmission case. Inspect for damage and rough rotation. Replace as necessary.




54. Push the output shaft slightly forward and remove the snap ring from the output shaft.




55. Slide the output shaft from the rear of the transmission case.







56. Remove the front internal gear (integrated with rear planetary carrier).




57. Remove the rear internal gear, forward clutch hub, and overrunning clutch hub assembly.



58. Remove the forward clutch drum (forward clutch, overrunning clutch, and low one-way clutch) assembly.

**TORQUE CONVERTER****Inspection**

1. Check the outside of the converter for damage and cracks. Replace the torque converter if there are any problems.
2. Check for rust on the pilot hub or the boss. Remove any rust completely.


**Cleaning the inside of the converter**

1. Drain all ATF remaining in the converter.
2. Pour in new ATF (2.0 L {2.1 US qt, 1.8 Imp qt}).
3. Shake the converter to clean the inside. Drain the ATF.
4. Repeat steps 2 and 3 until you are sure that the inside of the torque converter is clean.


### ACCUMULATORS

#### Disassembly / Inspection / Assembly

1. Disassemble in the order in the figure, referring to **Disassembly Note**.
2. Inspect all parts and replace if necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



- |   |  |
|---|--|
| 1. 3-4/N-R accumulator spring<br>Inspection . . . . . page K-59 | 7. 2-3 accumulator piston<br>Disassembly Note . . . . . below      |
| 2. 1-2 accumulator spring<br>Inspection . . . . . page K-59     | 8. O-rings   |
| 3. 2-3 accumulator spring<br>Inspection . . . . . page K-59     | 9. 1-2 accumulator piston<br>Disassembly Note . . . . . below      |
| 4. N-D accumulator piston<br>Disassembly Note . . . . . below   | 10. O-rings  |
| 5. O-rings  | 11. 3-4/N-R accumulator piston<br>Disassembly Note . . . . . below |
| 6. N-D accumulator spring<br>Inspection . . . . . page K-59     | 12. O-rings  |
|   | 13. Transmission case  |




#### Disassembly note

##### Accumulator piston

Remove the accumulator pistons from transmission case by applying compressed air through the oil passage as shown in the figure.

Item	Location	Oil passage
Accumulator		
N-D accumulator	A	a
2-3 accumulator	B	b
1-2 accumulator	C	c
3-4/N-R accumulator	D	d



**Inspection**

**Accumulator spring**

1. Measure the spring free length




Spring	Item	Outer dia. mm {in}	Free length mm {in}	No. of coils	Wire dia. mm {in}
N-D accumulator spring		18.0 {0.71}	43.0 {1.69}	7.9	2.3 {0.091}
1-2 accumulator spring		29.3 {1.15}	45.0 {1.77}	3.8	3.7 {0.15}
2-3 accumulator spring		19.5 {0.77}	66.0 {2.60}	8.6	3.0 {0.12}
3-4/N-R accumulator spring		18.0 {0.71}	43.0 {1.69}	7.9	2.3 {0.091}

2. If not within specification, replace the spring.

**Assembly procedure**

**Outer diameter and installation order of spring**

Spring	Installation order	Outer dia. mm {in}
a N-D accumulator	Spring - Piston	18.0 {0.709}
b 2-3 accumulator	Piston - Spring	20.0 {0.787}
c 1-2 accumulator	Piston - Spring	29.3 {1.154}
d 3-4/N-R accumulator	Piston - Spring	17.3 {0.681}




1. Apply ATF to the new O-rings and install them onto the accumulator pistons.

Piston	O-ring	Large mm {in}	Small mm {in}
		A N-D accumulator	45.0 {1.77}
B 2-3 accumulator		50.0 {1.97}	32.0 {1.26}
C 1-2 accumulator		50.0 {1.97}	45.0 {1.77}
D 3-4/N-R accumulator		45.0 {1.77}	29.0 {1.14}




2. Apply even pressure to the perimeter of the accumulator pistons and install them into the transmission case.

3. Install each spring into its own accumulator piston.




### OIL PUMP

#### Preparation SST


<p>49 G030 795</p> <p>Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 G030 796</p> <p>Body (Part of 49 G030 795)</p> 	<p>For installation of oil seal</p>
<p>49 G030 797</p> <p>Handle (Part of 49 G030 795)</p> 	<p>For installation of oil seal</p>		

#### Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- |   |   |
|---|---|
| <p>1. Bearing<br/>Inspect for damage and rough rotation</p> <p>2. Oil pump cover<br/>Disassembly Note ..... page K-61<br/>Inspection ..... page K-61</p> <p>3. Seal ring (small diameter)</p> <p>4. Seal ring (large diameter)</p> <p>5. O-ring</p> <p>6. Vane ring</p> <p>7. Rotor<br/>Disassembly Note ..... page K-61<br/>Inspection ..... page K-62</p> <p>8. Vane<br/>Inspection ..... page K-62</p> <p>9. Vane ring</p> <p>10. Pivot pin<br/>Disassembly Note ..... page K-61</p> | <p>11. Cam ring<br/>Disassembly Note ..... page K-61<br/>Inspection ..... page K-62</p> <p>12. Cam ring spring<br/>Inspection ..... page K-62</p> <p>13. Spring seat</p> <p>14. Friction ring</p> <p>15. O-ring</p> <p>16. Pivot pin</p> <p>17. Control piston<br/>Inspection ..... page K-62</p> <p>18. Side seal</p> <p>19. Oil pump housing<br/>Inspection ..... page K-62</p> <p>20. Oil seal</p> |
|---|---|

**Disassembly note****Oil pump cover**


1. Gradually loosen the mounting bolts in the order shown.
2. Remove the oil pump cover from the oil pump housing.

**Rotor**


1. Mark the rotor and cam ring without scratching or denting them.
2. Remove the rotor and vanes from the cam ring.

**Pivot pin**

Hold the cam ring back with a tape-wrapped screwdriver and remove the pivot pin.

**Cam ring**

1. Hold the cam ring spring back and remove the cam ring.
2. Remove the cam ring spring.

**Inspection****Oil pump cover**


1. Fit new seal rings into the oil pump cover.
2. Measure the clearance between the seal ring and the ring groove.

**Standard clearance:**

0.10–0.25 mm {0.004–0.010 in}

**Maximum clearance: 0.25 mm {0.010 in}**

3. If not within specification, replace the oil pump assembly.



### Oil pump housing, cam ring, rotor, vane, and control piston


1. Install the cam ring, vanes, rotor, and control piston. Do not install the friction ring, O-ring, control piston, side seals, and cam ring spring yet.
2. Measure the distance from the edge of the oil pump housing to the cam ring, rotor, vanes, and control piston at least four points along their circumferences.

### Clearance

mm {in}

Part	Distance	Standard	Maximum
Cam ring		0.010–0.024 {0.0004–0.0009}	0.030 {0.0012}
Rotor, vane, control piston		0.030–0.044 {0.0012–0.0017}	0.050 {0.0020}

3. If not within specification, replace the oil pump assembly.




### Cam ring spring

1. Measure the spring free length.

### Specification


Outer dia. mm {in}	Free length mm {in}	No. of coils	Wire dia. mm {in}
13.7 {0.539}	39.8 {1.567}	7.8	2.3 {0.091}

2. If not correct, replace the cam ring spring.




### Assembly procedure


1. Apply ATF to the lip of a new oil seal, and install it by using the SSTs.




2. Apply ATF to side seals, and install them on the control piston with the black surface facing the control piston.
3. Install the control piston and pivot pin.




4. Apply petroleum jelly to the cam ring groove and install a new O-ring and friction ring into the cam ring.
5. Install the cam ring and spring while compressing the spring against the oil pump housing.



6. Hold the cam ring with a tape-wrapped screwdriver, and install the pivot pin.




7. Confirm that the mark on the rotor is facing upward, and install the rotor, vanes, and vane rings.
8. Carefully install the oil pump cover onto the oil pump housing.



9. Tighten the bolts evenly and gradually in the order shown.


**Tightening torque:**

**16–20 N·m {1.6–2.1 kgf·m, 12–15 ft·lbf}**



10. Apply petroleum jelly to the seal rings. Fit the large seal ring (yellow mark) into the bottom ring groove and small ring (no mark) into the top ring groove.
11. Apply ATF to a new O-ring and install it onto the oil pump.











12. Apply petroleum jelly to the bearing and set it on the oil pump.

**Bearing outer diameter: 47.0 mm {1.85 in}**

### REVERSE CLUTCH

#### Preparation SST

<p>49 G019 0A7A Compressor set, return spring</p> 	<p>For disassembly / assembly of snap ring</p>	<p>49 G019 025 Body B (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>
<p>49 G019 026 Plate (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>	<p>49 G019 027 Attachment A (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>
<p>49 G019 029 Nut (Part of 49 G019 0A7A)</p> 	<p>For disassembly / assembly of snap ring</p>		




#### Preinspection

##### Reverse clutch operation

1. Install the reverse clutch onto the oil pump along with the seal rings. Apply compressed air to the oil passage as shown.
2. Verify that the retaining plate moves toward the snap ring.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**

3. If not, the D-ring or the seal ring may be damaged or fluid may be leaking at the piston check ball. Inspect and replace as necessary when assembling



**Clearance between retaining plate and snap ring**


1. Measure the clearance between the retaining plate and the snap ring.

**Clearance: 0.50–1.20 mm {0.020–0.047 in}**


2. Select the correct retaining plate when assembling. (Refer to page K-68)

**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



- |                                   |   |
|-----------------------------------|---|
| 1. Snap ring                      | 7. Return springs                           |
| 2. Retaining plate                | Inspection ..... page K-66                  |
| 3. Drive plates and driven plates | 8. Clutch piston                            |
| Inspect for wear and burning      | Shake the clutch piston and verify that the |
| Inspection ..... page K-66        | check ball is free                          |
| 4. Dished plate                   | Disassembly Note ..... page K-66            |
| 5. Snap ring                      | Inspection ..... page K-66                  |
| Disassembly Note ..... page K-66  | 9. Seal ring                                |
| 6. Spring retainer                | 10. D-ring                                  |
|                                   | 11. Reverse clutch drum                     |




**Disassembly Note**  
Snap ring

**Caution**

- Depress the spring retainer only enough to remove the snap ring. Overpressing will damage the retainer assembly edges.


1. While holding the spring retainer down with the SSTs, remove the snap ring by using snap ring pliers.
2. Remove the spring retainer and return springs.



**Clutch piston**

1. Install the reverse clutch with seal rings onto the oil pump.
2. Remove the piston by applying compressed air through the oil passage.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**




**Inspection**  
Drive plates

1. Measure the facing thickness in three places, and calculate the average.

**Thickness**

**Standard: 2.0 mm {0.079 in}**  
**Minimum: 1.8 mm {0.071 in}**

2. If not within specification, replace the drive plate.




**Return springs**

1. Measure the spring free length.

**Specification**

Outerdia. mm {in}	Free length mm {in}	No. of coils	Wire dia. mm {in}
11.6 {0.457}	19.69 {0.775}	4.0	1.3 {0.051}


2. If not within specification, replace the return spring.




**Clutch piston**

1. Shake the clutch piston and verify that the check ball is free.
2. Verify that there is no air flow when applying compressed air through the oil hole on the clutch drum side.
3. Verify that there is air flow when applying compressed air through the oil hole on the return spring side.


**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**

**Assembly procedure**


1. Apply ATF to a new D-ring and install it into the clutch piston.




2. Apply ATF to a new seal ring and install it into the clutch piston.




3. Apply ATF to the inner face of the reverse clutch drum.  
 4. Apply even pressure to the perimeter of the clutch piston, and install it into the reverse clutch drum by turning it evenly and gradually.  
 5. Verify that the piston can be turned by hand.  
 If it cannot, then remove it and check for damage to the seal ring.




6. Install the return springs and spring retainer.

**Caution**


- Depress the spring retainer only enough to install the snap ring. Overpressing will damage the retainer assembly edges.




7. While holding the snap ring retainer down with the SSTs, install the snap ring into the spring retainer stopper.




8. Install the dished plate as shown in the figure.



- 9. Soak new drive plates in ATF for at least two hours.
- 10. Apply ATF to the driven plates immediately before assembly.
- 11. Install the drive and driven plates into the reverse clutch drum in the following order.  
Driven-Drive-Driven-Drive



- 12. Install the retaining plate.
- 13. Install the snap ring.



14. Measure the clearance between the retaining plate and the snap ring by using a feeler gauge.


**Clearance: 0.50–1.20 mm {0.020–0.047 in}**

15. If not within specification, adjust the clearance by selecting the correct retaining plate.

**Retaining plate size**


mm {in}

4.6 {0.181}	4.8 {0.189}	5.0 {0.197}	5.2 {0.205}
5.4 {0.213}	5.6 {0.220}	5.8 {0.228}	—



16. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates, and drive plates. Adjust the clearance by selecting the correct retaining plate.

**Clearance: 0.50–0.80 mm {0.020–0.031 in}**



**Caution**






- Applying compressed air to the assembled clutch pack for longer than 3 seconds at a time will damage the seal.


17. Install the reverse clutch with seal rings onto the oil pump. Apply compressed air through the oil passage and verify clutch operation.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**

### HIGH CLUTCH AND FRONT SUN GEAR

#### Preparation SST

<p>49 G019 0A7A Compressor set, return spring</p> 	<p>For removal / installation of snap ring</p>	<p>49 G019 025 Body B (Part of 49 G019 0A7A)</p> 	<p>For removal / installation of snap ring</p>
<p>49 G019 026 Plate (Part of 49G0190A7A)</p> 	<p>For removal / installation of snap ring</p>	<p>49 G019 027 Attachment A (Part of 49 G019 0A7A)</p> 	<p>For removal / installation of snap ring</p>
<p>49 G019 029 Nut (Part of 49 G019 0A7A)</p> 	<p>For removal / installation of snap ring</p>		



#### Preinspection

##### High clutch operation

1. Install the high clutch with seal rings onto the oil pump. Apply compressed air through the oil passage as shown.
2. Verify that the retaining plate moves toward the snap ring.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**


3. If not, the D-rings may be damaged or fluid may be leaking at the piston check ball. Inspect and replace as necessary when assembling.

##### Clearance between retaining plate and snap ring

1. Measure the clearance between the retaining plate and the snap ring.


**Clearance: 1.8–3.0 mm {0.071–0.118 in}**

2. Select the correct retaining plate when assembling. (Refer to page K-74.)




**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly procedure**.



- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Front sun gear<br/>Inspect gear teeth for damage, wear, and cracks</li> <li>2. Bearing race<br/>Inspect bearing surface for scoring and scratches</li> <li>3. Bearing<br/>Inspect for damage and rough rotation</li> <li>4. High clutch hub</li> <li>5. Bearing<br/>Inspect for damage and rough rotation</li> <li>6. Bearing race<br/>Inspect bearing surface for scoring and scratches</li> <li>7. Snap ring</li> <li>8. Retaining plate</li> <li>9. Drive plates and driven plates<br/>Inspect for wear and burning<br/>Inspection ..... page K-72</li> </ol> | <ol style="list-style-type: none"> <li>10. Snap ring<br/>Disassembly Note ..... page K-72</li> <li>11. Spring retainer</li> <li>12. Return springs<br/>Inspection ..... page K-72</li> <li>13. Clutch piston<br/>Shake the clutch piston and verify that the check ball is free<br/>Disassembly Note ..... page K-72<br/>Inspection ..... page K-72</li> <li>14. D-ring</li> <li>15. D-ring</li> <li>16. Bearing race<br/>Inspect bearing surface for scoring and scratches</li> <li>17. High clutch drum</li> </ol> |
|--|--|






**Disassembly note**  
**Snap ring**

**Caution**

- Depress the spring retainer only enough to remove the snap ring. Overpressing will damage the retainer assembly edges.


1. While holding the spring retainer down by using the SSTs, remove the snap ring by using snap ring pliers.
2. Remove the piston retainer and return springs.



**Clutch piston**

1. Install the high clutch with seal rings onto the oil pump.
2. Remove the piston by applying compressed air through the oil passage.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**




**Inspection**  
**Drive plates**

1. Measure the facing thickness in three places, and calculate the average.

**Thickness**

**Standard: 1.6 mm {0.063 in}**  
**Minimum: 1.4 mm {0.055 in}**

2. If not within specification, replace the drive plate.




**Return springs**

1. Measure the spring free length.

**Specification**

Outer dia. mm {in}	Free length mm {in}	No. of coils	Wire dia. mm {in}
11.6 {0.457}	22.3 {0.878}	5.2	1.2 {0.047}






2. If not within specification, replace the return spring.



**Clutch piston**

1. Shake the clutch piston and verify that the check ball is free.
2. Verify that there is no air flow when applying compressed air through the oil hole on the clutch drum side.
3. Verify that there is air flow when applying compressed air through the oil hole on the return spring side.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**



**Assembly procedure**

1. Apply ATF to new D-rings and install them into the clutch piston.


- 2. Apply ATF to the inner face of the high clutch drum.
- 3. Apply even pressure to the perimeter of the clutch piston, and install it into the reverse clutch drum by turning it evenly and gradually.
- 4. Verify that the piston can be turned by hand. If it cannot, then remove it and check for damage to the seal ring.

5. Install the return springs and spring retainer.


**Caution**

- Depress the spring retainer only enough to install the snap ring. Overpressing will damage the retainer assembly edges.


6. While holding the spring retainer down by using the SSTs, install the snap ring into the spring retainer stopper.



7. Soak new drive plates in ATF for at least two hours.
8. Apply ATF to the driven plates immediately before assembly.
9. Install the drive and driven plates into the high clutch drum in the following order.  
Driven-Drive-Driven-Driven-Drive-Driven-Driven-Drive-Driven-Driven-Drive



10. Install the retaining plate.
11. Install the snap ring.




12. Measure the clearance between the retaining plate and the snap ring by using a feeler gauge.

**Clearance: 1.8–3.0 mm {0.071–0.118 in}**

13. If not within specification, adjust the clearance by selecting the correct retaining plate.

### Retaining plate size

mm {in}		
3.4 {0.134}	3.6 {0.142}	3.8 {0.150}
4.0 {0.157}	4.2 {0.165}	—




14. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the driven plates and drive plates. Adjust the clearance by selecting the correct retaining plate.

**Clearance: 1.8–2.2 mm {0.071–0.087 in}**


### Caution

- Applying compressed air to the assembled clutch pack for longer than 3 seconds at a time will damage the seal.




15. Install the high clutch with the seal rings onto the oil pump. Apply compressed air through the oil passage and verify clutch operation.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**



16. Apply petroleum jelly to the bearing races and install them in the high clutch drum as shown.


**Bearing race outer diameter**  
**Front: 43.5 mm {1.71 in}**  
**Rear: 51.5 mm {2.03 in}**



17. Apply petroleum jelly to the bearing and install it in the high clutch hub as shown.

**Bearing outer diameter: 53.0 mm {2.09 in}**


18. Apply ATF to the high clutch hub, and install it in the high clutch drum by turning it evenly and gradually.



19. Apply petroleum jelly to the bearing and bearing race, and install them to the front sun gear.

**Bearing outer diameter: 53.0 mm {2.09 in}**  
**Bearing race outer diameter: 75.0 mm {2.95 in}**

20. Assemble the front sun gear, reverse clutch, high clutch, and high clutch hub.



### BAND SERVO

#### Preinspection

#### Band servo operation


1. Apply compressed air through the oil passage as shown.
2. Verify that the piston stem moves toward the brake band.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**


3. If not, the D-rings or the O-rings may be damaged or the piston assembly may be sticking. Inspect and replace as necessary when assembling.

### Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- |                                  |  |                           |
|----------------------------------|--|---------------------------|
| 1. Locknut                       | 9. Piston and servo piston<br>retainer | 15. Servo spring retainer |
| 2. Anchor end bolt               | Disassembly Note                       | 16. Band servo piston     |
| 3. Band strut                    | ..... below                            | 17. D-rings               |
| 4. Brake band                    | 10. Retaining ring (small)             | 18. Servo piston retainer |
| 5. Band servo retainer           | 11. Spring retainer                    | 19. O-rings               |
| 6. Gasket                        | 12. Return spring C                    | 20. Return spring B       |
| 7. Fourth gear band servo piston | Inspection ..... below                 | Inspection ..... below    |
| Disassembly Note                 | 13. Piston stem                        | 21. Return spring A       |
| ..... below                      | 14. Retaining ring (large)             | Inspection ..... below    |
| 8. D-ring                        |  |                           |



**Disassembly note**

**Piston and servo piston retainer**

Remove the piston and servo piston retainer from the transmission case by using a plastic hammer.




**4GR band servo piston**

1. Block one oil hole of the Fourth gear servo piston retainer and the center hole in the Fourth gear band servo piston.
2. Apply compressed air through the other oil hole in the Fourth gear servo piston retainer to remove the Fourth gear band servo piston.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**

3. Remove the D-ring from the Fourth gear band servo piston.



**Inspection**

**Return spring**

1. Measure the spring free length.


**Specification**


Item Spring	Outer dia. mm {in}	Free length mm {in}	No. of coils	Wire dia. mm {in}
Spring A	40.3 {1.59}	53.8 {2.12}	3.0	2.3 {0.091}
Spring B	34.3 {1.35}	45.6 {1.80}	3.0	2.3 {0.091}
Spring C	27.6 {1.09}	2.97 {1.17}	3.2	2.6 {0.102}

2. If not within specification, replace the return spring.


**Assembly procedure**

1. Apply ATF to new O-rings and install them onto the servo piston retainer.
2. Apply ATF to new D-rings and install them onto the band servo piston.






3. Apply ATF to the servo spring retainer and retaining ring (large). Assemble them in the band servo piston.




4. Assemble the band servo piston, piston stem, return spring, and spring retainer.

5. Install the retaining ring (small).




6. Apply ATF to the band servo piston assembly.

7. Apply even pressure to the perimeter of the piston, and install it onto the servo piston retainer.




8. Apply ATF to a new D-ring and install it onto the Fourth gear band servo piston.




9. Apply ATF to the Fourth gear band servo piston.


10. Apply even pressure to the perimeter of the piston, and install it into the band servo retainer.



11. Install return springs A and B.
12. Apply ATF to the piston assembly.
13. Apply even pressure to the perimeter of the piston assembly, and install it into the transmission case.




14. Apply ATF to the band servo retainer and a new gasket, and install them on the transmission case.




15. Tighten the bolts evenly and gradually in the order shown.

**Tightening torque:**  
 6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}




16. Verify servo piston operation by applying compressed air through the oil holes as shown.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**







### FRONT INTERNAL GEAR, REAR INTERNAL GEAR, FORWARD CLUTCH HUB, OVERRUNNING CLUTCH HUB


#### Preinspection

#### Forward one-way clutch operation

1. While holding the forward clutch hub, verify that the rear internal gear rotates smoothly when turned clockwise and locks when turned counterclockwise.
2. If not as specified, replace the one-way clutch.


#### Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Inspect all parts and replace if necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




1. Front internal gear (with rear planetary carrier)  
Inspect gear teeth for damage, wear, and cracks  
Check rotation of pinion gears
2. Bearing race  
Inspect bearing surface for scoring and scratches
3. Bearing  
Inspect for damage and rough rotation
4. Rear internal gear  
Inspect gear teeth for damage, wear, and cracks

5. Thrust washer
6. Bearing  
Inspect for damage and rough rotation
7. Overrunning clutch hub
8. Thrust washer
9. Snap ring
10. Forward one-way clutch  
Inspection ..... page K-80
11. Snap ring
12. Forward clutch hub




**Assembly procedure**


1. Install the snap ring into the forward clutch hub.
2. Apply ATF to the forward one-way clutch. Install it into the forward clutch hub, with the flange facing upward.



3. Apply petroleum jelly to the thrust washer, and set it so that the tabs fit in the holes of the rear internal gear.




4. Apply ATF to the rear internal gear, and install it in the forward clutch hub by turning it evenly and gradually.
5. Hold the forward clutch hub and verify that the rear internal gear turns counterclockwise. If it does not, then the one-way clutch is installed upside down.




6. Apply petroleum jelly to the bearing, and install it on the rear internal gear.


**Bearing outer diameter: 78.0 mm {3.07 in}**



7. Apply petroleum jelly to the thrust washer, and set it so that the tabs fit in the holes of the overrunning clutch hub.




8. Set the overrunning clutch hub on the rear internal gear.



9. Apply petroleum jelly to the bearing, and set it on the overrunning clutch hub.

**Bearing outer diameter: 59.0 mm {2.32 in}**










10. Apply petroleum jelly to the bearing race, and set it on the front internal gear.

**Bearing race outer diameter: 75.0 mm {2.95 in}**

**FORWARD CLUTCH DRUM  
(FORWARD CLUTCH, OVERRUNNING CLUTCH, LOW ONE-WAY CLUTCH)**

**Preparation  
SST**


<p>49 G019 0A7A Compressor set, return spring</p> 	<p>For removal / installation of snap ring</p>	<p>49 G019 025 Body B (Part of 49 G019 0A7A)</p> 	<p>For removal / installation of snap ring</p>
<p>49 G019 026 Plate (Part of 49 G019 0A7A)</p> 	<p>For removal / installation of snap ring</p>	<p>49 G019 027 Attachment A (Part of 49 G019 0A7A)</p> 	<p>For removal / installation of snap ring</p>
<p>49 G019 029 Nut (Part of 49 G019 0A7A)</p> 	<p>For removal / installation of snap ring</p>	<p>49 L019 001 Bolt</p> 	<p>For removal / installation of snap ring</p>



**Preinspection**

**Low one-way clutch operation**

1. Install the forward clutch drum into the transmission case.
2. Verify that the forward clutch drum rotates smoothly when turned clockwise, and locks when turned counterclockwise.
3. If not, replace the one-way clutch.




**Forward clutch and overrunning clutch operation**

1. Install the forward clutch drum and low one-way clutch inner race into the transmission case. Apply compressed air through the oil passage as shown.
2. Verify that the retaining plates move toward the snap rings.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**

3. If not, the D-rings or the seal ring may be damaged or fluid may be leaking at the piston check ball. Inspect and replace as necessary when assembling.



### Clearance between retaining plate and snap ring

1. Measure the clearance between the retaining plate and the snap ring of the forward clutch and the overrunning clutch.

### Clearance


**Forward clutch:** 0.45–1.85 mm {0.018–0.073 in}

**Overrunning clutch:** 1.0–2.0 mm {0.039–0.079 in}


2. Select the correct retaining plate when assembling.  
(Refer to pages K-89, 90.)

### Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



- 1. Snap ring
- 2. Snap ring
- 3. Retaining plate
- 4. Drive plates and driven plates  
Inspect for wear and burning  
Inspection ..... page K-86
- 5. Dished plate
- 6. Snap ring
- 7. Retaining plate
- 8. Drive plates and driven plates  
Inspect for wear and burning  
Inspection ..... page K-86
- 9. Dished plate
- 10. Snap ring  
Disassembly Note ..... below
- 11. Spring retainer and return springs  
Inspection ..... page K-86
- 12. Forward clutch piston  
Disassembly Note ..... below
- 13. Seal ring
- 14. D-ring
- 15. Overrunning clutch piston  
Shake the clutch piston and verify that the  
check ball is free  
Disassembly Note ..... below  
Inspection ..... page K-86
- 16. D-ring
- 17. D-ring
- 18. Snap ring
- 19. Side plate
- 20. Low one-way clutch  
Inspection ..... page K-83
- 21. Snap ring
- 22. Bearing (radial bearing)  
Inspect for damage and rough rotation
- 23. Forward clutch drum  
Inspection ..... page K-86




**Disassembly note**  
**Snap ring**  
 1. Assemble the SST.



**Caution**  
 • Depress the spring retainer only enough to install the snap ring. Overpressing will damage the retainer assembly edges.


- 2. While holding the spring retainer down with the SSTs, and remove the snap ring by using snap ring pliers.
- 3. Remove the spring retainer and return springs.



**Forward clutch piston, Overrunning clutch piston**  
 1. Set the forward clutch drum in the transmission case.  
 2. Remove the piston by applying compressed air through the oil passage.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**

- 3. Remove the overrunning clutch piston from the forward clutch piston.



### Inspection

#### Drive plates

1. Measure the facing thickness in three places, and calculate the average.


#### Forward clutch

Standard: 2.0 mm {0.079 in}  
 Minimum: 1.8 mm {0.071 in}

#### Overrunning clutch

Standard: 2.0 mm {0.079 in}  
 Minimum: 1.8 mm {0.071 in}

2. If not within specification, replace the drive plate.




### Return springs

1. Measure the spring free length.

### Specification

Outer dia. mm {in}	Free length mm {in}	No. of coils	Wire dia. mm {in}
9.7 {0.38}	35.8 {1.41}	10.3	1.3 {0.051}


2. If not within specification, replace the return spring.



### Overrunning clutch piston

1. Shake the clutch piston and verify that the check ball is free.
2. Verify that there is no air flow when applying compressed air through the oil hole on the clutch drum side.
3. Verify that there is air flow when applying compressed air through the oil hole on return spring side.


**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**



### Forward clutch drum


1. Verify that there is no air flow when applying compressed air through the oil hole on the front side.
2. Verify that there is airflow when applying compressed air through the oil hole on the rear side.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**




### Assembly procedure


1. Apply ATF to the bearing and install it into the forward clutch drum.
2. Install the snap ring.




3. Apply ATF to the low one-way clutch. Install it carefully into the forward clutch drum, with the flange facing upward.




4. Apply ATF to the side plate and snap ring, and install them into the forward clutch drum.



5. Apply ATF to a new D-ring and seal ring, and install them into the forward clutch piston as shown.




6. Apply ATF to the new D-rings, and install them to the over-running clutch piston as shown.




7. Apply ATF to the inner face of the forward clutch drum and to the forward clutch piston.
8. Apply even pressure to the perimeter of the forward clutch piston, and install it into the forward clutch drum by turning it evenly and gradually. Align the notches in the forward clutch piston with the grooves in the forward clutch drum.
9. Verify that the piston can be turned by hand. If it cannot, then remove it and check for damage to the seal ring.






10. Apply ATF to the inner face of the forward clutch piston and to the overrunning clutch piston.
11. Apply even pressure to the perimeter of the overrunning clutch piston, and install it into the forward clutch piston by turning it evenly and gradually.




12. Install the return springs and spring retainer.




**Caution**


- Depress the spring retainer only enough to install the snap ring. Overpressing will damage the retainer assembly edges.




13. While holding the spring retainer down with the SSTs, install the snap ring into the spring retainer stopper.



14. Install the dished plate as shown.
15. Soak new drive plates in ATF for at least two hours.
16. Apply ATF to the driven plates immediately before assembly.
17. Install the drive and driven plates into the forward clutch piston in the following order.  
Driven-Drive-Driven-Driven-Drive-Driven-Driven-Drive



- 18. Install the retaining plate.
- 19. Install the snap ring.



- 20. Measure the clearance between the retaining plate and the snap ring by using a feeler gauge


**Clearance: 1.0–2.0 mm {0.039–0.079 in}**

- 21. If not within specification, adjust the clearance by selecting the correct retaining plate.

**Retaining plate size**


mm {in}

4.0 {0.157}	4.2 {0.165}	4.4 {0.173}	4.6 {0.181}
4.8 {0.189}	5.0 {0.197}	5.2 {0.205}	—




- 22. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates, and drive plates. Adjust the clearance by selecting the correct retaining plate.


**Clearance: 1.0–1.4 mm {0.039–0.055 in}**



- 23. Install the dished plate as shown.
- 24. Soak new drive plates in ATF for at least two hours.
- 25. Apply ATF to the driven plates immediately before assembly.
- 26. Install the drive and driven plates into the forward clutch drum in the following order:  
Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive



- 27. Install the retaining plate.
- 28. Install the snap ring.




29. Measure the clearance between the retaining plate and the snap ring by using a feeler gauge. If not within specification, adjust the clearance by selecting the correct retaining plate.

**Clearance: 0.45–1.85 mm {0.018–0.073 in}**

### Retaining plate size


mm {in}

8.0 {0.315}	8.2 {0.323}	8.4 {0.331}	8.6 {0.339}
8.8 {0.346}	9.0 {0.354}	9.2 {0.362}	—




30. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates, and drive plates. Adjust the clearance by selecting the correct retaining plate.


**Clearance: 0.45–0.85 mm {0.018–0.033 in}**



31. Install the snap ring.

### Illustration of proper assembly




**Caution**

- Applying compressed air to the assembled clutch pack for longer than 3 seconds at a time will damage the seal.


32. Set the forward clutch drum in the transmission.
33. Apply compressed air through the oil passage as shown, and verify the forward clutch operation.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**




34. Apply compressed air through the oil passage, and check the overrunning clutch operation. Hold a paper towel around the nozzle of the air gun to keep air from escaping around the edges.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**




35. Verify that the forward clutch drum turns clockwise only. If it turns counterclockwise, the one-way clutch is installed upside down.

**LOW AND REVERSE BRAKE****Preinspection****Low and reverse brake operation**

1. Apply compressed air through the oil passage as shown.
2. Verify that the retaining plate moves toward the snap ring.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**

3. If not, the D-ring or the seal ring may be damaged or fluid may be leaking at the piston check ball. Inspect and replace as necessary when assembling.

**Clearance between retaining plate and snap ring**

1. Measure the clearance between the retaining plate and the snap ring.

**Clearance: 0.8–2.6 mm {0.031–0.102 in}**


2. Select the correct retaining plate when assembling. (Refer to page K-95.)

# K

## TRANSMISSION

### Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly note**.
2. Inspect all parts and replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



N·m {kgf·m, ft·lbf}

1. Snap ring
2. Retaining plate
3. Drive plates and driven plates  
Inspect for damage and burning  
Inspection ..... page K-93
4. Dished plate
5. Allen-head bolts and washers
6. Low one-way clutch inner race  
Disassembly Note ..... page K-93  
Inspection ..... page K-93
7. Bearing  
Inspect for damage and rough rotation


8. Seal rings
9. Thrust washers
10. Spring retainer
11. Return springs  
Inspection ..... page K-93
12. Low and reverse brake piston  
Shake the clutch piston and verify that the check ball is free  
Disassembly Note ..... page K-93
13. D-ring
14. Seal ring



**Disassembly note**

**Low one-way clutch inner race**


1. Loosen the bolts gradually in a crisscross pattern. Hold the inner race with your free hand so that it doesn't spring out as the last bolt is removed.
2. Remove the Allen-head bolts, washers, and low one-way clutch inner race.



**Low and reverse brake piston**

Remove the low and reverse brake piston by applying compressed air through the oil passage as shown.

**Air pressure: 390 kPa {4.0 kg/cm<sup>2</sup>, 57 psi} max.**



**Inspection**

**Drive plates**


1. Measure the facing thickness in three places, and calculate the average.

**Thickness**

**Standard: 2.0 mm {0.079 in}**

**Minimum: 1.8 mm {0.071 in}**

2. If not within specification, replace the drive plate.




**Return springs**

1. Measure the spring free length.

**Specification**

Outer dia. mm {in}	Free length mm {in}	No. of coils	Wire dia. mm {in}
11.6 {0.457}	22.3 {0.878}	5.2	1.2 {0.047}

2. If not within specification, replace the return spring.



**Low one-way clutch inner race**


1. Apply petroleum jelly to new seal rings and install them to the one-way clutch inner race.
2. Measure the clearance between each seal ring and ring groove.

**Standard clearance:**

**0.10–0.25 mm {0.004–0.010 in}**


**Maximum clearance: 0.25 mm {0.010 in}**

3. If not within specification, replace the low one-way clutch inner race.




**Assembly procedure**


1. Apply ATF to a new D-ring and seal ring and install them to the low and reverse brake piston.




- 2. Apply ATF to the inner face of the transmission case.
- 3. Apply even pressure to the perimeter of the low and reverse brake piston, and install it into the transmission case by turning it evenly and gradually.
- 4. Verify that the piston can be turned by hand. If it cannot, then remove it and check for damage to the seal ring.



5. Set the return springs, spring retainer, and low one-way clutch inner race into the transmission case.




6. Verify that the return springs, spring retainer, and low one-way clutch inner race are properly positioned.




7. Tighten the Allen-head bolts evenly and gradually in the order shown.

**Tightening torque:**


21-26 N·m {2.1-2.7 kgf·m, 16-19 ft·lbf}




8. Install the dished plate as shown.



- 9. Soak new drive plates in ATF for at least two hours before installation.
- 10. Apply ATF to the driven plates immediately before assembly.
- 11. Install the drive and driven plates into the transmission case in the following order.  
Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive



- 12. Install the retaining plate.
- 13. Install the snap ring.




14. Measure the clearance between the retaining plate and the snap ring by using a feeler gauge. If not within specification, adjust the clearance by selecting the correct retaining plate.

**Clearance: 0.8–2.6 mm {0.031–0.102 in}**

**Retaining plate size**


			mm {in}
6.2 {0.244}	6.4 {0.252}	6.6 {0.260}	6.8 {0.268}
7.0 {0.276}	7.2 {0.283}	7.4 {0.291}	7.6 {0.299}
7.8 {0.307}	8.0 {0.315}	—	—



15. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by selecting the correct retaining plate.

**Clearance: 0.8–1.2 mm {0.031–0.047 in}**




**Caution**

- Applying compressed air to the assembled clutch pack for longer than 3 seconds at a time will damage the seal.


16. Verify operation of the piston by applying compressed air through the oil passage of the low and reverse brake as shown.

**Air pressure: 390 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**




17. Apply petroleum jelly to the bearing, and install it on the low one-way clutch inner race with the black surface facing downward.

**Bearing outer diameter: 78.1 mm {3.07 in}**



18. Apply petroleum jelly to the seal rings, and fit them into the ring grooves of the low one-way clutch inner race.










19. Apply petroleum jelly to the bearing, and install it onto the low one-way clutch inner race.

**Bearing outer diameter: 59.0 mm {2.32 in}**


EXTENSION HOUSING / PARKING MECHANISM

Preparation  
SST


<p>49 G017 5A0 Support, engine</p> 	<p>For support of engine</p>	<p>49 G017 501 Bar (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>
<p>49 G017 502 Support (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>	<p>49 G017 503 Hook (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>
<p>49 G030 795 Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 G030 797 Handle (Part of 49 G030 795)</p> 	<p>For installation of oil seal</p>
<p>49 F019 001 Installer, oil seal</p> 	<p>For installation of oil seal</p>		

### Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.




- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Extension housing</li> <li>2. Parking gear<br/>Inspect gear teeth for damage and wear<br/>Inspect bearing for rough rotation</li> <li>3. Output shaft<br/>Inspect splines for damage and wear</li> <li>4. Parking pawl spacer</li> <li>5. Return spring</li> <li>6. Parking pawl</li> <li>7. Parking pawl shaft</li> <li>8. Parking actuator</li> <li>9. Locknuts</li> <li>10. Manual plate</li> </ol> | <ol style="list-style-type: none"> <li>11. Parking rod</li> <li>12. Roll pin</li> <li>13. Manual shaft</li> <li>14. Spacer</li> <li>15. Detent spring<br/>Inspect for fracture and wear</li> <li>16. Oil seal (extension housing)</li> <li>17. Transmission case<br/>Inspection<br/>a) Damage and wear of oil seal<br/>Disassembly Note ..... below<br/>b) Damage and rough rotation of inner bearing</li> </ol> |
|--|--|




#### Disassembly note

##### Oil seal (transmission side)

Remove the oil seal, being careful to not allow any metal tools to scratch the inside of the transmission case.

**Assembly procedure**


1. Apply ATF to the lip of the new oil seal.
2. Install the oil seal by using the SSTs.




3. Apply ATF to the parking rod guide and parking actuator and install them in the extension housing.

**Tightening torque:**


24–29 N·m {2.4–3.0 kgf·m, 18–21 ft·lbf}




4. Apply ATF to the parking pawl shaft and install it in the extension housing.
5. Apply ATF to the parking pawl, return spring, and spacer. Install them in the extension housing.




6. Wrap the threads of the manual shaft with tape.
7. Apply ATF to the lip of a new oil seal and install it onto the manual shaft.



8. Apply ATF to the bearing in the transmission case.
9. Install the manual shaft into the transmission case.
10. Push the oil seal squarely into the transmission case.
11. Remove the tape.




12. Align the groove in manual shaft with the roll pin hole.  
Tap the roll pin into the case as shown in the figure.




13. Install the detent spring and spacer.

**Tightening torque:**  
**4.0–5.8 N·m {40–60 kgf·cm, 36–52 in·lbf}**




14. Install the manual plate and parking rod.



15. While holding the manual shaft as shown in the figure,  
tighten the locknuts.


**Tightening torque:**  
**30–39 N·m {3.0–4.0 kgf·m, 22–28 ft·lbf}**




16. Verify operation of the parking mechanism.

**On-Vehicle Removal / Installation**

1. Disconnect the negative battery cable.
2. Clean the transmission exterior thoroughly.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install the reverse order of removal, referring to **Installation Note**.
5. Perform the following after installation of the extension housing.
  - (1) Connect the negative battery cable.
  - (2) Check the ATF level and add ATF to specification, if necessary.




- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. Undercover (right and left)</li> <li>2. Center tunnel member</li> <li>3. Secondary air injection pipe</li> <li>4. Three-way catalyst assembly</li> <li>5. Front tunnel member</li> <li>6. Rear tunnel member</li> <li>7. Propeller shaft</li> </ol> | <ol style="list-style-type: none"> <li>8. Power plant frame (PPF)</li> <li>9. Front exhaust pipe bracket</li> <li>10. Vehicle speed sensor</li> <li>11. Vehicle speedometer sensor</li> <li>12. Solenoid valve connector</li> <li>13. Extension housing</li> </ol> |
|---|--|
- Removal / Installation ..... section L
- Removal Note ..... page K-102
- Installation Note ..... page K-102
- Installation Note ..... page K-102



### Removal note


#### Power plant frame (PPF)

1. Hold the engine by using the SST.



2. Hold the differential with the transmission jack.

3. Remove the PPF.



### Installation note

#### Extension housing

1. Install a new gasket on the transmission case.

2. Install the extension housing.


#### Bolt length (measured from below the head):

A: 30 mm {1.18 in}

B: 45 mm {1.77 in}


#### Tightening torque:

20–24 N·m {2.0–2.5 kgf·m, 15–18 ft·lbf}




#### Power plant frame (PPF)

1. Hold the differential at a 0° angle by using the transmission jack.




2. Hold the PPF in place with a new bolt and nuts.



3. Tighten the differential-side PPF installation bolt and nuts in the order A, B, C.

**Tightening torque:**

**A, C: 148–176 N·m {15.0–18.0 kgf·m, 109–130 ft·lbf}**  
**B: 75–93 N·m {7.6–9.5 kgf·m, 55–68 ft·lbf}**




4. Tighten the transmission-side PPF installation nuts in the order D, E.

**Tightening torque:**

**148–176 N·m {15.0–18.0 kgf·m, 109–130 ft·lbf}**

5. Remove the transmission jack.



6. Measure A as shown in the figure.

**Specification**

**Right side: 73.0 mm {2.87 in} min.**  
**Left side : 75.0 mm {2.95 in} min.**

**Note**

- When measuring with a straight edge placed on both the right and left sides, the clearance should be 74.0 mm {2.91 in} minimum.




7. If not within specification, readjust the PPF.



### OIL SEAL (EXTENSION HOUSING)


#### Preparation

#### SST

<p>40 G030 795</p> <p>Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>40 G030 797</p> <p>Handle (Part of 49 G030 795)</p> 	<p>For installation of oil seal</p>
<p>40 F019 001</p> <p>Installer, oil seal</p> 	<p>For installation of oil seal</p>		


## On-Vehicle Removal / Installation

1. Disconnect the negative battery cable.
2. Clean the transmission exterior thoroughly with a steam cleaner or cleaning solvents.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Perform the following after installation of the oil seal.
  - (1) Connect the negative battery cable.
  - (2) Check the ATF level and add ATF to specification, if necessary.




1. Undercover (right and left)
2. Center tunnel member
3. Secondary air injection pipe
4. Three-way catalyst assembly
5. Front tunnel member
6. Rear tunnel member

7. Propeller shaft  
Removal / Installation ..... section L
8. Oil seal  
Removal Note ..... page K-106  
Installation Note ..... page K-106

**Removal note****Oil seal**

Remove the oil seal, being careful to not allow any metal tools to scratch the extension housing or output shaft.

**Installation note****Oil seal**

1. Using the SST and a hammer, tap the new oil seal in evenly until the SST contacts the extension housing.
2. Coat the lip of the oil seal with ATF.

MEMO

### CONTROL VALVE BODY (DISASSEMBLY / INSPECTION)

#### Disassembly / Inspection

##### Caution


- Denting or scratching these components will reduce the ability of the transmission to shift properly. When handling these components or the valve body that contains them, be careful not to drop on hit them.

1. Disassemble in the order shown in the figure, referring to Disassembly Procedure.
2. Neatly arrange the removed parts to avoid confusing similar parts.
3. Inspect all parts and repair or replace as necessary.


##### Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.

4. Clean the removed parts with cleaning solvent, and dry them with compressed air. Clean out all holes and passages with compressed air.




- |  |   |
|--|---|
| <p>1. Lockup solenoid valve<br/>Inspect filter for clogging and damage<br/>Inspection ..... page K- 32</p> <p>2. Side plate</p> <p>3. Lockup control solenoid valve<br/>Inspect filter for clogging and damage<br/>Inspection ..... page K- 32</p> <p>4. Line pressure solenoid valve<br/>Inspect filter for clogging and damage<br/>Inspection ..... page K- 32</p> <p>5. Overrunning clutch, shift A, and shift B solenoid valves<br/>Inspect filter for clogging and damage<br/>Inspection ..... page K- 32</p> <p>6. Support plate</p> <p>7. Retaining bolts and nuts<br/>Installation position ..... page K-124</p> <p>8. Brackets<br/>Installation position ..... page K-123</p> | <p>9. Lower control valve body<br/>Disassembly / Inspection /<br/>Assembly ..... page K-120</p> <p>10. Steel balls<br/>Installation position ..... page K-123</p> <p>11. Upper gasket</p> <p>12. Separator plate<br/>Inspect fluid passages for clogging and damage</p> <p>13. Lower gasket</p> <p>14. Orifice check valve and spring</p> <p>15. Pilot filter<br/>Inspect for clogging and damage</p> <p>16. Accumulator filter<br/>Inspect for clogging and damage</p> <p>17. Manual valve<br/>Inspect for sticking, scoring, and scratches</p> <p>18. Upper control valve body<br/>Disassembly / Inspection /<br/>Assembly ..... page K-112</p> |
|--|---|




**Disassembly procedure**

1. Remove the lockup solenoid valve and side plate from the lower control valve body.




2. Remove the O-ring from the lockup solenoid valve.




3. Remove the lockup control solenoid valve from the lower control valve body.
4. Remove the O-ring from the lockup control solenoid valve.

# K


## TRANSMISSION




5. Remove the line pressure solenoid valve from the upper control valve body.
6. Remove the O-ring from the line pressure solenoid valve.




7. Remove the solenoids from the upper control valve body.
8. Remove the O-rings from the solenoids.




9. Remove the support plates.
10. Remove the bolts, nuts, and brackets.




11. Separate the lower control valve body, lower and upper gaskets, and separator plate assembly from the upper control valve body.




12. Remove the steel balls from the upper control valve body.



- 13. Face the lower control valve body downward.
- 14. Remove the separator plate and gaskets.



- 15. Remove the orifice check valve, spring, pilot filter, and accumulator filter.



- 16. Remove the manual valve from the lower control valve body.



### UPPER CONTROL VALVE BODY

#### Disassembly / Inspection / Assembly

##### Caution

- Denting or scratching these precisely machined components will reduce the ability of the transmission to shift properly. When handling these components or the valve body that contains them, be careful not to drop or hit them.
- Using a magnet in this procedure could magnetize the valve body inner components, reducing the ability of the transmission to shift properly.

##### Note

- If a valve does not slide out under its own weight, place the valve body open-side down and tap on the valve body lightly with a plastic hammer.

1. Disassemble in the order shown in the figure, noting the proper reassembly direction of the valves and internal parts.
2. Inspect all parts and repair or replace as necessary.


##### Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.


3. Clean all parts and bores with compressed air and apply ATF to them immediately before assembly.
4. Assemble in the reverse order of disassembly, referring to Assembly Procedure.



APPLY SPECIFIED ATF TO INDIVIDUAL PARTS




1. Retainer  
Disassembly Note ..... page K-114
2. Torque converter relief spring  
Inspection ..... page K-115
3. Torque converter relief valve  
Inspect for sticking, scoring, and scratches
4. Stopper pin  
Disassembly Note ..... page K-114
5. Pressure regulator sleeve
6. Pressure regulator plug  
Inspect for sticking, scoring, and scratches
7. Spring seat
8. Pressure regulator spring  
Inspection ..... page K-115
9. Pressure regulator valve  
Inspect for sticking, scoring, and scratches
10. Stopper pin  
Disassembly Note ..... page K-114
11. Pressure modifier plug
12. Pressure modifier spring  
Inspection ..... page K-115
13. Pressure modifier valve  
Inspect for sticking, scoring, and scratches
14. Stopper pin  
Disassembly Note ..... page K-114
15. Accumulator control plug
16. Accumulator control valve spring  
Inspection ..... page K-115
17. Accumulator control valve  
Inspect for sticking, scoring, and scratches
18. Accumulator control sleeve  
Inspect for sticking, scoring, and scratches
19. Stopper pin  
Disassembly Note ..... page K-114
20. Shuttle shift valve D plug
21. Shuttle shift valve D  
Inspect for sticking, scoring, and scratches
22. Shuttle shift valve D spring  
Inspection ..... page K-115
23. Retainer  
Disassembly Note ..... page K-114
24. Shift valve B spring  
Inspection ..... page K-115
25. Shift valve B  
Inspect for sticking, scoring, and scratches
26. Stopper pin  
Disassembly Note ..... page K-114
27. 4-2 sequence plug
28. 4-2 sequence valve  
Inspect for sticking, scoring, and scratches
29. 4-2 sequence spring  
Inspection ..... page K-115
30. Shift valve A spring  
Inspection ..... page K-115
31. Shift valve A  
Inspect for sticking, scoring, and scratches
32. Stopper pin  
Disassembly Note ..... page K-114
33. 4-2 relay plug
34. 4-2 relay valve  
Inspect for sticking, scoring and scratches
35. 4-2 relay spring  
Inspection ..... page K-115
36. Stopper pin  
Disassembly Note ..... page K-114
37. Overrunning clutch control plug
38. Overrunning clutch control spring  
Inspection ..... page K-115
39. Overrunning clutch control valve  
Inspect for sticking, scoring and scratches
40. Stopper pin  
Disassembly Note ..... page K-114
41. Overrunning clutch reducing plug
42. Overrunning clutch reducing valve  
Inspect for sticking, scoring and scratches
43. Overrunning clutch reducing spring  
Inspection ..... page K-115
44. Stopper pin  
Disassembly Note ..... page K-114
45. Shuttle shift valve S plug 1
46. Shuttle shift valve S plug 2
47. Shuttle shift valve S  
Inspect for sticking, scoring and scratches
48. Retainer  
Disassembly Note ..... page K-114
49. Pilot spring  
Inspection ..... page K-115
50. Pilot valve  
Inspect for sticking, scoring and scratches
51. Retainer  
Disassembly Note ..... page K-114
52. Lockup modifier spring  
Inspection ..... page K-115
53. Lockup modifier valve  
Inspect for sticking, scoring and scratches
54. Stopper pin  
Disassembly Note ..... page K-114
55. Lockup control sleeve
56. Lockup control plug  
Inspect for sticking, scoring and scratches
57. Lockup control valve  
Inspect for sticking, scoring and scratches
58. Lockup control spring  
Inspection ..... page K-115
59. Upper control valve body  
Inspect for damage and scoring



### Disassembly note


#### Stopper pin

1. Push the stopper pin out with a wire.
2. Depress and hold the plug or sleeve with a finger to prevent the valve from popping out.
3. Remove the stopper pin, and remove the valve and internal parts.



#### Retainer


1. Push the retainer out with a wire.
2. Hold the inside parts with a finger to prevent the valve from popping out.
3. Remove the retainer, the valve, and the internal parts.



#### Stopper pin

#### (4-2 sequence valve and 4-2 relay valve)

1. Push the stopper pin out with a wire.
2. Depress the plug with a vinyl-tape-wrapped 1.5 mm {0.059 in} diameter rod.
3. Remove the stopper pin, the valve, and the internal parts.




**Inspection  
Springs**

1. Measure the spring free length.
2. If not within specification, replace the spring.

**Specification**


Spring	Item	Outer dia. mm {in}	Free length mm {in}	No. of coils	Wire dia. mm {in}
Torque converter relief valve		9.2 {0.362}	38.3 {1.508}	14.2	1.5 {0.059}
Pressure regulator valve		14.0 {0.551}	29.0 {1.142}	5.6	1.6 {0.063}
Pressure modifier valve*	A	6.8 {0.268}	31.95 {1.258}	15.5	0.8 {0.031}
	B	6.9 {0.272}	32.6 {1.283}	13.2	0.8 {0.031}
	C	6.9 {0.272}	32.8 {1.291}	15.6	0.9 {0.035}
Accumulator control valve spring		10.5 {0.413}	17.0 {0.669}	4.3	0.5 {0.012}
Shuttle shift valve D		6.0 {0.236}	26.5 {1.043}	12.0	0.7 {0.028}
4-2 sequence valve		6.95 {0.274}	29.1 {1.146}	11.0	0.55 {0.022}
Shift valve B		7.0 {0.276}	25.0 {0.984}	9.5	0.65 {0.026}
4-2 relay valve		6.95 {0.274}	29.1 {1.146}	11.0	0.55 {0.022}
Shift valve A		7.0 {0.276}	25.0 {0.984}	9.5	0.65 {0.026}
Overrunning clutch control valve		7.0 {0.276}	23.6 {0.929}	7.9	0.6 {0.024}
Overrunning clutch reducing valve		7.0 {0.276}	32.5 {1.280}	12.6	0.85 {0.033}
Pilot valve		9.1 {0.358}	25.7 {1.012}	8.3	1.1 {0.043}
Lockup modifier valve		4.2 {0.165}	21.5 {0.846}	13.6	0.4 {0.016}
Lockup control valve		4.7 {0.185}	23.4 {0.921}	15.6	0.45 {0.018}

\* Either A, B, or C type spring is installed at shipment. Only A type spring is available for replacement.




**Assemble procedure**


1. Insert the torque converter relief valve and spring.




2. Install the retainer while compressing the spring.




3. Insert the pressure regulator valve, spring, spring seat, plug, and sleeve.




4. Insert the stopper pin while pushing the sleeve.




5. Insert the pressure modifier valve, spring, and plug.  
6. Insert the stopper pin while pushing the plug.




7. Align the tab of the sleeve with the plug notch.




8. Insert the accumulator control sleeve, valve, and spring.  
9. Insert the plug.  
10. Insert the stopper pin.




11. Insert the shuttle shift valve D spring, valve, and plug.
12. Insert the stopper pin while pushing the plug.




13. Insert the 4-2 sequence spring, valve, and plug.




14. Push in the plug with a vinyl-tape-wrapped 1.5 mm (0.059 in) diameter rod.
15. Insert the stopper pin.




16. Insert the 4-2 relay spring, valve, and plug.




17. Push in the plug with a vinyl-tape-wrapped 1.5 mm (0.059 in) diameter rod and insert the stopper pin.




- 18. Insert shift valve A and spring.
- 19. Insert shift valve B and spring.
- 20. Install the retainer while compressing the springs.




- 21. Insert the overrunning clutch control valve, spring, and plug.
- 22. Insert the stopper pin while pushing the plug.




- 23. Insert the overrunning clutch reducing spring, valve, and plug.
- 24. Insert the stopper pin while pushing the plug.




- 25. Insert the shuttle shift valve S, plug 2, and plug 1.
- 26. Insert the stopper pin.



- 27. Insert the lockup control spring, valve, plug, and sleeve.
- 28. Insert the stopper pin while pushing the sleeve.



29. Insert the lockup modifier valve and spring.  
30. Insert the retainer while pushing the spring.



31. Insert the pilot valve and spring.  
32. Insert the retainer while pushing the spring.



**LOWER CONTROL VALVE BODY****Disassembly / Inspection / Assembly****Caution**

- Denting or scratching these precisely machined components will reduce the ability of the transmission to shift properly. When handling these components or the valve body that contains them, be careful not to drop or hit them.
- Using a magnet in this procedure could magnetize the valve body inner components, reducing the ability of the transmission to shift properly.

1. Disassemble in the order shown in the figure, noting the proper reassembly direction of the valves and internal parts.
2. Inspect all parts and repair or replace as necessary.


**Warning**

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.


3. Clean all parts and bores with compressed air and apply ATF to them immediately before assembly.
4. Assemble in the reverse order of disassembly, referring to **Assembly Procedure**.



APPLY SPECIFIED ATF TO INDIVIDUAL PARTS



- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>1. Stopper pin<br/>Disassembly Note ..... page K-114</li> <li>2. Modifier accumulator plug</li> <li>3. Modifier accumulator spring<br/>Inspection ..... below</li> <li>4. Modifier accumulator valve<br/>Inspect for sticking, scoring and scratches</li> <li>5. Retainer<br/>Disassembly Note ..... page K-114</li> <li>6. 1st reducing spring<br/>Inspection ..... below</li> <li>7. 1st reducing valve<br/>Inspect for sticking, scoring and scratches</li> <li>8. Retainer<br/>Disassembly Note ..... page K-114</li> </ul> | <ul style="list-style-type: none"> <li>9. 3-2 timing valve<br/>Inspect for sticking, scoring and scratches</li> <li>10. Steel ball</li> <li>11. Stopper pin<br/>Disassembly Note ..... page K-114</li> <li>12. Servo charger plug</li> <li>13. Servo charger valve<br/>Inspect for sticking, scoring and scratches</li> <li>14. Servo charger spring<br/>Inspection ..... below</li> <li>15. Lower control valve body<br/>Inspect for damage and scoring</li> </ul> |
|--|---|




**Inspection  
Springs**

- 1. Measure the spring free length.
- 2. If not within specification, replace the spring.


**Specification**

Item	Outer dia. mm {in}	Free length mm {in}	No. of coils	Wire dia. mm {in}
Spring				
Modifier accumulator valve	9.8 {0.39}	30.5 {1.20}	8.75	1.3 {0.05}
1st reducing valve	6.8 {0.27}	25.4 {1.00}	12.5	0.8 {0.03}
Servo charger valve	6.5 {0.26}	33.2 {1.31}	12.0	0.5 {0.02}




**Assembly procedure**


- 1. Insert the servo charger spring, valve, and plug.
- 2. Insert the stopper pin while pushing the plug.



3. Insert the steel ball and 3-2 timing valve.
4. Insert the retainer.




5. Insert the 1st reducing valve and spring.
6. Insert the retainer while compressing the spring.




7. Insert the modifier accumulator valve, spring, and plug.
8. Insert the stopper key while pushing the plug.

Steel ball installation positions




Bracket installation positions










# K

## TRANSMISSION


### Bolt and nut installation positions




Identification letter	Bolt and nut	Length mm {in}	Torque specification N·m {kgf·cm, in·lbf}
A		65 {2.6}	6.9-8.8 {70-90, 61-78}
B		50 {2.0}	
C		40 {1.6}	
D		33 {1.3}	
E		27 {1.1}	
F		55 {2.2}	
G		45 {1.8}	

**CONTROL VALVE BODY (ASSEMBLY)****Assembly**


1. Verify that all parts are clean and free of dust and other small particles.
2. Apply ATF to all O-rings and gaskets.
3. Assemble as shown in the figure, referring to **Assembly Procedure**.




4. Install the steel balls and reamer bolts into their proper positions in the upper control valve body. (Refer to page K-123 for installation positions.)




5. Install the pilot filter, accumulator filter, orifice check valve, and spring into their proper positions in the lower control valve body.




6. Set the new upper and lower gaskets onto the lower valve body. Refer to the figure to distinguish the two gaskets.





7. Set the lower control valve body onto the upper control valve body.




8. Install the support plates as shown.

**Bolt length (measured from below bolt head):**

**A: 33 mm {1.3 in}**


**B: 27 mm {1.1in}**




9. Install the brackets in their proper positions.  
(Refer to page K-123 for installation positions.)
10. Install the bolts and nuts in their proper positions, and tighten the fasteners evenly and gradually. (Refer to page K-124 for installation positions.)

**Tightening torque:**


**6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}**




11. Install a new O-ring onto the lockup solenoid valve.



12. Install the lockup solenoid valve and side plate to the lower valve body, as shown in the figure.




**Tightening torque:**  
 9.9–12.7 N·m {100–130 kgf·cm, 87–112 in·lbf}




13. Install a new O-ring onto the lockup control solenoid valve.
14. Install the lockup control solenoid valve into the lower control valve body.

**Tightening torque:**  
 9.9–12.7 N·m {100–130 kgf·cm, 87–112 in·lbf}




15. Install the new O-rings onto the solenoids.
16. Install the solenoids into the upper control valve body.

**Tightening torque:**  
 6.9–9.8 N·m {70–100 kgf·cm, 61–86 in·lbf}




17. Install a new O-ring onto the line pressure solenoid valve.
18. Install the line pressure solenoid valve into the upper control valve body.

**Tightening torque:**  
 6.9–9.8 N·m {70–100 kgf·cm, 61–86 in·lbf}



19. Insert the manual valve.






### CONTROL VALVE BODY (ON-VEHICLE REMOVAL / INSTALLATION) On-vehicle Removal


#### Warning

- Be careful when draining; the ATF is hot.

1. Disconnect the negative battery cable.
2. Clean the transmission exterior thoroughly with a steam cleaner or cleaning solvents.
3. On level ground, jack up the vehicle and support it evenly on safety stands.
4. Loosen the oil pan bolts and drain the ATF into a suitable container.
5. Remove the oil pan and gasket.
6. Remove the magnet from the oil pan and examine any material found in the pan or on the magnet to determine the condition of the transmission.




7. Remove the clip.
8. Disconnect the lockup solenoid valve connector.




9. Remove the ATF thermosensor.

**Bolt length (measured from below bolt head):  
45 mm {1.8 in}**




10. Remove the oil strainer.


**Bolt length (measured from below bolt head):  
50 mm {2.0 in}**



11. Remove the O-ring from the oil strainer.



12. Separate the solenoid valve harness from the harness clip.




13. Remove bolts A and B and the brackets shown in the figure.

**Bolt length (measured from below bolt head):**


**A: 33 mm {1.3 in}**

**B: 45 mm {1.8 in}**




14. Remove the clip.

15. Disconnect the solenoid valve connectors.




16. Carefully remove the control valve body assembly and accumulator springs.

1-2 ACCUM. SPRING  
3-4/N-R ACCUM. SPRING    2-3 ACCUM. SPRING




17. If necessary, remove the solenoid valve harness from the transmission case.
18. Remove the O-ring from the solenoid valve harness.




### On-Vehicle Installation

1. Apply ATF to the new O-ring and install it onto the solenoid valve harness.
2. Install the solenoid valve harness into the transmission case.



3. Connect the solenoid valve connectors.
4. Install the clip.




5. Set the accumulator springs into the control valve body as shown.


### Spring specifications

mm {in}

Spring	Item	Outer dia.	Free length	No. of coils	wire dia.
3-4 / N-R accumulator piston		18.0 {0.71}	43.0 {1.69}	7.9	2.3 {0.091}
1-2 accumulator piston		29.3 {1.15}	45.0 {1.77}	3.8	3.7 {0.15}
2-3 accumulator piston		19.5 {0.77}	66.0 {2.60}	8.6	3.0 {0.12}



6. Verify that the manual valve and manual shaft are assembled correctly.
7. Set the control valve into the transmission case and secure it.



8. Install the A and B bolts and bracket as shown in the figure.


**Bolt length (measured from below bolt head):**

**A: 33 mm {1.3 in}**

**B: 45 mm {1.8 in}**

**Tightening torque:**

**6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}**



9. Apply ATF to a new O-ring and install it onto the oil strainer.


10. Install the oil strainer.

**Bolt length (measured from below bolt head):**


**50 mm {2.0 in}**

**Tightening torque:**

**6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}**



11. Secure the solenoid valve harness with the harness clip.




12. Install the ATF thermosensor.

**Bolt length (measured from below bolt head):**


**45 mm {1.8 in}**

**Tightening torque:**

**6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}**




13. Connect the lockup solenoid valve connector.
14. Install the clip.



15. Clean the oil pan and the magnet, and set the magnet into the oil pan.
16. Remove any old locking compound from the bolt holes.
17. Install a new gasket and the oil pan.
18. Tighten the new bolts evenly and quickly.

**Tightening torque:**  
**6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}**







19. Connect the negative battery cable.
20. Pour in ATF and verify that the ATF level is as specified. (Refer to page K-25.)

### TRANSMISSION UNIT (ASSEMBLY)

#### Preparation


#### SST

<p>49 0107 680A</p> <p>Engine stand</p> 	<p>For assembly of transmission</p>	<p>49 U019 0A0A</p> <p>Hanger set, transmission</p> 	<p>For assembly of transmission</p>
<p>49 H075 495B</p> <p>Body (Part of 49 U019 0A0A)</p> 	<p>For assembly of transmission</p>	<p>49 U019003</p> <p>Holder (Part of 49U019 0A0A)</p> 	<p>For assembly of transmission</p>

### Precaution

1. If the drive plates or brake band is replaced with new one(s), soak them in ATF for at least 2 hours before installation.
2. Before assembly, apply ATF to all seal rings, rotating parts, O-rings, D-rings and sliding parts.
3. All O-rings, D-rings, seals, and gaskets must be replaced with new ones included in the overhaul kit.
4. Use petroleum jelly, not grease, during reassembly.
5. When it is necessary to replace a bushing, replace the subassembly that includes that bushing.
6. Assemble the housing within 10 minutes after applying sealant, and allow it to cure at least 30 minutes after assembly before filling the transmission with ATF.

### Thrust washer, bearing, and bearing race locations




### Outer diameter of bearing and race

		1	2	3	4	5	6
Bearing	mm {in}	47.0 {1.85}	53.0 {2.09}	53.0 {2.09}	78.0 {3.07}	53.0 {2.09}	78.0 {3.07}
Race	mm {in}	43.5 {1.71}	51.5 {2.03}	—	75.0 {2.95}	—	75.0 {2.95}

		7	8
Bearing	mm {in}	59.0 {2.32}	64.0 {2.52}
Race	mm {in}	—	—


### Components 1



1. Accumulator  
2. Band servo

3. Low and reverse brake

Components 2




1. Oil pump
2. Input shaft
3. Brake band and strut
4. Reverse clutch
5. High clutch and front sun gear
6. Front planetary carrier
7. Rear sun gear
8. Snap ring
9. Speedometer drive gear
10. Steel ball

11. Snap ring
12. Parking gear and bearing
13. Snap ring
14. Output shaft
15. Front internal gear, rear internal gear, forward clutch hub, overrunning clutch hub
16. Forward clutch drum (forward clutch, overrunning clutch, low one-way clutch)




### Components 3




1. Park/neutral switch
2. Vehicle speed sensor
3. Vehicle speedometer sensor
4. Vehicle speed pulse generator
5. Torque converter
6. Converter housing


7. Oil pan
8. Oil strainer
9. Control valve body
10. Solenoid valve harness
11. Anchor end bolt and nut
12. Extension housing / Parking mechanism

**Assembly procedure**

1. Install the forward clutch drum while slowly turning it clockwise until its hub passes fully over the low one-way clutch inner race.




2. Verify that the forward clutch drum will turn only clockwise.



3. Verify that the bearing is installed on the rear of the overrunning clutch hub.


4. Install the overrunning clutch hub into the forward clutch drum.

5. Verify that the thrust washer is installed on the front of the overrunning clutch hub.




6. Install the rear internal gear and forward clutch hub assembly into the forward clutch drum.

7. Verify that the bearing is installed on the rear internal gear.




8. Measure the height difference between the forward clutch retaining plate and the top of the forward clutch hub.


**Height: 2.0–3.0 mm {0.079–0.118 in} approx.**




9. Verify that the bearing race is installed on the front internal gear (rear planetary carrier).
10. Install the front internal gear (rear planetary carrier) into the forward clutch assembly.



11. Insert the output shaft from the rear of the transmission case.




12. Push the output shaft slightly forward, and install a new snap ring on the shaft. Verify that the output shaft cannot be pulled from the rear of the transmission case.




13. Apply petroleum jelly to the bearing and install it to the transmission case with the black surface facing outward.


**Bearing outer diameter: 64.0 mm {2.52 in}**



14. Install the parking gear.
15. Pull the output shaft slightly back, and install a new snap ring on the shaft. Verify that the output shaft cannot be pulled from the front of the transmission case.




16. Install the steel ball and speedometer drive gear onto the output shaft.
17. Secure the speedometer drive gear with the snap ring.




18. Install a new gasket and the extension housing.

**Bolt length (measured from below bolt head):**  
**A: 30 mm {1.2 in}**  
**B: 45 mm {1.8 in}**

**Tightening torque:**  
**20–24 N·m {2.0–2.5 kgf·m, 15–18 ft·lbf}**




19. Install the rear sun gear into the rear planetary carrier with the oil grooves of the gear facing outward.




20. Apply petroleum jelly to the bearings and install them to the front planetary carrier. Install the rear bearing with the black surface facing outward.


**Bearing outer diameter**  
**Front: 78.0 mm {3.07 in}**  
**Rear: 53.0 mm {2.09 in}**




21. While rotating the forward clutch drum clockwise, install the front planetary carrier into the forward clutch drum.




22. Verify that the bearing race is installed on the front sun gear.
23. Install the reverse clutch, high clutch, and front sun gear assembly into the transmission case.
24. Verify that the bearing race is installed on the high clutch drum.




25. Adjust the total end play.
  - (1) Install a new oil pump gasket.



- (2) Measure height A by using vernier calipers and a straightedge.




- (3) Measure height B.




- (4) Apply petroleum jelly to the bearing and install it on the oil pump.

**Bearing outer diameter: 47.0 mm {1.85 in}**



(5) Measure height C.



(6) Calculate the total end play by using the formula below.

**Formula:  $T1 = A - B - C - 0.1 \text{ mm } \{0.004 \text{ in}\}$**

T1: Total end play

A: Distance between front of transmission case and bearing race on the high clutch drum

B: Distance between front of transmission case and oil pump gasket

C: Distance between upper surface of oil pump bearing and oil pump gasket contact surface.

0.1 mm {0.0039 in}: Amount of compression of new oil pump gasket


**Total end play:**

**0.25–0.55 mm {0.010–0.022 in}**

(7) If the total end play is not within specification, adjust it by selecting and installing the proper bearing race.

**Bearing race size**


			mm {in}
0.8 {0.031}	1.0 {0.039}	1.2 {0.047}	1.4 {0.055}
1.6 {0.063}	1.8 {0.071}	2.0 {0.079}	—




26. Adjust the reverse clutch end play.

(1) Install the thrust washer on the reverse clutch.

(2) Measure height E by using vernier calipers and a straightedge.



(3) Measure height B.



(4) Measure height F.

(5) Calculate the reverse clutch end play by using the formula below.

**Formula:  $T_2 = E - B - F - 0.1 \text{ mm } \{0.004 \text{ in}\}$**


**T<sub>2</sub>:** Reverse clutch end play

**B:** Distance between front of transmission case and oil pump gasket.

**E:** Distance between front of transmission case and thrust washer on the reverse clutch drum

**F:** Distance between reverse clutch thrust washer contact surface of oil pump and oil pump gasket contact surface

0.1 mm {0.0039 in}: Amount of compression of new oil pump gasket




**Reverse clutch end play:**

**0.55–0.90 mm {0.022–0.035 in}**


(6) If the reverse clutch end play is not within specification, adjust it by selecting and installing the proper thrust washer.

### Thrust washer size


				mm {in}
0.7 {0.028}	0.9 {0.035}	1.1 {0.043}	1.3 {0.051}	
1.5 {0.059}	1.7 {0.067}	1.9 {0.075}	—	




27. Apply ATF to the brake band and band strut, and install them into the transmission. Refer to page K-76 to adjust the brake band during transmission assembly.




28. Temporarily install a new anchor end bolt.



29. Apply ATF to the input shaft and install it into the transmission case.




30. Apply petroleum jelly to the oil pump assembly as shown.




31. Install the oil pump assembly into the transmission case by hand only, using two converter housing bolts as guides.

Height: 1.0 mm {0.039 in} approx.





32. Apply ATF to a new O-ring, and install it onto the input shaft.




33. Apply sealant lightly around the bolt holes as shown.






34. Remove the converter housing guide bolts.  
 35. Install the converter housing onto the transmission case, and tighten the bolts evenly in the order shown.

**Tightening torque:**  
 61–63 N·m {6.2–6.5 kgf·m, 45–47 ft·lbf}




36. Apply ATF to a new O-ring and install it onto the vehicle speed pulse generator.  
 37. Install a new gasket and the vehicle speed pulse generator.  
 38. Install new bolts and tighten them.

**Tightening torque:**  
 5.0–6.8 N·m {50–70 kgf·cm, 44–60 in·lbf}




39. Adjust the brake band.  
 (1) Tighten the anchor end bolt.

**Tightening torque:**  
 4.0–5.8 N·m {40–60 kgf·cm, 35–52 in·lbf}




- (2) Loosen the anchor end bolt 2.5 turns.  
 (3) Install the locknut.  
 (4) Hold the anchor end bolt and tighten the locknut.

**Tightening torque:**  
 32–42 N·m {3.2–4.3 kgf·m, 24–31 ft·lbf}




- 40. Apply ATF to a new O-ring and install it onto the vehicle speedometer sensor.
- 41. Install the vehicle speedometer sensor into the extension housing.

**Tightening torque:**  
 7.9–10.7 N·m {80–110 kgf·cm, 70–95 in·lbf}




- 42. Apply ATF to a new O-ring and install it onto the vehicle speed sensor.
- 43. Install the vehicle speed sensor into the extension housing.

**Tightening torque:**  
 5.0–6.8 N·m {50–70 kgf·cm, 44–60 in·lbf}



- 44. Apply ATF to a new O-ring and install it onto the solenoid valve harness.
- 45. Install the solenoid valve harness into the transmission case.




- 46. Install the accumulator spring into the accumulator piston.


**Spring specifications**

mm (in)


Spring	Item	Outer dia.	Free length	No. of coils	Wire dia.
3-4/N-R accumulator piston		18.0 {0.71}	43.0 {1.69}	7.9	2.3 {0.091}
1-2 accumulator piston		29.3 {1.15}	45.0 {1.77}	3.8	3.7 {0.15}
2-3 accumulator piston		19.5 {0.77}	66.0 {2.60}	8.6	3.0 {0.12}



- 47. Connect the solenoid valve connectors.
- 48. Install the clip.



49. Verify that the manual valve and manual shaft are assembled correctly.



50. Install the valve body assembly, and tighten the bolts evenly.


**Bolt length (measured from below bolt head):**

**A: 33 mm {1.3 in}**

**B: 45 mm {1.8 in}**

**Tightening torque:**

**6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}**



51. Apply ATF to a new O-ring and install it onto the oil strainer.


52. Install the oil strainer into the control valve body.

**Bolt length (measured from below bolt head):**


**50 mm {2.0 in}**

**Tightening torque:**

**6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}**




53. Secure the solenoid valve harness with the clips.




54. Install the ATF thermosensor as shown in the figure.

**Bolt length (measured from below bolt head):**  
45 mm {1.8 in}

**Tightening torque:**  
6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}



55. Connect the lockup solenoid valve connector.  
56. Install the clip.




57. Set the magnet into the oil pan.  
58. Remove any old locking compound from the bolt holes.  
59. Install a new gasket and the oil pan.  
60. Tighten the new bolts evenly and quickly.

**Tightening torque:**  
6.9–8.8 N·m {70–90 kgf·cm, 61–78 in·lbf}


61. Remove the transmission from the SSTs (transmission hanger).  
62. Install the connector brackets onto the extension housing.

**Tightening torque:**  
7.9–11.7 N·m {80–120 kgf·cm, 70–104 in·lbf}



63. Install the harness onto the connector bracket.  
64. Install and adjust the park/neutral switch.


- (1) Verify that the manual shaft is set at the L position (fully forward).
- (2) Install the park/neutral switch over the manual shaft and install new bolts.




- (3) Turn the manual shaft fully rearward, then return it 2 notches (N range position).
- (4) Insert a 4.0 mm {0.16 in} outer diameter pin through the holes of the park/neutral switch and the manual shaft lever.
- (5) Tighten the park/neutral switch retaining bolts.

**Tightening torque:**  
2.5–3.9 N·m {25–40 kgf·cm, 22–34 in·lbf}

- (6) Remove the pin.



65. Remove the transmission from the SST. If the torque converter is completely empty, hold it upright, and fill it with 2.0 L {2.1 US qt, 1.8 Imp qt} of ATF.
66. Install the torque converter to the transmission. Rotate the torque converter to align the splines.









67. Measure the installation depth of the torque converter by using vernier calipers and a straightedge.


**Specification: 29 mm {1.1in} min.**

**TRANSMISSION UNIT (INSTALLATION)**

**Preparation**

**SST**


<p>49 J019 002 Cap</p> 	<p>For prevention of ATF leakage</p>	<p>49 0877 435 Special wrench</p> 	<p>For loosening of torque converter installation bolts</p>
<p>49 G017 5A0 Support, engine</p> 	<p>For support of engine</p>	<p>49 G017 501 Bar (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>
<p>49 G017 502 Support (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>	<p>49 G017 503 Hook (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>



1. Install in the order shown in the figure, referring to Installation Note.
2. Fill the transmission with the specified ATF after installation.
3. Connect the negative battery cable.
4. Inspect the park/neutral switch operation. (Refer to page K-28).
5. Inspect the selector lever operation. (Refer to page K-164).
6. Inspect for oil leakage from the transmission.
7. Perform a road test. (Refer to page K-16).
8. Inspect the ATF level and condition. (Refer to page K-25).


TRANSMISSION

- |   |   |
|---|---|
| 1. Transmission<br>Installation Note ..... below                            | 12. Vehicle speed sensor connector                  |
| 2. Power plant frame (PPF)<br>Installation Note ..... below                 | 13. Park/neutral switch connector                   |
| 3. Torque converter bolts<br>Installation Note ..... page K-153             | 14. Front exhaust pipe                              |
| 4. Oil cooler hose  | 15. Propeller shaft<br>Installation ..... section L |
| 5. Oil filler tube (lower)  | 16. Cover   |
| 6. Oil filler tube (upper)  | 17. Rear tunnel member                              |
| 7. Service hole cover   | 18. Front tunnel member                             |
| 8. Selector rod (selector lever side)<br>Installation Note ..... page K-153 | 19. Three-way catalyst assembly                     |
| 9. Vehicle speedometer sensor connector                                     | 20. Secondary air injection pipe                    |
| 10. Solenoid valve connector  | 21. Center tunnel member                            |
| 11. Vehicle speed pulse generator connector                                 | 22. Starter   |
|   | 23. Undercover (right and left)                     |
|   | 24. ATF dipstick                                    |




**Installation note  
Transmission**

1. Set the transmission onto the transmission jack, paying special attention not to damage the oil pipes. Make sure that the torque converter side of the transmission is tilted slightly upward.
2. Mount the transmission to the engine.



3. Gradually tighten the mounting bolts.


**Tightening torque:**  
38-51N·m {3.8-5.3kgf·m, 28-38ft·lbf}




**Power plant frame (PPF)**

1. Hold the differential at a 0° angle by using the transmission jack.






2. Hold the PPF in place with a new bolt and nuts.



3. Tighten the differential-side PPF installation bolt and nuts in the order A, B, C.

**Tightening torque:**

**A, C: 148–176 N·m {15.0–18.0 kgf·m, 109–130 ft·lbf}**  
**B: 75–93 N·m {7.6–9.5 kgf·m, 55–68 ft·lbf}**




4. Tighten the transmission-side PPF installation nuts in the order D, E.

**Tightening torque:**

**148–176 N·m {15.0–18.0 kgf·m, 109–130 ft·lbf}**

5. Remove the transmission jack.




6. Place a straightedge on the flat area on the front/left edge of the tunnel mount (A) so that it passes under the PPF installation bolts.

Measure from the top of the straightedge to the PPF.

**Standard: 75.1 mm {2.96 in}**

**Acceptable: range : 70–77 mm {2.76–3.03 in}**


7. If the clearance is not within specification, readjust the PPF.

**Torque converter bolts**

1. Align the holes by turning the torque converter.
2. Lock the drive plate by using a screwdriver.
3. Hand-tighten the torque converter mounting bolts in a crisscross pattern, and then tighten them to the specified torque by using the SST.
4. Modify the torque converter tightening torque to allow for use of a torque wrench-SST combination. (Refer to section GI, "Torque Formulas".)
5. Tighten the torque converter installation bolts to the specified torque by using the SST.

**Tightening torque:**

35–49 N·m {3.5–5.0 kgf·m, 26–36 ft·lbf}

**Selector rod**


1. Install the selector rod.
2. Install the washer and a new spring pin as shown.

### OIL COOLER


#### OIL COOLER

##### Removal / Inspection / Installation


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Add ATF to the specified level.
6. Connect the negative battery cable.
7. Inspect the oil leakage from the oil pipes and oil hoses.
8. Inspect the ATF level and condition. (Refer to page K-25.)




- |   |   |
|---|---|
| 1. Air duct   | 5. Oil pipes<br>Inspect for damage and cracks |
| 2. Connector bolts<br>Inspect for or clogging                                       | 6. Oil cooler<br>Inspection ..... page K-155  |
| 3. Washers  | 7. Radiator<br>Service ..... section E        |
| 4. Oil hoses<br>Inspect for damage and cracks<br>Installation Note ..... page K-155 |   |

**Inspection****Oil cooler**

1. Inspect for cracks, damage, and water leakage, and replace as necessary.
2. Inspect for bent fins and repair with a screwdriver as necessary.


**Installation note****Oil hoses**

1. Align the marks, and slide the oil cooler hose onto the oil cooler pipe until it is fully seated as shown.




2. Install the hose clamp onto the hose at the center of the mark and at the angle shown. If reusing the oil hose, position the new hose clamp exactly into the mark left by the previous hose clamp.

3. Verify that the hose clamp does not interfere with any other parts.



### DRIVE PLATE


#### PREPARATION SST

49 1881 055A		For prevention of engine rotation
Stopper, counter weight		

### DRIVE PLATE


#### Removal / Inspection / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



- |                               |            |
|-------------------------------|------------|
| 1. Transmission               |            |
| Removal .....                 | page K- 42 |
| Installation .....            | page K-149 |
| 2. Drive plate mounting bolts |            |
| Removal Note .....            | page K-157 |
| Installation Note .....       | page K-157 |


- |                |  |
|----------------|--|
| 3. Adapter     |  |
| 4. Drive plate | Inspect for cracks and for ring gear wear and damage |



**Removal note**

**Drive plate mounting bolts**

1. Set the SST or equivalent against the drive plate.
2. Remove the drive plate.



**Installation note**

**Drive plate mounting bolts**


1. Set the SST or equivalent against the drive plate.
2. Tighten the drive plate installation bolts in two or three steps as shown.

**Tightening torque:**


**103–109 N·m {10.5–11.2 kgf·m, 76.0–81.0 ft·lbf}**

### SHIFT MECHANISM

#### SHIFT-LOCK SYSTEM COMPONENTS



## TROUBLESHOOTING Circuit Diagram



### Diagnosis chart

Problem	Possible cause	Action	Page	
Selector lever cannot be moved from P range with brake pedal depressed and ignition switch ON	MAIN 120A fuse burned	Replace	K-159	
	BTN 60A fuse burned	Replace	K-159	
	STOP 20A fuse burned	Replace	K-159	
	METER 15A fuse burned	Replace	K-159	
	Ignition switch system malfunction	<ul style="list-style-type: none"> <li>● Wire harness broken</li> <li>● Poor connection</li> </ul>	Repair or replace Connect firmly	K-159 K-159
	Ignition switch malfunction		Inspect and replace	section T*
	Stoplight switch system malfunction	<ul style="list-style-type: none"> <li>● Wire harness broken</li> <li>● Poor connection</li> </ul>	Repair or replace Connect firmly	K-159 K-159
	Stoplight switch remains OFF		Adjust or replace	section T*
	Shift-lock control system malfunction	<ul style="list-style-type: none"> <li>● Wire harness broken</li> <li>● Poor connection</li> <li>● P range switch remains OFF</li> <li>● Shift-lock control unit malfunction</li> <li>● Shift-lock solenoid malfunction</li> </ul>	Repair or replace Connect firmly Inspect and replace Inspect and replace Inspect and replace	K-159 K-159 K-162 K-162 K-162
	Misadjustment of selector lever or improper assembly of shift-lock solenoid		Adjust or repair	K-164

\* Refer to 1994 RX-7 Body Electrical Troubleshooting Manual.




# K

## SHIFT MECHANISM

Problem	Possible cause	Action	Page
Selector lever can be moved from P range with ignition switch ON, but without brake pedal depressed	Stoplight switch remains ON	Adjust or replace	section T*
	Shift-lock control system malfunction ● Shift-lock control unit malfunction	Inspect and replace	K-162
	Misadjustment of selector lever or improper assembly of Shift-lock solenoid	Adjust or repair	K-164
Selector lever can be moved from P range with ignition switch OFF and brake pedal depressed	Ignition switch malfunction	Inspect and replace	section T*
	Shift-lock control system malfunction ● Shift-lock control unit malfunction	Inspect and replace	K-162
	Misadjustment of selector lever or improper assembly of Shift-lock solenoid	Adjust or repair	K-164
Shift-lock solenoid operation heard when brake pedal depressed with ignition switch ON in other than P range	P range switch remains ON	Inspect and replace	K-162
	Misadjustment of selector lever or improper assembly of Shift-lock solenoid	Adjust or repair	K-164
Selector lever remains locked when emergency override button operated	Emergency override button not pushed fully down	Push down fully and hold emergency override button, and move selector lever	—
	Broken emergency override button	Replace	K-168
	Misadjustment of indicator panel	Adjust	K-165
Ignition key can be turned to lock position with selector lever in other than P range	MAIN 120A fuse burned	Replace	K-159
	BTN 60A fuse burned	Replace	K-159
	ROOM 10A fuse burned or not installed	Replace or install	K-159
	P range switch system malfunction ● Wire harness broken ● Poor connection	Repair or replace Connect firmly	K-159 K-159
	P range switch remains ON	Inspect and replace	K-162
	Key interlock solenoid malfunction ● Wire harness broken ● Poor connection ● Key interlock solenoid malfunction	Repair or replace Connect firmly Inspect and replace	K-159 K-159 K-162
	Key interlock resistor malfunction ● Wire harness broken ● Poor connection	Repair or replace Connect firmly	— —
	Key cylinder (push switch) malfunction ● Wire harness broken ● Poor connection	Inspect and replace Repair or replace Connect firmly	section T* K-159 K-159
	Central processing unit (CPU) malfunction	Inspect and replace	section T*
Ignition key cannot be turned to lock position with selector lever in P range	P range switch remains OFF	Inspect and replace	K-162
	Key interlock solenoid malfunction	Inspect and replace	K-162
	Key cylinder (push switch) malfunction	Inspect and replace	section T*
	Misadjustment of selector lever	Adjust	K-164


\* Refer to 1994 RX-7 Body Electrical Troubleshooting Manual



**SHIFT-LOCK**

**Inspection**


1. Turn the ignition switch to ON (engine off).
2. Verify that the selector lever is in P range.
3. Without the brake pedal depressed, verify that the selector lever cannot be shifted from P range.
4. Depress the brake pedal and verify that the selector lever can be shifted from P range.
5. If not as specified, check the Shift-lock control system connector terminal voltage and continuity. (Refer to page K-162)



**EMERGENCY OVERRIDE BUTTON**

**Inspection**



1. Turn the ignition switch to OFF.
2. Verify that the selector lever is in P range.
3. Without the brake pedal depressed, verify that the selector lever cannot be shifted from P range.
4. Insert the screwdriver provided in the tool kit into the emergency override hole and push down. Verify that the selector lever can be shifted from P range.
5. If not as specified, inspect and repair as necessary, referring to Troubleshooting. (Refer to page K-159.)



**KEY INTERLOCK**

**Inspection**

1. Turn the ignition switch ON (engine off).
2. Shift the selector lever to R range.
3. Verify that the ignition key cannot be turned to LOCK position.
4. Shift the selector lever to P range.
5. Verify that the ignition key can be turned to LOCK position.
6. If not as specified, inspect and repair as necessary, referring to Troubleshooting. (Refer to page K-159.)



### KEY INTERLOCK SOLENOID

#### Inspection

#### Terminal voltage

1. Remove the column cover.
2. Turn the ignition switch ON.
3. Measure the voltage between terminals B and a ground.


B+: Battery positive voltage

Selector lever position	Voltage
P range	B+
Except P range	0V

4. If not correct, check the key interlock solenoid continuity.

#### Continuity

1. Disconnect the negative battery cable and the key interlock solenoid connector.
2. Check continuity between terminals B and C.
3. If not correct, replace the key interlock solenoid.
4. Connect the key interlock solenoid connector.
5. Connect the negative battery cable.




#### Replacement

1. Disconnect the negative battery cable.
2. Remove the column cover.
3. Disconnect the key interlock solenoid connector.
4. Remove the screws and the key interlock solenoid.
5. Install the new key interlock solenoid and tighten the screws.

#### Tightening torque:

6.9–12.7 N·m {70–130 kgf·cm, 61–112 in·lbf}

6. Connect the key interlock solenoid connector.
7. Install the column cover.
8. Connect the negative battery cable.



### SHIFT-LOCK CONTROL SYSTEM


#### Inspection

1. Remove the console panel.
2. Shift the selector lever to P range.
3. Turn the ignition switch to ON (engine off), and check terminal voltages and continuity, referring to the chart below. When checking continuity between terminal J (harness side) and ground, disconnect the connector.

4. Turn the ignition switch OFF, and check continuity between terminal J and a ground, referring to the chart below.
5. If not as specified, repair the wire harness and/or replace the P range switch, shift-lock solenoid, and shift-lock control unit as an assembly.

B+: Battery positive voltage


Terminal	(-) terminal connected to	Measured value	Condition	Specification	
G	Ground	Voltage	Brake pedal released → depressed	0V → B+	
H	J	Continuity	P range	Selector lever push button released	No
				Selector lever push button depressed	Yes
			Except P range		Yes
I	Ground	Voltage	Ignition switch OFF → ON	0V → B+	
J	Ground	Continuity	Constant	Yes	




5. Install the console panel.
6. Verify correct operation of the shift-lock system. (Refer to page K-161.)






### Replacement

Replace the P range switch, shift-lock solenoid, and shift-lock control unit as an assembly if even one of them is not correct.



1. Disconnect the negative battery cable.
2. Remove the console panel and rear console.
3. Remove the indicator screws and lift up the indicator panel.
4. Disconnect the shift-lock control unit connector.
5. Pull the hold switch terminals and the position indicator light terminals out of the connector.
6. Remove the P range switch, shift-lock solenoid, and shift-lock control unit as an assembly.
7. Install the new P range switch, shift-lock solenoid, and shift-lock control unit as an assembly.
8. Insert the hold switch terminals and the position indicator light terminals into the connector.
9. Connect the shift-lock control unit connector.
10. Install and adjust the indicator panel. (Refer to page K-165.)
11. Install the console panel and rear console.
12. Connect the negative battery cable.
13. Verify correct operation of the shift-lock system. (Refer to page K-161.)





### SELECTOR LEVER

#### Inspection

1. Turn the ignition switch to ON (engine off).
2. With the brake pedal depressed, verify that there is a "click" at each range when shifted in the pattern shown.
3. Verify that the selector lever can only be shifted as shown.
4. Verify that there is a "click" at each range when shifted from P → L range.
5. Verify that the positions of the selector lever and the indicator are aligned.
6. If not as specified, adjust the indicator panel. (Refer to page K-165.)
7. Verify that the positions of the selector lever and the selector indicator light in the instrument cluster are aligned.
8. If not as specified, adjust the park/neutral switch. (Refer to page K-28.)
9. Verify that the vehicle operates correctly in the selected ranges.


#### Adjustment

1. Remove the console panel.
2. Remove the indicator screws and lift up the indicator panel.
3. Shift the selector lever to P range.
4. Loosen the locknut as shown.
5. Adjust the lever so that the clearance between the guide plate and the guide pin in P range is as shown.
6. Tighten the locknut.

#### Tightening torque:

20-28 N·m {2.0-2.9 kgf·m, 15-20 ft·lbf}

7. Move the selector lever to N and D ranges and verify that the clearance between the guide plate and the guide pin is the same at both positions.
8. If not as specified, readjust the lever.
9. Install and adjust the indicator panel. (Refer to page K-165.)
10. Install the console panel.
11. Connect the negative battery cable.

**Indicator panel adjustment**

1. Shift the selector lever to P range.
2. Align the alignment holes in the slider with the holes in the indicator panel.
3. Install a suitable heavy-gauge wire to hold the slider.
4. Tighten the indicator screws.


**Tightening torque:**

**2.0–2.9 N·m {20–30 kgf·cm, 18–26 in·lbf}**

5. Remove the wire.
6. Verify that the selector lever properly aligns with the indicator in each range.

### Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Connect the negative battery cable.
5. After installation, check the shift-lock, emergency override button, and key interlock operations.



1. Console panel

2. Spring pin

Removal Note ..... page K-167

Installation Note ..... page K-167

3. Wave washer


4. Washer

5. Selector lever


Inspection ..... page K-164

Adjustment ..... page K-164


Disassembly / Inspection /  
Assembly ..... page K-168

**Removal Note****Spring pin**

1. Shift the selector lever to L range.
2. Remove the spring pin and washer.
3. Remove the selector rod from the adjustment lever.

**Installation Note****Spring pin**

1. Shift the selector lever to L range.
2. Install the selector rod to the adjustment lever.
3. Install the washer and new spring pin as shown.



4. Tighten the selector lever bolt.

**Tightening torque:**

**6.9–9.8 N·m {70–100 kgf·cm, 61–86 in·lbf}**

5. Verify that the positions of the selector lever and the selector indicator light are aligned.




### Disassembly / Inspection / Assembly


#### Note

- The P range switch does not need to be removed unless necessary.

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.
4. If the adjustment lever locknut is loosened, adjust the selector lever after installation.  
(Refer to page K-164.)




- |  |            |
|--|------------|
| 1. Bushing                               |            |
| 2. Spacer                                |            |
| 3. Boot                                  |            |
| 4. Position indicator light              |            |
| 5. Indicator panel                       |            |
| Assembly Note                            | page K-170 |
| 6. Connector pin                         |            |
| Disassembly Note                         | page K-169 |
| 7. Selector lever knob                   |            |
| Disassembly Note                         | page K-169 |
| Assembly Note                            | page K-170 |
| 8. Shift-lock solenoid                   |            |
| Inspection                               | page K-162 |
| 9. Shift-lock control unit               |            |
| Inspection                               | page K-162 |
| 10. P range switch                       |            |
| Inspection                               | page K-162 |
| 11. Guide plate                          |            |
| 12. Spindle                              |            |
| Disassembly Note                         | page K-169 |
| Assembly Note                            | page K-169 |
| 13. Bushing                              |            |
| 14. Adjustment lever                     |            |
| 15. Selector lever                       |            |
| Inspection for smooth operation          |            |
| Inspection guide pin for damage and wear |            |
| 16. Selector lever bracket.              |            |




### Disassembly Note Connector pin

1. Insert a thin piece of metal from the terminal side of the connector, and press down the terminal locking top.
2. Pull the terminal out of the connector.




### Selector lever knob

1. Remove the screws from selector lever knob.
2. Remove the selector lever knob and sleeve.



### Spindle

1. Shift the selector lever to P range.
2. Secure the adjustment lever in a vise.
3. Remove the spindle nut.




### Assembly Note Spindle


1. Install the selector lever and spindle to the selector lever bracket.
2. Shift the selector lever to P range.
3. Place the adjustment lever in a vise and tighten the spindle nut.

### Tightening torque:


6.9–9.8 N·m {70–100 kgf·cm, 61–86 in·lbf}

4. Verify that the overlap of the guide pin and the lock lever is within specification with the selector lever pushed forward.



**Indicator panel**

1. Install the selector sleeve and the selector lever knob to the selector lever.
2. Position the hold switch harness as shown.
3. Insert the connector pin to the connector.
4. Shift the selector lever to P range.




5. Align the alignment holes in the slider with the holes in the indicator panel.
6. Install a suitable heavy-gauge wire to hold the slider.
7. Tighten the indicator screws.

**Tightening torque:**

**2.0–2.9 N·m {20–30 kgf·cm, 18–26 in·lbf}**

8. Remove the wire.
9. Verify that the selector lever properly aligns with the indicator in each range.

**Selector lever knob**

1. Apply locking compound to the screws.
2. Tighten the screws.


**Tightening torque:**

**1.5–2.9 N·m {15–30 kgf·cm, 14–26 in·lbf}**

## TROUBLESHOOTING GUIDE

## GENERAL NOTES


A problem with the Powertrain Control Module (Transmission) may be caused by the engine, the Powertrain Control Module (Transmission), the hydraulic control system, or the electronic control system. When troubleshooting, begin with those points which can be inspected quickly and easily. The recommended troubleshooting sequence is described below.

**Step 1: Self-diagnostic System Inspection**


Check for diagnostic trouble code(s) memorized in the Powertrain Control Module (Transmission) by using the Self-Diagnosis Checker. (Refer to page K-214.)

**Note**

- You can also check the flashing sequence of the HOLD indicator light for diagnostic trouble codes (Refer to page K-214)

**Step 2: Mechanical System Test**

- Check the engine stall speed, time lag, and line pressure. (Refer to page K-9.)
- Check the shift point, shift schedule, and shift shock (Refer to page K-16). Use the Powertrain Control Module (Transmission) when checking vehicle speed, engine speed, throttle opening (throttle position sensor voltage), and gear position

**Step 3: Road Test**

Check the shift point, shift schedule, and shift shock. (Refer to page K-16) For correct testing, the vehicle speed, engine speed, throttle opening (throttle sensor voltage), and gear position should be checked with the Engine Signal Monitor.

### QUICK DIAGNOSIS CHART

#### OUTLINE

The Quick Diagnosis Chart shows various problems and the various components that might be the cause of the problem.

1. Components indicated in the "Self-diagnosis" row of the QUICK DIAGNOSIS CHART (I) are diagnosed by the powertrain control module (Transmission) self-diagnosis function. **Self-Diagnosis Checker** can be used for easy retrieval of the service code numbers.
2. Components indicated in the "Adjustment" row of the QUICK DIAGNOSIS CHART (I) indicate that there is a possibility that the problem may be the result of an incorrect adjustment. Check the adjustment of each component, and readjust if necessary.
3. Input and output signals of the powertrain control module (Transmission) for the components indicated in the Engine Signal Monitor row of the QUICK DIAGNOSIS CHART (I) can be easily checked by using the **Engine Signal Monitor**.
4. Components indicated in the "Stall Test" row of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the stall test.
5. Components indicated in the "Time Lag Test" row of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the time lag test.
6. Components indicated in the "Line Pressure Test" row of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the row pressure test.
7. Components indicated in the "Road Test" row of the QUICK DIAGNOSIS CHART (I) can be checked for malfunction by observing the results of the road test.
8. QUICK DIAGNOSIS CHART (II) shows the relationship between the troubleshooting item and inspection point.

#### QUICK DIAGNOSIS CHART (I)

Possible parts and reference page	Preliminary										Electronic system																	
	K-25	K-164	section F	section G	K-9	K-12	K-14	K-16	K-28	section F	K-29	K-29	section G	K-31	K-32	K-32	K-32	K-33	K-32	K-32	K-32	K-30	K-35	section F	K-35	K-27	K-35	
Item	ATF level and condition	Selector lever	Idle speed and ignition timing	Ignition system and starter	Stall test	Time lag test	Line pressure test	Road test	Park/neutral switch	Throttle position sensor	Vehicle speed sensor (revolution sensor)	Vehicle speedometer sensor	Engine rpm signal	ATF thermosensor	Shift A solenoid valve	Shift B solenoid valve	Line pressure solenoid valve	Dropping resistor	Lockup solenoid valve	Lockup control solenoid valve	Overrunning clutch solenoid valve	Vehicle speed pulse generator	Inhibitor signal	Idle signal	4GR inhibit signal (ASC signal)	Hold switch	A/C signal	
Self-diagnosis																												
Adjustment	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>						<input type="checkbox"/>	<input type="checkbox"/>																		
Testers	Self-diagnosis Checker																											
	Engine Signal Monitor																											
Stall test																												
Time lag test																												
Line pressure test																												
Road test																												

QUICK DIAGNOSIS CHART (I)

Electronic system		Hydraulic control system		Powertrain		Possible parts and reference page		
	K-35		K-108		K-83		Item	
	K-35		K-58		K-80			
	K-35		K-58		K-83			
	K-35		K-58		K-83			
	K-35		K-58		K-83			
	K-34		K-58		K-91			
	K-35		K-58		K-76			
			K-76		K-60			
			K-60		K-253			
			K-57		K-64			
			K-64		K-70			
			K-70		K-83			
			K-83		K-80			
			K-80		K-83			
			K-83		K-83			
			K-91		K-91			
			K-76		K-76			
			K-97		K-97			
	Slip lockup signal		Control valve body		Forward clutch			
	Torque reduced signal		N-D accumulator		Forward one-way clutch			
	Reduce torque signal		1-2 accumulator		Overrunning clutch			
	Stoplight switch		2-3 accumulator		Low one-way clutch			
	Slip lockup OFF signal		3-4/N-R accumulator		Low and reverse brake			
	Water thermostat		Band servo		Brake band (and servo)			
	Barometric absolute pressure sensor		Oil pump		Parking mechanism			
	Mileage switch		Hydraulic circuit					
			Torque converter					
			Reverse clutch					
			High clutch					
			Forward clutch					
			Forward one-way clutch					
			Overrunning clutch					
			Low one-way clutch					
			Low and reverse brake					
			Brake band (and servo)					
			Parking mechanism					
							Self-diagnosis	
							Adjustment	
							Self-Diagnosis Checker	
							Engine Signal Monitor	
							Testers	
							Stall test	
							Time lag test	
							Line pressure test	
							Road test	

### QUICK DIAGNOSIS CHART (II-1)

Possible parts and reference page		Preliminary										Electronic system																	
		K-25	K-164	section F	section G	K-9	K-12	K-14	K-16	K-28	section F	K-29	K-29	section G	K-31	K-32	K-32	K-32	K-33	K-32	K-32	K-32	K-30	K-35	section F	K-35	K-27	K-35	
Troubleshooting item		ATF level and condition	Selector lever	Idle speed and ignition timing	Ignition system and starter	Stall test	Time lag test	Line pressure test	Road test	Park/neutral switch	Throttle position sensor	Vehicle speed sensor (revolution sensor)	Vehicle speedometer sensor	Engine rpm signal	ATF thermosensor	Shift A solenoid valve	Shift B solenoid valve	Line pressure solenoid valve	Dropping resistor	Lockup solenoid valve	Lockup control solenoid valve	Overrunning clutch solenoid valve	Vehicle speed pulse generator	Inhibitor signal	Idle signal	4GR inhibit signal (ASC signal)	Hold switch	AC signal	
6	Engine starts in other than P and N ranges		3		2						1																		
14	Engine stalls	Idle when shifted from N or P to other ranges		1						3	5													4	2				
18		On deceleration	1	2						4	6													5	3				
24	Engine rough	On deceleration	1	3				2			6							4	5										
25	Poor acceleration	Drive away	1			3	2	7	10	6	12				8	9	4	5										11	
26		On acceleration																											
30	Surges while cruising										1	3								4						2			
31	Lack of power	1			3	2	7	10	6	12					8	9	4	5										11	
32	Poor fuel economy								10	7	11		9	6	3	4				1	2	5			8	13	14		
40	Vehicle does not move in D, S, L, and/or R range		1	4			2	3		7									5	6									
	①	Vehicle does not move in D, S, and/or L range		1																									
	②	Vehicle does not move in D, and/or S range		1			2												3	4									
	③	Vehicle does not move in R range		1			2												3	4									
41	Vehicle moves in N range		1	3			2			6								4	5										
42	Vehicle moves in P range			1				2																					
43	Excessive creep			1	3	2	9	6										4	5				8	7					
44	No shift							1		5					2	3												4	
	①	Does not shift from 1st to 2nd								4					2	3												1	
	②	Does not shift from 2nd to 3GR								2						1													
	③	Does not shift from to 4GR														1													
	④	Does not shift from 4GR to 3GR						5	6		1	2	3									4				7	8		
	⑤	Does not shift from 4GR to 2nd, or 3GR to 2nd	1				6		2						3	4												5	
	⑥	Does not shift from 3GR to 1st, or 2nd to 1st	1				6		2						3	4												5	
45	Abnormal shift		1							2	3																		
	①	Shifts directly from 1st to 3GR	1																										
	②	Does not kickdown when accelerator is depressed in 4GR within kickdown range								1	2				3	4													
	③	Excessive engine speed when accelerated in 4GR due to delayed kickdown								2	1				3	4													
46	Frequent shifting									1																			
47	Shift point high or low									1	3	2																4	
48	No lockup								7	4	8	6	3						1	2					5				
49	No kickdown									1	5				2	3												4	

\* Numbers in ○ indicate the inspection sequence.

# QUICK DIAGNOSIS CHART

# K

## QUICK DIAGNOSIS CHART (II-1)

Electronic system				Hydraulic control system				Powertrain										Possible parts and reference page									
K-35	K-35	K-35	K-35	K-108	K-58	K-58	K-58	K-58	K-76	K-60	K-253	K-57	K-64	K-70	K-83	K-80	K-83			K-83	K-91	K-76	K-97				
Slip lockup signal	Torque reduced signal	Reduce torque signal	Stoplight switch	Slip lockup OFF signal	Water thermostswitch	Barometric absolute pressure sensor	Mileage switch	Control valve body	N-D accumulator	1-2 accumulator	2-3 accumulator	3-4/N-R accumulator	Band servo	Oil pump	Hydraulic circuit	Torque converter	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrunning clutch	Low one-way clutch	Low and reverse brake	Brake band (and servo)	Parking mechanism	Troubleshooting item	
																									Engine starts in other than P and N ranges	6	
					6									8	7										Idle when shifted from N or P to other ranges	14	
					7									9	8										On deceleration	18	
					7									10	9					8	12	11		On deceleration	24		
																									Drive away	25	
5					13							14	19	21	20	15	16					18	17		On acceleration	26	
					6									7	8										Surges while cruising	30	
					13							14	19	21	20	15	16					18	17		Lack of power	31	
						12						18	17	16									19		Poor fuel economy	32	
					8							9	10	18	14	17	11	16					13	12	15	Vehicle does not move in D, S, L, and/or R range	40
													3												Vehicle does not move in D, S, and/or L range	①	
					5								11	6	7	8					9	10		Vehicle does not move in D, and/or S range	②		
					5	6							12	7	8	9	10				11			Vehicle does not move in R range	③		
					7								11	10	8	9								Vehicle moves in N range	41		
																						3			Vehicle moves in P range	42	
					10																				Excessive creep	43	
					6							7	10		9									8	No shift	44	
					5							6	9	8									7	Does not shift from 1st to 2nd	①		
					3							4	7	6									5	Does not shift from 2nd to 3GR	②		
					2							3	7							5	6	4	Does not shift from to 4GR	③			
					9							10	12										11	Does not shift from 4GR to 3GR	④		
					7							9	11	8									10	Does not shift from 4GR to 2nd, or 3GR to 2nd	⑤		
					7							10	12	8						9	11		Does not shift from 3GR to 1st, or 2nd to 1st	⑥			
					4							5	7										6	Abnormal shift	45		
						2						3	5										4	Shifts directly from 1st to 3GR		①	
																								Does not kickdown when accelerator is depressed in 4GR with in kickdown range		②	
																								Excessive engine speed when accelerated in 4GR due to delayed kickdown		③	
					2								3											Frequent shifting	46		
					5																			Shift point high or low	47		
					9								11	10										No lockup	48		
					6																			No kickdown	49		



### QUICK DIAGNOSIS CHART (II-2)

Possible parts and reference page		Troubleshooting item		Preliminary		Electronic system																										
				K-25	K-164	section F	section G	K-9	K-12	K-14	K-16	K-28	section F	K-29	K-29	section G	K-31	K-32	K-32	K-32	K-33	K-32	K-32	K-32	K-30	K-35	section F	K-35	K-27	K-35		
				ATF level and condition	Selector lever	Idle speed and ignition timing	Ignition system and starter	Stall test	Time lag test	Line pressure test	Road test	Park/neutral switch	Throttle position sensor	Vehicle speed sensor (revolution sensor)	Vehicle speedometer sensor	Engine rpm signal	ATF thermosensor	Shift A solenoid valve	Shift B solenoid valve	Line pressure solenoid valve	Dropping resistor	Lockup solenoid valve	Lockup control solenoid valve	Overrunning clutch solenoid valve	Vehicle speed pulse generator	Inhibitor signal	Idle signal	4GR inhibit signal (ASC signal)	Hold switch	A/C signal		
50			When accelerating	1	3					2			6							4	5											
			When upshifting and/or downshifting	1	3		9		2				6	8						4	5			7								
	①	Engine speed flares up	During 1st to 2nd shifting	1	2		9		3				6	8						4	5			7								
	②		During 2nd to 3GR shifting	1	2		9		3					6	8						4	5			7							
	③		During 3GR to 4GR shifting	1	2		9		3					6	8						4	5			7							
	④		During 4GR, or 3GR to 2nd shifting	1	2		8		3					6							4	5			7							
	⑤		During 3GR, or 2nd to 1st shifting	1	2		9		3					6			8				4	5			7							
	⑥																															
52			P, N to R and/or N to D	1	2	4	3	10	7											5	6			9	8							
	①	Excessive shift shock	When upshifting and/or downshifting	1		3	2		6	10			8							4	5			9	7							
	②		During 1st to 2nd shifting			12	1		4	7			5								2	3			6							
	③		During 2nd to 3GR shifting			12	1		4	7			5								2	3			6							
	④		During 3GR to 4GR shifting			8	1		4	7			5								2	3			6							
	⑤		During 2nd to 1st shifting in L range			10	1		4	7			5								2	3			6							
	⑥		When coasting					2		5	8		6								3	4			1	7	9					
	⑦		During lockup	1										3	7	6							2		5	4						
	⑧																															
54	No engine braking			1								5	3											2					4			
55	No mode changes																													1		
56	Transmission noise	N and/or P ranges		1									4	5	6					2	3											
57		All ranges		1																												
58	Transmission overheats			1		3	2		6											4	5	7	8									
				2	1		4		7	10		9								5	6	3					8					
				3	2						1																					
											3															2	1					

\* Numbers in ○ indicate the inspection sequence.

# QUICK DIAGNOSIS CHART

# K

## QUICK DIAGNOSIS CHART (II-2)

Electronic system										Hydraulic control system							Powertrain										Possible parts and reference page			
K-35	K-35	K-35	K-35	K-35	K-34	K-35	K-35	K-108	K-58	K-58	K-58	K-58	K-58	K-76	K-60	K-253	K-57	K-64	K-70	K-83	K-80	K-83	K-83	K-91	K-76	K-97			Troubleshooting item	
Slip lockup signal	Torque reduced signal	Reduce torque signal	Stoplight switch	Slip lockup OFF signal	Water thermostat	Barometric absolute pressure sensor	Mileage switch	Control valve body	N-D accumulator	1-2 accumulator	2-3 accumulator	3-4/N-R accumulator	Band servo	Oil pump	Hydraulic circuit	Torque converter	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrunning clutch	Low one-way clutch	Low and reverse brake	Brake band (and servo)	Parking mechanism					
								7						13	15	14	11		8	9		10	12					When accelerating		50
								10	11	12	13	14			20				16	17	18		19	15			When upshifting and/or downshifting			
								10	11		12				14									13			During 1st to 2nd shifting	①		
								10	11			12			15			14						13			During 2nd to 3GR shifting	②		
								10				11			14			13						12			During 3GR to 4GR shifting	③	51	
								9							12			11						10			During 4GR, or 3GR to 2nd shifting			
								10							12									11			During 3GR, or 2nd to 1st shifting	④		
								11	12			13			17	15	14						16			P, N to R and/or N to D		52		
	11	12				13	14	15	16	17				21			20				19		18			When upshifting and/or downshifting				
	8	9				11	10	12		13				15									14			During 1st to 2nd shifting	①			
	8	9				11	10	12		13				16			15						14			During 2nd to 3GR shifting	②			
						9	10			11				14								13		12		During 3GR to 4GR shifting	③	53		
	8	9				11	12							14									13			During 2nd to 1st shifting in L range	④			
							10																			When coasting	⑤			
							8							10	9											During lockup	⑥			
							6							9								7	8			No engine braking		54		
																										No mode changes		55		
														7	8											N and/or P ranges	Transmission noise	56		
															2											All ranges		57		
							9							10	18	17	11	12	14		15		16	13		Transmission overheats		58		
							11								13	12														


### SYMPTOM TROUBLESHOOTING

#### USING THIS SECTION

##### Introduction

Most of the automatic transmission control system is electronically controlled, often making it difficult to diagnose problems in the system, especially intermittent problems. Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a drivability complaint. The customer is often a good source of information on such problems, especially intermittent ones. Through talks with the customer, one can find out what the symptoms are and under what conditions they occur.

##### Work Flow



#### Diagnostic Index

### K SYMPTOM TROUBLESHOOTING

#### DIAGNOSTIC INDEX

TROUBLESHOOTING ITEM		DESCRIPTION	PAGE
No.	TROUBLE		
1	Melts main or other fuse		Section F
2	Will not crank or cranks slowly	Starter does not work Starter cranks engine at slow speed	Section F
3	Cranks normally but will not start	No combustion Starter cranks engine at normal speed but engine shows no indication of firing	Section F
4		Partial combustion — when engine cold Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is cold or at initial starting Engine will not continue running when cold when ignition switch is returned from STA to IG position	Section F
5		Partial combustion — when warm-up Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is warm. Engine will not continue running when warm when IGN switch is returned from STA to IG position	Section F
6	Will start in other than P Cranks normally	Will start in other than P, N and other ranges Starter cranks engine at normal speed but engine does not start before starting of any	K-183 Section F



**No.:**  
Each troubleshooting item is assigned a number


**Troubleshooting Item:**  
There are 58 troubleshooting items. Choose the item that most closely corresponds to the actual symptom.

**Description:**  
Describes each troubleshooting item

**Page:**  
Shows the reference page.

Troubleshooting Chart

14		ENGINE STALLS IDLE WHEN SHIFTED FROM N OR P TO OTHER RANGES	
<b>DESCRIPTION</b>		• Engine stops unexpectedly when shifted from N or P to other ranges at idle	
<b>[TROUBLESHOOTING HINTS]</b>			
① Engine idle speed low		③ Inhibitor signal malfunction	
② Control valve stuck (lockup control valve, shuttle shift valve D, lockup modifier valve, or pilot valve)		④ Park/Neutral switch worn or misadjusted	
		⑤ Vehicle speed pulse generator malfunction	
		⑥ Vehicle speed sensor (revolution sensor) malfunction	
STEP	INSPECTION	ACTION	
1	Are ignition timing and idle speed OK?  Section F	Yes	Go to next step
	Ignition timing: Leading 5° ATDC, Trailing 20° ATDC Idle speed: 700–750 rpm (P range)	No	Adjust ignition timing and/or idle speed  Section F



**DESCRIPTION:**

Further describes the symptom. Confirm that the chart addresses the actual symptom before beginning troubleshooting.


**TROUBLESHOOTING HINTS:**

Describes the possible point of malfunction.


**STEP:**

Shows the order of troubleshooting. Proceed with troubleshooting as indicated.

**INSPECTION:**

Describes an inspection method to quickly determine the malfunction of parts. If a detailed procedure is necessary to perform the INSPECTION, refer to the page shown by the  mark.

**ACTION:**

Recommends the appropriate action to take as a result (Yes/No) of the INSPECTION. How to perform the action is described on the reference page shown by the  mark.

### DIAGNOSTIC INDEX

TROUBLESHOOTING ITEM		DESCRIPTION	PAGE
No.	TROUBLE		
1	Melts main or other fuse		section F
2	Will not crank or cranks slowly	Starter does not work Starter cranks engine at slow speed	section F
3	Cranks normally but will not start	No combustion	Starter cranks engine at normal speed but engine shows no indication of firing
4		Partial combustion - when engine cold	Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is cold or at initial starting Engine will not continue running when cold when ignition switch is returned from STA to IG position
5		Partial combustion - when warm-up	Starter cranks engine at normal speed and engine shows indication of firing but will not run when engine is warm. Engine will not continue running when warm when IGN switch is returned from STA to IG position
6	Will start in other than P and N ranges	Engine starts in P, N and other ranges	K-183
7	Cranks normally but hard to start	Any engine temp.	Starter cranks engine at normal speed but engine requires excessive cranking time before starting at any engine temperature Engine starts after stalling a few times at any engine temperature
8		When engine cold	Starter cranks engine at normal speed but engine requires excessive cranking time before starting when engine is cold Engine starts after stalling a few times when engine is cold
9		After warm-up	Starter cranks engine at normal speed but engine requires excessive cranking time before starting after warm-up
10	Engine stalls	Idle at any engine temp.	Engine stops unexpectedly at any engine temp.
11		During fast idle	Engine stops unexpectedly during fast-idle operation
12		Idle after warm-up	Engine stops unexpectedly at idle after warm-up
13		Idle with A/C, P/S, and/or E/L ON	Engine stops unexpectedly when A/C, P/S, and/or E/L turned ON at idle
* 14		Idle when shifted from N or P to other ranges	Engine stops unexpectedly when shifted from N or P to other ranges at idle
15		Driveway	Engine stops unexpectedly upon driveway
16		On acceleration	Engine stops unexpectedly at beginning of acceleration or during acceleration
17		While cruising	Engine stops unexpectedly while cruising
*18	On deceleration	Engine stops unexpectedly at beginning of deceleration or recovery from deceleration exhaust afterburn	
19	Engine rough	Idle at any engine temp.	Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at any engine temp. Idle speed too slow and excessive engine shake at any engine temp.
20		During fast idle	Fast idle speed too slow and excessive engine shake during fast idle, but returns to normal after warm-up
21		Idle after warm-up	Engine speed fluctuates between specified idle speed and lower speed and excessive engine shake at idle after warm-up

\* Refer to section F before referring to K sections.

# SYMPTOM TROUBLESHOOTING

# K

TROUBLESHOOTING ITEM		DESCRIPTION	PAGE
No.	TROUBLE		
22	Engine rough	Idle with A/C, P/S, and/or E/L ON	section F
23		Idle when shifted from N or P to other range	section F
* 24		On deceleration	section F K-187
* 25	Poor acceleration	Driveaway	section F K-189
* 26		On acceleration	
27	High idle speed after warm-up	Idle speed continues at fast idle after warm-up Engine returns slowly to idle after acceleration is released	section F
28	Idle fluctuates / Idle hants	Engine speed changes back and forth between specified idle speed and higher speed	section F
29	Hesitates / Stumbles on acceleration	Momentary pause at beginning of acceleration or during acceleration	section F
* 30	Surges while cruising	Momentary minor irregularity in engine output at steady vehicle speed	section F K-192
* 31	Lack of power	Performance poor under load (i.e., power down when climbing hills)	section F K-194
* 32	Poor fuel economy	Fuel economy unsatisfactory	section F K-194
33	A/C does not work	A/C compressor magnetic clutch does not engage when Air conditioning sensor ON	section F
34	Knocking / Pinging	Sound produced when air/fuel mixture is ignited by something other than spark plug (i.e., hot spot in combustion chamber)	section F
35	Fuel odor	Gasoline fuel smell or visible leaks	section F
36	Exhaust sulfur smell	Rotten egg smell from exhaust	section F
37	High oil consumption	Oil consumption excessive	section F
38	Self-Diagnosis Checker flashes 88	MIL always ON/Self-Diagnosis Checker flashes 88 with test connector ground	section F
39	MIL never ON	Self-Diagnosis Checker indicates diagnostic trouble code No. of input device but MIL never ON	section F
40	Vehicle does not move in D, S, L and/or R ranges	No creep at all Vehicle does not move when accelerator pedal depressed after shifted to D, S, L and/or R range	K-194
41	Vehicle moves in N range	Vehicle creeps in N range Vehicle moves when accelerator pedal not depressed	F-195
42	Vehicle moves in P range	Vehicle rolls in P range, and drivetrain not lockup	F-195
43	Excessive creep	Vehicle moves quickly in D, S, L and R ranges (accelerator pedal not depressed) Excessive N to R range and N to D range shift shock felt	F-195

\* Refer to section F before referring to K section.

## SYMPTOM TROUBLESHOOTING

TROUBLESHOOTING ITEM		DESCRIPTION	PAGE	
No.	TROUBLE			
44	No shift	With gear position in hold mode: Single range shift (1st → 2nd, 2nd → 3GR, or 3GR → 4GR) only Sometimes shifts correctly	K-196	
45	Abnormal shift	Shifts incorrectly (incorrect shift pattern) (ex) Vehicle shifts 1st → 4GR directly when accelerating with accelerator pedal depressed slightly	K-198	
46	Frequent shifting	Downshift occurs when accelerator depressed slightly in D, S and L ranges (except hold mode)	K-200	
47	Shift point high or low	Shift points do not match shift diagram Shift delayed when accelerating Shifts occur too fast when accelerating and engine speed does not increase	K-201	
48	No lockup	No lockup when vehicle speed reaches lockup range	K-202	
49	No kickdown	Does not downshift when accelerator pedal depressed more than 7/8 within kickdown range	K-202	
50	Engine speed flares up	When accelerating	Engine speed flares up on acceleration	K-202
51		When upshifting and/or downshifting	Engine flares up when accelerator pedal depressed for upshifting Engine flares up suddenly when accelerator pedal depressed for downshifting	K-203
52	Excessive shift shock	P, N to R and/or N to D	Strong shift shock felt at idle when shifting from N to D or R range	K-205
53		When upshifting and/or downshifting	Excessive shift shock felt when accelerating at upshifting During cruising, excessive shift shock felt when accelerator pedal depressed at downshifting	K-208
54	No engine braking	Engine speed drops to idle but vehicle does not slow when accelerator pedal released during cruising at medium to high speed Engine speed drops to idle but vehicle does not slow when accelerator pedal released when in L range at low vehicle speed	K-211	
55	No mode change	Mode does not change to/from normal mode in D range Hole mode not selected or not cancelled	K-213	
56	Transmission noise	All ranges	Transmission noisy in all ranges when vehicle is idling	K-213
57		D, S, L, R ranges	Abnormal noise from transmission in D, S, L, R	K-213
58	Transmission overheats	ATF smells burnt and/or is discolored	K-213	

SYMPTOM TROUBLESHOOTING CHART

6	<b>WILL START IN OTHER THAN P AND N RANGES</b>						
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine starts in P, N and other ranges</li> </ul>						
<p><b>[TROUBLESHOOTING HINTS]</b>                  Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;">① Park/Neutral switch worn or misadjusted</td> <td style="width: 50%;">☛ page K-28</td> </tr> <tr> <td>② Ignition system malfunction</td> <td>☛ section G</td> </tr> <tr> <td>③ Selector lever installation or adjustment incorrect</td> <td>☛ page K-164</td> </tr> </table>		① Park/Neutral switch worn or misadjusted	☛ page K-28	② Ignition system malfunction	☛ section G	③ Selector lever installation or adjustment incorrect	☛ page K-164
① Park/Neutral switch worn or misadjusted	☛ page K-28						
② Ignition system malfunction	☛ section G						
③ Selector lever installation or adjustment incorrect	☛ page K-164						








# SYMPTOM TROUBLESHOOTING

STEP	INSPECTION	ACTION																																												
4	Are measurements at powertrain control module (Transmission) terminals OK?  B+: Battery positive voltage	Yes: Replace powertrain control module (Transmission) <span style="float: right;">☛ page K-41</span>  No: Check for malfunctioning parts and wiring ● Park/Neutral switch <span style="float: right;">☛ page K-28</span> ● Vehicle speed pulse generator <span style="float: right;">☛ page K-30</span> ● Vehicle speed sensor (revolution sensor) <span style="float: right;">☛ page K-29</span>																																												
	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Term.</th> <th style="width: 10%;">Unit</th> <th style="width: 15%;">Spec.</th> <th style="width: 45%;">Condition</th> <th style="width: 10%;">Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">2D</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0</td> <td>P and N ranges</td> <td rowspan="10" style="text-align: center; vertical-align: middle;">K-35</td> </tr> <tr> <td style="text-align: center;">B+</td> <td>Except P and N ranges</td> </tr> <tr> <td rowspan="2" style="text-align: center;">1E</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">B+</td> <td>R range</td> </tr> <tr> <td style="text-align: center;">0</td> <td>Except R range</td> </tr> <tr> <td rowspan="2" style="text-align: center;">2B</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">B+</td> <td>D range</td> </tr> <tr> <td style="text-align: center;">0</td> <td>Except D range</td> </tr> <tr> <td rowspan="2" style="text-align: center;">2S</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">B+</td> <td>S range</td> </tr> <tr> <td style="text-align: center;">0</td> <td>Except S range</td> </tr> <tr> <td rowspan="2" style="text-align: center;">2Q</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">B+</td> <td>L range</td> </tr> <tr> <td style="text-align: center;">0</td> <td>Except L range</td> </tr> <tr> <td style="text-align: center;">2E↔2L</td> <td style="text-align: center;">kΩ</td> <td style="text-align: center;">2.2-3.5</td> <td>Constant (Ign: OFF)</td> </tr> <tr> <td style="text-align: center;">2J↔2L</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">500-1,000</td> <td>Constant (Ign: OFF)</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	2D	V	0	P and N ranges	K-35	B+	Except P and N ranges	1E	V	B+	R range	0	Except R range	2B	V	B+	D range	0	Except D range	2S	V	B+	S range	0	Except S range	2Q	V	B+	L range	0	Except L range	2E↔2L	kΩ	2.2-3.5	Constant (Ign: OFF)	2J↔2L	Ω	500-1,000	Constant (Ign: OFF)	
	Term.	Unit	Spec.	Condition	Page																																									
	2D	V	0	P and N ranges	K-35																																									
			B+	Except P and N ranges																																										
	1E	V	B+	R range																																										
			0	Except R range																																										
	2B	V	B+	D range																																										
			0	Except D range																																										
	2S	V	B+	S range																																										
0			Except S range																																											
2Q	V	B+	L range																																											
		0	Except L range																																											
2E↔2L	kΩ	2.2-3.5	Constant (Ign: OFF)																																											
2J↔2L	Ω	500-1,000	Constant (Ign: OFF)																																											
Unit: V → Voltage Ω → Resistance																																														
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">TERMINAL</th> <th style="width: 50%;">FUNCTION</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">2D, 1E, 2B, 2S, 2Q</td> <td style="text-align: center;">Park/Neutral switch</td> </tr> <tr> <td style="text-align: center;">2E</td> <td style="text-align: center;">Vehicle speed pulse generator</td> </tr> <tr> <td style="text-align: center;">2J</td> <td style="text-align: center;">Vehicle speed sensor</td> </tr> <tr> <td style="text-align: center;">2L</td> <td style="text-align: center;">Ground (input)</td> </tr> </tbody> </table>		TERMINAL	FUNCTION	2D, 1E, 2B, 2S, 2Q	Park/Neutral switch	2E	Vehicle speed pulse generator	2J	Vehicle speed sensor	2L	Ground (input)																																			
TERMINAL	FUNCTION																																													
2D, 1E, 2B, 2S, 2Q	Park/Neutral switch																																													
2E	Vehicle speed pulse generator																																													
2J	Vehicle speed sensor																																													
2L	Ground (input)																																													

# K

## SYMPTOM TROUBLESHOOTING



18		ENGINE STALLS ON DECELERATION	
<b>DESCRIPTION</b>		<ul style="list-style-type: none"> <li>• Engine stops unexpectedly at beginning of deceleration or recovery from deceleration</li> <li>• Exhaust afterburn</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b>			
① ATF level low			
STEP	INSPECTION	ACTION	
1	Is ATF level OK? ⇨ page K-25  Level: Between notches on dipstick  	Yes	Go to No.14 "ENGINE STALLS WHEN SHIFTED FROM N TO D AND/OR FROM N TO R RANGE" in section K of this manual ⇨ page K-184
		No	Adjust ATF level  ⇨ page K-25

24	ENGINE ROUGH ON DECELERATION													
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine shakes at beginning of deceleration, during deceleration, or recovery from deceleration</li> <li>• Exhaust afterburn</li> </ul>													
<b>[TROUBLESHOOTING HINTS]</b>														
<ul style="list-style-type: none"> <li>① ATF level low</li> <li>② Selector lever installation or adjustment incorrect</li> <li>③ Throttle position sensor malfunction or misadjusted</li> <li>④ Line pressure low</li> <li>⑤ Powertrain slippage (forward clutch, forward one-way clutch, low one-way clutch, reverse clutch, or low and reverse brake)</li> </ul>		<ul style="list-style-type: none"> <li>⑥ Control valve stuck (pressure regulator valve, pressure modifier valve, or pilot valve)</li> <li>⑦ Line pressure solenoid valve worn</li> <li>⑧ Dropping resistor malfunction</li> </ul>												
STEP	INSPECTION	ACTION												
1	Are ATF level and condition OK? <span style="float: right;">☞ page K-25</span>	Yes Go to next step	No Problem within transmission Go to next step, and check for the main cause When the problem is found, overhaul the transmission and repair or replace parts as necessary											
														
2	Are there any diagnostic trouble code(s) displayed on the Self-Diagnosis Checker when the ignition switch is ON? <span style="float: right;">☞ page K-214</span>	Yes Check for cause of code(s) <span style="float: right;">☞ page K-214</span>  If problem remains, overhaul transmission and repair or replace parts as necessary	No Go to next step											
														
3	Is line pressure OK? <span style="float: right;">☞ page K-14</span>  <b>Specified line pressure      kPa (kgf/cm<sup>2</sup>, psi)</b>	Yes Overhaul transmission and repair or replace parts as necessary	No Check selector lever operation <span style="float: right;">☞ page K-164</span>  If OK, go to next step If not OK, adjust, repair or replace selector lever <span style="float: right;">☞ page K-164, 166</span>											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Engine</th> <th style="text-align: center;">Range</th> <th style="text-align: center;">Idle</th> <th style="text-align: center;">Stall</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">13B</td> <td style="text-align: center;">D, S, L</td> <td style="text-align: center;">500-520 {5.0-5.4, 72-76}</td> <td style="text-align: center;">1,200-1,270 {12.2-13.0, 174-184}</td> </tr> <tr> <td style="text-align: center;">R</td> <td style="text-align: center;">620-650 {6.3-6.7, 90-95}</td> <td style="text-align: center;">1,510-1,570 {15.3-16.1, 218-228}</td> </tr> </tbody> </table>		Engine	Range	Idle	Stall	13B	D, S, L	500-520 {5.0-5.4, 72-76}	1,200-1,270 {12.2-13.0, 174-184}	R	620-650 {6.3-6.7, 90-95}	1,510-1,570 {15.3-16.1, 218-228}		
Engine	Range	Idle	Stall											
13B	D, S, L	500-520 {5.0-5.4, 72-76}	1,200-1,270 {12.2-13.0, 174-184}											
	R	620-650 {6.3-6.7, 90-95}	1,510-1,570 {15.3-16.1, 218-228}											

STEP	INSPECTION				ACTION																												
4	Are measurements at powertrain control module (Transmission) terminals OK?				Yes	Replace control valve body assembly ☞ page K-128																											
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1F</td> <td>Ω</td> <td>2.5-5.0</td> <td>Constant (Ign OFF)</td> <td>K-35</td> </tr> <tr> <td rowspan="2">%</td> <td>Approx. 100</td> <td>Throttle valve fully closed (Ign: ON)</td> <td rowspan="2">K-246</td> </tr> <tr> <td>Approx. 5</td> <td>Throttle valve fully opened (Ign: ON)</td> </tr> <tr> <td rowspan="2">1H</td> <td>Ω</td> <td>12.5-19.0</td> <td>Constant (Ign OFF)</td> <td>K-35</td> </tr> <tr> <td rowspan="2">%</td> <td>Approx. 100</td> <td>Throttle valve fully closed v(Ign: ON)</td> <td rowspan="2">K-246</td> </tr> <tr> <td>Approx. 5</td> <td>Throttle valve opened (Ign: ON)</td> </tr> </tbody> </table>				Term.	Unit	Spec.	Condition	Page	1F	Ω	2.5-5.0	Constant (Ign OFF)	K-35	%	Approx. 100	Throttle valve fully closed (Ign: ON)	K-246	Approx. 5	Throttle valve fully opened (Ign: ON)	1H	Ω	12.5-19.0	Constant (Ign OFF)	K-35	%	Approx. 100	Throttle valve fully closed v(Ign: ON)	K-246	Approx. 5	Throttle valve opened (Ign: ON)	No	If resistance not OK, check for malfunctioning parts and wiring <ul style="list-style-type: none"> <li>● Line pressure solenoid valve ☞ page K-32</li> <li>● Dropping resistor ☞ page K-33</li> </ul> If resistance OK but voltage not, go to next step
	Term.	Unit	Spec.	Condition	Page																												
	1F	Ω	2.5-5.0	Constant (Ign OFF)	K-35																												
%		Approx. 100	Throttle valve fully closed (Ign: ON)	K-246																													
	Approx. 5	Throttle valve fully opened (Ign: ON)																															
1H	Ω	12.5-19.0	Constant (Ign OFF)	K-35																													
	%	Approx. 100	Throttle valve fully closed v(Ign: ON)	K-246																													
Approx. 5		Throttle valve opened (Ign: ON)																															
Unit: Ω → Resistance % → ON duty																																	
<table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>1F</td> <td>Line pressure solenoid valve</td> </tr> <tr> <td>1H</td> <td>Dropping resistor</td> </tr> </tbody> </table>				TERMINAL	FUNCTION	1F	Line pressure solenoid valve	1H	Dropping resistor																								
TERMINAL	FUNCTION																																
1F	Line pressure solenoid valve																																
1H	Dropping resistor																																
5	Is input voltage of throttle position sensor at powertrain control module (Transmission) OK?				Yes	Replace powertrain control module (Transmission) ☞ page K-41																											
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2T</td> <td rowspan="2">V</td> <td>0.1-1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">K-35</td> </tr> <tr> <td>4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table>				Term.	Unit	Spec.	Condition	Page	2T	V	0.1-1.1	Throttle valve closed throttle position	K-35	4.0-4.5	Throttle valve wide open throttle	No	Check throttle position sensor and wiring ☞ section F															
	Term.	Unit	Spec.	Condition	Page																												
2T	V	0.1-1.1	Throttle valve closed throttle position	K-35																													
		4.0-4.5	Throttle valve wide open throttle																														
Unit: V → Voltage																																	

# SYMPTOM TROUBLESHOOTING


# K

25, 26	POOR ACCELERATION WHEN DRIVE AWAY OR ON ACCELERATION		
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Engine speed increases normally but vehicle speed slowly increases during driveaway.</li> <li>• Engine speed increases normally but vehicle speed slowly increases during acceleration.</li> </ul>		
<b>[TROUBLESHOOTING HINTS]</b>			
<ul style="list-style-type: none"> <li>① ATF level low</li> <li>② Selector lever installation or adjustment incorrect</li> <li>③ Throttle position sensor malfunction or misadjusted</li> <li>④ Line pressure low</li> <li>⑤ Powertrain slippage</li> <li>⑥ Control valve stuck (pressure regulator valve, pressure modifier valve, pilot valve, shift valve A, or shift valve B)</li> <li>⑦ Line pressure solenoid valve worn</li> </ul>		<ul style="list-style-type: none"> <li>⑧ Dropping resistor malfunction</li> <li>⑨ Shift A, B solenoid valve worn</li> <li>⑩ Park/Neutral switch worn</li> <li>⑪ Hold switch worn</li> <li>⑫ Vehicle speed sensor (revolution sensor) malfunction</li> <li>⑬ Torque converter worn</li> <li>⑭ Engine power low</li> </ul>	
STEP	INSPECTION	ACTION	
1	Are ATF level and condition OK? <span style="float: right;">☞ page K-25</span>	Yes Go to next step	No Problem within transmission Go to next step, and check for the main cause when the problem is found, overhaul the transmission and repair or replace parts as necessary
			
2	Are there any diagnostic trouble code(s) displayed on the Self-Diagnosis Checker when the ignition switch is ON? <span style="float: right;">☞ page K-214</span>	Yes Check for cause of code(s) <span style="float: right;">☞ page K-214</span>	No Go to next step
			
3	Is line pressure OK? <span style="float: right;">☞ page K-14</span>	Yes Go to next step	No Check selector lever operation <span style="float: right;">☞ page K-164</span>
<b>Specified line pressure</b> <b>kPa {kgf/cm<sup>2</sup>, psi}</b>		If OK, go to next step If not OK, adjust, repair or replace selector lever <span style="float: right;">☞ page K-164, 166</span>	
<b>Engine</b>	<b>Range</b>	<b>Idle</b>	<b>Stall</b>
13B	D, S, L	500-520 {5.0-5.4, 72-76}	1,200-1,270 {12.2-13.0, 174-184}
	R	620-650 {6.3-67, 90-95}	1,510-1,570 {15.3-16.1, 218-228}

STEP	INSPECTION	ACTION																																
4	Is engine stall speed OK? <b>☞ page K-9</b> rpm	Yes Go to Step 7																																
	<table border="1"> <thead> <tr> <th>Engine</th> <th>Engine stall speed</th> </tr> </thead> <tbody> <tr> <td>13B</td> <td>3,000-3,300</td> </tr> </tbody> </table>	Engine	Engine stall speed	13B	3,000-3,300	No Overhaul transmission and repair or replace parts as necessary																												
Engine	Engine stall speed																																	
13B	3,000-3,300																																	
5	Are measurements at powertrain control module (Transmission) terminals OK?	Yes Overhaul transmission and repair or replace parts as necessary																																
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1F</td> <td>Ω</td> <td>2.5-5.0</td> <td>Constant (Ign: OFF)</td> <td>K-35</td> </tr> <tr> <td rowspan="2">%</td> <td>Approx. 100</td> <td>Throttle valve closed throttle position (Ign: ON)</td> <td rowspan="2">K-246</td> </tr> <tr> <td>Approx. 5</td> <td>Throttle valve wide open throttle (Ign: ON)</td> </tr> <tr> <td rowspan="2">1H</td> <td>Ω</td> <td>12.5-190</td> <td>Constant (Ign: OFF)</td> <td>K-35</td> </tr> <tr> <td rowspan="2">%</td> <td>Approx. 100</td> <td>Throttle valve closed throttle position (Ign: ON)</td> <td rowspan="2">K-246</td> </tr> <tr> <td>Approx. 5</td> <td>Throttle valve wide open throttle (Ign: ON)</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance % → ON duty</p> <table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>1F</td> <td>Line pressure solenoid valve</td> </tr> <tr> <td>1H</td> <td>Dropping resistor</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	1F	Ω	2.5-5.0	Constant (Ign: OFF)	K-35	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246	Approx. 5	Throttle valve wide open throttle (Ign: ON)	1H	Ω	12.5-190	Constant (Ign: OFF)	K-35	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246	Approx. 5	Throttle valve wide open throttle (Ign: ON)	TERMINAL	FUNCTION	1F	Line pressure solenoid valve	1H	Dropping resistor
Term.	Unit	Spec.	Condition	Page																														
1F	Ω	2.5-5.0	Constant (Ign: OFF)	K-35																														
	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246																														
Approx. 5		Throttle valve wide open throttle (Ign: ON)																																
1H	Ω	12.5-190	Constant (Ign: OFF)	K-35																														
	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246																														
Approx. 5		Throttle valve wide open throttle (Ign: ON)																																
TERMINAL	FUNCTION																																	
1F	Line pressure solenoid valve																																	
1H	Dropping resistor																																	
6	Is input voltage of throttle position sensor at powertrain control module (Transmission) OK?	Yes Replace powertrain control module (Transmission) <b>☞ page K-41</b>  If problem remains, overhaul transmission and repair or replace parts as necessary																																
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2T</td> <td rowspan="2">V</td> <td>0.1-1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">K-35</td> </tr> <tr> <td>4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> <p>Unit: V → Voltage</p>	Term.	Unit	Spec.	Condition	Page	2T	V	0.1-1.1	Throttle valve closed throttle position	K-35	4.0-4.5	Throttle valve wide open throttle	No Check throttle position sensor and wiring <b>☞ section F</b>  If problem remains, overhaul transmission and repair or replace parts as necessary																				
Term.	Unit	Spec.	Condition	Page																														
2T	V	0.1-1.1	Throttle valve closed throttle position	K-35																														
		4.0-4.5	Throttle valve wide open throttle																															
7	Disconnect solenoid 8-pin connector; is vehicle driven as follows? <b>☞ page K-247</b>	Yes Go to next step																																
	<table border="1"> <thead> <tr> <th>Range</th> <th>Gear position</th> </tr> </thead> <tbody> <tr> <td>D range</td> <td>3GR (fixed)</td> </tr> <tr> <td>S range</td> <td>3GR (fixed)</td> </tr> <tr> <td>L range</td> <td>2nd (fixed)</td> </tr> <tr> <td>R range</td> <td>Reverse (fixed)</td> </tr> </tbody> </table>	Range	Gear position	D range	3GR (fixed)	S range	3GR (fixed)	L range	2nd (fixed)	R range	Reverse (fixed)	No Replace control valve body assembly <b>☞ page K-128</b>  If problem remains, overhaul transmission and repair or replace parts as necessary																						
Range	Gear position																																	
D range	3GR (fixed)																																	
S range	3GR (fixed)																																	
L range	2nd (fixed)																																	
R range	Reverse (fixed)																																	
8	Drive vehicle in D, S, and L ranges (except hold mode); does vehicle start from stop in 1st gear?	Yes Overhaul transmission and repair or replace parts as necessary																																
	Are engine rpm at 20km/h {12 mph} and throttle opening OK? <b>RPM: Approx. 2,100</b> <b>Throttle opening: 4/8</b>	No Go to next step																																

STEP	INSPECTION	ACTION																																																							
9	Are measurements at powertrain control module (Transmission) terminals OK? B+: Battery positive voltage	Yes Replace control valve body assembly <b>page K-128</b>  If problem remains, overhaul transmission and repair or replace parts as necessary																																																							
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">1D</td> <td>Ω</td> <td>20-40</td> <td>Constant (Ign: OFF)</td> <td rowspan="6">K-35</td> </tr> <tr> <td rowspan="2">V</td> <td>Below 1.0</td> <td>2nd and 3GR gear</td> </tr> <tr> <td>B+</td> <td>1st and 4GR gear</td> </tr> <tr> <td rowspan="3">1B</td> <td>Ω</td> <td>20-40</td> <td>Constant (Ign: OFF)</td> </tr> <tr> <td rowspan="2">V</td> <td>Below 1.0</td> <td>3GR and 4GR gear</td> </tr> <tr> <td>B+</td> <td>1st and 2nd gear</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> <table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>1D</td> <td>Shift A solenoid valve</td> </tr> <tr> <td>1B</td> <td>Shift B solenoid valve</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	1D	Ω	20-40	Constant (Ign: OFF)	K-35	V	Below 1.0	2nd and 3GR gear	B+	1st and 4GR gear	1B	Ω	20-40	Constant (Ign: OFF)	V	Below 1.0	3GR and 4GR gear	B+	1st and 2nd gear	TERMINAL	FUNCTION	1D	Shift A solenoid valve	1B	Shift B solenoid valve	No If resistance not OK, check for malfunctioning parts and wiring ● Shift A solenoid valve <b>page K-32</b> ● Shift B solenoid valve <b>page K-32</b>  If resistance OK but voltage not, go to next step																									
Term.	Unit	Spec.	Condition	Page																																																					
1D	Ω	20-40	Constant (Ign: OFF)	K-35																																																					
	V	Below 1.0	2nd and 3GR gear																																																						
		B+	1st and 4GR gear																																																						
1B	Ω	20-40	Constant (Ign: OFF)																																																						
	V	Below 1.0	3GR and 4GR gear																																																						
		B+	1st and 2nd gear																																																						
TERMINAL	FUNCTION																																																								
1D	Shift A solenoid valve																																																								
1B	Shift B solenoid valve																																																								
10	Are measurements at powertrain control module (Transmission) terminals OK? B+: Battery positive voltage	Yes Go to next step																																																							
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2D</td> <td rowspan="2">V</td> <td>0</td> <td>P and N ranges</td> <td rowspan="14">K-35</td> </tr> <tr> <td>B+</td> <td>Except P and N ranges</td> </tr> <tr> <td rowspan="2">1E</td> <td rowspan="2">V</td> <td>0</td> <td>R range</td> </tr> <tr> <td>B+</td> <td>Except R range</td> </tr> <tr> <td rowspan="2">2B</td> <td rowspan="2">V</td> <td>0</td> <td>D range</td> </tr> <tr> <td>B+</td> <td>Except D range</td> </tr> <tr> <td rowspan="2">2S</td> <td rowspan="2">V</td> <td>0</td> <td>S range</td> </tr> <tr> <td>B+</td> <td>Except S range</td> </tr> <tr> <td rowspan="2">2Q</td> <td rowspan="2">V</td> <td>0</td> <td>L range</td> </tr> <tr> <td>B+</td> <td>Except L range</td> </tr> <tr> <td rowspan="2">2I</td> <td rowspan="2">V</td> <td>0</td> <td>Switch depressed</td> </tr> <tr> <td>B+</td> <td>Switch released</td> </tr> <tr> <td>2J ↔ 2L</td> <td>Ω</td> <td>500-1,000</td> <td>Constant (Ign: OFF)</td> </tr> </tbody> </table> <p>Unit: V → Resistance Ω → Voltage</p> <table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>2D, 1E, 2B, 2S, 2Q</td> <td>Park/Neutral switch</td> </tr> <tr> <td>2I</td> <td>Hold switch</td> </tr> <tr> <td>2J</td> <td>Vehicle speed sensor</td> </tr> <tr> <td>2L</td> <td>Ground (Input)</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	2D	V	0	P and N ranges	K-35	B+	Except P and N ranges	1E	V	0	R range	B+	Except R range	2B	V	0	D range	B+	Except D range	2S	V	0	S range	B+	Except S range	2Q	V	0	L range	B+	Except L range	2I	V	0	Switch depressed	B+	Switch released	2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)	TERMINAL	FUNCTION	2D, 1E, 2B, 2S, 2Q	Park/Neutral switch	2I	Hold switch	2J	Vehicle speed sensor	2L	Ground (Input)
Term.	Unit	Spec.	Condition	Page																																																					
2D	V	0	P and N ranges	K-35																																																					
		B+	Except P and N ranges																																																						
1E	V	0	R range																																																						
		B+	Except R range																																																						
2B	V	0	D range																																																						
		B+	Except D range																																																						
2S	V	0	S range																																																						
		B+	Except S range																																																						
2Q	V	0	L range																																																						
		B+	Except L range																																																						
2I	V	0	Switch depressed																																																						
		B+	Switch released																																																						
2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)																																																						
TERMINAL	FUNCTION																																																								
2D, 1E, 2B, 2S, 2Q	Park/Neutral switch																																																								
2I	Hold switch																																																								
2J	Vehicle speed sensor																																																								
2L	Ground (Input)																																																								
11	Replace with known good powertrain control module (Transmission); is problem corrected? <b>page K-41</b>	Yes Replace powertrain control module (Transmission) <b>page K-41</b>																																																							
		No Replace torque converter																																																							



30	SURGES WHILE CRUISING																							
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>● Momentary minor irregularity in engine output at steady vehicle speed</li> </ul>																							
<b>[TROUBLESHOOTING HINTS]</b> ① ATF level low ② Throttle position sensor malfunction or misadjusted ③ Lockup solenoid valve worn ④ Idle signal malfunction ⑤ Slip lockup OFF signal malfunction																								
STEP	INSPECTION			ACTION																				
1	Are there any diagnostic trouble code(s) displayed on the Self-Diagnosis Checker when the ignition switch is ON? ☞ page K-214 			<table border="1"> <tr> <td data-bbox="811 402 826 795">Yes</td> <td data-bbox="826 402 1453 795">           Check for cause of code(s)             ☞ page K-214         </td> </tr> <tr> <td data-bbox="811 795 826 795">No</td> <td data-bbox="826 795 1453 795">Go to next step</td> </tr> </table>	Yes	Check for cause of code(s)  ☞ page K-214	No	Go to next step																
Yes	Check for cause of code(s)  ☞ page K-214																							
No	Go to next step																							
2	Is input voltage of throttle position sensor at powertrain control module (Transmission) OK? <table border="1" data-bbox="223 868 735 1064"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2T</td> <td rowspan="2">V</td> <td>0.1-1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">K-35</td> </tr> <tr> <td>4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> Unit: V → Voltage			Term.	Unit	Spec.	Condition	Page	2T	V	0.1-1.1	Throttle valve closed throttle position	K-35	4.0-4.5	Throttle valve wide open throttle	<table border="1"> <tr> <td data-bbox="811 795 826 1134">Yes</td> <td data-bbox="826 795 1453 1134">Go to next step</td> </tr> <tr> <td data-bbox="811 1134 826 1134">No</td> <td data-bbox="826 1134 1453 1134">           Check throttle position sensor and wiring            ☞ section F         </td> </tr> </table>	Yes	Go to next step	No	Check throttle position sensor and wiring ☞ section F				
Term.	Unit	Spec.	Condition	Page																				
2T	V	0.1-1.1	Throttle valve closed throttle position	K-35																				
		4.0-4.5	Throttle valve wide open throttle																					
Yes	Go to next step																							
No	Check throttle position sensor and wiring ☞ section F																							
3	Are resistance and output duty of lockup solenoid valve at powertrain control module (Transmission) terminals OK? <table border="1" data-bbox="223 1229 735 1415"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">1M</td> <td>Ω</td> <td>10-20</td> <td>Constant (Ign: OFF)</td> <td>K-35</td> </tr> <tr> <td rowspan="2">%</td> <td>Approx. 5</td> <td>No lockup (Ign: ON)</td> <td rowspan="2">K-247</td> </tr> <tr> <td>Approx. 95</td> <td>Lockup (Ign: ON)</td> </tr> </tbody> </table> Unit: Ω → Resistance % → ON duty			Term.	Unit	Spec.	Condition	Page	1M	Ω	10-20	Constant (Ign: OFF)	K-35	%	Approx. 5	No lockup (Ign: ON)	K-247	Approx. 95	Lockup (Ign: ON)	<table border="1"> <tr> <td data-bbox="811 1134 826 1513">Yes</td> <td data-bbox="826 1134 1453 1513">           Replace control valve body assembly            ☞ page K-128             If problem remains, overhaul transmission and repair or replace parts as necessary         </td> </tr> <tr> <td data-bbox="811 1513 826 1513">No</td> <td data-bbox="826 1513 1453 1513">           If resistance not OK, check for lockup solenoid valve and wiring            ☞ page K-32             If resistance OK but duty not, go to next step         </td> </tr> </table>	Yes	Replace control valve body assembly ☞ page K-128  If problem remains, overhaul transmission and repair or replace parts as necessary	No	If resistance not OK, check for lockup solenoid valve and wiring ☞ page K-32  If resistance OK but duty not, go to next step
Term.	Unit	Spec.	Condition	Page																				
1M	Ω	10-20	Constant (Ign: OFF)	K-35																				
	%	Approx. 5	No lockup (Ign: ON)	K-247																				
		Approx. 95	Lockup (Ign: ON)																					
Yes	Replace control valve body assembly ☞ page K-128  If problem remains, overhaul transmission and repair or replace parts as necessary																							
No	If resistance not OK, check for lockup solenoid valve and wiring ☞ page K-32  If resistance OK but duty not, go to next step																							

STEP	INSPECTION					ACTION
4	Are measurements at powertrain control module (Transmission) terminals OK?  B+: Battery positive voltage				Yes	Replace powertrain control module (Transmission)  ☛ page K-41  If problem remains, overhaul transmission and repair or replace parts as necessary
	Term.	Unit	Spec.	Condition	Page	No Check for malfunctioning parts and wiring ● Idle signal ☛ page K-35 ● Slip lockup OFF signal ☛ page K-35
	2M	V	Below 1.0	Throttle valve closed throttle position	K-35	
			4.5-5.5	Throttle valve opened		
	2G	V	Below 1.0	Engine running at 3,000 rpm		
		B+	Engine running at idle			
Unit: V → Voltage						
<b>TERMINAL</b>		<b>FUNCTION</b>				
2M		Idle signal				
2G		Slip lockup OFF signal				

# K

## SYMPTOM TROUBLESHOOTING

<b>31</b>	<b>LACK OF POWER</b>																													
<b>DESCRIP- TION</b>	<ul style="list-style-type: none"> <li>• Performance poor under load (i.e., power down when climbing hills)</li> </ul>																													
<p><b>[TROUBLESHOOTING HINTS]</b> Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary</p> <table border="0"> <tr> <td>① ATF level low</td> <td>☞ page K-25</td> <td>⑧ Dropping resistor malfunction</td> <td>☞ page K-33</td> </tr> <tr> <td>② Selector lever installation or adjustment incorrect</td> <td>☞ page K-164</td> <td>⑨ Shift A and/or B solenoid valve worn</td> <td>☞ page K-32</td> </tr> <tr> <td>③ Throttle position sensor malfunction or misadjusted</td> <td>☞ section F</td> <td>⑩ Park/Neutral switch worn or misadjusted</td> <td>☞ page K-28</td> </tr> <tr> <td>④ Line pressure low</td> <td>☞ page K-14</td> <td>⑪ Hold switch circuit malfunction</td> <td>☞ page K-27</td> </tr> <tr> <td>⑤ Powertrain slippage</td> <td></td> <td>⑫ Vehicle speed sensor (revolution sensor) malfunction</td> <td>☞ page K-29</td> </tr> <tr> <td>⑥ Control valve stuck (pressure regulator valve, pressure modifier valve, shift valve A or shift valve B)</td> <td></td> <td>⑬ Torque converter worn</td> <td>☞ page K-57</td> </tr> <tr> <td>⑦ Line pressure solenoid valve worn</td> <td>☞ page K-32</td> <td>⑭ Engine power low</td> <td></td> </tr> </table>			① ATF level low	☞ page K-25	⑧ Dropping resistor malfunction	☞ page K-33	② Selector lever installation or adjustment incorrect	☞ page K-164	⑨ Shift A and/or B solenoid valve worn	☞ page K-32	③ Throttle position sensor malfunction or misadjusted	☞ section F	⑩ Park/Neutral switch worn or misadjusted	☞ page K-28	④ Line pressure low	☞ page K-14	⑪ Hold switch circuit malfunction	☞ page K-27	⑤ Powertrain slippage		⑫ Vehicle speed sensor (revolution sensor) malfunction	☞ page K-29	⑥ Control valve stuck (pressure regulator valve, pressure modifier valve, shift valve A or shift valve B)		⑬ Torque converter worn	☞ page K-57	⑦ Line pressure solenoid valve worn	☞ page K-32	⑭ Engine power low	
① ATF level low	☞ page K-25	⑧ Dropping resistor malfunction	☞ page K-33																											
② Selector lever installation or adjustment incorrect	☞ page K-164	⑨ Shift A and/or B solenoid valve worn	☞ page K-32																											
③ Throttle position sensor malfunction or misadjusted	☞ section F	⑩ Park/Neutral switch worn or misadjusted	☞ page K-28																											
④ Line pressure low	☞ page K-14	⑪ Hold switch circuit malfunction	☞ page K-27																											
⑤ Powertrain slippage		⑫ Vehicle speed sensor (revolution sensor) malfunction	☞ page K-29																											
⑥ Control valve stuck (pressure regulator valve, pressure modifier valve, shift valve A or shift valve B)		⑬ Torque converter worn	☞ page K-57																											
⑦ Line pressure solenoid valve worn	☞ page K-32	⑭ Engine power low																												

<b>32</b>	<b>POOR FUEL ECONOMY</b>																	
<b>DESCRIP- TION</b>	<ul style="list-style-type: none"> <li>• Fuel economy unsatisfactory</li> </ul>																	
<p><b>[TROUBLESHOOTING HINTS]</b> Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary</p> <table border="0"> <tr> <td>① Lockup solenoid valve worn</td> <td>☞ page K-32</td> <td>⑤ Throttle position sensor malfunction or misadjusted</td> <td>☞ section F</td> </tr> <tr> <td>② Lockup control solenoid valve worn</td> <td>☞ page K-32</td> <td>⑥ Engine rpm signal malfunction</td> <td>☞ page K-35</td> </tr> <tr> <td>③ Control valve stuck (lockup control valve, lockup modifier valve, pilot valve, or shuttle shift valve D)</td> <td></td> <td>⑦ Vehicle speed sensor (revolution sensor) malfunction</td> <td>☞ page K-29</td> </tr> <tr> <td>④ ATF thermosensor malfunction</td> <td>☞ page K-31</td> <td>⑧ Park/Neutral switch worn or misadjusted</td> <td>☞ page K-28</td> </tr> </table>			① Lockup solenoid valve worn	☞ page K-32	⑤ Throttle position sensor malfunction or misadjusted	☞ section F	② Lockup control solenoid valve worn	☞ page K-32	⑥ Engine rpm signal malfunction	☞ page K-35	③ Control valve stuck (lockup control valve, lockup modifier valve, pilot valve, or shuttle shift valve D)		⑦ Vehicle speed sensor (revolution sensor) malfunction	☞ page K-29	④ ATF thermosensor malfunction	☞ page K-31	⑧ Park/Neutral switch worn or misadjusted	☞ page K-28
① Lockup solenoid valve worn	☞ page K-32	⑤ Throttle position sensor malfunction or misadjusted	☞ section F															
② Lockup control solenoid valve worn	☞ page K-32	⑥ Engine rpm signal malfunction	☞ page K-35															
③ Control valve stuck (lockup control valve, lockup modifier valve, pilot valve, or shuttle shift valve D)		⑦ Vehicle speed sensor (revolution sensor) malfunction	☞ page K-29															
④ ATF thermosensor malfunction	☞ page K-31	⑧ Park/Neutral switch worn or misadjusted	☞ page K-28															

<b>40</b>	<b>VEHICLE DOES NOT MOVE IN D, S, L AND/OR R RANGES</b>																					
<b>DESCRIP- TION</b>	<ul style="list-style-type: none"> <li>• No creep at all</li> <li>• Vehicle does not move when accelerator pedal depressed after shifted to D, S, L and/or R range</li> </ul>																					
<p><b>[TROUBLESHOOTING HINTS]</b> Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary</p> <table border="0"> <tr> <td>① ATF level low</td> <td>☞ page K-25</td> <td>⑥ Control valve stuck (manual valve pressure regulator valve, pressure modifier valve or pilot valve)</td> <td></td> </tr> <tr> <td>② Selector lever installation or adjustment incorrect</td> <td>☞ page K-164</td> <td>⑦ Line pressure solenoid valve worn</td> <td>☞ page K-32</td> </tr> <tr> <td>③ Throttle position sensor malfunction or misadjusted</td> <td>☞ section F</td> <td>⑧ Dropping resistor malfunction</td> <td>☞ page K-33</td> </tr> <tr> <td>④ Line pressure low</td> <td>☞ page K-14</td> <td>⑨ Parking mechanism worn</td> <td>☞ page K-97</td> </tr> <tr> <td>⑤ Powertrain slippage (high clutch, brake band, forward clutch, or reverse clutch)</td> <td></td> <td></td> <td></td> </tr> </table>			① ATF level low	☞ page K-25	⑥ Control valve stuck (manual valve pressure regulator valve, pressure modifier valve or pilot valve)		② Selector lever installation or adjustment incorrect	☞ page K-164	⑦ Line pressure solenoid valve worn	☞ page K-32	③ Throttle position sensor malfunction or misadjusted	☞ section F	⑧ Dropping resistor malfunction	☞ page K-33	④ Line pressure low	☞ page K-14	⑨ Parking mechanism worn	☞ page K-97	⑤ Powertrain slippage (high clutch, brake band, forward clutch, or reverse clutch)			
① ATF level low	☞ page K-25	⑥ Control valve stuck (manual valve pressure regulator valve, pressure modifier valve or pilot valve)																				
② Selector lever installation or adjustment incorrect	☞ page K-164	⑦ Line pressure solenoid valve worn	☞ page K-32																			
③ Throttle position sensor malfunction or misadjusted	☞ section F	⑧ Dropping resistor malfunction	☞ page K-33																			
④ Line pressure low	☞ page K-14	⑨ Parking mechanism worn	☞ page K-97																			
⑤ Powertrain slippage (high clutch, brake band, forward clutch, or reverse clutch)																						

# SYMPTOM TROUBLESHOOTING

# K

<b>41</b>	<b>VEHICLE MOVES IN N RANGE</b>	
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>● Vehicle creeps in N range</li> <li>● Vehicle moves when accelerator pedal not depressed</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b>		
Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary		
<ul style="list-style-type: none"> <li>① Selector lever installation or adjustment incorrect</li> <li>② Powertrain burnt (forward clutch, or overrunning clutch)</li> <li>③ Throttle position sensor malfunction or misadjusted</li> </ul>	<ul style="list-style-type: none"> <li>④ Control valve stuck (manual valve)</li> <li>⑤ Line pressure solenoid valve worn</li> <li>⑥ Dropping resistor malfunction</li> </ul>	
	<ul style="list-style-type: none"> <li>☞ page K-164</li> <li>☞ section F</li> </ul>	<ul style="list-style-type: none"> <li>☞ page K-32</li> <li>☞ page K-33</li> </ul>

<b>42</b>	<b>VEHICLE MOVES IN P RANGE</b>
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>● Vehicle rolls in P range, and drivetrain not lookup</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b>	
Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary	
<ul style="list-style-type: none"> <li>① Selector lever installation or adjustment incorrect</li> <li>② Parking mechanism worn</li> </ul>	<ul style="list-style-type: none"> <li>☞ page K-164</li> <li>☞ page K-97</li> </ul>

<b>43</b>	<b>EXCESSIVE CREEP</b>
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>● Vehicle moves quickly in D, S, L, and R ranges (accelerator pedal not depressed)</li> <li>● Excessive N to R range and N to D range shift shock felt</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b>	
Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary	
<ul style="list-style-type: none"> <li>① Engine idle speed misadjusted</li> <li>② Line pressure at idle high</li> </ul>	<ul style="list-style-type: none"> <li>☞ section F</li> <li>☞ page K-14</li> </ul>



STEP	INSPECTION	ACTION																									
4	Are measurements at powertrain control module (Transmission) terminals OK?  B+: Battery positive voltage	Yes	Replace control valve body assembly  If problem remains, overhaul transmission and repair or replace parts as necessary  ☞ page K-128																								
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">1D</td> <td>Ω</td> <td>20-40</td> <td>Constant (Ign: OFF)</td> <td rowspan="6">K-35</td> </tr> <tr> <td rowspan="2">V</td> <td>Below 1.0</td> <td>2nd and 3GR gear</td> </tr> <tr> <td>B+</td> <td>1st and 4GR gear</td> </tr> <tr> <td rowspan="3">1B</td> <td>Ω</td> <td>20-40</td> <td>Constant (Ign: OFF)</td> </tr> <tr> <td rowspan="2">V</td> <td>Below 1.0</td> <td>3GR and 4GR gear</td> </tr> <tr> <td>B+</td> <td>1st and 2nd gear</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	1D	Ω	20-40	Constant (Ign: OFF)	K-35	V	Below 1.0	2nd and 3GR gear	B+	1st and 4GR gear	1B	Ω	20-40	Constant (Ign: OFF)	V	Below 1.0	3GR and 4GR gear	B+	1st and 2nd gear	No	If resistance not OK, check for malfunctioning parts and wiring <ul style="list-style-type: none"> <li>• Shift A solenoid valve ☞ page K-32</li> <li>• Shift B solenoid valve ☞ page K-32</li> </ul> If resistance OK, but voltage not, go to next step
	Term.	Unit	Spec.	Condition	Page																						
	1D	Ω	20-40	Constant (Ign: OFF)	K-35																						
V		Below 1.0	2nd and 3GR gear																								
		B+	1st and 4GR gear																								
1B	Ω	20-40	Constant (Ign: OFF)																								
	V	Below 1.0	3GR and 4GR gear																								
		B+	1st and 2nd gear																								
Unit: Ω → Resistance V → Voltage																											
<table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>1D</td> <td>Shift A solenoid valve</td> </tr> <tr> <td>1B</td> <td>Shift B solenoid valve</td> </tr> </tbody> </table>	TERMINAL	FUNCTION	1D	Shift A solenoid valve	1B	Shift B solenoid valve																					
TERMINAL	FUNCTION																										
1D	Shift A solenoid valve																										
1B	Shift B solenoid valve																										
5	Are measurements at powertrain control module (Transmission) terminals OK?  B+: Battery positive voltage	Yes	Go to next step																								
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2I</td> <td rowspan="2">V</td> <td>0</td> <td>Switch depressed</td> <td rowspan="3">K-35</td> </tr> <tr> <td>B+</td> <td>Switch released</td> </tr> <tr> <td>2J ↔ 2L</td> <td>Ω</td> <td>500-1,000</td> <td>Constant (Ign: OFF)</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	2I	V	0	Switch depressed	K-35	B+	Switch released	2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)	No	Check for malfunctioning parts and wiring <ul style="list-style-type: none"> <li>• Hold switch ☞ page K-27</li> <li>• Vehicle speed sensor (revolution sensor) ☞ page K-29</li> </ul> If problem remains, return to step 3								
	Term.	Unit	Spec.	Condition	Page																						
	2I	V	0	Switch depressed	K-35																						
B+			Switch released																								
2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)																								
Unit: V → Voltage Ω → Resistance																											
<table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>2I</td> <td>Hold switch</td> </tr> <tr> <td>2J</td> <td>Vehicle speed sensor</td> </tr> <tr> <td>2L</td> <td>Ground (input)</td> </tr> </tbody> </table>	TERMINAL	FUNCTION	2I	Hold switch	2J	Vehicle speed sensor	2L	Ground (input)																			
TERMINAL	FUNCTION																										
2I	Hold switch																										
2J	Vehicle speed sensor																										
2L	Ground (input)																										
6	Is voltage between terminal 1L of powertrain control module (Transmission) and transmission case OK?  <b>Specified voltage: 0V (Normal condition)</b>	Yes	Go to next step																								
		No	Problem in ground circuit Repair wiring or replace connector																								
7	Replace with known good powertrain control module (Transmission); is problem corrected?  ☞ page K-41	Yes	Replace powertrain control module (Transmission)  ☞ page K-41																								
		No	Overhaul transmission and repair or replace parts as necessary																								





# SYMPTOM TROUBLESHOOTING

# K

STEP	INSPECTION		ACTION																								
4	Are measurements at powertrain control module (Transmission) terminals OK?	Yes	Go to next step																								
	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Term.</th> <th style="width: 10%;">Unit</th> <th style="width: 15%;">Spec.</th> <th style="width: 30%;">Condition</th> <th style="width: 15%;">Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">2T</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0.1-1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2" style="text-align: center;">K-35</td> </tr> <tr> <td style="text-align: center;">4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> <tr> <td style="text-align: center;">2J ↔ 2L</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">500-1,000</td> <td>Constant</td> <td></td> </tr> </tbody> </table> <p>Unit: V → Voltage Ω → Resistance</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">TERMINAL</th> <th style="width: 50%;">FUNCTION</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">2T</td> <td style="text-align: center;">Throttle position sensor</td> </tr> <tr> <td style="text-align: center;">2J</td> <td style="text-align: center;">Vehicle speed sensor</td> </tr> <tr> <td style="text-align: center;">2L</td> <td style="text-align: center;">Ground (input)</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	2T	V	0.1-1.1	Throttle valve closed throttle position	K-35	4.0-4.5	Throttle valve wide open throttle	2J ↔ 2L	Ω	500-1,000	Constant		TERMINAL	FUNCTION	2T	Throttle position sensor	2J	Vehicle speed sensor	2L	Ground (input)	No
Term.	Unit	Spec.	Condition	Page																							
2T	V	0.1-1.1	Throttle valve closed throttle position	K-35																							
		4.0-4.5	Throttle valve wide open throttle																								
2J ↔ 2L	Ω	500-1,000	Constant																								
TERMINAL	FUNCTION																										
2T	Throttle position sensor																										
2J	Vehicle speed sensor																										
2L	Ground (input)																										
5	Replace with known good powertrain control module (Transmission); is problem corrected? ⇨ page K-41	Yes	Replace powertrain control module (Transmission) ⇨ page K-41																								
		No	Replace control valve body assembly ⇨ page K-128  If problem remains, overhaul transmission and repair or replace parts as necessary																								





46		FREQUENT SHIFTING														
<b>DESCRIPTION</b>		<ul style="list-style-type: none"> <li>Downshift occurs when accelerator depressed slightly in D, S, and L ranges (except hold mode)</li> </ul>														
<b>[TROUBLESHOOTING HINTS]</b>																
① Poor ground ② Throttle position sensor malfunction or misadjusted ③ Powertrain control module (Transmission) misadjusted																
STEP	INSPECTION		ACTION													
1	Are there any diagnostic trouble code(s) displayed on the Self-Diagnosis Checker when the ignition switch is ON?  	Yes	Check for cause of code(s)  If problem remains, overhaul transmission and repair or replace parts as necessary  ⇨ page K-214													
		No	Go to next step													
2	Is voltage between terminal 1L of powertrain control module (Transmission) and transmission case OK?  <b>Specified voltage: 0V (Normal condition)</b>	Yes	Go to next step													
		No	Problem in ground circuit Repair wiring or replace connector													
3	Is input voltage of throttle position sensor at powertrain control module (Transmission) OK?  <table border="1" data-bbox="224 991 733 1187"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2T</td> <td rowspan="2">V</td> <td>0.1-1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">K-35</td> </tr> <tr> <td>4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> Unit: V → Voltage	Term.	Unit	Spec.	Condition	Page	2T	V	0.1-1.1	Throttle valve closed throttle position	K-35	4.0-4.5	Throttle valve wide open throttle	Yes	Go to next step	
		Term.	Unit	Spec.	Condition	Page										
2T	V	0.1-1.1	Throttle valve closed throttle position	K-35												
		4.0-4.5	Throttle valve wide open throttle													
No	Check for throttle position sensor and wiring  ⇨ section F															
4	Replace with known good powertrain control module (Transmission); is problem corrected?  ⇨ page K-41	Yes	Replace powertrain control module (Transmission)  ⇨ page K-41													
		No	Replace control valve body assembly  ⇨ page K-128  If problem remains, overhaul transmission and repair or replace parts as necessary													

47	SHIFT POINT HIGH OR LOW																																								
<b>DESCRIP-TION</b>	<ul style="list-style-type: none"> <li>● Shift points do not match shift diagram</li> <li>● Shifts delayed when accelerating</li> <li>● Shifts occur too fast when accelerating and engine speed does not increase</li> </ul>																																								
<b>[TROUBLESHOOTING HINTS]</b>																																									
① Throttle position sensor malfunction or misadjusted		③ Vehicle speed sensor (revolution sensor) malfunction																																							
② Engine rpm signal malfunction		④ A/C signal malfunction																																							
STEP	INSPECTION		ACTION																																						
1	Are there any diagnostic trouble code(s) displayed on the Self-Diagnosis Checker when the ignition switch is ON?  	Yes	Check for cause of code(s)  <div style="text-align: right;">⇨ page K-214</div>																																						
		No	Go to next step																																						
2	Is input voltage of throttle position sensor at powertrain control module (Transmission) OK?  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">2T</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">0.1-1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2" style="text-align: center;">K-35</td> </tr> <tr> <td style="text-align: center;">4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> Unit: V → Voltage	Term.	Unit	Spec.	Condition	Page	2T	V	0.1-1.1	Throttle valve closed throttle position	K-35	4.0-4.5	Throttle valve wide open throttle	Yes	Go to next step																										
		Term.	Unit	Spec.	Condition	Page																																			
2T	V	0.1-1.1	Throttle valve closed throttle position	K-35																																					
		4.0-4.5	Throttle valve wide open throttle																																						
3	Are measurements at powertrain control module (Transmission) terminals OK?  B+: Battery positive voltage  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center;">1G</td> <td rowspan="3" style="text-align: center;">V</td> <td style="text-align: center;">0.3-0.8</td> <td>Engine running at idle</td> <td rowspan="3" style="text-align: center;">K-35</td> </tr> <tr> <td style="text-align: center;">0</td> <td>Engine stopped</td> </tr> <tr> <td style="text-align: center;">1.8-2.2</td> <td>Engine running at 3,000 rpm (no load)</td> </tr> <tr> <td style="text-align: center;">2J ↔ 2L</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">500-1,000</td> <td>Constant (Ign: OFF)</td> <td></td> </tr> <tr> <td rowspan="2" style="text-align: center;">1L</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">Below 3.0</td> <td>A/C ON</td> <td></td> </tr> <tr> <td style="text-align: center;">B+</td> <td>A/C OFF</td> <td></td> </tr> </tbody> </table> Unit: V → Voltage Ω → Resistance  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1G</td> <td style="text-align: center;">Engine rpm signal</td> </tr> <tr> <td style="text-align: center;">2J</td> <td style="text-align: center;">Vehicle speed sensor</td> </tr> <tr> <td style="text-align: center;">1L</td> <td style="text-align: center;">A/C signal</td> </tr> <tr> <td style="text-align: center;">2L</td> <td style="text-align: center;">Ground (Input)</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	1G	V	0.3-0.8	Engine running at idle	K-35	0	Engine stopped	1.8-2.2	Engine running at 3,000 rpm (no load)	2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)		1L	V	Below 3.0	A/C ON		B+	A/C OFF		TERMINAL	FUNCTION	1G	Engine rpm signal	2J	Vehicle speed sensor	1L	A/C signal	2L	Ground (Input)	Yes	Replace powertrain control module (Transmission) ⇨ page K-41  If problem remains, overhaul transmission and repair or replace parts as necessary	
		Term.	Unit	Spec.	Condition	Page																																			
1G	V	0.3-0.8	Engine running at idle	K-35																																					
		0	Engine stopped																																						
		1.8-2.2	Engine running at 3,000 rpm (no load)																																						
2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)																																						
1L	V	Below 3.0	A/C ON																																						
		B+	A/C OFF																																						
TERMINAL	FUNCTION																																								
1G	Engine rpm signal																																								
2J	Vehicle speed sensor																																								
1L	A/C signal																																								
2L	Ground (Input)																																								
3	Are measurements at powertrain control module (Transmission) terminals OK?  B+: Battery positive voltage  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center;">1G</td> <td rowspan="3" style="text-align: center;">V</td> <td style="text-align: center;">0.3-0.8</td> <td>Engine running at idle</td> <td rowspan="3" style="text-align: center;">K-35</td> </tr> <tr> <td style="text-align: center;">0</td> <td>Engine stopped</td> </tr> <tr> <td style="text-align: center;">1.8-2.2</td> <td>Engine running at 3,000 rpm (no load)</td> </tr> <tr> <td style="text-align: center;">2J ↔ 2L</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">500-1,000</td> <td>Constant (Ign: OFF)</td> <td></td> </tr> <tr> <td rowspan="2" style="text-align: center;">1L</td> <td rowspan="2" style="text-align: center;">V</td> <td style="text-align: center;">Below 3.0</td> <td>A/C ON</td> <td></td> </tr> <tr> <td style="text-align: center;">B+</td> <td>A/C OFF</td> <td></td> </tr> </tbody> </table> Unit: V → Voltage Ω → Resistance  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1G</td> <td style="text-align: center;">Engine rpm signal</td> </tr> <tr> <td style="text-align: center;">2J</td> <td style="text-align: center;">Vehicle speed sensor</td> </tr> <tr> <td style="text-align: center;">1L</td> <td style="text-align: center;">A/C signal</td> </tr> <tr> <td style="text-align: center;">2L</td> <td style="text-align: center;">Ground (Input)</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	1G	V	0.3-0.8	Engine running at idle	K-35	0	Engine stopped	1.8-2.2	Engine running at 3,000 rpm (no load)	2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)		1L	V	Below 3.0	A/C ON		B+	A/C OFF		TERMINAL	FUNCTION	1G	Engine rpm signal	2J	Vehicle speed sensor	1L	A/C signal	2L	Ground (Input)	No	Check for malfunctioning parts and wiring ● Engine rpm signal ● Vehicle speed sensor (revolution sensor) ● A/C signal  ⇨ section G ⇨ page K-29 ⇨ section F	
		Term.	Unit	Spec.	Condition	Page																																			
1G	V	0.3-0.8	Engine running at idle	K-35																																					
		0	Engine stopped																																						
		1.8-2.2	Engine running at 3,000 rpm (no load)																																						
2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)																																						
1L	V	Below 3.0	A/C ON																																						
		B+	A/C OFF																																						
TERMINAL	FUNCTION																																								
1G	Engine rpm signal																																								
2J	Vehicle speed sensor																																								
1L	A/C signal																																								
2L	Ground (Input)																																								

<b>48</b>	<b>NO LOCKUP</b>		
<b>DESCRIP- TION</b>	<ul style="list-style-type: none"> <li>• No lockup when vehicle speed reaches lockup range</li> </ul>		
<p><b>[TROUBLESHOOTING HINTS]</b> Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary</p>			
<ul style="list-style-type: none"> <li>① Lockup solenoid valve worn</li> <li>② Lockup control solenoid valve worn</li> <li>③ Control valve stuck (lockup control valve, lockup modifier valve, pilot valve, or shuttle shift valve D)</li> <li>④ ATF thermosensor malfunction</li> </ul>	<ul style="list-style-type: none"> <li>☞ <b>page K-32</b></li> <li>☞ <b>page K-32</b></li> <li>☞ <b>page K-31</b></li> </ul>	<ul style="list-style-type: none"> <li>⑤ Throttle position sensor malfunction or misadjusted</li> <li>⑥ Idle signal malfunction</li> <li>⑦ Engine rpm signal malfunction</li> <li>⑧ Vehicle speed sensor (revolution sensor)</li> <li>⑨ Park/Neutral switch worn or misadjusted</li> </ul>	<ul style="list-style-type: none"> <li>☞ <b>section F</b></li> <li>☞ <b>page K-35</b></li> <li>☞ <b>page K-35</b></li> <li>☞ <b>page K-29</b></li> <li>☞ <b>page K-28</b></li> </ul>

<b>49</b>	<b>NO KICKDOWN</b>		
<b>DESCRIP- TION</b>	<ul style="list-style-type: none"> <li>• Does not downshift when accelerator pedal depressed more than 7/8 within kickdown range</li> </ul>		
<p><b>[TROUBLESHOOTING HINTS]</b> Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary</p>			
<ul style="list-style-type: none"> <li>① Throttle position sensor malfunction or misadjusted</li> <li>② Shift A and/or B solenoid valve worn</li> <li>③ Control valve stuck (shift valve A, shift valve B, or pilot valve)</li> </ul>	<ul style="list-style-type: none"> <li>☞ <b>section F</b></li> <li>☞ <b>page K-32</b></li> </ul>	<ul style="list-style-type: none"> <li>④ Hold switch malfunction</li> <li>⑤ Vehicle speed sensor (revolution sensor) malfunction</li> </ul>	<ul style="list-style-type: none"> <li>☞ <b>page K-27</b></li> <li>☞ <b>page K-29</b></li> </ul>



<b>50</b>	<b>ENGINE SPEED FLARES UP WHEN ACCELERATING</b>		
<b>DESCRIP- TION</b>	<ul style="list-style-type: none"> <li>• Engine speed flares up on acceleration</li> </ul>		
<p><b>[TROUBLESHOOTING HINTS]</b> Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary</p>			
<ul style="list-style-type: none"> <li>① ATF level low</li> <li>② Selector lever installation or adjustment incorrect</li> <li>③ Throttle position sensor malfunction or misadjusted</li> <li>④ Line pressure low</li> <li>⑤ Powertrain slippage (forward clutch, forward one-way clutch, low one-way clutch, reverse clutch, or low and reverse brake)</li> </ul>	<ul style="list-style-type: none"> <li>☞ <b>page K-25</b></li> <li>☞ <b>page K-164</b></li> <li>☞ <b>section F</b></li> <li>☞ <b>page K-14</b></li> </ul>	<ul style="list-style-type: none"> <li>⑥ Control valve stuck (pressure regulator valve, pressure modifier valve or pilot valve)</li> <li>⑦ Line pressure solenoid valve worn</li> <li>⑧ Dropping resistor malfunction</li> </ul>	<ul style="list-style-type: none"> <li>☞ <b>page K-32</b></li> <li>☞ <b>page K-33</b></li> </ul>

51	ENGINE SPEED FLARES UP WHEN UPSHIFTING AND/OR DOWNSHIFTING												
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>● Engine flares up when accelerator pedal depressed for upshifting</li> <li>● Engine flares up suddenly when accelerator pedal depressed for downshifting</li> </ul>												
<b>[TROUBLESHOOTING HINTS]</b>													
<ul style="list-style-type: none"> <li>① ATF level low</li> <li>② Selector lever installation or adjustment incorrect</li> <li>③ Throttle position sensor malfunction or misadjusted</li> <li>④ Line pressure low</li> <li>⑤ Powertrain slippage (brake band, high clutch, forward clutch, forward one-way clutch, or low one-way clutch)</li> </ul>		<ul style="list-style-type: none"> <li>⑥ Control valve stuck (pressure regulator valve, pressure modifier valve, pilot valve, shift valve A, or shift valve B)</li> <li>⑦ Line pressure solenoid valve worn</li> <li>⑧ Dropping resistor malfunction</li> <li>⑨ Vehicle speed pulse generator malfunction</li> <li>⑩ Vehicle speed sensor (revolution sensor) malfunction</li> <li>⑪ Barometric absolute pressure sensor malfunction</li> </ul>											
STEP	INSPECTION	YES	ACTION										
1	Are ATF level and condition OK? <span style="float: right;">☞ page K-25</span>	Yes	Go to next step										
		No	Problem within transmission Go to next step, and check for the main cause When the problem is found, overhaul the transmission and repair or replace parts as necessary										
2	Are there any diagnostic trouble code(s) displayed on the Self-Diagnosis Checker when the ignition switch is ON? <span style="float: right;">☞ page K-214</span>	Yes	Check for cause of code(s) <span style="float: right;">☞ page K-214</span>										
		No	Go to next step										
3	Is line pressure OK? <span style="float: right;">☞ page K-14</span>	Yes	Overhaul transmission and repair or replace parts as necessary										
<b>Specified line pressure</b> <b>kPa (kgf/cm<sup>2</sup>, psi)</b>		No	Check selector lever operation <span style="float: right;">☞ page K-164</span>										
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Engine</th> <th style="text-align: left;">Range</th> <th style="text-align: left;">Idle</th> <th style="text-align: left;">Stall</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">13B</td> <td style="text-align: center;">D, S, L</td> <td style="text-align: center;">500-520 {5.0-5.4, 72-76}</td> <td style="text-align: center;">1,200-1,270 {12.2-13.0, 174-184}</td> </tr> <tr> <td style="text-align: center;">R</td> <td style="text-align: center;">620-650 {6.3-6.7, 90-95}</td> <td style="text-align: center;">1,510-1,570 {15.3-16.1, 218-228}</td> </tr> </tbody> </table>		Engine	Range	Idle	Stall	13B	D, S, L	500-520 {5.0-5.4, 72-76}	1,200-1,270 {12.2-13.0, 174-184}	R	620-650 {6.3-6.7, 90-95}	1,510-1,570 {15.3-16.1, 218-228}	If OK, go to next step If not OK, adjust, repair, or replace selector lever <span style="float: right;">☞ page K-164, 166</span>
Engine	Range	Idle	Stall										
13B	D, S, L	500-520 {5.0-5.4, 72-76}	1,200-1,270 {12.2-13.0, 174-184}										
	R	620-650 {6.3-6.7, 90-95}	1,510-1,570 {15.3-16.1, 218-228}										

STEP	INSPECTION	ACTION																																
4	Are measurements at powertrain control module (Transmission) terminals OK?	Yes Replace control valve body assembly <b>☞ page K-128</b>  If problem remains, overhaul transmission and repair or replace parts as necessary																																
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1F</td> <td>Ω</td> <td>2.5-5.0</td> <td>Constant (Ign: OFF)</td> <td>K-35</td> </tr> <tr> <td rowspan="2">%</td> <td>Approx. 100</td> <td>Throttle valve closed throttle position (Ign: ON)</td> <td rowspan="2">K-246</td> </tr> <tr> <td>Approx. 5</td> <td>Throttle valve wide open throttle (Ign: ON)</td> </tr> <tr> <td rowspan="2">1H</td> <td>Ω</td> <td>12.5-19.0</td> <td>Constant (Ign: OFF)</td> <td>K-35</td> </tr> <tr> <td rowspan="2">%</td> <td>Approx. 100</td> <td>Throttle valve closed throttle position (Ign: ON)</td> <td rowspan="2">K-246</td> </tr> <tr> <td>Approx. 5</td> <td>Throttle valve wide open throttle (Ign: ON)</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance % → ON duty</p> <table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>1F</td> <td>Line pressure solenoid valve</td> </tr> <tr> <td>1H</td> <td>Dropping resistor</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	1F	Ω	2.5-5.0	Constant (Ign: OFF)	K-35	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246	Approx. 5	Throttle valve wide open throttle (Ign: ON)	1H	Ω	12.5-19.0	Constant (Ign: OFF)	K-35	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246	Approx. 5	Throttle valve wide open throttle (Ign: ON)	TERMINAL	FUNCTION	1F	Line pressure solenoid valve	1H	Dropping resistor
Term.	Unit	Spec.	Condition	Page																														
1F	Ω	2.5-5.0	Constant (Ign: OFF)	K-35																														
	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246																														
Approx. 5		Throttle valve wide open throttle (Ign: ON)																																
1H	Ω	12.5-19.0	Constant (Ign: OFF)	K-35																														
	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246																														
Approx. 5		Throttle valve wide open throttle (Ign: ON)																																
TERMINAL	FUNCTION																																	
1F	Line pressure solenoid valve																																	
1H	Dropping resistor																																	
5	Is input voltage of throttle position sensor at powertrain control module (Transmission) OK?	Yes Go to next step																																
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2T</td> <td rowspan="2">V</td> <td>0.1-1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">K-35</td> </tr> <tr> <td>4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> <p>Unit: V → Voltage</p>	Term.	Unit	Spec.	Condition	Page	2T	V	0.1-1.1	Throttle valve closed throttle position	K-35	4.0-4.5	Throttle valve wide open throttle	No Check throttle position sensor and wiring <b>☞ section F</b>																				
Term.	Unit	Spec.	Condition	Page																														
2T	V	0.1-1.1	Throttle valve closed throttle position	K-35																														
		4.0-4.5	Throttle valve wide open throttle																															
6	Are measurements at powertrain control module (Transmission) terminals OK?	Yes Replace powertrain control module (Transmission) <b>☞ page K-41</b>																																
	<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td>2E ↔ 2L</td> <td>kΩ</td> <td>2.2-3.5</td> <td>Constant (Ign: OFF)</td> <td rowspan="3">K-35</td> </tr> <tr> <td>2J ↔ 2L</td> <td>Ω</td> <td>500-1,000</td> <td>Constant (Ign: OFF)</td> </tr> <tr> <td rowspan="2">2C</td> <td rowspan="2">V</td> <td>2.0-4.5V</td> <td>Ignition switch ON</td> </tr> <tr> <td>0V</td> <td>Ignition switch OFF</td> </tr> </tbody> </table> <p>Unit: Ω → Resistance V → Voltage</p> <table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>2E</td> <td>Vehicle speed pulse generator</td> </tr> <tr> <td>2J</td> <td>Vehicle speed sensor</td> </tr> <tr> <td>2C</td> <td>Barometric absolute pressure sensor</td> </tr> <tr> <td>2L</td> <td>Ground (input)</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	2E ↔ 2L	kΩ	2.2-3.5	Constant (Ign: OFF)	K-35	2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)	2C	V	2.0-4.5V	Ignition switch ON	0V	Ignition switch OFF	TERMINAL	FUNCTION	2E	Vehicle speed pulse generator	2J	Vehicle speed sensor	2C	Barometric absolute pressure sensor	2L	Ground (input)	No Check for malfunctioning parts and wiring ● Vehicle speed pulse generator <b>☞ page K-30</b> ● Vehicle speed sensor (revolution sensor) <b>☞ page K-29</b> ● Barometric absolute pressure sensor <b>☞ page K-35</b>		
Term.	Unit	Spec.	Condition	Page																														
2E ↔ 2L	kΩ	2.2-3.5	Constant (Ign: OFF)	K-35																														
2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)																															
2C	V	2.0-4.5V	Ignition switch ON																															
		0V	Ignition switch OFF																															
TERMINAL	FUNCTION																																	
2E	Vehicle speed pulse generator																																	
2J	Vehicle speed sensor																																	
2C	Barometric absolute pressure sensor																																	
2L	Ground (input)																																	

# SYMPTOM TROUBLESHOOTING

# K

52	EXCESSIVE SHIFT SHOCK P, N TO R AND/OR N TO D													
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>● Strong shift shock felt at idle when shifting from N to D or R range</li> </ul>													
<b>[TROUBLESHOOTING HINTS]</b>														
<ul style="list-style-type: none"> <li>① ATF level low</li> <li>② Idle speed high</li> <li>③ Throttle position sensor malfunction or misadjusted</li> <li>④ Line pressure high</li> <li>⑤ Control valve stuck (pressure regulator valve, pressure modifier valve, or pilot valve)</li> </ul>		<ul style="list-style-type: none"> <li>⑥ Powertrain slippage</li> <li>⑦ Line pressure solenoid valve worn</li> <li>⑧ Dropping resistor malfunction</li> <li>⑨ N-D, or 3-4/N-R accumulator worn</li> <li>⑩ Inhibitor signal malfunction</li> <li>⑪ Vehicle speed pulse generator malfunction</li> <li>⑫ Park/Neutral switch worn or misadjusted</li> </ul>												
STEP	INSPECTION		ACTION											
1	Are ATF level and condition OK? <span style="float: right;">☞ page K-25</span>	Yes	Go to next step											
		No	Problem within transmission Go to next step and check for the main cause When the problem is found, overhaul the transmission and repair or replace parts as necessary											
														
2	Are ignition timing and idle speed OK? <span style="float: right;">☞ section F</span>	Yes	Go to next step											
		No	Adjust ignition timing and/or idle speed <span style="float: right;">☞ section F</span>											
3	Are there any diagnostic trouble code(s) displayed on the Self-Diagnosis Checker when the ignition switch is ON? <span style="float: right;">☞ page K-214</span>	Yes	Check for cause of code(s) <span style="float: right;">☞ page K-214</span>											
		No	Go to next step											
														
4	Is line pressure OK? <span style="float: right;">☞ page K-14</span>  <b>Specified line pressure</b> <b>kPa (kgf/cm<sup>2</sup>, psi)</b>	Yes	Go to next step											
		No	Go to step 6											
<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="width: 10%;">Engine</th> <th style="width: 15%;">Range</th> <th style="width: 20%;">Idle</th> <th style="width: 55%;">Stall</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="font-size: 1.2em;">13B</td> <td style="font-size: 1.2em;">D, S, L</td> <td>500-520 {5.0-5.4, 72-76}</td> <td>1,200-1,270 {12.2-13.0, 174-184}</td> </tr> <tr> <td style="font-size: 1.2em;">R</td> <td>620-650 {6.3-6.7, 90-95}</td> <td>1,510-1,570 {15.3-16.1, 218-228}</td> </tr> </tbody> </table>				Engine	Range	Idle	Stall	13B	D, S, L	500-520 {5.0-5.4, 72-76}	1,200-1,270 {12.2-13.0, 174-184}	R	620-650 {6.3-6.7, 90-95}	1,510-1,570 {15.3-16.1, 218-228}
Engine	Range	Idle	Stall											
13B	D, S, L	500-520 {5.0-5.4, 72-76}	1,200-1,270 {12.2-13.0, 174-184}											
	R	620-650 {6.3-6.7, 90-95}	1,510-1,570 {15.3-16.1, 218-228}											



# K

## SYMPTOM TROUBLESHOOTING

STEP	INSPECTION	ACTION																																	
5	Is engine stall speed OK? ↳ page K-9 rpm <table border="1"> <thead> <tr> <th>Engine</th> <th>Engine stall speed</th> </tr> </thead> <tbody> <tr> <td>13B</td> <td>3,000-3,300</td> </tr> </tbody> </table>	Engine	Engine stall speed	13B	3,000-3,300	Yes Go to step 8																													
		Engine	Engine stall speed																																
13B	3,000-3,300																																		
No Overhaul transmission and repair or replace parts as necessary																																			
6	Are measurements at powertrain control module (Transmission) terminals OK? <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1F</td> <td><math>\Omega</math></td> <td>2.5-5.0</td> <td>Constant (Ign: OFF)</td> <td>K-35</td> </tr> <tr> <td rowspan="2">%</td> <td>Approx. 100</td> <td>Throttle valve closed throttle position (Ign: ON)</td> <td rowspan="2">K-246</td> </tr> <tr> <td>Approx. 5</td> <td>Throttle valve wide open throttle (Ign: ON)</td> </tr> <tr> <td rowspan="2">1H</td> <td><math>\Omega</math></td> <td>12.5-19.0</td> <td>Constant (Ign: OFF)</td> <td>K-35</td> </tr> <tr> <td rowspan="2">%</td> <td>Approx. 100</td> <td>Throttle valve closed throttle position (Ign: ON)</td> <td rowspan="2">K-246</td> </tr> <tr> <td>Approx. 5</td> <td>Throttle valve wide open throttle (Ign: ON)</td> </tr> </tbody> </table> Unit: $\Omega$ → Resistance % → ON duty <table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>1F</td> <td>Line pressure solenoid valve</td> </tr> <tr> <td>1H</td> <td>Dropping resistor</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	1F	$\Omega$	2.5-5.0	Constant (Ign: OFF)	K-35	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246	Approx. 5	Throttle valve wide open throttle (Ign: ON)	1H	$\Omega$	12.5-19.0	Constant (Ign: OFF)	K-35	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246	Approx. 5	Throttle valve wide open throttle (Ign: ON)	TERMINAL	FUNCTION	1F	Line pressure solenoid valve	1H	Dropping resistor	Yes Overhaul transmission and repair or replace parts as necessary
		Term.	Unit	Spec.	Condition	Page																													
1F	$\Omega$	2.5-5.0	Constant (Ign: OFF)	K-35																															
	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246																															
Approx. 5		Throttle valve wide open throttle (Ign: ON)																																	
1H	$\Omega$	12.5-19.0	Constant (Ign: OFF)	K-35																															
	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246																															
Approx. 5		Throttle valve wide open throttle (Ign: ON)																																	
TERMINAL	FUNCTION																																		
1F	Line pressure solenoid valve																																		
1H	Dropping resistor																																		
No If resistance not OK, check for malfunctioning parts and wiring • Line pressure solenoid valve ↳ page K-32 • Dropping resistor ↳ page K-33 If resistance OK but duty not, go to next step																																			
7	Is input voltage of throttle position sensor at powertrain control module (Transmission) OK? <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2T</td> <td rowspan="2">V</td> <td>0.1-1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2">K-35</td> </tr> <tr> <td>4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> Unit: V → Voltage	Term.	Unit	Spec.	Condition	Page	2T	V	0.1-1.1	Throttle valve closed throttle position	K-35	4.0-4.5	Throttle valve wide open throttle	Yes Replace powertrain control module (Transmission) ↳ page K-41																					
		Term.	Unit	Spec.	Condition	Page																													
2T	V	0.1-1.1	Throttle valve closed throttle position	K-35																															
		4.0-4.5	Throttle valve wide open throttle																																
No Check throttle position sensor and wiring ↳ section F																																			

STEP	INSPECTION				ACTION																																																											
8	Are measurements at powertrain control module (Transmission) terminals OK?				Yes	Overhaul transmission and repair or replace parts as necessary																																																										
	B+: Battery positive voltage				No	Check for malfunctioning parts and wiring																																																										
	<table border="1"> <thead> <tr> <th data-bbox="305 304 388 336">Term.</th> <th data-bbox="388 304 446 336">Unit</th> <th data-bbox="446 304 545 336">Spec.</th> <th data-bbox="545 304 743 336">Condition</th> <th data-bbox="743 304 809 336">Page</th> </tr> </thead> <tbody> <tr> <td data-bbox="305 351 388 393">1C</td> <td data-bbox="388 351 446 393">V</td> <td data-bbox="446 351 545 393">B+</td> <td data-bbox="545 351 743 393">D range</td> <td data-bbox="743 351 809 393" rowspan="10">K-35</td> </tr> <tr> <td></td> <td></td> <td data-bbox="446 393 545 436">Below. 1.0</td> <td data-bbox="545 393 743 436">P and N ranges</td> </tr> <tr> <td data-bbox="305 436 388 478">2E ↔ 2L</td> <td data-bbox="388 436 446 478">kΩ</td> <td data-bbox="446 436 545 478">2.2-3.5</td> <td data-bbox="545 436 743 478">Constant (Ign: OFF)</td> </tr> <tr> <td data-bbox="305 478 388 521">2D</td> <td data-bbox="388 478 446 521">V</td> <td data-bbox="446 478 545 521">0</td> <td data-bbox="545 478 743 521">P and N ranges</td> </tr> <tr> <td></td> <td></td> <td data-bbox="446 521 545 563">B+</td> <td data-bbox="545 521 743 563">Except P and N ranges</td> </tr> <tr> <td data-bbox="305 563 388 606">1E</td> <td data-bbox="388 563 446 606">V</td> <td data-bbox="446 563 545 606">B+</td> <td data-bbox="545 563 743 606">R range</td> </tr> <tr> <td></td> <td></td> <td data-bbox="446 606 545 649">0</td> <td data-bbox="545 606 743 649">Except R range</td> </tr> <tr> <td data-bbox="305 649 388 691">2B</td> <td data-bbox="388 649 446 691">V</td> <td data-bbox="446 649 545 691">B+</td> <td data-bbox="545 649 743 691">D range</td> </tr> <tr> <td></td> <td></td> <td data-bbox="446 691 545 734">0</td> <td data-bbox="545 691 743 734">Except D range</td> </tr> <tr> <td data-bbox="305 734 388 776">2S</td> <td data-bbox="388 734 446 776">V</td> <td data-bbox="446 734 545 776">B+</td> <td data-bbox="545 734 743 776">S range</td> </tr> <tr> <td></td> <td></td> <td data-bbox="446 776 545 819">0</td> <td data-bbox="545 776 743 819">Except S range</td> </tr> <tr> <td data-bbox="305 819 388 861">2Q</td> <td data-bbox="388 819 446 861">V</td> <td data-bbox="446 819 545 861">B+</td> <td data-bbox="545 819 743 861">L range</td> </tr> <tr> <td></td> <td></td> <td data-bbox="446 861 545 904">0</td> <td data-bbox="545 861 743 904">Except L range</td> </tr> </tbody> </table>				Term.	Unit	Spec.	Condition	Page	1C	V	B+	D range	K-35			Below. 1.0	P and N ranges	2E ↔ 2L	kΩ	2.2-3.5	Constant (Ign: OFF)	2D	V	0	P and N ranges			B+	Except P and N ranges	1E	V	B+	R range			0	Except R range	2B	V	B+	D range			0	Except D range	2S	V	B+	S range			0	Except S range	2Q	V	B+	L range			0	Except L range	<ul style="list-style-type: none"> <li>● Park/Neutral signal</li> <li>● Vehicle speed pulse generator</li> <li>● Park/Neutral switch</li> </ul>	<ul style="list-style-type: none"> <li>☞ page K-35</li> <li>☞ page K-30</li> <li>☞ page K-28</li> </ul>
Term.	Unit	Spec.	Condition	Page																																																												
1C	V	B+	D range	K-35																																																												
		Below. 1.0	P and N ranges																																																													
2E ↔ 2L	kΩ	2.2-3.5	Constant (Ign: OFF)																																																													
2D	V	0	P and N ranges																																																													
		B+	Except P and N ranges																																																													
1E	V	B+	R range																																																													
		0	Except R range																																																													
2B	V	B+	D range																																																													
		0	Except D range																																																													
2S	V	B+	S range																																																													
		0	Except S range																																																													
2Q	V	B+	L range																																																													
		0	Except L range																																																													
	Unit: V → Voltage Ω → Resistance																																																															
	TERMINAL		FUNCTION																																																													
	1C		Inhibitor signal																																																													
	2E		Vehicle speed pulse generator																																																													
	2D, 1E, 2B, 2S, 2Q		Park/Neutral switch																																																													
	2L		Ground (Input)																																																													





53	EXCESSIVE SHIFT SHOCK WHEN UPSHIFTING AND/OR DOWNSHIFTING													
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Excessive shift shock felt when accelerating at upshifting</li> <li>• During cruising, excessive shift shock felt when accelerator pedal depressed at downshifting</li> </ul>													
<p><b>[TROUBLESHOOTING HINTS]</b></p> <ul style="list-style-type: none"> <li>① ATF level low</li> <li>② Throttle position sensor malfunction or misadjusted</li> <li>③ Line pressure high</li> <li>④ Powertrain slippage</li> <li>⑤ Control valve stuck (pressure regulator valve, pressure modifier valve, pilot valve, servo charger valve, or accumulator control valve)</li> <li>⑥ Line pressure solenoid valve worn</li> <li>⑦ Dropping resistor malfunction</li> <li>⑧ Idle signal malfunction</li> <li>⑨ ATF thermosensor malfunction</li> <li>⑩ Vehicle speed pulse generator malfunction</li> <li>⑪ Vehicle speed sensor (revolution sensor) malfunction</li> <li>⑫ Barometric absolute pressure sensor</li> <li>⑬ Torque reduced signal and/or reduce torque signal malfunction?</li> </ul>														
STEP	INSPECTION	ACTION												
1	<p>Are ATF level and condition OK?</p> <p style="text-align: right;">☞ page K-25</p> 	Yes	Go to next step											
		No	<p>Problem within transmission</p> <p>Go to next step, and check for the main cause</p> <p>When the problem is found, overhaul the transmission and repair or replace parts as necessary</p>											
2	<p>Are there any diagnostic trouble code(s) displayed on the Self-Diagnosis Checker when the ignition switch is ON?</p> <p style="text-align: right;">☞ page K-214</p> 	Yes	<p>Check for cause of code(s)</p> <p style="text-align: right;">☞ page K-214</p>											
		No	Go to next step											
3	<p>Is line pressure OK?</p> <p style="text-align: right;">☞ page K-14</p> <p><b>Specified line pressure</b>      <b>kPa (kgf/cm<sup>2</sup>, psi)</b></p> <table border="1" data-bbox="208 1523 720 1672"> <thead> <tr> <th>Engine</th> <th>Range</th> <th>Idle</th> <th>Stall</th> </tr> </thead> <tbody> <tr> <td rowspan="2">13B</td> <td>D, S, L</td> <td>500-520 {5.0-5.4, 72-76}</td> <td>1,200-1,270 {12.2-13.0, 174-184}</td> </tr> <tr> <td>R</td> <td>620-650 {6.3-6.7, 90-95}</td> <td>1,510-1,570 {15.3-16.1, 218-228}</td> </tr> </tbody> </table>	Engine	Range	Idle	Stall	13B	D, S, L	500-520 {5.0-5.4, 72-76}	1,200-1,270 {12.2-13.0, 174-184}	R	620-650 {6.3-6.7, 90-95}	1,510-1,570 {15.3-16.1, 218-228}	Yes	Go to next step
Engine	Range	Idle	Stall											
13B	D, S, L	500-520 {5.0-5.4, 72-76}	1,200-1,270 {12.2-13.0, 174-184}											
	R	620-650 {6.3-6.7, 90-95}	1,510-1,570 {15.3-16.1, 218-228}											
		No	Go to step 5											

# SYMPTOM TROUBLESHOOTING

STEP	INSPECTION		ACTION																																
4	Is engine stall speed OK? <span style="float: right;">☞ page K-9</span> <span style="float: right;">rpm</span>	Yes	Go to step 8																																
	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Engine</th> <th style="width: 50%;">Engine stall speed</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">13B</td> <td style="text-align: center;">3,000-3,300</td> </tr> </tbody> </table>	Engine	Engine stall speed	13B	3,000-3,300	No	Overhaul transmission and repair or replace parts as necessary																												
Engine	Engine stall speed																																		
13B	3,000-3,300																																		
5	Are measurements at powertrain control module (Transmission) terminals OK?	Yes	Overhaul transmission and repair or replace parts as necessary																																
	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Term.</th> <th style="width: 10%;">Unit</th> <th style="width: 15%;">Spec.</th> <th style="width: 30%;">Condition</th> <th style="width: 15%;">Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center; vertical-align: middle;">1F</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">2.5-5.0</td> <td>Constant (Ign: OFF)</td> <td style="text-align: center;">K-35</td> </tr> <tr> <td rowspan="2" style="text-align: center; vertical-align: middle;">%</td> <td style="text-align: center;">Approx. 100</td> <td>Throttle valve closed throttle position (Ign: ON)</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">K-246</td> </tr> <tr> <td style="text-align: center;">Approx. 5</td> <td>Throttle valve wide open throttle (Ign: ON)</td> </tr> <tr> <td rowspan="3" style="text-align: center; vertical-align: middle;">1H</td> <td style="text-align: center;">Ω</td> <td style="text-align: center;">12.5-19.0</td> <td>Constant (Ign: OFF)</td> <td style="text-align: center;">K-35</td> </tr> <tr> <td rowspan="2" style="text-align: center; vertical-align: middle;">%</td> <td style="text-align: center;">Approx. 100</td> <td>Throttle valve closed throttle position (Ign: ON)</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">K-246</td> </tr> <tr> <td style="text-align: center;">Approx. 5</td> <td>Throttle valve wide open throttle (Ign: ON)</td> </tr> </tbody> </table> <p style="margin-top: 5px;">Unit: Ω → Resistance % → ON duty</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th style="width: 50%;">TERMINAL</th> <th style="width: 50%;">FUNCTION</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1F</td> <td style="text-align: center;">Line pressure solenoid valve</td> </tr> <tr> <td style="text-align: center;">1H</td> <td style="text-align: center;">Dropping resistor</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	1F	Ω	2.5-5.0	Constant (Ign: OFF)	K-35	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246	Approx. 5	Throttle valve wide open throttle (Ign: ON)	1H	Ω	12.5-19.0	Constant (Ign: OFF)	K-35	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246	Approx. 5	Throttle valve wide open throttle (Ign: ON)	TERMINAL	FUNCTION	1F	Line pressure solenoid valve	1H	Dropping resistor	No
Term.	Unit	Spec.	Condition	Page																															
1F	Ω	2.5-5.0	Constant (Ign: OFF)	K-35																															
	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246																															
		Approx. 5	Throttle valve wide open throttle (Ign: ON)																																
1H	Ω	12.5-19.0	Constant (Ign: OFF)	K-35																															
	%	Approx. 100	Throttle valve closed throttle position (Ign: ON)	K-246																															
		Approx. 5	Throttle valve wide open throttle (Ign: ON)																																
TERMINAL	FUNCTION																																		
1F	Line pressure solenoid valve																																		
1H	Dropping resistor																																		
6	Is input voltage of throttle position sensor at powertrain control module (Transmission) OK?	Yes	Go to next step																																
	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Term.</th> <th style="width: 10%;">Unit</th> <th style="width: 15%;">Spec.</th> <th style="width: 30%;">Condition</th> <th style="width: 15%;">Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center; vertical-align: middle;">2T</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">V</td> <td style="text-align: center;">0.1-1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">K-35</td> </tr> <tr> <td style="text-align: center;">4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table> <p style="margin-top: 5px;">Unit: V → Voltage</p>	Term.	Unit	Spec.	Condition	Page	2T	V	0.1-1.1	Throttle valve closed throttle position	K-35	4.0-4.5	Throttle valve wide open throttle	No	Check throttle position sensor and wiring ☞ section F																				
Term.	Unit	Spec.	Condition	Page																															
2T	V	0.1-1.1	Throttle valve closed throttle position	K-35																															
		4.0-4.5	Throttle valve wide open throttle																																
7	Is input voltage of idle signal at powertrain control module (Transmission) OK?	Yes	Replace powertrain control module (Transmission) ☞ page K-41																																
	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Term.</th> <th style="width: 10%;">Unit</th> <th style="width: 15%;">Spec.</th> <th style="width: 30%;">Condition</th> <th style="width: 15%;">Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center; vertical-align: middle;">2M</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">V</td> <td style="text-align: center;">Below 1.0</td> <td>Throttle valve closed throttle position</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">K-35</td> </tr> <tr> <td style="text-align: center;">4.5-5.5</td> <td>Throttle valve opened</td> </tr> </tbody> </table> <p style="margin-top: 5px;">Unit: V → Voltage</p>	Term.	Unit	Spec.	Condition	Page	2M	V	Below 1.0	Throttle valve closed throttle position	K-35	4.5-5.5	Throttle valve opened	No	Check throttle position sensor and wiring ☞ section F																				
Term.	Unit	Spec.	Condition	Page																															
2M	V	Below 1.0	Throttle valve closed throttle position	K-35																															
		4.5-5.5	Throttle valve opened																																

STEP	INSPECTION	ACTION																																																								
8	<p>Are measurement at powertrain control module (Transmission) terminals OK?</p> <p>B+: Battery positive voltage</p> <table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">2R ↔ 2L</td> <td rowspan="3">V</td> <td>Approx. 1.8</td> <td>ATF temp. 10°C (50°F)</td> <td rowspan="10">K-35</td> </tr> <tr> <td>Approx. 1.1</td> <td>ATF temp. 40°C (104°F)</td> </tr> <tr> <td>Approx. 0.4</td> <td>ATF temp. 80°C (176°F)</td> </tr> <tr> <td>2E ↔ 2L</td> <td>kΩ</td> <td>2.2-3.5</td> <td>Constant (Ign: OFF)</td> </tr> <tr> <td>2J ↔ 2L</td> <td>Ω</td> <td>500-1,000</td> <td>Constant (Ign: OFF)</td> </tr> <tr> <td rowspan="2">2C</td> <td rowspan="2">V</td> <td>2.0-4.5V</td> <td>Ignition switch ON</td> </tr> <tr> <td>0V</td> <td>Ignition switch OFF</td> </tr> <tr> <td rowspan="2">2H</td> <td rowspan="2">V</td> <td>B+</td> <td>Engine running at idle</td> </tr> <tr> <td>Below 1.0</td> <td>Throttle opening above 1/8 (Engine coolant temp. below 40°C (104°F))</td> </tr> <tr> <td rowspan="2">2P</td> <td rowspan="2">V</td> <td>Below 1.0</td> <td>Shifting</td> </tr> <tr> <td>B+</td> <td>Engine running at idle</td> </tr> </tbody> </table> <p>Unit: V → Voltage Ω → Resistance</p> <table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>2R</td> <td>ATF thermosensor</td> </tr> <tr> <td>2E</td> <td>Vehicle speed pulse generator</td> </tr> <tr> <td>2J</td> <td>Vehicle speed sensor</td> </tr> <tr> <td>2C</td> <td>Barometric absolute pressure sensor</td> </tr> <tr> <td>2H</td> <td>Reduce torque signal</td> </tr> <tr> <td>2P</td> <td>Torque reduced signal</td> </tr> <tr> <td>2L</td> <td>Ground (input)</td> </tr> </tbody> </table>	Term.	Unit	Spec.	Condition	Page	2R ↔ 2L	V	Approx. 1.8	ATF temp. 10°C (50°F)	K-35	Approx. 1.1	ATF temp. 40°C (104°F)	Approx. 0.4	ATF temp. 80°C (176°F)	2E ↔ 2L	kΩ	2.2-3.5	Constant (Ign: OFF)	2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)	2C	V	2.0-4.5V	Ignition switch ON	0V	Ignition switch OFF	2H	V	B+	Engine running at idle	Below 1.0	Throttle opening above 1/8 (Engine coolant temp. below 40°C (104°F))	2P	V	Below 1.0	Shifting	B+	Engine running at idle	TERMINAL	FUNCTION	2R	ATF thermosensor	2E	Vehicle speed pulse generator	2J	Vehicle speed sensor	2C	Barometric absolute pressure sensor	2H	Reduce torque signal	2P	Torque reduced signal	2L	Ground (input)	<p>Yes Overhaul transmission and repair or replace parts as necessary</p> <p>No</p> <p>Check for malfunctioning parts and wiring</p> <ul style="list-style-type: none"> <li>● ATF thermosensor</li> <li>● Vehicle speed pulse generator</li> <li>● Vehicle speed sensor (revolution sensor)</li> <li>● Barometric absolute pressure sensor</li> <li>● Reduce torque signal</li> <li>● Torque reduced signal</li> </ul> <p>☞ page K-31 ☞ page K-30 ☞ page K-29 ☞ page K-35 ☞ page K-35 ☞ page K-35</p>
Term.	Unit	Spec.	Condition	Page																																																						
2R ↔ 2L	V	Approx. 1.8	ATF temp. 10°C (50°F)	K-35																																																						
		Approx. 1.1	ATF temp. 40°C (104°F)																																																							
		Approx. 0.4	ATF temp. 80°C (176°F)																																																							
2E ↔ 2L	kΩ	2.2-3.5	Constant (Ign: OFF)																																																							
2J ↔ 2L	Ω	500-1,000	Constant (Ign: OFF)																																																							
2C	V	2.0-4.5V	Ignition switch ON																																																							
		0V	Ignition switch OFF																																																							
2H	V	B+	Engine running at idle																																																							
		Below 1.0	Throttle opening above 1/8 (Engine coolant temp. below 40°C (104°F))																																																							
2P	V	Below 1.0	Shifting																																																							
		B+	Engine running at idle																																																							
TERMINAL	FUNCTION																																																									
2R	ATF thermosensor																																																									
2E	Vehicle speed pulse generator																																																									
2J	Vehicle speed sensor																																																									
2C	Barometric absolute pressure sensor																																																									
2H	Reduce torque signal																																																									
2P	Torque reduced signal																																																									
2L	Ground (input)																																																									

54		NO ENGINE BRAKING	
<b>DESCRIP-TION</b>		<ul style="list-style-type: none"> <li>• Engine speed drops to idle but vehicle does not slow when accelerator pedal released during cruising at medium to high speed</li> <li>• Engine speed drops to idle but vehicle does not slow when accelerator pedal released when in L range at low vehicle speed</li> </ul>	
<b>[TROUBLESHOOTING HINTS]</b>			
① ATF level low ② Powertrain slippage ③ Control valve stuck (overrunning clutch control valve, overrunning clutch reducing valve, 1st reducing valve, or pilot valve)		④ Overrunning clutch solenoid valve worn ⑤ Throttle position sensor malfunction or misadjusted ⑥ 4GR inhibit signal (ASC signal) malfunction ⑦ Park/Neutral switch worn or misadjusted	
STEP	INSPECTION		ACTION
1	Are ATF level and condition OK? ☞ page K-25 	Yes	Go to next step
		No	Problem within transmission Go to next step and check for the main cause When the problem is found, overhaul the transmission and repair or replace parts as necessary
2	Are there any diagnostic trouble code(s) displayed on the Self-Diagnosis Checker when the ignition switch is ON? ☞ page K-214 	Yes	Check for cause of code(s) ☞ page K-214
		No	Go to next step
3	Is there slippage when accelerating or shifting, or flare up when shifting?	Yes	Powertrain slipped Go to No.50 "ENGINE SPEED FLARES UP WHEN ACCELERATING" or No.51 "ENGINE SPEED FLARES UP WHEN UP-SHIFTING AND/OR DOWNSHIFTING" in section K of this manual ☞ page K-202, 203
		No	Go to next step

# K

## SYMPTOM TROUBLESHOOTING

STEP	INSPECTION	ACTION																																																								
4	Is engine braking felt in L range? ☞ page K-21	Yes Go to next step																																																								
		No Replace control valve body assembly ☞ page K-128  If problem remains, overhaul transmission and repair or replace parts as necessary																																																								
5	Are resistance and output voltage of overrunning clutch solenoid valve at powertrain control module (Transmission) terminal OK?  B+: Battery positive voltage	Yes Go to next or replace step																																																								
		No If resistance not OK, check for overrunning clutch solenoid valve and wiring ☞ page K-32  If resistance OK and voltage not, go to next step																																																								
<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="3">1O</td> <td>Ω</td> <td>20-40</td> <td>Constant (Ign: OFF)</td> <td rowspan="3">K-35</td> </tr> <tr> <td rowspan="2">V</td> <td>Below 1.0</td> <td>2nd gear and throttle opening less than 1.3/8 in S range hold mode</td> </tr> <tr> <td>B+</td> <td>4GR</td> </tr> </tbody> </table> <p>Unit: V → Resistance Ω → Voltage</p>			Term.	Unit	Spec.	Condition	Page	1O	Ω	20-40	Constant (Ign: OFF)	K-35	V	Below 1.0	2nd gear and throttle opening less than 1.3/8 in S range hold mode	B+	4GR																																									
Term.	Unit	Spec.	Condition	Page																																																						
1O	Ω	20-40	Constant (Ign: OFF)	K-35																																																						
	V	Below 1.0	2nd gear and throttle opening less than 1.3/8 in S range hold mode																																																							
		B+	4GR																																																							
6	Are measurements at powertrain control module (Transmission) terminals OK?  B+: Battery positive voltage	Yes Replace powertrain control module (Transmission) ☞ page K-41																																																								
		No Check for malfunctioning parts and wiring <ul style="list-style-type: none"> <li>• Throttle position sensor ☞ section F</li> <li>• 4GR inhibit signal (ASC signal), TAT terminal ☞ page K-35</li> <li>• Park/Neutral switch ☞ page K-28</li> </ul>																																																								
<table border="1"> <thead> <tr> <th>Term.</th> <th>Unit</th> <th>Spec.</th> <th>Condition</th> <th>Page</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2T</td> <td rowspan="2">V</td> <td>0.1-1.1</td> <td>Throttle valve closed throttle position</td> <td rowspan="10">K-35</td> </tr> <tr> <td>4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> <tr> <td rowspan="2">2K</td> <td rowspan="2">V</td> <td>4.5-5.5</td> <td>Ignition switch ON</td> </tr> <tr> <td>0</td> <td>TAT terminal grounded</td> </tr> <tr> <td rowspan="2">2D</td> <td rowspan="2">V</td> <td>0</td> <td>P and N ranges</td> </tr> <tr> <td>B+</td> <td>Except F and N ranges</td> </tr> <tr> <td rowspan="2">1E</td> <td rowspan="2">V</td> <td>B+</td> <td>R range</td> </tr> <tr> <td>0</td> <td>Except R range</td> </tr> <tr> <td rowspan="2">2B</td> <td rowspan="2">V</td> <td>B+</td> <td>D range</td> </tr> <tr> <td>0</td> <td>Except D range</td> </tr> <tr> <td rowspan="2">2S</td> <td rowspan="2">V</td> <td>B+</td> <td>S range</td> </tr> <tr> <td>0</td> <td>Except S range</td> </tr> <tr> <td rowspan="2">2Q</td> <td rowspan="2">V</td> <td>B+</td> <td>L range</td> </tr> <tr> <td>0</td> <td>Except L range</td> </tr> </tbody> </table> <p>Unit: V → Voltage</p> <table border="1"> <thead> <tr> <th>TERMINAL</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>2T</td> <td>Throttle position sensor</td> </tr> <tr> <td>2K</td> <td>4GR inhibit signal, TAT terminal</td> </tr> <tr> <td>2D, 1E, 2B, 2S, 2Q</td> <td>Park/Neutral switch</td> </tr> </tbody> </table>			Term.	Unit	Spec.	Condition	Page	2T	V	0.1-1.1	Throttle valve closed throttle position	K-35	4.0-4.5	Throttle valve wide open throttle	2K	V	4.5-5.5	Ignition switch ON	0	TAT terminal grounded	2D	V	0	P and N ranges	B+	Except F and N ranges	1E	V	B+	R range	0	Except R range	2B	V	B+	D range	0	Except D range	2S	V	B+	S range	0	Except S range	2Q	V	B+	L range	0	Except L range	TERMINAL	FUNCTION	2T	Throttle position sensor	2K	4GR inhibit signal, TAT terminal	2D, 1E, 2B, 2S, 2Q	Park/Neutral switch
Term.	Unit	Spec.	Condition	Page																																																						
2T	V	0.1-1.1	Throttle valve closed throttle position	K-35																																																						
		4.0-4.5	Throttle valve wide open throttle																																																							
2K	V	4.5-5.5	Ignition switch ON																																																							
		0	TAT terminal grounded																																																							
2D	V	0	P and N ranges																																																							
		B+	Except F and N ranges																																																							
1E	V	B+	R range																																																							
		0	Except R range																																																							
2B	V	B+	D range																																																							
		0	Except D range																																																							
2S	V	B+	S range																																																							
		0	Except S range																																																							
2Q	V	B+	L range																																																							
		0	Except L range																																																							
TERMINAL	FUNCTION																																																									
2T	Throttle position sensor																																																									
2K	4GR inhibit signal, TAT terminal																																																									
2D, 1E, 2B, 2S, 2Q	Park/Neutral switch																																																									

# SYMPTOM TROUBLESHOOTING

# K

<b>55</b>	<b>NO MODE CHANGE</b>
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Mode does not change to/from normal mode in D range</li> <li>• Hold mode not selected or not cancelled</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b>	
Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary	
<ul style="list-style-type: none"> <li>① Hold switch malfunction <span style="float: right;">⇨ page K-27</span></li> <li>② Throttle position sensor malfunction or misadjusted <span style="float: right;">⇨ section F</span></li> <li>③ Powertrain control module (Transmission) malfunction <span style="float: right;">⇨ page K-35</span></li> </ul>	

<b>56</b>	<b>TRANSMISSION NOISE ALL RANGES</b>
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Transmission noisy in all ranges when vehicle is idling</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b>	
Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary	
<ul style="list-style-type: none"> <li>① ATF level low <span style="float: right;">⇨ page K-25</span></li> <li>② Throttle position sensor malfunction or misadjusted <span style="float: right;">⇨ section F</span></li> <li>③ Vehicle speed sensor (revolution sensor) malfunction <span style="float: right;">⇨ page K-29</span></li> <li>④ Engine rpm signal malfunction <span style="float: right;">⇨ page K-35</span></li> </ul>	

<b>57</b>	<b>TRANSMISSION NOISE D, S, L, R RANGES</b>
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Abnormal noise from transmission in D, S, L, R</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b>	
Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary	
<ul style="list-style-type: none"> <li>① ATF level low <span style="float: right;">⇨ page K-25</span></li> <li>② Torque converter malfunction <span style="float: right;">⇨ page K-57</span></li> </ul>	

<b>58</b>	<b>TRANSMISSION OVERHEATS</b>
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• ATF smells burnt and/or is discolored</li> </ul>
<b>[TROUBLESHOOTING HINTS]</b>	
Inspect parts and wiring; repair, adjust, or replace malfunctioning parts as necessary	
<ul style="list-style-type: none"> <li>① ATF level low <span style="float: right;">⇨ page K-25</span></li> <li>② Line pressure low <span style="float: right;">⇨ page K-14</span></li> <li>③ Powertrain burnt</li> <li>④ Line pressure solenoid valve stuck <span style="float: right;">⇨ page K-246</span></li> <li>⑤ Dropping resistor malfunction <span style="float: right;">⇨ page K-33</span></li> <li>⑥ Throttle position sensor malfunction or misadjusted <span style="float: right;">⇨ section F</span></li> <li>⑦ Lockup solenoid valve worn <span style="float: right;">⇨ page K-32</span></li> <li>⑧ Lockup control solenoid valve worn <span style="float: right;">⇨ page K-32</span></li> <li>⑨ Oil cooler circuit malfunction <span style="float: right;">⇨ page K-154</span></li> </ul>	

# K

## SELF-DIAGNOSIS FUNCTION

### SELF-DIAGNOSIS FUNCTION

#### DESCRIPTION

The self-diagnosis system integrated in the powertrain control module (Transmission) diagnoses malfunction of the main sensors (input), solenoid valves (output), and of the powertrain control module (Transmission) itself.



Malfunctions or intermittent malfunctions are memorized in the powertrain control module (Transmission) to later be output as diagnostic trouble codes.

The **Self-Diagnosis Checker** can be used to retrieve these diagnostic trouble codes. The **Self-Diagnosis Checker** indicates a malfunction by displaying a code and sounding a buzzer.


When the TAT and GND terminals of the data link connector are jumped with the ignition switch ON, the powertrain control module (Transmission) outputs any memorized diagnostic trouble codes by flashing the hold indicator.

#### PREPARATION

##### SST




<p>49 B019 9A0 System Selector</p> 	<p>For diagnosis of PCMT</p>	<p>49 H018 9A1 Self-Diagnosis Checker</p> 	<p>For diagnosis of PCMT</p>
--	------------------------------	--	------------------------------

#### Assembly of SST



MEMO



**DIAGNOSTIC TROUBLE CODE NUMBER****Inspection Procedure****Self-Diagnosis Checker**

1. Connect the SST (System Selector) to the data link connector.
2. Set the SYSTEM SELECT switch A to position 2.
3. Set the TEST SW to SELF TEST position.
4. Connect the SST (Self-Diagnosis Checker) to the SST (System Selector) and a ground.
5. Set the SELECT SW to position A.
6. Turn the ignition switch ON.
7. Verify that "88" flashes on the digital display and that the buzzer sounds for 3 seconds.
8. If "88" does not flash, check the main relay and terminals 1N and/or 1P of the powertrain control module (Transmission) for an open or short circuit.
9. If "88" flashes and the buzzer sounds continuously for more than 20 seconds, check the wiring to terminal 2N of the powertrain control module (Transmission) for an open or short circuit.  
If necessary, replace the powertrain control module (Transmission) and repeat from step 2.
10. Note any code(s) and check for the cause(s). Repair as necessary.
11. After repairs are made, do the After-Repair Procedure (Refer to page K-234) to verify that there are no remaining codes.

Diagnostic trouble code number

Code No.	Indicator flashing pattern	Diagnosed circuit	Condition	Point	Memo-rized	Page
01		Engine rpm signal	No input signal from ECU	<ul style="list-style-type: none"> <li>Wiring from powertrain control module (Engine) to powertrain control module (Transmission)</li> <li>Powertrain control module (Engine)</li> </ul>	Yes	K-219
06		Vehicle speed sensor (Revolution sensor)	No input signal from vehicle speed sensor (Revolution sensor)	<ul style="list-style-type: none"> <li>Vehicle speed sensor connector</li> <li>Wiring from vehicle speed sensor to powertrain control module (Transmission)</li> <li>Vehicle speedometer sensor resistance</li> </ul>	Yes	K-220
07		Vehicle speedometer sensor	No input signal from vehicle speedometer sensor	<ul style="list-style-type: none"> <li>Vehicle speedometer sensor connector</li> <li>Wiring from vehicle speedometer sensor to combination meter</li> <li>Wiring from combination meter to powertrain control module (Transmission)</li> <li>Speedometer resistance</li> </ul>	Yes	K-221
12		Throttle position sensor	Open or short circuit of throttle position sensor or wiring	<ul style="list-style-type: none"> <li>Throttle position sensor connector</li> <li>Wiring from throttle position sensor to powertrain control module (Transmission)</li> <li>Throttle position sensor resistance</li> </ul>	Yes	K-222
55		Vehicle speed pulse generator	No input signal from vehicle speed pulse generator	<ul style="list-style-type: none"> <li>Vehicle speed pulse generator connector</li> <li>Wiring from vehicle speed pulse generator to powertrain control module (Transmission)</li> <li>Vehicle speed pulse generator resistance</li> </ul>	Yes	K-223
56		ATF thermo-sensor	Open or short circuit of ATF thermosensor or wiring	<ul style="list-style-type: none"> <li>ATF thermosensor connector</li> <li>Wiring from ATF thermosensor to powertrain control module (Transmission)</li> <li>ATF thermosensor resistance</li> </ul>	Yes	K-224
57		Reduce torque signal/Slip lock-up signal, torque reduced signal	Open or short circuit of reduce torque signal/slip lockup signal wiring, and/or torque reduced signal wiring	<ul style="list-style-type: none"> <li>Wiring from powertrain control module (Engine) to powertrain control module (Transmission)</li> <li>Powertrain control module (Transmission)</li> <li>Powertrain control module (engine)</li> </ul>	Yes	K-225
58		Barometric absolute pressure sensor	Open or short circuit of barometric absolute pressure sensor wiring	<ul style="list-style-type: none"> <li>Wiring from powertrain control module (Engine) to powertrain control module (Transmission)</li> <li>Powertrain control module (engine)</li> </ul>	Yes	K-226
60		Shift A solenoid valve	Open or short circuit of solenoid valve wiring	<ul style="list-style-type: none"> <li>Solenoid valve connector</li> <li>Wiring from solenoid valve to powertrain control module (Transmission)</li> <li>Solenoid valve resistance</li> <li>Wiring from dropping resistor to powertrain control module (Transmission) (Only No.64)</li> <li>Dropping resistor resistance (Only No.64)</li> </ul>	Yes	K-227
61		Shift B solenoid valve			Yes	K-228
62		Overrunning clutch solenoid valve			Yes	K-229
63		Lockup solenoid valve			Yes	K-230
64		Line pressure solenoid valve			Yes	K-231
65		Lockup control solenoid valve			Yes	K-233


# K

## SELF-DIAGNOSIS FUNCTION

### Note


- If there is more than one malfunction, the codes will be indicated in numerical order, lowest number first.

### Diagnostic trouble code display pattern example

Diagnostic trouble code number	Display pattern
55	


DIAGNOSTIC TROUBLE CODE NO.01		ENGINE RPM SIGNAL													
STEP	INSPECTION	ACTION													
1	Are there any poor connections at distributor, powertrain control module (Engine) and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector												
		No	Go to next step												
2	Connect a circuit tester to terminals as shown Is input voltage of engine rpm signal at powertrain control module (Transmission) OK? <b>☞ page K-35</b>	Yes	Go to step 5												
		No	Go to next step												
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">(+ term.)</th> <th style="text-align: center;">(- term.)</th> <th style="text-align: center;">Voltage (V)</th> <th style="text-align: center;">Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center; vertical-align: middle;">1G</td> <td rowspan="3" style="text-align: center; vertical-align: middle;">Ground</td> <td style="text-align: center;">0</td> <td>Engine stopped</td> </tr> <tr> <td style="text-align: center;">0.3-0.8</td> <td>Engine idling</td> </tr> <tr> <td style="text-align: center;">1.8-2.2</td> <td>Engine running at 3,000 rpm (no load)</td> </tr> </tbody> </table>				(+ term.)	(- term.)	Voltage (V)	Condition	1G	Ground	0	Engine stopped	0.3-0.8	Engine idling	1.8-2.2	Engine running at 3,000 rpm (no load)
(+ term.)	(- term.)	Voltage (V)	Condition												
1G	Ground	0	Engine stopped												
		0.3-0.8	Engine idling												
		1.8-2.2	Engine running at 3,000 rpm (no load)												
3	Disconnect 16-pin powertrain control module (Transmission) connector Is there continuity between terminal 1G of powertrain control module (Transmission) and terminal 2B of powertrain control module (Engine)	Yes	Go to next step												
		No	Repair wiring												
4	Connect a circuit tester to terminals as shown Is input voltage of engine rpm signal at powertrain control module (Engine) OK? <b>☞ section F</b>	Yes	Go to next step												
		No	Check crank angle sensor and/or wiring <b>☞ section F</b>  If OK, replace powertrain control module (Engine) If not OK, repair or replace malfunction parts and/or wiring												
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">(+ term.)</th> <th style="text-align: center;">(- term.)</th> <th style="text-align: center;">Voltage (V)</th> <th style="text-align: center;">Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center; vertical-align: middle;">2B</td> <td rowspan="3" style="text-align: center; vertical-align: middle;">Ground</td> <td style="text-align: center;">0</td> <td>Engine stopped</td> </tr> <tr> <td style="text-align: center;">0.3-0.8</td> <td>Engine idling</td> </tr> <tr> <td style="text-align: center;">1.8-2.2</td> <td>Engine running at 3,000 rpm (no load)</td> </tr> </tbody> </table>				(+ term.)	(- term.)	Voltage (V)	Condition	2B	Ground	0	Engine stopped	0.3-0.8	Engine idling	1.8-2.2	Engine running at 3,000 rpm (no load)
(+ term.)	(- term.)	Voltage (V)	Condition												
2B	Ground	0	Engine stopped												
		0.3-0.8	Engine idling												
		1.8-2.2	Engine running at 3,000 rpm (no load)												
5	Disconnect negative battery cable for at least 20 seconds, and depress the brake pedal. Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed? <b>☞ page K-234</b>	Yes	Replace powertrain control module (Transmission) <b>☞ page K-41</b>												
		No	Intermittent poor connection Check for cause												

### CIRCUIT DIAGRAM




DIAGNOSTIC TROUBLE CODE NO.06		VEHICLE SPEED SENSOR (REVOLUTION SENSOR)								
STEP	INSPECTION	ACTION								
1	Are there any poor connections at vehicle speed sensor and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector							
		No	Go to next step							
2	Connect a circuit tester to terminals as shown Is input voltage of vehicle speed sensor at powertrain control module (Transmission) OK? ☞ page K-35	Yes	Go to step 5							
		No	Go to next step							
				<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Voltage (V)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2J</td> <td rowspan="2">2L</td> <td>Approx. above 1.0 (AC range)</td> <td>While driving (above 25km/h {16MPH})</td> </tr> <tr> <td>Approx. 0 (AC range)</td> <td>Vehicle stopped</td> </tr> </tbody> </table>	(+) term.	(-) term.	Voltage (V)	Condition	2J	2L
(+) term.	(-) term.	Voltage (V)	Condition							
2J	2L	Approx. above 1.0 (AC range)	While driving (above 25km/h {16MPH})							
		Approx. 0 (AC range)	Vehicle stopped							
3	Disconnect 20-pin powertrain control module (Transmission) connector Is resistance between terminal 2J and terminal 2L OK? <b>Resistance: 500-1,000 Ω</b>	Yes	Go to step 5							
		No	Go to next step							
4	Disconnect vehicle speed sensor connector Is resistance of sensor OK? ☞ page K-29	Yes	Check wiring and connectors from powertrain control module (Transmission) to vehicle speed sensor If OK, go to next step If not OK, repair wiring and/or connector							
		No	Replace vehicle speed sensor ☞ page K-29							
				<table border="1"> <thead> <tr> <th>Terminal</th> <th>Resistance (Ω)</th> </tr> </thead> <tbody> <tr> <td>A ↔ B</td> <td>500-1,000</td> </tr> <tr> <td>B ↔ C</td> <td>∞</td> </tr> <tr> <td>A ↔ C</td> <td>∞</td> </tr> </tbody> </table>	Terminal	Resistance (Ω)	A ↔ B	500-1,000	B ↔ C	∞
Terminal	Resistance (Ω)									
A ↔ B	500-1,000									
B ↔ C	∞									
A ↔ C	∞									
5	Disconnect negative battery cable for at least 20 seconds, and depress the brake pedal. Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed? ☞ page K-234	Yes	Replace powertrain control module (Transmission) ☞ page K-41							
		No	Intermittent poor connection Check for cause							

### CIRCUIT DIAGRAM




DIAGNOSTIC TROUBLE CODE NO.07		VEHICLE SPEEDOMETER SENSOR													
STEP	INSPECTION		ACTION												
1	Are there any poor connections at vehicle speedometer sensor and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector												
		No	Go to next step												
2	Connect a circuit tester to terminals as shown Is input voltage of vehicle speedometer sensor at powertrain control module (Transmission) OK? ☞ page K-35	Yes	Go to step 8												
		No	Go to next step												
<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Voltage (V)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td>1I</td> <td>Ground</td> <td>2-3</td> <td>Vehicle moving</td> </tr> <tr> <td></td> <td></td> <td>0 or 4.5-5.5</td> <td>Vehicle stopped</td> </tr> </tbody> </table>		(+) term.	(-) term.	Voltage (V)	Condition	1I	Ground	2-3	Vehicle moving			0 or 4.5-5.5	Vehicle stopped		
(+) term.	(-) term.	Voltage (V)	Condition												
1I	Ground	2-3	Vehicle moving												
		0 or 4.5-5.5	Vehicle stopped												
3	Remove combination meter Is there continuity between terminal 3E of meter connector and terminal 1I of powertrain control module (Transmission)?	Yes	Go to next step												
		No	Repair or replace wiring and/or connector												
4	Connect circuit tester to terminals 3C and 3A of meter connector Does pointer of circuit tester move slightly when rear wheels are slowly turned? ☞ page K-29	Yes	Go to next step												
		No	Replace speedometer												
5	Remove vehicle speedometer sensor Is resistance felt when turning speedometer driven gear by hand? ☞ page K-30	Yes	Go to next step												
		No	Replace vehicle speedometer sensor ☞ page K-30												
6	Disconnect vehicle speedometer sensor connector and connect circuit tester Does pointer of circuit tester move slightly when driven gear is slowly turned? ☞ page K-30	Yes	Go to next step												
		No	Replace vehicle speedometer sensor ☞ page K-30												
7	Disconnect vehicle speedometer sensor connector Is continuity of sensor OK? ☞ page K-30  Resistance: Approx. 290 Ω (20°C (68°F)); reference	Yes	Check wiring and connectors from vehicle speedometer sensor to speedometer If OK, go to next step If not OK, repair wiring and/or connector												
		No	Replace vehicle speedometer sensor ☞ page K-30												
8	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed? ☞ page K-234	Yes	Replace powertrain control module (Transmission) ☞ page K-41												
		No	Intermittent poor connection Check for cause												

CIRCUIT DIAGRAM




DIAGNOSTIC TROUBLE CODE NO.12		THROTTLE POSITION SENSOR											
STEP	INSPECTION		ACTION										
1	Are there any poor connections at throttle position sensor and powertrain control module (Transmission) connector or terminal?	Yes	Repair or replace connector										
		No	Go to next step										
2	Connect a circuit tester to terminals as shown Is input voltage of throttle position sensor (TVO) at powertrain control module (Transmission) OK? ☞ page K-35	Yes	Go to step 5										
		No	Go to next step										
<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Voltage (V)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2T</td> <td rowspan="2">Ground</td> <td>0.1-1.1</td> <td>Throttle valve closed throttle position</td> </tr> <tr> <td>4.0-4.5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table>				(+) term.	(-) term.	Voltage (V)	Condition	2T	Ground	0.1-1.1	Throttle valve closed throttle position	4.0-4.5	Throttle valve wide open throttle
(+) term.	(-) term.	Voltage (V)	Condition										
2T	Ground	0.1-1.1	Throttle valve closed throttle position										
		4.0-4.5	Throttle valve wide open throttle										
3	Connect a circuit tester to terminals as shown Is input voltage of throttle position sensor (VREP) at powertrain control module (Transmission) OK? ☞ page K-35	Yes	Go to next step										
		No	Check voltage at terminal 3I of powertrain control module (Engine)  <b>Voltage: 4.5-5.5V (ignition switch ON)</b>  If OK, go to next step If not OK, repair wiring and/or connector, or replace powertrain control module (Transmission)										
<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Voltage (V)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2A</td> <td rowspan="2">Ground</td> <td>4.5-5.5</td> <td>Ignition switch ON</td> </tr> <tr> <td>0</td> <td>Ignition switch OFF</td> </tr> </tbody> </table>				(+) term.	(-) term.	Voltage (V)	Condition	2A	Ground	4.5-5.5	Ignition switch ON	0	Ignition switch OFF
(+) term.	(-) term.	Voltage (V)	Condition										
2A	Ground	4.5-5.5	Ignition switch ON										
		0	Ignition switch OFF										
4	Is throttle position sensor OK? ☞ section F	Yes	Check wiring and connectors from powertrain control module (Transmission) to throttle position sensor If OK, go to next step If not OK, repair wiring and/or connector										
		No	Adjust or replace throttle position sensor ☞ section F										
5	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed? ☞ page K-234	Yes	Replace powertrain control module (Transmission) ☞ page K-41										
		No	Intermittent poor connection Check for cause										

### CIRCUIT DIAGRAM



DIAGNOSTIC TROUBLE CODE NO.55		VEHICLE SPEED PULSE GENERATOR											
STEP	INSPECTION	ACTION											
1	Are there any poor connections at vehicle speed pulse generator and powertrain control module (Transmission) connector or terminal?	Yes	Repair or replace connector										
		No	Go to next step										
2	Connect a circuit tester to terminals as shown Is input voltage of vehicle speed pulse generator at powertrain control module (Transmission) OK? ☞ page K-35	Yes	Go to step 5										
		No	Go to next step										
<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Voltage (V)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2E</td> <td rowspan="2">2L</td> <td>Approx. 0 above 0.5 (AC range)</td> <td>While driving (above 25km/h {16mph})</td> </tr> <tr> <td>Approx. 0 (AC range)</td> <td>Vehicle stopped</td> </tr> </tbody> </table>		(+) term.	(-) term.	Voltage (V)	Condition	2E	2L	Approx. 0 above 0.5 (AC range)	While driving (above 25km/h {16mph})	Approx. 0 (AC range)	Vehicle stopped		
(+) term.	(-) term.	Voltage (V)	Condition										
2E	2L	Approx. 0 above 0.5 (AC range)	While driving (above 25km/h {16mph})										
		Approx. 0 (AC range)	Vehicle stopped										
3	Disconnect 20-pin powertrain control module (Transmission) connector Is resistance between terminal 2E and terminal 2L OK? <b>Resistance: 2.2-3.5 kΩ</b>	Yes	Go to next step										
		No	Go to next step										
4	Disconnect vehicle speed pulse generator connector Is resistance of vehicle speed pulse generator OK? ☞ page K-30	Yes	Check wiring and connectors from powertrain control module (Transmission) to vehicle speed pulse generator If OK, go to next step If not OK, repair wiring and/or connector										
		No	Replace vehicle speed pulse generator ☞ page K-31										
<table border="1"> <thead> <tr> <th>Terminal</th> <th>Resistance (KΩ)</th> </tr> </thead> <tbody> <tr> <td>A ↔ B</td> <td>2.2-3.5</td> </tr> <tr> <td>B ↔ C</td> <td>∞</td> </tr> <tr> <td>A ↔ C</td> <td>∞</td> </tr> </tbody> </table>		Terminal	Resistance (KΩ)	A ↔ B	2.2-3.5	B ↔ C	∞	A ↔ C	∞				
Terminal	Resistance (KΩ)												
A ↔ B	2.2-3.5												
B ↔ C	∞												
A ↔ C	∞												
5	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed. Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed? ☞ page K-234	Yes	Replace powertrain control module (Transmission) ☞ page K-41										
		No	Intermittent poor connection Check for cause										


CIRCUIT DIAGRAM





DIAGNOSTIC TROUBLE CODE NO.56		ATF THERMOSENSOR													
STEP	INSPECTION	ACTION													
1	Are there any poor connections at ATP thermosensor and powertrain control module (Transmission) connector or terminal?	Yes	Repair or replace connector												
		No	Go to next step												
2	Connect a circuit tester to terminals as shown Is input voltage of ATF thermosensor at powertrain control module (Transmission) OK? <b>☞ page K-35</b>	Yes	Go to step 5												
		No	Go to next step												
<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Voltage (V)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="3">2R</td> <td rowspan="3">2L</td> <td>Approx. 1.8</td> <td>ATF temp. 10°C {50°F}</td> </tr> <tr> <td>Approx. 1.1</td> <td>ATF temp. 40°C {104°F}</td> </tr> <tr> <td>Approx. 0.4</td> <td>ATF temp. 80°C {176°F}</td> </tr> </tbody> </table>				(+) term.	(-) term.	Voltage (V)	Condition	2R	2L	Approx. 1.8	ATF temp. 10°C {50°F}	Approx. 1.1	ATF temp. 40°C {104°F}	Approx. 0.4	ATF temp. 80°C {176°F}
(+) term.	(-) term.	Voltage (V)	Condition												
2R	2L	Approx. 1.8	ATF temp. 10°C {50°F}												
		Approx. 1.1	ATF temp. 40°C {104°F}												
		Approx. 0.4	ATF temp. 80°C {176°F}												
3	Disconnect 20-pin powertrain control module (Transmission) connector Is resistance between terminal 2R and terminal 2L OK?	Yes	Go to step 5												
		No	Go to next step												
<table border="1"> <thead> <tr> <th>Terminal</th> <th>Resistance (KΩ)</th> </tr> </thead> <tbody> <tr> <td rowspan="3">2R ↔ 2L</td> <td>Approx. 3.8 ATF temp. 10°C {50°F}</td> </tr> <tr> <td>Approx. 1.2 ATF temp. 40°C {104°F}</td> </tr> <tr> <td>Approx. 0.3 ATF temp. 80°C {176°F}</td> </tr> </tbody> </table>				Terminal	Resistance (KΩ)	2R ↔ 2L	Approx. 3.8 ATF temp. 10°C {50°F}	Approx. 1.2 ATF temp. 40°C {104°F}	Approx. 0.3 ATF temp. 80°C {176°F}						
Terminal	Resistance (KΩ)														
2R ↔ 2L	Approx. 3.8 ATF temp. 10°C {50°F}														
	Approx. 1.2 ATF temp. 40°C {104°F}														
	Approx. 0.3 ATF temp. 80°C {176°F}														
4	Disconnect solenoid connector Is resistance between terminal G and terminal H of ATF thermosensor OK? <b>☞ page K-32</b>	Yes	Check wiring and connectors from powertrain control module (Transmission) to ATF thermosensor If OK, go to next step If not OK, repair wiring and/or connector												
		No	Replace ATF thermosensor <b>☞ page K-31</b>												
<table border="1"> <thead> <tr> <th>Terminal</th> <th>Resistance (KΩ)</th> </tr> </thead> <tbody> <tr> <td rowspan="3">G ↔ H</td> <td>Approx. 3.8 ATF temp. 10°C {50°F}</td> </tr> <tr> <td>Approx. 1.2 ATF temp. 40°C {104°F}</td> </tr> <tr> <td>Approx. 0.3 ATF temp. 80°C {176°F}</td> </tr> </tbody> </table>				Terminal	Resistance (KΩ)	G ↔ H	Approx. 3.8 ATF temp. 10°C {50°F}	Approx. 1.2 ATF temp. 40°C {104°F}	Approx. 0.3 ATF temp. 80°C {176°F}						
Terminal	Resistance (KΩ)														
G ↔ H	Approx. 3.8 ATF temp. 10°C {50°F}														
	Approx. 1.2 ATF temp. 40°C {104°F}														
	Approx. 0.3 ATF temp. 80°C {176°F}														
5	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed? <b>☞ page K-234</b>	Yes	Replace powertrain control module (Transmission) <b>☞ page K-41</b>												
		No	Intermittent poor connection Check for cause												


### CIRCUIT DIAGRAM



# SELF-DIAGNOSIS FUNCTION


**K**

DIAGNOSTIC TROUBLE CODE NO.57		REDUCE TORQUE SIGNAL / SLIP LOCKUP SIGNAL, TORQUE REDUCED SIGNAL											
STEP	INSPECTION	ACTION											
1	Are there any poor connections at powertrain control module (Engine) and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector										
		No	Go to next step										
2	Connect a circuit tester to terminals as shown Is input voltage of torque reduced signal at powertrain control module (Transmission) OK? ⚡ page K-35 B+: Battery positive voltage	Yes	Go to step 4										
		No	Go to next step										
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">(+ term.)</th> <th style="width: 10%;">(- term.)</th> <th style="width: 15%;">Voltage (V)</th> <th style="width: 75%;">Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">2H</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">B+</td> <td>Engine idling</td> </tr> <tr> <td style="text-align: center;">Below 1.0</td> <td>Throttle opening above 1/8 (Engine coolant temp below 40°C {104°F})</td> </tr> </tbody> </table>				(+ term.)	(- term.)	Voltage (V)	Condition	2H	Ground	B+	Engine idling	Below 1.0	Throttle opening above 1/8 (Engine coolant temp below 40°C {104°F})
(+ term.)	(- term.)	Voltage (V)	Condition										
2H	Ground	B+	Engine idling										
		Below 1.0	Throttle opening above 1/8 (Engine coolant temp below 40°C {104°F})										
3	Disconnect 20-pin powertrain control module (Transmission) connector Is there continuity between terminal 2H of powertrain control module (Transmission) and terminal 2G of powertrain control module (Engine)?	Yes	Go to next step										
		No	Repair wiring										
4	Connect a circuit tester to terminals as shown Is input voltage of torque reduced signal at powertrain control module (Transmission) OK? ⚡ page K-35 B+: Battery positive voltage	Yes	Go to step 6										
		No	Go to next step										
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">(+ term.)</th> <th style="width: 10%;">(- term.)</th> <th style="width: 15%;">Voltage (V)</th> <th style="width: 75%;">Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">2P</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Below 1.0</td> <td>When shifting from 1st to 2nd or from 2nd to 3GR with the throttle opening above 1.5/8 When slip lockup with the throttle opening below 0.5/8</td> </tr> <tr> <td style="text-align: center;">B+</td> <td>Engine idling</td> </tr> </tbody> </table>				(+ term.)	(- term.)	Voltage (V)	Condition	2P	Ground	Below 1.0	When shifting from 1st to 2nd or from 2nd to 3GR with the throttle opening above 1.5/8 When slip lockup with the throttle opening below 0.5/8	B+	Engine idling
(+ term.)	(- term.)	Voltage (V)	Condition										
2P	Ground	Below 1.0	When shifting from 1st to 2nd or from 2nd to 3GR with the throttle opening above 1.5/8 When slip lockup with the throttle opening below 0.5/8										
		B+	Engine idling										
5	Disconnect 20-pin powertrain control module (Transmission) connector Is there continuity between terminal 2P of powertrain control module (Transmission) and terminal 1Q of powertrain control module (Engine)?	Yes	Go to next step										
		No	Repair wiring										
6	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed? ⚡ page K-234	Yes	Replace powertrain control module (Transmission) or powertrain control module (Engine) ⚡ page K-41										
		No	Intermittent poor connection Check for cause										



DIAGNOSTIC TROUBLE CODE NO.58		BAROMETRIC ABSOLUTE PRESSURE SENSOR											
STEP	INSPECTION	ACTION											
1	Are there any poor connections at powertrain control module (Engine) and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector										
		No	Go to next step										
2	Connect a circuit tester to terminals as shown Is input voltage of barometric absolute pressure sensor at powertrain control module (Transmission) OK? ☞ page K-35	Yes	Go to step 5										
		No	Go to next step										
<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Voltage (V)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2C</td> <td rowspan="2">Ground</td> <td>2.0-4.5</td> <td>Ignition switch ON</td> </tr> <tr> <td>0V</td> <td>Ignition switch OFF</td> </tr> </tbody> </table>				(+) term.	(-) term.	Voltage (V)	Condition	2C	Ground	2.0-4.5	Ignition switch ON	0V	Ignition switch OFF
(+) term.	(-) term.	Voltage (V)	Condition										
2C	Ground	2.0-4.5	Ignition switch ON										
		0V	Ignition switch OFF										
3	Disconnect 20-pin powertrain control module (Transmission) connector Is there continuity between terminal 2C of powertrain control module (Transmission) and terminal 2D of powertrain control module (Engine)?	Yes	Go to next step										
		No	Repair wiring										
4	Connect a circuit tester to terminals as shown Is output voltage of barometric absolute pressure sensor at powertrain control module (Engine) OK? ☞ section F	Yes	Go to next step										
		No	Replace powertrain control module (Engine) ☞ section F										
<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Voltage (V)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2D</td> <td rowspan="2">Ground</td> <td>2.0-4.5V</td> <td>Ignition switch ON</td> </tr> <tr> <td>0V</td> <td>Ignition switch OFF</td> </tr> </tbody> </table>				(+) term.	(-) term.	Voltage (V)	Condition	2D	Ground	2.0-4.5V	Ignition switch ON	0V	Ignition switch OFF
(+) term.	(-) term.	Voltage (V)	Condition										
2D	Ground	2.0-4.5V	Ignition switch ON										
		0V	Ignition switch OFF										
5	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed? ☞ page K-234	Yes	Replace powertrain control module (Transmission) ☞ page K-41										
		No	Intermittent poor connection Check for cause										

### CIRCUIT DIAGRAM




# SELF-DIAGNOSIS FUNCTION

**K**


DIAGNOSTIC TROUBLE CODE NO.60		SHIFT A SOLENOID VALVE											
STEP	INSPECTION		ACTION										
1	Are there any poor connections at solenoid valve and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector										
		No	Go to next step										
2	Connect a circuit tester to terminals as shown Is output voltage of shift A solenoid valve at powertrain control module (Transmission) OK? ⇨ page K-35  B+: Battery positive voltage	Yes	Check wiring and go to step 5										
		No	Go to next step										
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">(+ term.)</th> <th style="width: 10%;">(-) term.</th> <th style="width: 15%;">Voltage (V)</th> <th style="width: 25%;">Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">1D</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">B+</td> <td style="text-align: center;">1st, 4GR gear</td> </tr> <tr> <td style="text-align: center;">Below 1.0</td> <td style="text-align: center;">2nd, 3GR gear</td> </tr> </tbody> </table>				(+ term.)	(-) term.	Voltage (V)	Condition	1D	Ground	B+	1st, 4GR gear	Below 1.0	2nd, 3GR gear
(+ term.)	(-) term.	Voltage (V)	Condition										
1D	Ground	B+	1st, 4GR gear										
		Below 1.0	2nd, 3GR gear										
3	Disconnect 16-pin powertrain control module (Transmission) connector Is resistance between terminal 1D and a ground  Resistance: 20-40Ω	Yes	Go to step 5										
		No	Go to next step										
4	Disconnect solenoid connector Is resistance between ground and terminal B of shift A solenoid valve OK?  Resistance: 20-40Ω  ⇨ page K-32	Yes	Check wiring and connectors from powertrain control module (Transmission) to shift A solenoid valve If OK, go to next step If not OK, repair wiring and/or connector										
		No	Replace shift A solenoid valve  ⇨ page K-33										
5	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed?  ⇨ page K-234	Yes	Replace powertrain control module (Transmission)  ⇨ page K-41										
		No	Intermittent poor connection Check for cause										

## CIRCUIT DIAGRAM




DIAGNOSTIC TROUBLE CODE NO.61		SHIFT B SOLENOID VALVE											
STEP	INSPECTION	ACTION											
1	Are there any poor connections at solenoid valve and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector										
		No	Go to next step										
2	Connect a circuit tester to terminals as shown Is output voltage of shift B solenoid valve at powertrain control module (Transmission) OK? ☞ page K-35  B+: Battery positive voltage	Yes	Check wiring and go to step 5										
		No	Go to next step										
<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Voltage (V)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1B</td> <td rowspan="2">Ground</td> <td>B+</td> <td>1st, 2nd gear</td> </tr> <tr> <td>Below 1.0</td> <td>3GR, 4GR gear</td> </tr> </tbody> </table>				(+) term.	(-) term.	Voltage (V)	Condition	1B	Ground	B+	1st, 2nd gear	Below 1.0	3GR, 4GR gear
(+) term.	(-) term.	Voltage (V)	Condition										
1B	Ground	B+	1st, 2nd gear										
		Below 1.0	3GR, 4GR gear										
3	Disconnect 16-pin powertrain control module (Transmission) connector Is resistance between terminal 1B and a ground OK?  Resistance: 20-40Ω	Yes	Go to step 5										
		No	Go to next step										
4	Disconnect solenoid connector Is resistance between ground and terminal C of shift B solenoid valve OK?  Resistance: 20-40Ω  ☞ page K-32	Yes	Check wiring and connectors from powertrain control module (Transmission) to shift B solenoid valve If OK, go to next step If not OK, repair wiring and/or connector										
		No	Replace shift B solenoid valve  ☞ page K-33										
5	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed?  ☞ page K-234	Yes	Replace powertrain control module (Transmission)  ☞ page K-41										
		No	Intermittent poor connection Check for cause										

### CIRCUIT DIAGRAM




DIAGNOSTIC TROUBLE CODE NO.62		OVERRUNNING CLUTCH SOLENOID VALVE											
STEP	INSPECTION	ACTION											
1	Are there any poor connections at solenoid valve and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector										
		No	Go to next step										
2	Connect a circuit tester to terminals as shown Is output voltage of overrunning clutch solenoid valve at powertrain control module (Transmission) OK?  ⚡ page K-35  B+: Battery positive voltage	Yes	Check wiring and go to step 5										
		No	Go to next step										
<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Voltage (V)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1O</td> <td rowspan="2">Ground</td> <td>B+</td> <td>D range (throttle valve closed)</td> </tr> <tr> <td>Below 1.0</td> <td>D range (throttle valve wide open throttle)</td> </tr> </tbody> </table>				(+) term.	(-) term.	Voltage (V)	Condition	1O	Ground	B+	D range (throttle valve closed)	Below 1.0	D range (throttle valve wide open throttle)
(+) term.	(-) term.	Voltage (V)	Condition										
1O	Ground	B+	D range (throttle valve closed)										
		Below 1.0	D range (throttle valve wide open throttle)										
3	Disconnect 16-pin powertrain control module (Transmission) connector Is resistance between terminal 1O and a ground OK?  Resistance: 20-40Ω	Yes	Go to step 5										
		No	Go to next step										
4	Disconnect solenoid connector Is resistance between ground and terminal D of overrunning clutch solenoid valve OK?  Resistance: 20-40Ω ⚡ page K-32	Yes	Check wiring and connectors from powertrain control module (Transmission) to overrunning clutch solenoid valve If OK, go to next step If not OK, repair wiring and/or connector										
		No	Replace overrunning clutch solenoid valve ⚡ page K-33										
5	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed? ⚡ page K-234	Yes	Replace powertrain control module (Transmission) ⚡ page K-41										
		No	Intermittent poor connection Check for cause										

CIRCUIT DIAGRAM



DIAGNOSTIC TROUBLE CODE NO.63		LOCKUP SOLENOID VALVE											
STEP	INSPECTION	ACTION											
1	Are there any poor connections at solenoid valve and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector										
		No	Go to next step										
2	Disconnect 16-pin powertrain control module (Transmission) connector Is resistance between terminal 1M and a ground OK?  <b>Resistance: 10-20Ω</b>	Yes	Go to step 4										
		No	Go to next step										
3	Disconnect solenoid connector Is resistance between ground and terminal F of lockup solenoid valve OK?  <b>Resistance: 10-20Ω</b> ⚡ page K-32	Yes	Check wiring and connectors from powertrain control module (Transmission) to lockup solenoid valve If OK, go to next step If not OK, repair wiring and/or connector										
		No	Replace lockup solenoid valve      ⚡ page K-33										
4	Connect a dwell meter to terminals as shown Is output duty of lockup solenoid valve at powertrain control module (Transmission) OK?  ⚡ page K-247	Yes	Go to next step										
		No	Replace powertrain control module (Transmission)      ⚡ page K-41										
<table border="1"> <thead> <tr> <th>(+) term.</th> <th>(-) term.</th> <th>Duty (ON %)</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1M</td> <td rowspan="2">Ground</td> <td>Approx. 5</td> <td>No lockup</td> </tr> <tr> <td>Approx. 100</td> <td>Lockup</td> </tr> </tbody> </table>				(+) term.	(-) term.	Duty (ON %)	Condition	1M	Ground	Approx. 5	No lockup	Approx. 100	Lockup
(+) term.	(-) term.	Duty (ON %)	Condition										
1M	Ground	Approx. 5	No lockup										
		Approx. 100	Lockup										
5	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed?      ⚡ page K-234	Yes	Replace powertrain control module (Transmission)      ⚡ page K-41										
		No	Intermittent poor connection Check for cause										

### CIRCUIT DIAGRAM




# SELF-DIAGNOSIS FUNCTION

# K

DIAGNOSTIC TROUBLE CODE NO.64		LINE PRESSURE SOLENOID VALVE											
STEP	INSPECTION		ACTION										
1	Are there any poor connections at solenoid valve and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector										
		No	Go to next step										
2	Disconnect 16-pin powertrain control module (Transmission) connector Is resistance between terminal 1F (line pressure solenoid valve) and a ground OK?  <b>Resistance: 2.5–5.0Ω</b>	Yes	Go to next step										
		No	Go to step 4										
3	Disconnect 16-pin powertrain control module (Transmission) connector Is resistance between terminal 1H (dropping resistor) and a ground OK?  <b>Resistance: 12.5–19.0Ω</b>	Yes	Go to step 5										
		No	Go to step 7										
4	Disconnect solenoid connector Is resistance between ground and terminal E of line pressure solenoid valve OK?  <b>Resistance: 2.5–5.0Ω</b> ⇨ page K-32	Yes	Check wiring and connectors from powertrain control module (Transmission) to line pressure solenoid valve If OK, go to next step If not OK, repair wiring and/or connector										
		No	Replace line pressure solenoid valve      ⇨ page K-33										
5	Connect a dwell meter to terminals as shown Is output duty of dropping resistor at powertrain control module (Transmission) OK?  ⇨ page K-246	Yes	Go to next step										
		No	Replace powertrain control module (Transmission), perform road test, and go to step 8  ⇨ page K-41,16										
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">(+ ) term.</th> <th style="width: 15%;">(-) term.</th> <th style="width: 15%;">Duty (ON %)</th> <th style="width: 55%;">Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center; vertical-align: middle;">1H</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">Ground</td> <td style="text-align: center;">Approx. 100</td> <td>Throttle valve closed throttle</td> </tr> <tr> <td style="text-align: center;">Approx. 5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table>				(+ ) term.	(-) term.	Duty (ON %)	Condition	1H	Ground	Approx. 100	Throttle valve closed throttle	Approx. 5	Throttle valve wide open throttle
(+ ) term.	(-) term.	Duty (ON %)	Condition										
1H	Ground	Approx. 100	Throttle valve closed throttle										
		Approx. 5	Throttle valve wide open throttle										
6	Connect a dwell meter to terminals as shown Is output duty of line pressure solenoid valve at powertrain control module (Transmission) OK?  ⇨ page K-246	Yes	Go to next step										
		No	Replace powertrain control module (Transmission), perform road test, and go to step 8  ⇨ page K-41,16										
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">(+ ) term.</th> <th style="width: 15%;">(-) term.</th> <th style="width: 15%;">Duty (ON %)</th> <th style="width: 55%;">Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center; vertical-align: middle;">1F</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">Ground</td> <td style="text-align: center;">Approx. 100</td> <td>Throttle valve closed throttle position</td> </tr> <tr> <td style="text-align: center;">Approx. 5</td> <td>Throttle valve wide open throttle</td> </tr> </tbody> </table>				(+ ) term.	(-) term.	Duty (ON %)	Condition	1F	Ground	Approx. 100	Throttle valve closed throttle position	Approx. 5	Throttle valve wide open throttle
(+ ) term.	(-) term.	Duty (ON %)	Condition										
1F	Ground	Approx. 100	Throttle valve closed throttle position										
		Approx. 5	Throttle valve wide open throttle										
7	Disconnect dropping resistor connector Is resistance of resistor OK?  <b>Resistance: 10–14Ω</b> ⇨ page K-33	Yes	Check wiring and connectors from powertrain control module (Transmission) to dropping resistor If OK, go to next step If not OK, repair wiring and/or connector										
		No	Repair or dropping resistor      ⇨ page K-33										
8	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed?  ⇨ page K-234	Yes	Replace powertrain control module (Transmission)      ⇨ page K-41										
		No	Intermittent poor connection Check for cause										



CIRCUIT DIAGRAM





# SELF-DIAGNOSIS FUNCTION

**K**

DIAGNOSTIC TROUBLE CODE NO.65		LOCKUP CONTROL SOLENOID VALVE											
STEP	INSPECTION	ACTION											
1	Are there any poor connections at solenoid valve and powertrain control module (Transmission) connectors?	Yes	Repair or replace connector										
		No	Go to next step										
2	Connect a circuit fester to terminals as shown Is output voltage of lockup control solenoid valve at powertrain control module (Transmission) OK?  <div style="text-align: center;"> <b>☞ page K-35</b>                           B+: Battery positive voltage                     </div> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">(+ ) term.</th> <th style="width: 10%;">(-) term.</th> <th style="width: 15%;">Voltage (V)</th> <th style="width: 15%;">Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">2F</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">B+</td> <td style="text-align: center;">Lockup</td> </tr> <tr> <td style="text-align: center;">Below 1.0</td> <td style="text-align: center;">No lockup</td> </tr> </tbody> </table>	(+ ) term.	(-) term.	Voltage (V)	Condition	2F	Ground	B+	Lockup	Below 1.0	No lockup	Yes	Check wiring and go to step 5
		(+ ) term.	(-) term.	Voltage (V)	Condition								
2F	Ground	B+	Lockup										
		Below 1.0	No lockup										
No	Go to next step												
3	Disconnect 20-pin powertrain control module (Transmission) connector Is resistance between terminal 2F and a ground OK?  <b>Resistance: 20-40Ω</b>	Yes	Go to step 5										
		No	Go to next step										
4	Disconnect solenoid connector Is resistance between ground and terminal A of lockup control solenoid valve OK?  <b>Resistance: 20-40Ω</b> <div style="text-align: right;"><b>☞ page K-32</b></div>	Yes	Check wiring and connectors from powertrain control module (Transmission) to lockup control solenoid valve If OK, go to next step If not OK, repair wiring and/or connector										
		No	Replace lockup control solenoid valve  <div style="text-align: right;"><b>☞ page K-33</b></div>										
5	Disconnect negative battery cable for at least 20 seconds and the brake pedal is depressed Connect battery cable and recheck for diagnostic trouble code Is diagnostic trouble code displayed?  <div style="text-align: right;"><b>☞ page K-234</b></div>	Yes	Replace powertrain control module (Transmission)  <div style="text-align: right;"><b>☞ page K-41</b></div>										
		No	Intermittent poor connection Check for cause										

## CIRCUIT DIAGRAM





**DRIVE AT 50 km/h {31 MPH}**

**KICKDOWN**

**STOP THE VEHICLE**

**After-Repair Procedure**

1. Cancel the memory of diagnostic trouble codes by disconnecting the negative battery cable for at least **20 seconds** and the brake pedal is depressed. Reconnect the battery cable.
2. Remove the **SST (Self-diagnosis Checker)** if connected.
3. Drive the vehicle at 50 km/h {31MPH}, and depress the accelerator pedal fully to activate kickdown. Stop the vehicle gradually.
4. Connect the **SST (Self-diagnosis Checker)** to the data link connector.
5. Turn the ignition switch to ON.
6. Verify that no codes are displayed.

**SERVICE POINTS**

**OUTLINE**

**Hold Switch**

- If the wiring of the hold switch is open or shorted, selection to/from hold mode is not possible.

**Park/Neutral Switch**

- If a malfunction occurs in the wiring of the park/neutral switch, the powertrain control module (Transmission) cannot determine the range position, and shifting may be abnormal in D, S, and L ranges. There may not be a shift to Fourth gear.

**Throttle Position Sensor**

- If the wiring of the throttle position sensor is open or shorted, diagnostic trouble code No.12 is displayed by the self-diagnosis function, and hold mode is canceled.
- If a malfunction occurs in the throttle position sensor, the powertrain control module (Transmission) judges the throttle opening signals from the idle signal, and sets the line pressure as follows:

Idle signal	Throttle opening angle	Line pressure
OFF (throttle valve opened)	4/8 stroke	Maximum
ON (throttle valve closed throttle position)	0/8 stroke	Minimum

**Idle Signal**

- If the wiring is open, the powertrain control module (Transmission) does not correct the throttle characteristics. In this case, lockup is not canceled when cruising (closed throttle position) and vehicle jolts when accelerator pedal is depressed or released.
- If the wiring is shorted, the line pressure will be low (does not match throttle characteristics) and the transmission may slip when shifting.

**Vehicle Speed Sensor**

- If there is no input signal from vehicle speed sensor, diagnostic trouble code No.06 is displayed by the self-diagnosis function and hold mode is canceled.
- Shifting is made based on signals from vehicle speedometer sensor.
- If a malfunction occurs in vehicle speed sensor and vehicle speedometer sensor at the same time, shift A and B solenoid valve go OFF and D and S ranges become in Third gear position, L range becomes in 2nd gear position, and lockup is inhibited.

**Vehicle Speedometer Sensor**

- If there is no input signal from vehicle speedometer sensor, diagnostic trouble code No.07 is displayed by the self-diagnosis function, and hold mode is canceled.
- If a malfunction occurs in vehicle speedometer sensor, shifting is made normal based on signals from the vehicle speed sensor (revolution sensor).
- If a malfunction occurs in vehicle speed sensor and vehicle speedometer sensor at the same time, shift A and B solenoid valve go OFF and D and S ranges become in Third gear position, L range becomes in 2nd gear position, and lockup is inhibited.

**Vehicle Speed Pulse Generator**

- If no input signal from the vehicle speed pulse generator, diagnostic trouble code No.55 is displayed by the self-diagnosis function and hold mode is canceled.
- If a malfunction occurs in the vehicle speed pulse generator, the torque reduction control function is inhibited.

The gear position at shifting cannot be determined and timing control at shifting is made based on signals from vehicle speed sensor (revolution sensor). Shift shock may be slightly strong.

**Stoplight Switch**

- If the wiring of the stoplight switch is open or shorted, PCMT control is made normal.
- If the wiring is shorted to the battery power, there may be a shift from Fourth gear to Third gear when the throttle valve is at the closed throttle position.

**Torque Reduced Signal**

- If the wiring is open or shorted, diagnostic trouble code No.57 is displayed by the self-diagnosis function and hold mode is canceled.
- If a malfunction occurs in the torque reduced signal, the torque reduction control function is inhibited and the line pressure characteristics will be high when shifting. Shift shock may be slightly strong.
- If a malfunction occurs in the reduce torque signal or slip lockup signal, diagnostic trouble code No.57 is displayed by the self-diagnosis function.

**Mileage Switch**

- If the wiring is open, the line pressure characteristics will be slightly high. Shift shock may be slightly strong when shifting from 1st to 2nd or from 2nd to Third gear.
- If the wiring is shorted, the transmission may slip when shifting from 1st to 2nd or from 2nd to Third gear until the total mileage of the vehicle exceeds approximately 600 km {372 miles}.

**Water Thermostat**

- If the wiring of the water thermostat is open or shorted, PCMT control is made normal.
- If the wiring is shorted, the engine coolant temperature may increase.

**A/C Signal**

- If the wiring is open, normal mode, A/C ON is selected because an ON A/C signal is judged.
- If the wiring is shorted, normal mode, A/C OFF is selected because an OFF A/C signal is judged.

**Slip Lockup OFF Signal**

- If the wiring of the slip lockup OFF signal is open or shorted, PCMT control is made normal.

**Engine RPM Signal**

- If there is no input signal from the engine rpm signal, diagnostic trouble code No.01 is displayed by the self-diagnosis function and hold mode is canceled.
- If a malfunction occurs in the engine rpm signal, lockup shock may be slightly strong.

**ATF Thermosensor**

- If the wiring is open, diagnostic trouble code No.56 is memorized by the self-diagnosis function. Line pressure is set at maximum and Fourth gear and lockup are inhibited.
- If the wiring is shorted, diagnostic trouble code No.56 is memorized by the self-diagnosis function. Shift shock at low ATF temperature may be strong.

**Barometric Absolute Pressure Sensor**

- If the wiring is open or shorted, diagnostic trouble code No.58 is displayed by the self-diagnosis function. Line pressure is not controlled correctly at high altitude and shift shock will be strong.

**4GR Inhibit Signal (ASC Signal)**

- If the wiring is open, there is no input signal from the cruise control unit and acceleration feeling (driving performance) will be deteriorated when the vehicle speed drops 8km/h {5mph} below the set speed or RESUME/ACCEL switch is operated during cruise control operation.
- If the wiring is shorted, there is no shift to Fourth gear.

**TAT Terminal (Data Link Connector)**

- If the wiring is open, diagnostic trouble code(s) are not displayed by the self-diagnosis function.
- If the wiring is shorted, diagnostic trouble code(s) memorized in the powertrain control module (Transmission) are displayed by hold indicator.

**Shift A and B Solenoid Valve**

- If the wiring is open or shorted, diagnostic trouble code No.60 for shift A solenoid valve or diagnostic trouble code No.61 for shift B solenoid valve is displayed and hold mode is canceled.
- If either solenoid valve malfunctions, both solenoid valves go OFF and D and S ranges become in Third gear position, L range becomes in 2nd gear position, and lockup is inhibited.

**Line Pressure Solenoid Valve**

- If the wiring is open or shorted, diagnostic trouble code No.64 is displayed by the self-diagnosis function and hold mode is canceled.
- If a malfunction occurs in the line pressure solenoid valve, line pressure is set at maximum to make driving possible.
- If a malfunction occurs in the dropping resistor, diagnostic trouble code No.64 is displayed by the self-diagnosis function.

**Lockup Solenoid Valve**

- If the wiring is open or shorted, diagnostic trouble code No.63 is displayed by the self-diagnosis function and hold mode is canceled.
- If a malfunction occurs in the lockup solenoid valve, the solenoid valve goes OFF and lockup is canceled.

**Lockup Control Solenoid Valve**

- If the wiring is open or shorted, diagnostic trouble code No.65 is displayed by the self-diagnosis function and hold mode is canceled.
- If a malfunction occurs in the lockup control solenoid valve, the solenoid valve goes OFF and lockup is canceled.

**Overrunning Clutch Solenoid Valve**

- If the wiring is open or shorted, diagnostic trouble code No.62 is displayed by the self-diagnosis function and hold mode is canceled.
- If a malfunction occurs in the overrunning clutch solenoid valve, the solenoid valve goes OFF and the overrunning clutch engages. Engine braking is available when coasting. There is no shift to Fourth gear.

**Dropping Resistor**

- If the wiring is open or shorted, diagnostic trouble code No.64 is displayed by the self-diagnosis function and hold mode is canceled.
- If a malfunction occurs in the dropping resistor, the line pressure is set at maximum to make driving possible.
- If a malfunction occurs in the line pressure solenoid valve, diagnostic trouble code No.64 is displayed by the self-diagnosis function.

**Reduce Torque Signal**

- If the wiring is open or shorted, diagnostic trouble code No.57 is displayed by the self-diagnosis function and hold mode is canceled.
- If a malfunction occurs in the reduce torque signal, the torque reduction control function is inhibited and line pressure will be high at shifting. Shift shock may be slightly strong.
- If a malfunction occurs in the torque reduced signal or slip lockup signal, diagnostic trouble code No.57 is displayed by the self-diagnosis function.

**Slip Lockup Signal**

- If the wiring is open or shorted, diagnostic trouble code No.57 is displayed by the self-diagnosis function and hold mode is canceled.
- If a malfunction occurs in the slip lockup signal, the torque reduction control function is inhibited and line pressure will be high at shifting. Shift shock may be slightly strong.
- If a malfunction occurs in the torque reduced signal or reduce torque signal, diagnostic trouble code No.57 is displayed by the self-diagnosis function.

**Inhibitor Signal**

- If the wiring is open, the engine speed will be slightly low in P and N ranges.
- If the wiring is shorted, the engine speed will be slightly high in R, D, S, and L ranges.

**Hold Indicator Light**

- If the wiring is open, the hold indicator light will not illuminate.
- If the wiring is shorted, the hold indicator light will remain illuminated.
- If the wiring between the FAT terminal and terminal 2N is open or shorted, diagnostic trouble code(s) will not be displayed by the self-diagnosis function.







**K**

**SERVICE POINTS**

---

**MEMO**

**ELECTRICAL DIAGNOSIS SUPPORT**

**Hold Switch**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2I – hold switch	Mode does not change when hold switch is not operated	Mode does not change when hold switch is operated	Shifting may be abnormal Mode may change when hold switch not operated
Hold switch-ground		No symptom	

**Park/Neutral Switch**

If the park/neutral switch fuse burns out while the vehicle is being driven, the Powertrain control module (Transmission) will operate as if in the current range only. If the ignition switch is turned from OFF to ON after the fuse burns out, the vehicle can still be driven, but the Powertrain control module (Transmission) will operate as if in N range, and will inhibit lockup.

**R Range Switch**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1E – R range switch	No symptom	METER 15A fuse burns out when R range is selected	May not shift to 4GR in D range S, L range shift pattern may be same as D range
R range switch – battery		Fuse burns out	
R range switch – range indicator light	Range indicator light does not illuminate	METER 15A fuse burns out when R range is selected	

**L Range Switch**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2Q – L range switch	L range shift pattern may be same as D or S range	METER 15A fuse burns out when L range is selected	May not shift to 4GR in D range S, L range shift pattern may be same as D range
L range switch – battery		Fuse burns out	
L range switch – range indicator light	Range indicator light does not illuminate	METER 15A fuse burns out when L range is selected	

**S Range Switch**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2S – S range switch	S range shift pattern may be same as D or L range	METER 15A fuse burns out when S range is selected	May not shift to 4GR in D range S, R range shift pattern may be same as D range
S range switch – battery		Fuse burns out	
S range switch – range indicator light	Range indicator light does not illuminate	METER 15A fuse burns out when S range is selected	

**D Range Switch**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2B – D range switch	D range shift pattern may be same as S or L range	METER 15A fuse burns out when D range is selected	May not shift to 4GR in D range S, R range shift pattern may be same as D range
D range switch – battery		Fuse burns out	
D range switch – range indicator light	Range indicator light does not illuminate	METER 15A fuse burns out when D range is selected	

**P, N Range Switch**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2D – P, N range switch	No symptom	IG KEY 40A fuse burns out when ignition switch turned START	May not shift to 4GR in D range S, L range shift pattern may be same as D range
P, N range switch – starter circuit	Starter does not operate		

NA: Not applicable

### Throttle Position Sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2A – throttle position sensor	Code No.12 output Shift point incorrect and shift shock strong	Code No.12 output Shift point incorrect and shift shock strong	Line pressure will be abnormal and clutch may slip if Powertrain control module (Transmission) does not judge malfunction Vehicle may jolt
Powertrain control module (Transmission) terminal 2T – throttle position sensor			

### Idle Signal

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2M – Powertrain control module (Engine) terminal 2E	Vehicle jolts when accelerator pedal depressed or released	Clutches may slip when shifting	Line pressure will be abnormal and clutches may slip if Powertrain control module (Transmission) does not judge Vehicle malfunction may jolt

### Vehicle Speed Sensor (Revolution Sensor)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2J – vehicle speed sensor	Code No.06 output	Code No.06 output	NA
Vehicle speed sensor – ground (Powertrain control module (Transmission) terminal 2L)		NA	

### Vehicle Speedometer Sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 11 – vehicle speedometer sensor	Code No.07 output	Code No.07 output	NA

### Vehicle Speed Pulse Generator

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2E – vehicle speed pulse generator	Code No.55 output Shift shock may be slightly strong	Code No.55 output Shift shock may be slightly strong	NA
Vehicle speed pulse generator – ground (Powertrain control module (Transmission) terminal 2L)		NA	

### Stoplight Switch

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2Q – stoplight switch	No symptom	Stop 15A fuse burns out when brake pedal is depressed	NA
Stoplight switch – battery		NA	

NA: Not applicable

**Torque Reduced Signal**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2H - Powertrain control module (Engine) terminal 2G	Code No.57 output Shift shock may be slightly strong	Code No.57 output Shift shock may be slightly strong	NA

**Mileage Switch**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2N - speedometer	Shift shock may be strong when shifting from 1st to 2nd or from 2nd to 3GR	Transmission may slip when shifting from 1st to 2nd or from 2nd to 3GR until the total mileage of the vehicle exceeds approximately 600 km {372 mile}	NA

**Water Thermoswitch**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2N - water thermoswitch	Acceleration feeling (driving performance) will be deteriorated	Engine coolant temperature may increase	Acceleration feeling (driving performance) will be deteriorated

**A/C Signal**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1L - Powertrain control module (Engine) terminal 1K	Will always be normal, A/C ON mode	Will always be normal, A/C OFF mode	NA

**Slip Lockup OFF Signal**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2G - Powertrain control module (Engine) terminal 2C	No symptom	No symptom	NA

**Engine RPM Signal**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1G - Powertrain control module (Engine) terminal 2B	Code No.01 output Lockup shock will be strong	Code No.01 output Lockup shock will be strong	NA

**ATF Thermosensor**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2R - ATF thermosensor	Code No.56 output 4GR and lockup will be inhibited	No code No.56 output Shift shock will be strong at low ATF temperature	NA
ATF thermosensor - ground (Powertrain control module (Transmission) terminal 2L)		NA	

NA: Not applicable

### Barometric Absolute Pressure Sensor

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2C – Powertrain control module (Engine) terminal 2D	Code No.58 output Shift shock will be strong at high altitude	Code No.58 output Shift shock will be strong at high altitude	NA

### 4GR Inhibit Signal (ASC Signal)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2K – cruise control unit terminal 1G	4GR not inhibited when 4GR inhibit signal ON	Does not shift to 4GR Always diagnoses Powertrain control module (Transmission) system	NA

### TAT Terminal (Data Link Connector)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2K – TAT terminal	Does not diagnose PCMT system	Always diagnoses Powertrain control module (Transmission) system Does not shift to 4GR	NA

### Shift A Solenoid Valve

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1D – shift A solenoid valve	Code No.60 output D, S range: Third gear fixed L range: 2nd gear fixed	Code No. 60 output D, S range: Third gear fixed L range: 2nd gear fixed	Shifting may be abnormal if Powertrain control module (Transmission) does not judge malfunction
Shift A solenoid valve – ground		No symptom	

### Shift B Solenoid Valve

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1B – shift B solenoid valve	Code No.61 output D, S range: Third gear fixed L range: 2nd gear fixed	Code No.61 output D, S range: Third gear fixed L range: 2nd gear fixed	Shifting may be abnormal if Powertrain control module (Transmission) does not judge malfunction
Shift B solenoid valve – ground		No symptom	

### Line Pressure Solenoid Valve

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1F – line pressure solenoid valve	Code No.64 output Shift shock and select shock will be strong	Code No.64 output Shift shock and select shock will be strong	Shifting may be abnormal if Powertrain control module (Transmission) does not judge malfunction
Line pressure solenoid valve – ground		No symptom	

### Lockup Solenoid Valve

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1M – lockup solenoid valve	Code No.63 output Lockup will not operate	Code No.63 output Lockup will not operate	Lockup may not be operated in lockup zone
Lockup solenoid valve – ground		No symptom	

NA: Not applicable

**Lockup Control Solenoid Valve**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2P – lockup control solenoid valve	Code No.65 output Lockup will not operate	Code No.65 output Lockup will not operate	Lockup may not be operated in lockup zone
Lockup control solenoid valve – ground		No symptom	

**Overrunning Clutch Solenoid Valve**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1O – overrunning clutch solenoid valve	Code No.62 output Engine breaking always operated during coasting Does not shift to 4GR	Code No.62 output Engine breaking always operated during coasting Does not shift to 4GR	May not shift to 4GR
Overrunning clutch solenoid valve – ground		No symptom	

**Dropping Resister**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1H – dropping resister	Code No.64 output Shift shock and select shock will be strong	Code No.64 output Shift shock and select shock will be strong	NA
Dropping resister – solenoid valve (line pressure)			

**Reduce Torque Signal**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2P – Powertrain control module (Engine) terminal 1Q	Code No.57 output Shift shock may be slightly strong	Code No.57 output Shift shock may be slightly strong	NA

**Slip Lockup Signal**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 2P – Powertrain control module (Engine) terminal 1Q	Code No.57 output Shift shock may be slightly strong	Code No.57 output Shift shock may be slightly strong	NA

**Inhibitor Signal**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1C – Powertrain control module (Engine) terminal 1R	Engine speed will be slightly low in P and N ranges	Engine speed will be slightly high in R, D, S, and L ranges	NA

**Hold Indicator Light**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1K – Hold indicator light	Hold indicator light not illuminated	Hold indicator light always illuminated	NA

NA: Not applicable

# K

## SERVICE POINTS

### FAT Terminal (Data Link Connector)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1K – FAT terminal (data link connector)	Diagnostic trouble code(s) not displayed by self-diagnosis function When using Self-Diagnosis Checker, "88" flashes after 20 seconds	Diagnostic trouble code(s) not displayed by self-diagnosis function When using Self-Diagnosis Checker, "88" flashes after 20 seconds	NA

### Battery Power (Backup)

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1A – battery	Memory functions that rely on Self-Diagnosis, such as diagnostic trouble code memory, do not operate	ROOM 10A fuse burns out	NA

### Battery Power

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Powertrain control module (Transmission) terminal 1N – battery	No symptom	METER 15A fuse burns out when ignition switch is ON	NA
Powertrain control module (Transmission) terminal 1P – battery	No symptom	METER 15A fuse burns out when ignition switch is ON	NA
Powertrain control module (Transmission) terminals 1N and 1P – battery	Powertrain control module (Transmission) does not function D, S range: Third gear fixed L range: 2nd gear fixed	METER 15A fuse burns out when ignition switch is ON	NA

### Ground

Circuit	Condition		
	Open circuit	Short circuit	Poor around
Powertrain control module (Transmission) 1J terminal – ground	Powertrain control module (Transmission) does not function D, S range: Third gear fixed L range: 2nd gear fixed	No symptom	Shifting may be abnormal

NA: Not applicable


If a solenoid circuit or sensor circuit has poor grounding, the following malfunctions may exist:

1. Abnormal shifting
  - Shift points abnormal
  - Transmission hunts (repeated upshifting/downshifting)
  - Drives away except in 1st gear
  - Does not shift to Fourth gear.
  - Fail-safe function may be operated by on-board diagnosis system according to extent of malfunction
2. Deterioration of shift feeling
  - Oil pressure high and shift shock strong
  - Shift timing incorrect and engine flares up
  - Shift timing incorrect and vehicle brakes on shifting
  - Fail-safe function may be operated by on-board diagnosis system according to extent of malfunction

**SYSTEM INSPECTION**

**LINE PRESSURE SOLENOID VALVE OUTPUT DUTY Inspection**

1. Connect the (+) terminal of a dwell meter to terminal 1F (line pressure solenoid valve) and terminal 1H (dropping resistor) of the powertrain control module (Transmission). Set the dwell meter selector to the 4 cylinder position.
2. Turn the ignition switch to ON.
3. Depress and release the accelerator pedal, and verify the OFF duty ratio by using the dwell meter.




Throttle opening	Duty ratio (ON %)
Closed throttle position (0/8)	Approx. 100
Wide open throttle (8/8)	Approx. 5


**Dwell angle/Duty ratio relationship**

Dwell angle (°)	0	18	36	54	72	90
Duty ratio (%)	0	20	40	60	80	100

4. Depress the accelerator pedal slowly and verify the duty ratio changes as shown in the graph.
5. If not as specified, check the powertrain control module (Transmission) (refer to page K-35), dropping resistor (refer to page K-33), and line pressure solenoid (refer to page K-32).







### LOCKUP SOLENOID VALVE OUTPUT DUTY

#### Inspection


1. Connect the (+) terminal of a dwell meter to terminal 1M of the powertrain control module (Transmission) and the (-) terminal to a ground.
2. Drive the vehicle and verify the OFF duty ratio in the lockup condition by using the dwell meter.
3. Verify the duty ratio in the lockup condition.

Condition	Duty ratio (ON %)
No lockup	Approx. 5
Lockup	Approx. 95

#### Dwell angle/Duty ratio relationship

Dwell angle (°)	0	18	36	54	72	90
Duty ratio (%)	0	20	40	60	80	100

4. If not as specified, check the powertrain control module (Transmission) (refer to page K-35), and lockup solenoid valve (refer to page K-32).



### MANUAL OPERATION TEST

#### Inspection

1. Disconnect solenoid connector.
2. Accelerate the vehicle from 0 km/h, and determine the gear position by observing the engine speed.  
When vehicle speed is 40 km/h {25 mph}, engine rpm in 2nd gear should be approximately 2,300 rpm, and in Third gear it should be approximately 1,500 rpm.
3. Verify the gear position of each range.

Range	Gear Position
D range	3rd, fixed
S range	3rd, fixed
L range	2nd, fixed
R range	Reverse

4. If not within specification, check the oil pressure or transmission.

**MEMO**




# PROPELLER SHAFT

<b>OUTLINE</b> .....	<b>L - 2</b>
<b>SPECIFICATIONS</b> .....	<b>L - 2</b>
<b>TROUBLESHOOTING GUIDE</b> .....	<b>L - 2</b>
<b>PROPELLER SHAFT</b> .....	<b>L - 3</b>
<b>PREPARATION</b> .....	<b>L - 3</b>
<b>REMOVAL/INSPECTION/ INSTALLATION</b> .....	<b>L - 3</b>

OUTLINE

SPECIFICATIONS

Item	Engine / Transmission		RE 13B (TURBO)	
			R15M-D (MT)	RB4A-EL (AT)
Length	mm (in)	L	863 {33.98}	875 {34.45}
Outer diameter	mm (in)	D	75 {3.0}	




TROUBLESHOOTING GUIDE

Problem	Possible cause	Action	Page
Vibration	Bent propeller shaft	Replace	L-3
	Worn or damaged universal joint	Replace	L-3
	Worn slip yoke or splines	Replace	L-3
	Damaged slip yoke	Replace	L-3
	Damaged universal joint yoke	Replace	L-3
Abnormal noise	Worn or damaged universal joint	Replace	L-3
	Damaged slip yoke	Replace	L-3
	Damaged universal joint yoke	Replace	L-3
	Worn slip yoke or splines	Replace	L-3

PROPELLER SHAFT


PREPARATION

SST


49 S120 440		For prevention of oil leakage
-------------	---	-------------------------------

REMOVAL / INSPECTION / INSTALLATION

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Clean the propeller shaft (except for the universal joint) with a steam cleaner or solvent.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.



- |                                  |                                 |                           |
|----------------------------------|---------------------------------|---------------------------|
| 1. Left undercover               | 5. Secondary air injection pipe | 11. Propeller shaft       |
| 2. Right undercover              | 6. Catalytic converter assembly | Removal Note              |
| 3. Tunnel reinforcement (center) | 7. Cover                        | ..... page L-4            |
| 4. Tunnel reinforcement (rear)   | 8. Nut                          | Inspection ..... page L-4 |
|                                  | 9. Lock washer                  | Installation Note         |
|                                  | 10. Bolt                        | ..... page L-4            |




### Removal Note Propeller shaft

1. Before removing the propeller shaft, mark the companion flange and yoke for correct reassembly.




2. Remove the propeller shaft from the extension housing, and immediately install the SST to prevent oil leakage.



### Inspection Propeller shaft

1. Measure the propeller shaft runout with a dial indicator.  
2. If the runout is excessive, replace the propeller shaft assembly.

**Runout: 0.4 mm {0.02 in} max.**



3. Move the universal joint in the direction shown, and inspect joint play.

### Note


#### • Starting torque

##### Front yoke:

30-98 N·m{3.0-10 kgf·m,22-72 ft·lbf}

##### Rear yoke:

30-98 N·m{3.0-10 kgf·m,22-72 ft·lbf}



4. If there is excessive play or the starting torque is not within specification, replace the propeller shaft.

### Installation Note Propeller shaft


1. Align the marks made during removal, and install the propeller shaft. If installing a new propeller shaft, align the differential companion flange precast marking with the tag on the propeller shaft.

### Tightening torque:

50-58 N·m{5.0-6.0 kgf·m,37-43 ft·lbf}

## PROPELLER SHAFT

L



2. Perform a road test and verify that there is no noise or vibration when driving the vehicle.
3. Replace the propeller shaft assembly if noise or vibration comes from it.


L



# FRONT AND REAR AXLES

<b>INDEX</b> .....	<b>M - 2</b>
<b>OUTLINE</b> .....	<b>M - 3</b>
<b>SPECIFICATIONS</b> .....	<b>M - 3</b>
<b>TROUBLESHOOTING GUIDE</b> .....	<b>M - 3</b>
<b>FRONT AXLE</b> .....	<b>M - 4</b>
<b>PREPARATION</b> .....	<b>M - 4</b>
<b>WHEEL HUB / STEERING KNUCKLE</b> ...	<b>M - 4</b>
<b>REAR AXLE</b> .....	<b>M - 9</b>
<b>PREPARATION</b> .....	<b>M - 9</b>
<b>WHEEL HUB</b> .....	<b>M - 9</b>
<b>DRIVE SHAFT</b> .....	<b>M -14</b>
<b>PREPARATION</b> .....	<b>M -14</b>
<b>DRIVE SHAFT</b> .....	<b>M -14</b>
<b>DIFFERENTIAL</b> .....	<b>M -22</b>
<b>PREPARATION</b> .....	<b>M -22</b>
<b>DIFFERENTIAL OIL</b> .....	<b>M -23</b>
<b>OIL SEAL</b> .....	<b>M -24</b>
<b>DIFFERENTIAL (TORQUE SENSING LSD)</b>	<b>M -27</b>

## INDEX



1. Front axle	
Preinspection .....	page M- 4
Removal / Inspection /	
Installation .....	page M- 5
Disassembly / Inspection /	
Assembly .....	page M- 7
2. Rear axle	
Preinspection .....	page M- 9
Removal / Inspection /	
Installation .....	page M-10
Disassembly / Inspection /	
Assembly .....	page M-12

3. Drive shaft	
Preinspection .....	page M-14
Removal / Installation .....	page M-15
Overhaul .....	page M-18
4. Differential	
Differential oil .....	page M-23
Oil seal .....	page M-24
Removal / Installation .....	page M-27
Disassembly / Inspection .....	page M-30
Assembly .....	page M-34

OUTLINE

SPECIFICATION

Item		Engine / Transmission	13B	
			MT	AT
<b>Front axle</b>				
Bearing type		Unitized angular ball bearing		
<b>Rear axle</b>				
Bearing type		Unitized angular ball bearing		
<b>Drive shaft</b>				
Type		Constant velocity (tripod) joint		
Length (between centers of joints)		mm {in}	484.2 {19.06}	
Diameter		mm {in}	29.0 {1.14}	
<b>Differential</b>				
Type		Torque sensing LSD		
Reduction gear		Hypoid gear		
Differential gear		Worm gear		
Reduction ratio			4.100	3.909
Number of teeth	Ring gear		41	43
	Drive pinion gear		10	11
Ring gear size		mm {in}	204.2 {8.038}	
Oil	Grade	API service GL-4 or GL-5		
	Viscosity	Above -18°C (0°F): SAE 90 Below -18°C (0°F): SAE 80		
	Capacity	L {US qt, Imp qt}	1.30 {1.38, 1.14}	




M


TROUBLESHOOTING GUIDE

Problem	Possible Cause	Action	Page
<b>Front axle</b>			
Steering wheel vibration	Worn or damaged wheel bearing	Replace	M-5
Pulls or one-sided braking	Worn or damaged wheel bearing	Replace	M-5
<b>Rear axle</b>			
Abnormal noise	Worn or damaged wheel bearing	Replace	M-12
	Bent drive shaft	Replace	M-15
	Worn drive shaft spline	Replace	M-15
<b>Differential</b>			
Abnormal noise	Insufficient differential oil	Add oil	M-23
	Incorrect differential oil	Replace	M-23
	Worn or damaged side bearing	Replace	M-30
	Worn or damaged ring gear	Replace	M-30
	Worn or damaged drive pinion bearing	Replace	M-30
	Worn or damaged gear in LSD assembly	Replace gear case	M-30
	Worn side gear spline	Replace	M-30
	Improperly adjusted drive pin ion gear preload	Adjust	M-38
	Improperly adjusted ring gear backlash	Adjust	M-39
	Poor contact of ring gear teeth	Adjust	M-41
	Heat bildup	Insufficient differential oil	Add oil
Insufficient drive pinion gear backlash		Adjust	M-39
Excessive bearing preload		Adjust	M-38
Oil leakage	Excessive differential oil	Remove oil	M-23
	Worn or damaged oil seal	Replace	M-24
	Loose differential carrier	Tighten or repair	M-30
No differential operation	Misassembled or damaged	Repair or replace	M-30

### FRONT AXLE

#### PREPARATION SST

<p>49 0118 850C Puller, ball joint</p> 	<p>For removal of ball joint</p>	<p>49 H028 2A0 Replacer set, rubber bushing</p> 	<p>For installation of ABS sensor rotor</p>
<p>49 H028 204 Attachment (Part of 49 H028 2A0)</p> 	<p>For installation of ABS sensor rotor</p>		



### WHEEL HUB / STEERING KNUCKLE

#### Preinspection


#### Wheel bearing play

1. Position a dial indicator against the wheel hub.
2. Push and pull the wheel hub by hand in the axial direction and measure the wheel bearing play.
3. If the bearing play exceeds specification, check and adjust the wheel hub nut torque or replace the wheel hub assembly, if necessary.


**Wheel bearing play: 0.05 mm {0.002 in} max.**

**Removal / Inspection / Installation**


1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheel.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Install the wheel. (Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–86 in·lbf})
7. After installation, check the front wheel alignment. (Refer to section R.)




- |   |   |
|---|---|
| <ol style="list-style-type: none"> <li>1. Tie rod end ball joint<br/>Removal Note ..... page M-6<br/>Service ..... Section N</li> <li>2. Lower arm ball joint<br/>Removal Note ..... page M-6<br/>Service ..... Section R</li> <li>3. ABS wheel-speed sensor<br/>Service ..... Section P</li> <li>4. Hub cap</li> <li>5. Wheel hub nut<br/>Installation Note ..... page M-6</li> <li>6. Brake caliper assembly<br/>Removal Note ..... page M-6<br/>Service ..... Section P</li> </ol> | <ol style="list-style-type: none"> <li>7. Disc plate<br/>Service ..... Section P</li> <li>8. Wheel hub assembly<br/>Inspect for cracks and damage<br/>Inspect bearing for rough rotation<br/>Disassembly / Inspection /<br/>Installation ..... page M-7</li> <li>9. Bolt (upper arm)</li> <li>10. Dust cover<br/>Inspect for cracks and damage</li> <li>11. Steering knuckle<br/>Inspect for cracks and damage</li> </ol> |
|---|---|

**Removal note****Tie rod end ball joint**


1. Loosen the tie rod end nut until it is flush with the end of the stud.
2. With the nut protecting the tie rod end stud, separate the tie rod end from the steering knuckle by using the SST.

**Lower arm ball joint**

1. Loosen the nut until it is flush with the end of the stud.
2. With the nut protecting the ball joint stud, separate the ball joint from the knuckle by using the SST.

**Brake caliper assembly**

Hang the brake caliper assembly out of the way as shown in the figure.

**Installation note****Wheel hub nut**

1. Install a new hub nut and stake it as shown.


**Tightening torque:**

177-235 N·m{18.0-24.0 kgf·m,131-173 ft·lbf}

2. Measure the wheel bearing play. (Refer to page M-4.)


**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



1. ABS sensor rotor  
 Disassembly Note ..... below  
 Assembly Note ..... page M-8
2. Hub bolt  
 Disassembly Note ..... below  
 Assembly Note ..... page M-8

3. Wheel hub  
 Inspect bearing for rough rotation  
 (Not repairable, replace hub assembly)




**Disassembly note  
ABS sensor rotor**

**Note**

- The sensor rotor does not need to be removed unless you are replacing it.

Remove the sensor rotor by using a brass bar and a hammer.




**Hub bolt**


**Note**

- The hub bolts do not need to be removed unless you are replacing them.

Remove the hub bolts by using a press.



**Assembly note**  
**Hub bolt**  
Press in new hub bolts.










**ABS sensor rotor**  
Press on the new sensor rotor by using the SST.




REAR AXLE

PREPARATION  
SST

<p>49 G033 102 Handle</p> 	<p>For removal of axle flange</p>	<p>49 G033 105 Attachment</p> 	<p>For removal of axle flange</p>
<p>49 F026 103 Plate, removing</p> 	<p>For removal of axle flange</p>	<p>49 F027 0A1 Installer set, bearing</p> 	<p>For removal of wheel bearing and installation of axle flange</p>
<p>49 F027 004 Attachment (Part of 49 F027 0A1)</p> 	<p>For installation of wheel bearing</p>	<p>49 F027 005 Attachment (part of 49 F027 0A1)</p> 	<p>For removal of wheel bearing and installation of axle flange</p>
<p>49 H034 201 Block, support</p> 	<p>For installation of wheel bearing</p>		

M



**WHEEL HUB**

**Preinspection**


**Wheel bearing play**

1. Position a dial indicator against the wheel hub.
2. Push and pull the wheel hub by hand in the axial direction and measure the wheel bearing play.
3. If the bearing play exceeds specification, check and adjust the wheel hub nut torque or replace the wheel bearing, if necessary.

**Wheel bearing play: 0.05 mm {0.002 In} max.**


### Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove the wheel.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Install the wheel. (Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–86 ft·lbf})
7. After installation, check the rear wheel alignment. (Refer to section R.)



1. Bolt (upper arm)
2. Bolt (toe control link)
3. Bolt (l-arm)
4. ABS wheel-speed sensor  
Service ..... Section P
5. Wheel hub nut  
Installation Note ..... page M-11
6. Washer


7. Brake caliper assembly  
Removal Note ..... page M-11  
Service ..... Section P
8. Disc plate  
Service ..... Section P
9. Rear hub support assembly  
Removal Note ..... page M-11  
Disassembly / Inspection /  
Assembly ..... page M-12



**Removal note**

**Brake caliper assembly**


Hang the brake caliper assembly as shown in the figure.



**Rear hub support assembly**

**Note**

- If the drive shaft will not come out of the wheel hub easily, install a discarded nut onto the drive shaft so that the nut is flush with the end of the drive shaft. Tap the nut with a copper hammer to loosen the drive shaft from the wheel hub.



**Installation note**

**Wheel hub nut**

1. Install a new hub nut and stake it as shown.


**Tightening torque:**

236–313 N·m{24.0–32.0 kgf·m,174–231 ft·lbf}


2. Check the wheel bearing play. (Refer to page M-9.)

### Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Axle flange assembly<br/>Disassembly Note ..... below<br/>Assembly Note ..... page M-13</li> <li>2. Hub bolt<br/>Disassembly Note ..... page M-13<br/>Assembly Note ..... page M-13</li> </ol> | <ol style="list-style-type: none"> <li>3. Axle flange<br/>Inspect for cracks and damage</li> <li>4. Retaining ring</li> <li>5. Wheel bearing<br/>Disassembly Note ..... page M-13<br/>Assembly Note ..... page M-13</li> <li>6. Rear hub support assembly<br/>Inspect for cracks and damage</li> </ol> |
|--|--|




### Disassembly note

#### Axle flange assembly

1. Remove the axle flange assembly by using the SST.



2. Grind a section of the bearing race until **approx. 0.5 mm {0.02 in}** thickness remains.
3. Cut the race by using a chisel and remove it.




**Hub bolt**

**Note**


- The hub bolts do not need to be removed unless you are replacing them.

Remove the hub bolts by using a press.



**Wheel bearing**


Remove the wheel bearing by using the SST.



**Assembly note**


**Wheel bearing**

Install the new wheel bearing by using the SST.



**Hub bolt**

Press in new hub bolts.





**Axle flange assembly**

Install the axle flange assembly by using the SST.

### DRIVE SHAFT

#### PREPARATION



#### DRIVE SHAFT (TRIPOD JOINT)


##### Preinspection

##### Drive shaft

1. Check the dust boot on the drive shaft for cracks, damage, grease leakage, and a loose boot band.
2. Check the drive shaft for bending, cracks, and wear of the joints and splines.
3. Repair or replace the drive shaft as necessary.


**Removal / Installation**

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove the wheel.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Install the wheel. (Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–86 ft·lbf})
6. Check the rear wheel alignment. (Refer to section R.)




- |                   |                 |
|-------------------|-----------------|
| 1. Wheel hub nut  |                 |
| Removal Note      | ..... page M-16 |
| Installation Note | ..... page M-17 |
| 2. Washer         |                 |
| 3. Bolt (l-arm)   |                 |

- |                   |                 |
|-------------------|-----------------|
| 4. Drive shaft    |                 |
| Removal Note      | ..... page M-16 |
| Installation Note | ..... page M-16 |
| Overhaul          | ..... page M-18 |



**Removal note****Wheel hub nut**

1. Raise the staked portion of the hub nut by using a chisel.
2. Lock the hub by applying the parking brakes.
3. Remove the hub nut.


**Drive shaft****Note**

- If the drive shaft will not come out of the rear hub support easily, install a discarded nut onto the drive shaft so that the nut is flush with the end of the drive shaft. Tap the nut with a copper hammer to loosen the drive shaft from the wheel hub.

1. Pull the rear hub support from the drive shaft.
2. Remove the drive shaft from the differential by using a pry bar.


**Installation note****Drive shaft**

1. Install a new clip onto the drive shaft.
2. Measure the outer diameter of the clip after installing, and replace the clip if it exceeds the specification.



3. With the ends of the clip facing upward, push the drive shaft into the differential. Then pull outward, on the drive shaft to verify that it is securely held by the clip.



**Wheel hub nut**

1. Install a new hub nut and stake it as shown.


**Tightening torque:**

**236–313 N·m{24.0–32.0 kgf·m,174–231 ft·lbf}**


2. Check the wheel bearing play. (Refer to page M-9.)

### Overhaul

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Verify that all parts are free of dust, dirt, and other foreign material immediately before reassembly.
4. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- |  |                 |
|--|-----------------|
| 1. Clip                                |                 |
| 2. Boot band                           |                 |
| Disassembly Note                       | ..... below     |
| Assembly Note                          | ..... page M-21 |
| 3. Boot band                           |                 |
| Disassembly Note                       | ..... below     |
| Assembly Note                          | ..... page M-21 |
| 4. Boot band                           |                 |
| Disassembly Note                       | ..... below     |
| Assembly Note                          | ..... page M-21 |
| 5. Boot band                           |                 |
| Disassembly Note                       | ..... below     |
| Assembly Note                          | ..... page M-21 |
| 6. Outer ring                          |                 |
| Disassembly Note                       | ..... below     |
| Inspect inside bore for wear,          |                 |
| corrosion, and scoring                 |                 |
| Assembly Note                          | ..... page M-21 |
| 7. Snap ring                           |                 |
| Disassembly Note                       | ..... below     |
| Assembly Note                          | ..... page M-21 |
| 8. Tripod joint                        |                 |
| Disassembly Note                       | ..... below     |
| Inspect for wear and damage            |                 |
| Assembly Note                          | ..... page M-21 |
| 9. Boot                                |                 |
| Disassembly Note                       | ..... page M-20 |
| Inspect for damage                     |                 |
| Assembly Note                          | ..... page M-20 |
| 10. Boot                               |                 |
| Disassembly Note                       | ..... page M-20 |
| Inspect for damage                     |                 |
| Assembly Note                          | ..... page M-20 |
| 11. ABS sensor rotor                   |                 |
| Disassembly Note                       | ..... page M-20 |
| Assembly Note                          | ..... page M-20 |
| 12. Shaft and ball joint assembly      |                 |
| Inspect splines for damage and wear    |                 |
| Inspect wheel-side joint for excessive |                 |
| play and rough rotation.               |                 |




**Disassembly note**  
**Boot band**

**Note**


- The wheel-side boot band does not need to be removed unless you are replacing the boot.

1. Pry up the locking tabs of the boot band by using a screwdriver.
2. Remove the band by using pliers.




**Outer ring**

Mark the outer ring and the shaft for proper reassembly.



**Snap ring / Tripod joint**

1. Mark the shaft and tripod joint for proper reassembly.
2. Remove the snap ring by using snap-ring pliers.
3. Drive the tripod joint from the shaft by using a bar and a hammer.




### Boot

#### Note

- The wheel-side boot does not need to be removed unless you are replacing it.

Wrap the splines of the shaft with tape to prevent damaging the boot.




### ABS sensor rotor

#### Note

- The sensor rotor does not need to be removed unless you are replacing it.


Tap the sensor rotor off the drive shaft by using a chisel and a hammer.



### Assembly note


#### ABS sensor rotor

Set a new sensor rotor on the drive shaft and press it on by using the SST.




### Boot

1. Wrap the differential-side splines with tape.




2. Install the wheel-side and differential-side boots, noting the shape and size of each one.
3. Fill the boot with the specified grease (supplied in the boot kit).

Grease amount: 100–120 g (3.53–4.23 oz)



**Tripod joint / Snap ring**


1. Align the marks and install the tripod joint by using a bar and a hammer.
2. Install a new snap ring by using snap-ring pliers.



**Outer ring**


Fill the outer ring and differential-side boot with the specified grease (Supplied in the boot kit).

**Grease amount: 170–190 g (6.01–6.70 oz)**




**Boot band**

1. Install the boot.
2. Carefully lift up the small end of the boot to release any trapped air.
3. Verify that the boot is not dented or twisted.



4. Measure the length of drive shaft.

**Drive shaft length: 791.2–801.2 mm {31.15–31.54 in}**



















5. Fold the new boot band back by pulling on the end with pliers.
6. Lock the end of the boot band by bending the locking tabs.






# M


## DIFFERENTIAL

### DIFFERENTIAL

#### PREPARATION SST

<p>49 V001 795 Installer, oil seal</p> 	<p>For installation of oil seal (companion flange)</p>	<p>49 B001 795 Installer, oil seal</p> 	<p>For installation of oil seal (side bearing)</p>
<p>49 U027 003 Installer, oil seal</p> 	<p>For installation of oil seal (side bearing)</p>	<p>49 B001 797 Handle (Part of 49 B001 795)</p> 	<p>For installation of oil seal (side bearing)</p>
<p>49 M005 561 Hanger, differential carrier</p> 	<p>For disassembly / assembly of differential</p>	<p>49 0107 680A Stand, engine</p> 	<p>For disassembly / assembly of differential</p>
<p>49 S120 710 Holder, coupling flange</p> 	<p>For removal / installation of companion flange nut</p>	<p>49 0839 425C Puller set, bearing</p> 	<p>For Removal of companion flange and side bearing</p>
<p>49 H027 002 Remover, bearing</p> 	<p>For removal of rear bearing</p>	<p>49 UB71 525 Installer, bearing</p> 	<p>For installation of side bearing</p>
<p>49 J027 002 Collar</p> 	<p>For adjustment of pinion height</p>	<p>49 J027 001 Installer, bearing</p> 	<p>For installation of rear bearing race</p>
<p>49 F027 007 Attachment <math>\phi</math> 72</p> 	<p>For installation of front bearing race</p>	<p>49 8531 567 Collar A (Part of 49 8531 565)</p> 	<p>For adjustment of pinion height</p>
<p>49 8531 565 Pinion model</p> 	<p>For adjustment of pinion height</p>	<p>49 0660 555 Gauge block (Part of 49 F027 0A0)</p> 	<p>For adjustment of pinion height</p>

<p>49 F027 0A0</p> <p>Gauge set, pinion height adjustment</p> 	<p>For adjustment of pinion height</p>	<p>49 F401 330B</p> <p>Installer set, bearing</p> 	<p>For installation of rear bearing</p>
<p>49 0727 570</p> <p>Gauge body, pinion height (Part of 49 F027 0A0)</p> 	<p>For adjustment of pinion height</p>	<p>49 G030 338</p> <p>Attachment E</p> 	<p>For installation of rear bearing</p>
<p>49 F401 331</p> <p>Body (Part of 49 F401 330B)</p> 	<p>For installation of rear bearing</p>		



**DIFFERENTIAL OIL**

**Inspection**

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the filler plug.
3. Verify that the oil is at the bottom of the filler plug hole. If it is low, add the specified oil.
4. Install a new washer and the filler plug.

**Tightening torque:**


40-53 N·m{4.0-5.5 kgf·m,29-39 ft·lbf}

**Replacement**

1. Remove the filler and drain plugs.
2. Drain the differential oil into a suitable container.
3. Wipe the plugs clean.
4. Install a new washer and the drain plug.

**Tightening torque:**

40-53 N·m{4.0-5.5 kgf·m,29-39 ft·lbf}



5. Add the specified oil from the filler plug hole until it reaches the bottom of the hole.

**Specified oil**






**Type**

Above - 18°C {0°F}: API GL-4 or GL-5, SAE 90  
 Below - 18°C {0°F}: API GL-4 or GL-5, SAE 80  
 Capacity: 1.30 L {1.38 US qt, 1.14 Imp qt}

6. Install a new washer and the filler plug.

**Tightening torque:**

40-53 N·m{4.0-5.5 kgf·m,29-39 ft·lbf}



## OIL SEAL

### Replacement

#### Oil seal (side bearing)

1. Remove the filler and drain plugs.
2. Drain the differential oil into a suitable container.
3. Wipe the plugs clean.
4. Install a new washer and the drain plug.

#### Tightening torque:

40–53 N·m {4.0–5.5 kgf·m, 29–39 ft·lbf}

5. Remove the drive shaft. (Refer to page M-15.)
6. Remove the clip from the drive shaft.
7. Remove the oil seal by using a cloth-wrapped screwdriver.

8. Apply clean differential oil to the lip of a new oil seal.
9. Install the oil seal by using the SST.

10. Install a new clip onto the drive shaft.
11. Measure the outer diameter of the clip after installing, and replace the clip if it exceeds the specification.

#### Caution

- The sharp edges of the drive shaft snap ring can slice or puncture the oil seal. Be careful when installing the drive shaft to the transmission.

12. Install the drive shaft with the ends of the clip facing upward.
13. Verify that the drive shaft is seated into the side gear by pulling it outward by hand. It should not come out.
14. Add the specified oil through the filler plug hole until it reaches the bottom of the hole.

#### Specified oil

##### Type

Above – 18°C {0°F}: API GL-4 or GL-5, SAE 90

Below – 18°C {0°F}: API GL-4 or GL-5, SAE 80

Capacity: 1.30 L {1.38 US qt, 1.14 Imp qt}


15. Install a new washer and the filler plug.

#### Tightening torque:

40–53 N·m {4.0–5.5 kgf·m, 29–39 ft·lbf}

16. Check for oil leakage.




**Oil seal (companion flange)**


1. Remove the filler and drain plugs.
2. Drain the differential oil into a suitable container.
3. Wipe the plugs clean.
4. Install a new washer and the drain plug.

**Tightening torque:**


**40–53 N·m{4.0–5.5 kgf·m,29–39 ft·lbf}**




5. Mark the propeller shaft and differential companion flange for proper reinstallation.
6. Remove the nuts and bolts and remove the propeller shaft.
7. Measure and record the rotation starting torque of the drive pinion.




8. Using the SST to hold the companion flange, remove the nut.



9. Use the SST to remove the companion flange.
10. Remove the oil seal by using a screwdriver.




11. Apply clean differential oil to the lip of the new oil seal.
12. Install the oil seal by using the SST.



13. Using the SST, hold the companion flange and tighten the new companion flange nut to the specified torque.


**Tightening torque:**  
**128–284 N·m{13.0–29.0 kgf·m,94.1–209 ft·lbf}**



14. Loosen the nut. Retighten it to get the starting torque recorded in Step 7.  
 15. Add the specified oil through the filler plug hole until it reaches the bottom of the hole.

**Specified oil**  
**Type**


**Above – 18°C {0°F}: API GL-4 or GL-5, SAE 90**  
**Below – 18°C {0°F}: API GL-4 or GL-5, SAE 80**  
**Capacity: 1.30 L {1.38 US qt, 1.14 Imp qt}**



16. Install a new washer and the filler plug.

**Tightening torque:**  
**40–53 N·m{4.0–5.5 kgf·m,29–39 ft·lbf}**

17. Check for oil leakage.




18. Align the marks and install the propeller shaft.

**Tightening torque:**  
**50–58 N·m{5.0–6.0 kgf·m,37–43 ft·lbf}**

**DIFFERENTIAL (TORQUE SENSING LSD)**


**Removal / Installation**

1. Remove the exhaust pipe. (Refer to section F.)
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the rear wheel alignment. (Refer to section R.)
5. Refill the differential with the specified type and amount of oil. (Refer to page M-23.)
6. Install the exhaust pipe. (Refer to section F.)




- |                                 |                 |
|---------------------------------|-----------------|
| 1. Propeller shaft              |                 |
| Removal Note                    | ..... page M-28 |
| Service                         | ..... Section L |
| Installation Note               | ..... page M-29 |
| 2. Tunnel reinforcement bracket |                 |
| 3. Power plant flame            |                 |
| Service                         | ..... Section J |
| 4. Bolt (l-arm)                 |                 |

- |                                     |                 |
|-------------------------------------|-----------------|
| 5. Drive shaft                      |                 |
| Removal Note                        | ..... page M-28 |
| Installation Note                   | ..... page M-28 |
| 6. Differential assembly            |                 |
| Removal Note                        | ..... page M-28 |
| 7. Differential                     |                 |
| Disassembly / Inspection /          |                 |
| Assembly                            | ..... page M-30 |
| 8. Differential mount               |                 |
| Inspect bushing for wear and damage |                 |



### Removal note Propeller shaft

1. Mark the propeller shaft and differential companion flange for proper reassembly.
2. Remove the nuts and bolts and remove the propeller shaft.




### Drive shaft

#### Caution


- The sharp edges of the drive shaft snap ring can slice or puncture the oil seal. Be careful when removing the drive shaft from the transmission.

1. Remove the drive shaft from the differential by using a pry bar.
2. Pull outward on the rear hub support and disc plate to disconnect the drive shaft from the differential.



### Differential assembly

1. Support the differential on a jack.
2. Remove the differential.



### Installation note


#### Drive shaft


1. Install a new clip onto the drive shaft.
2. Measure the outer diameter of the clip after installing, and replace the clip if it exceeds the specification.

#### Caution

- The sharp edges of the drive shaft snap ring can slice or puncture the oil seal. Be careful when installing the drive shaft to the transmission.

3. With the ends of the clip facing upward, push the drive shaft into the differential.
4. After installation, pull outward on the tripod joint outer ring and verify that the drive shaft is securely held by the clip.



**Propeller shaft**

Align the marks and install the propeller shaft.

**Tightening torque:**


**50–58 N·m{5.0–6.0 kgf·m,37–43 ft·lbf}**

# M


## DIFFERENTIAL

### Disassembly / Inspection


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.




1. Drain plug
2. Filler plug
3. Breather  
Inspect for clogging
4. Carrier bolt
5. Rear cover
6. Baffle
7. Differential gear assembly  
Disassembly Note ..... below
8. Bearing cap  
Disassembly Note ..... page M-32
9. Adjustment shim  
Disassembly Note ..... page M-32
10. Side bearing race  
Disassembly Note ..... page M-32  
Inspect for cracks and damage
11. Gear case assembly
12. Side bearing  
Disassembly Note ..... page M-32  
Inspect for damage and rough rotation
13. Ring gear  
Inspect gear teeth for wear and cracks
14. Gear case (Torsen LSD assembly)  
Inspect gear teeth for wear and cracks  
Inspect housing for cracks and damage
15. Companion flange nut and washer  
Disassembly Note ..... page M-32
16. Companion flange  
Disassembly Note ..... page M-33
17. Oil seal (companion flange)
18. Spacer
19. Front bearing  
Inspect for damage and rough rotation
20. Drive pinion assembly  
Disassembly Note ..... page M-33
21. Collapsible spacer
22. Rear bearing  
Disassembly Note ..... page M-33  
Inspect for damage and rough rotation
23. Spacer
24. Drive pinion  
Inspect splines for wear and damage  
Inspect gear teeth for wear and cracks
25. Front bearing race  
Disassembly Note ..... page M-33  
Inspect for cracks and damage
26. Rear bearing race  
Disassembly Note ..... page M-33  
Inspect for cracks and damage
27. Oil seal (side bearing)
28. Differential carrier  
Inspect for cracks and damage
29. Stud

**Disassembly note****Differential gear assembly**


Mount the differential gear assembly on the SSTs.

**Bearing cap**


1. Mark the bearing caps and differential carrier for proper reassembly.
2. Remove the bearing caps.

**Adjustment shim and side bearing race**


1. Remove the adjustment shim, without prying against the side bearing races.
2. Remove the gear case assembly, the side bearing races, and the other adjustment shim.



3. Tag the right and left adjustment shims and side bearing races for proper reassembly.


**Side bearing**

1. Mark the left and right side bearings for proper reassembly.
2. Remove the side bearings from the gear case by using the SST.


**Companion flange nut**

- Hold the companion flange by using the SST and remove the nut.




**Companion flange**


Remove the companion flange by using the SST.

**Drive pinion assembly**

1. Turn a used nut onto the drive pinion until it is about flush with the end of the shaft.
2. Tap the nut by using a brass hammer to drive the pinion assembly out of the differential carrier.

**Rear bearing**

While supporting the drive pinion, remove the rear bearing by using the SST.

**Front bearing race and rear bearing race**


Remove the bearing races by alternately tapping the sides of the races at the grooves in the differential carrier.

# M


## DIFFERENTIAL

### Assembly

Assemble in the other shown in the figure, referring to **Assembly Note**. When installing the rear cover, install it within 10 minutes after applying sealant. Allow the sealant to set at least 30 minutes after installation before filling the differential with the specified oil.



1. Stud		14. Collapsible spacer	
2. Gear case (Torsen LSD assembly)		15. Front bearing	
3. Ring gear		16. Spacer	
Assembly Note	..... page M-35	17. Oil seal (companion flange)	
4. Side bearing		Assembly Note	..... page M-38
Assembly Note	..... page M-35	18. Companion flange	
5. Gear case assembly		Assembly Note	..... page M-38
6. Differential carrier		19. Washer	
7. Oil seal (side gear)		20. Companion flange nut	
Assembly Note	..... page M-35	Assembly Note	..... page M-39
8. Rear bearing race		21. Adjustment shim	
Assembly Note	..... page M-36	Assembly Note	..... page M-39
9. Front bearing race		22. Side bearing race	
Assembly Note	..... page M-36	23. Bearing cap	
10. Spacer		Assembly Note	..... page M-40
Assembly Note	..... page M-36	24. Baffle	
11. Drive pinion		25. Rear cover	
12. Rear bearing		26. Carrier bolt	
Assembly Note	..... page M-37	27. Breather	
13. Drive pinion assembly		28. Filler plug	
Assembly Note	..... page M-38	29. Drain plug	




**Assembly note**

**Ring gear**

1. Apply about 0.04 cm<sup>3</sup> {0.0024 cu in} of thread locking compound to each of the bolt threads A and points B.
2. Install the ring gear onto the gear case.


**Tightening torque:**

69-83 N·m {7.0-8.5 kgf·m, 50-61 ft·lbf}




**Side bearing**

Press the side bearings on by using the SST.




**Oil seal**

1. Apply differential oil to the lips of the new seals.
2. Install the seals by using the SST.




### Rear bearing race

Install the rear bearing race by using the SST.




### Front bearing race

Install the front bearing race by using SST.




### Spacer (adjustment of pinion height)


1. Install the previously-removed spacer onto the SST so that the beveled side of the spacer faces the drive pinion. Then install the rear bearing and O-ring onto the SST/ spacer as shown in the figure.
2. Install this assembly into the differential carrier.




3. Install the SST (collar), front bearing, companion flange, washer and nut.
4. Tighten the nut just enough so that the companion flange can still be turned by hand.
5. Place the SST (gauge block) atop the SST (pinion model).



6. Place the **SST** on a surface plate and set the dial indicator to Zero.



7. Set the **SST** (gauge body) atop the **SST** (gauge block).  
8. Place the feeler of the dial indicator so that it contacts the side bearing saddle in the carrier. Measure the lowest position on the left and right sides of the carrier.




9. Add the two (left and right) values obtained in Step 8 and divide the total by 2.

**Specification : 0 mm {0 in}**


Mark	Thickness	Mark	Thickness
08	3.08 mm {0.1213 in}	29	3.29 mm {0.1295 in}
11	3.11 mm {0.1224 in}	32	3.32 mm {0.1307 in}
14	3.14 mm {0.1236 in}	35	3.35 mm {0.1319 in}
17	3.17 mm {0.1248 in}	38	3.38 mm {0.1331 in}
20	3.20 mm {0.1260 in}	41	3.41 mm {0.1343 in}
23	3.23 mm {0.1271 in}	44	3.44 mm {0.1354 in}
26	3.26 mm {0.1283 in}	47	3.47 mm {0.1366 in}

10. If not within specification, adjust the pinion height by using a spacer chosen from the table.




**Rear bearing**

1. Install the spacer, selected in the procedure above, with the beveled side facing the drive pinion.
2. Press the spacer onto the drive pinion until the force required starts to increase sharply.
3. Press on the spacer and rear bearing by using the **SST**.

**Drive pinion assembly****(adjustment of drive pinion preload)**

Perform the following procedure without the companion flange oil seal installed.


1. Apply a light coat of grease to the end face of the companion flange.
2. Install the drive pinion assembly in the differential carrier.



3. Install a new collapsible spacer, front bearing, new front spacer, companion flange, and new washer.
4. Temporarily tighten the new companion flange nut.
5. Hold the companion flange by using the SST and tighten the nut.

**Tightening torque: 128 N·m{13 kgf·m,94.1 ft·lbf}**

6. Turn the companion flange several turns by hand to seat the bearings.



7. Measure the drive pinion preload.
8. Adjust the preload by tightening the nut; then record the required tightening torque.


**Drive pinion preload:**

**1.3–1.8 N·m{13–18 kgf·cm,12–15 in·lbf}**


**Tightening torque:**

**128–284 N·m{13.0–29.0 kgf·m,94.1–209.7 ft·lbf}**


9. If the specified preload is not obtained after tightening the nut to the maximum torque, replace the collapsible spacer with a new one.
10. Remove the nut, washer, and companion flange.

**Oil seal (companion flange)**

1. Apply clean differential oil to the lip of the new oil seal.
2. Install the oil seal by using the SST.

**Companion flange**

Apply a light coat of grease to the end face of the companion flange.




**Companion flange nut**

1. Using the SST, hold the companion flange and tighten the nut to the tightening torque recorded in "adjustment of drive pinion preload."
2. Verify that the drive pinion preload is within specification.

**Drive pinion preload:**

1.3–1.8 N·m {13–18 kgf·cm, 12–15 in·lbf}




**Adjustment shims (adjustment of ring gear backlash)**

1. Install the bearing races and measure the side bearing and gear case assembly height A as shown.

**Standard height:**

158.4–159.6 mm {6.24–6.28 in}



2. Measure the width B of the inside of the differential carrier as shown.


**Standard width:**

170.9–171.1 mm {6.729–6.736 in}

3. The right and left total adjustment shims thickness C is determined by the following.

$$C \text{ mm} = B - A \text{ mm} + (0.01 - 0.03 \text{ mm})$$


$$C \text{ in} = B - A \text{ in} + (0.0004 - 0.0012 \text{ in})$$




4. If C is equal to the total thickness of the removed right and left adjustment shims, reuse them.

5. If C is not equal to the removed shims, or when the shims are to be replaced, select and use the shims from the following table. Use adjustment shims of the same thickness for both sides.

Identification mark	Thickness	Identification mark	Thickness
550	5.50 mm {0.2165 in}	605	6.05 mm {0.2382 in}
560	5.60 mm {0.2205 in}	610	6.10 mm {0.2402 in}
565	5.65 mm {0.2224 in}	615	6.15 mm {0.2421 in}
570	5.70 mm {0.2244 in}	620	6.20 mm {0.2441 in}
575	5.75 mm {0.2264 in}	625	5.25 mm {0.2461 in}
580	5.80 mm {0.2283 in}	630	6.30 mm {0.2480 in}
585	5.85 mm {0.2303 in}	635	6.35 mm {0.2500 in}
590	5.90 mm {0.2323 in}	640	6.40 mm {0.2520 in}
595	5.95 mm {0.2343 in}	650	6.50 mm {0.2559 in}
600	6.00 mm {0.2362 in}	—	—




6. Install the right and left side bearing race into the differential carrier, in exactly the same positions they were in at disassembly. Then install the gear case assembly and adjustment shim(s), making sure not to interchange the adjustment shim(s) if they are being reused.
7. Tap the other side adjustment shim(s) in by using a plastic hammer.
8. Install the bearing caps and loosely tighten the bolts.




9. Mark the ring gear at four points at approx. 90 degrees intervals. Mount a dial indicator to the carrier so that the feeler comes into contact at a right angle with one of the ring gear teeth at a point marked.
10. Measure the ring gear backlash.

**Standard backlash:**  
 0.09–0.11 mm {0.0035–0.0043 in}



11. Measure the backlash at the three other marked points, and verify that the minimum backlash is more than 0.05 mm {0.002 in} and the difference between the maximum and minimum is less than 0.07 mm {0.0028 in}.
12. If the backlash is not within specification, adjust it by inserting appropriate adjustment shim at both sides of the carrier. If replacing the adjustment shim on one side with a thinner shim, replace the shim on the other side with an equally thicker shim.




#### Bearing caps


1. Align the marks made on the right and left bearing caps and the differential case.
2. Tighten the bolts to the specified torque.
3. Check the drive pinion and ring gear tooth contact (page M-41)

**Tightening torque:**  
 73–106 N·m {7.4–10.9 kgf·cm, 53.6–78.8 ft·lbf}



**Inspection and adjustment of tooth contact**


1. Coat both surfaces of 6–8 teeth of the ring gear with a uniformly thin coat of red lead.
2. While moving the ring gear back and forth by hand, rotate the drive pinion several times and check the tooth contact.
3. If the tooth contact is good, wipe off the red lead.



4. If it is not good, readjust the pinion height, and then adjust the backlash.

**(1) Toe and flank contact**

Replace the spacer with a thinner one to move the drive pinion outward.

**(2) Heel and face contact**


Replace the spacer with a thicker one to bring the drive pinion inward.

Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.

# STEERING SYSTEM

INDEX .....	N - 2
OUTLINE .....	N - 3
SPECIFICATIONS .....	N - 3
ENGINE SPEED SENSING POWER	
STEERING .....	N - 3
PREPARATION .....	N - 3
TROUBLESHOOTING GUIDE .....	N - 5
AIR BLEEDING .....	N - 6
POWER STEERING FLUID .....	N - 6
BOOT .....	N - 9
STEERING WHEEL AND COLUMN .....	N -11
STEERING GEAR AND LINKAGE .....	N -16
POWER STEERING OIL PUMP .....	N -28
DRIVE BELT .....	N -31

## INDEX



1. Boot	
Replacement .....	page N- 9
2. Steering wheel and column	
On-vehicle inspection .....	page N-11
Removal / Inspection /	
Installation .....	page N-12
Disassembly / Inspection /	
Assembly .....	page N-14
3. Steering gear and linkage	
Removal / Installation .....	page N-16
Disassembly / Inspection .....	page N-18
Assembly .....	page N-23
Air bleeding .....	page N- 6

4. Power steering oil pump	
Removal / Installation .....	page N-28
Disassembly / Inspection /	
Assembly .....	page N-29
Air bleeding .....	page N- 6
Power steering fluid .....	page N- 6
5. Drive belt	
Inspection .....	page N-31
Adjustment .....	page N-31
Replacement .....	page N-31











OUTLINE

SPECIFICATIONS

Item		Specifications
Steering wheel	Outer diameter mm {in}	380 {15.0}
	Lock-to-lock turns	2.9
Steering shaft	Shaft	Collapsible
Steering gear	Power assist	Engine speed sensing
	Gear	Rack-and-pinion
	Gear ratio	∞ (infinite)
	Back stroke mm {in}	160 {6.30}
	Power steering fluid	ATF Dexron® II or M-III
Fluid capacity L {US qt, Imp qt}	0.96 {1.01, 0.84}	

ENGINE SPEED SENSING POWER STEERING


















PREPARATION  
SST

49 1232 670A Gauge set, power steering 	For inspection of power steering fluid pressure	49 D032 316 Protractor 	For installation of adjusting cover
49 1232 673 Body, valve (Part of 49 1232 670A) 	For inspection of power steering fluid pressure	49 F032 317 Remover, oil seal 	For removal of oil seal and backup washer
49 H032 322 Adapter, power steering gauge 	For inspection of power steering fluid pressure	49 F032 313 Wrench 	For removal of locknut
49 1232 672 Gauge (Part of 49 1232 670A) 	For inspection of power steering fluid pressure	49 F032 305 Handle 	For removal of needle bearing
49 H002 671 Adapter, power steering gauge 	For inspection of power steering fluid pressure	49 F032 310 Protector 	For installation of oil seal

N

# N

## ENGINE SPEED SENSING POWER STEERING

<p>49 0118 850C Puller, ball joint</p> 	<p>For removal of tie rod end ball joint</p>	<p>49 F032 303 Handle</p> 	<p>For installation of oil seal and backup washer</p>
<p>49 G032 3AI Set, joint hose</p> 	<p>For hermetic inspection of cylinder</p>	<p>49 G032 317 Hose ( Part of 49 G032 3AI )</p> 	<p>For hermetic inspection of cylinder</p>
<p>49 G032 319 Adapter ( Part of 49 G032 3AI )</p> 	<p>For hermetic inspection of cylinder</p>	<p>49 H032 301 Wrench</p> 	<p>For removal of tie rod</p>
<p>49 1243 785 Installer, boot</p> 	<p>For installation of outer ball joint</p>	<p>49 H032 328 Former, seal ring</p> 	<p>For formation of seal ring</p>
<p>49 F032 318 Installer, oil seal and bearing</p> 	<p>For installation of oil seal and bearing</p>	<p>49 F032 304 Body</p> 	<p>For installation of oil seal</p>
<p>49 F032 319 Installer</p> 	<p>For installation of oil seal</p>	<p>49 0180 510B Attachment, preload</p> 	<p>For measurement of pinion preload</p>
<p>49 0710 520 Puller, bearing</p> 	<p>For removal of bearing</p>	<p>49 F032 306A Body</p> 	<p>For removal of needle bearing</p>
<p>49 F032 301 Hanger, power steering pump</p> 	<p>For disassembly / assembly of power steering oil pump</p>	<p>49 W023 585A Adjust wrench</p> 	<p>For removal / installation of oil pump pulley</p>
<p>49 9200 020 V-ribbed belt tension gauge</p> 	<p>For measurement of drive belt tension</p>		




**TROUBLESHOOTING GUIDE**

<b>Problem</b>	<b>Possible cause</b>	<b>Action</b>	<b>Page/section</b>
<b>Steering feels heavy</b>	Poor lubrication, foreign material, or abnormal wear of steering ball joint Stuck or damaged lower arm ball joints Improper steering pinion preload Damaged steering gear Damaged steering shaft joint Improperly adjusted wheel alignment Incorrect tire pressure Loose or damaged oil pump drive belt Low fluid level or air in fluid Leakage of fluid Insufficient oil pump pressure	lubricate or replace  Replace Repair or replace Repair or replace Replace Adjust Adjust Adjust or replace Add fluid or bleed air Repair or replace Replace	N- 9  Section R N-26 N-16, 18 N-12 Section R Section Q N-31 N- 6 — N-28
<b>Steering wheel pulls to one side</b>	Incorrect tire pressure Unevenly worn tires Weak front coil spring Worn or damaged stabilizer and/or suspension bushing Dragging brake Loose lower arm Improperly adjusted wheel alignment	Adjust Replace Replace Replace Repair or adjust Tighten or replace Adjust	Section Q Section Q Section R Section R Section P Section R Section R
<b>General instability while driving</b>	Incorrect tire pressure Damaged or unbalanced wheel Worn or damaged steering joint Improper steering pinion preload Weak front coil spring Worn or damaged stabilizer and/or upper or lower arm bushing Damaged shock absorber Improperly adjusted wheel alignment	Adjust Adjust or replace Replace Repair or replace Replace Replace  Replace Adjust	Section Q Section Q N-12 N-26 Section R Section R  Section R Section R
<b>Shake (steering wheel vibrates up/down)</b>	Excessive tire and/or wheel runout Loose lug nuts Unbalanced wheel Cracked or worn engine mount rubber Cracked or worn transmission mount rubber	Replace Tighten Adjust or replace Replace Replace	Section Q Section Q Section Q Section B Section K
<b>Shimmy (steering wheel vibrates circumferentially)</b>	Cracked or worn steering gear mount rubber Loose steering gear mounting bolts Stuck or damaged steering ball joint Excessive tire and/or wheel runout Loose lug nuts Unbalanced wheel Incorrect tire pressure Unevenly worn tires Damaged shock absorber Loose shock absorber mounting bolts Stuck or damaged lower arm ball joint Cracked or worn suspension bushings Damaged or worn front wheel bearing Improperly adjusted front wheel alignment	Replace Tighten Replace Replace Tighten Adjust or replace Adjust Replace Replace Tighten Tighten Replace Replace Replace Adjust	N-18 N-16 N- 9, 18 Section Q Section Q Section Q Section Q Section R Section R Section R Section R Section R Section M Section R
<b>Excessive steering wheel play</b>	Worn steering gear Worn or damaged steering joints Worn or damaged lower arm bushing Loose steering gear mounting bolts Worn linkage or tie rod ball joint	Repair or replace Replace Replace Tighten Replace	N-16, 18 N-12 Section R N-16 N-18
<b>Poor steering wheel return</b>	Incorrect tire pressure Stuck or damaged steering joints Improperly adjusted front wheel alignment Improper steering pinion preload Ball joint not operating smoothly Obstruction near steering column	Adjust Replace Adjust Repair or replace Replace Repair	Section Q N-12 Section R N-26 N-16, 18 N-12

**N**

### TROUBLESHOOTING GUIDE (Cont'd)

Problem	Possible cause	Action	Page/section
Abnormal noise from steering system	Loose oil pump	Tighten	N-28
	Loose steering gear	Tighten	N-16
	Loose oil pump bracket	Tighten	N-28
	Loose or too tight drive belt	Adjust	N-31
	Air in system	Bleed air	N- 6
	Damaged steering gear	Repair or replace	N-16, 18
	Damaged oil pump	Repair or replace	N-28, 29
	Obstruction near steering column	Repair or replace	N-12
	Loose steering linkage	Tighten or replace	N-16
	Worn steering joints	Replace	N-12



#### AIR BLEEDING

1. Check the fluid level. (Refer to below.)
2. Jack up the front of the vehicle and support it on safety stands.
3. Turn the steering wheel fully to the left and right several times with the engine not running.
4. Recheck the fluid level. If it has dropped, add fluid.
5. Repeat Steps 3 and 4 until the fluid level stabilizes.
6. Lower the vehicle.
7. Start the engine and let it idle.
8. Turn the steering wheel fully to the left and right several times.
9. Verify that fluid is not foamy and that the fluid level has not dropped.
10. Add fluid if necessary and repeat Steps 6 and 7.

#### POWER STEERING FLUID

##### Inspection Fluid level

Check the power steering fluid level. Add specified power steering fluid to MAX if necessary.



**Fluid specification: ATF Dexron® II or M-III**

**Fluid leakage**

**Caution**

- Never hold the steering wheel to the extreme left or right for more than five seconds with the engine running. This could damage the power steering pump.

Start the engine and let it idle. Turn the steering wheel fully left and fully right to apply fluid pressure. Inspect the points shown in the figure for fluid leakage.




**Fluid pressure**

1. Assemble the SST as shown in the figure.


**Tightening torque:**

40–49 N·m {4.0–5.0 kgf·m, 29–36 ft·lbf}



2. Disconnect the pressure pipe from the oil pump, and connect the SST.
3. Bleed the air from the system. (Refer to page N-6.)






**Caution**

- Never hold the steering wheel to the extreme left or right for more than 15 seconds with the engine running. This could damage the power steering pump.


4. Open the gauge valve fully. Start the engine and turn the steering wheel fully left and right to raise the fluid temperature to 50–60°C {122–144°F}.



**Caution**

- Do not let the valve stay closed for more than 15 seconds. The increase in fluid temperature will damage the oil pump.


5. Close the gauge valve completely. Increase the engine speed to 1,000–1,500 rpm and measure the fluid pressure generated by the oil pump. If the pressure is not within specification, repair or replace the oil pump assembly. (Refer to page N–28.)



**Oil pump fluid pressure:**

7,620–8,350 kPa {77.7–85.2 kgf/cm<sup>2</sup>, 1,110–1,210 psi}

6. Open the gauge valve fully and increase the engine speed to 1,000–1,500 rpm.



7. Turn the steering wheel fully to the left and right and measure the fluid pressure generated at the gear housing. If the pressure is not within specification, repair or replace the steering gear assembly.

**Gear housing fluid pressure:**

7,620–8,350 kPa {77.7–85.2 kgf/cm<sup>2</sup>, 1,110–1,210 psi}

8. Remove the gauge set. Install and tighten the pressure pipe to the specified torque.

**Tightening torque:**

24–35 N·m {2.4–3.6 kgf·m, 18–26 ft·lbf}


9. Bleed the air from the system. (Refer to page N–6.)

**BOOT Replacement**

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheel and tire.
3. Remove in the order shown in the figure, referring to Removal Note.
4. Install in the reverse order of removal, referring Installation Note.
5. Install the wheel and tire.

**Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf}**


6. After installation, check the steering angle and toe-in and adjust if necessary. (Refer to section R.)




N·m {kgf·m, ft·lbf}

1. Cotter pin
2. Nut
3. Tie rod end ball joint  
Removal Note ..... page N-10
4. Locknut  
Removal Note ..... page N-10
5. Tie rod end


6. Tie rod end boot  
Removal Note ..... page N-10  
Installation Note ..... page N-10
7. Boot clamp
8. Boot wire
9. Steering gear boot  
Removal Note ..... page N-10  
Installation Note ..... page N-10

**Removal note****Locknut**


Before loosening the tie rod end locknut, make mark for reference when tightening.

**Tie rod end ball joint**


1. Loosen the tie rod end ball joint nut until it is about flush with the end of the stud.
2. With the nut protecting the stud, separate the tie rod end from the steering knuckle by using the SST.

**Steering gear boot**

If the steering gear boot is difficult to remove, use a razor knife to cut open the small diameter end.

**Tie rod end boot**


1. Secure the tie rod end in a vise.
2. Place a chisel against the boot and hold it at an angle as shown.
3. Remove the boot by tapping it with a hammer.

**Installation note****Tie rod end boot**

1. Wipe away the grease on the ball joint.
2. Put a small amount of grease (lithium base) into the new boot and set it onto the tie rod end.
3. Press the boot onto the tie rod end by using the SST and a press.
4. Wipe away any excess grease.

**Steering gear boot**


Verify that the boot is not twisted.

**STEERING WHEEL AND COLUMN****On-vehicle Inspection****Steering wheel play**


1. With the wheels in the straight-ahead position, gently turn the steering wheel to the left and right and verify that the play is within specification.

**Play: 0–30 mm {0–1.18 in}**


2. If the play exceeds specification, check the steering joints for wear and check the steering gear for excessive backlash. Correct as necessary.

**Looseness or play of steering wheel**

1. Move the steering wheel in the directions of the arrows to check for column bearing wear, steering shaft joint play, steering wheel looseness, and column looseness.
2. If looseness is noted, inspect for the cause and repair as necessary.

**Steering wheel effort**

1. With the vehicle on a hard, level surface, put the wheels in the straight-ahead position.
2. Start the engine and warm the power steering fluid to 50–60°C {122–140°F}.



3. With the engine running at idle, attach a pull scale to the outermost point of the steering wheel spoke. Then, starting with the wheels in the straight-ahead position, measure the effort required to turn the steering wheel to the left and to the right.

**Steering wheel effort:**


**30–38 N {3.0–3.9 kgf, 6.6–8.5 lbf}**

**[during one turn of the steering wheel]**

4. If not within specification, check the following: fluid level, air in system, fluid leakage in piping or connections, function of oil pump and gear box, and tire pressures.


### Removal / Inspection / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.



1. Air bag module  
Service ..... 1994 RX-7 Body Electrical Troubleshooting Manual
2. Steering wheel  
Removal Note ..... page N-13  
Installation Note ..... page N-13
3. Column cover
4. Combination switch  
Service ..... 1994 RX-7 Body Electrical Troubleshooting Manual
5. Lower panel

6. Steering shaft assembly  
Installation Note ..... page N-13  
Disassembly / Inspection / Assembly ..... page N-14  
Inspect dust cover for damage
7. Steering joint  
Installation Note ..... page N-13  
Inspect for damage and poor operation  
Inspect boot for cracking and tearing
8. Intermediate shaft  
Installation Note ..... page N-13  
Inspect for damage and bending  
Inspect boot for cracking and tearing




**Removal note**  
Steering wheel

**Caution**

- Do not try to remove the steering wheel by hitting the shaft with a hammer. The column will collapse.

Remove the steering wheel by using a suitable puller.



**Intermediate shaft**


**Note**

- Bolt A can be loosened but not removed from the intermediate shaft.

**Installation note**

**Steering shaft, steering joint, and intermediate shaft**

Assemble the steering shaft, steering joint, and intermediate shaft, then tighten the bolts. Tighten bolt A last.




**Steering wheel**

Install the steering wheel with the wheels in the straight-ahead position.


### Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assembly in the reverse order of disassembly, referring to **Assembly Note**.



1. Steering lock mounting bolts and bracket  
 Disassembly Note ..... below  
 Assembly Note ..... page N-15
2. Steering lock assembly  
 Inspection ..... page N-15


3. Steering shaft assembly  
 Inspection ..... page N-15



### Disassembly note

#### Steering lock mounting bolts and bracket

1. Secure the steering shaft in a vise.
2. Use a chisel to make a groove in the heads of the steering lock mounting bolts.
3. Remove the bolts by using a screwdriver.
4. Remove the steering lock assembly.



**Inspection**


**Steering shaft assembly**

Check for the following and replace the steering shaft assembly if necessary.

1. Column bearing for damage
2. Column bushing for damage


3. Steering shaft length

Length: 779.5–781.5 mm {30.69–30.76 in}



**Steering lock assembly**


1. Insert the ignition key in the key cylinder. Apply battery positive voltage between terminals B and C.
2. Verify that the solenoid operates.
3. If not as specified replace the key interlock solenoid. (Refer to section K).



**Assembly note**

**Steering lock mounting bolts and bracket**

1. Install the steering lock assembly on the jacket.
2. Verify that the lock operates correctly.
3. Install new steering lock mounting bolts.
4. Tighten each bolt until its head breaks off.






### STEERING GEAR AND LINKAGE

#### Removal / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheels and tires and the undercover.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Install the wheels and tires.


**Tightening torque: 89–117 N·m{9.0–12.0 kgf·m, 66–86 ft·lbf}**

6. Install the undercover.
7. After installation:
  - (1) Check for fluid leakage.(Refer to page N-7.)
  - (2) Bleed air from the system.(Refer to page N-6.)
  - (3) Check, and if necessary adjust, the toe-in and maximum steering angle.



- 1. Cotter pin
- 2. Nut
- 3. Tie rod end ball joint  
Removal Note ..... page N-10
- 4. Stabilizer bracket
- 5. Pressure hose  
Installation Note ..... Below
- 6. Return hose


- 7. Bolt(steering joint / pinion shaft)
- 8. Mounting bracket bolts  
Installation Note ..... Below
- 9. Crossmember nuts and bolts  
Removal Note ..... Below
- 10. Steering gear and linkage  
Removal Note ..... Below  
Disassembly / Inspection ..... page N-18  
Assembly ..... page N-23



**Removal note**

**Crossmember nuts and bolts, steering gear and linkage**

- 1. Support the crossmember with a jack, and remove the crossmember nuts, and bolts.
- 2. Slowly lower the crossmember and remove the steering gear and linkage.




**Installation note**

**Mounting bracket bolts**

- 1. Loosely tighten the bolts 3 and 4.
- 2. Tighten all of the mounting bracket bolts to the specified torque in the order shown.


**Tightening torque:**

38-51 N·m{3.8-5.3 kgf·m,27-38 ft·lbf}



**Pressure hose**


Before assembly, align the pin with the positioning hole.



**Disassembly / Inspection**  
 1. Disassemble in the order shown in the figure, referring to Disassembly Note.  
 2. Inspect all parts and repair or replace as necessary.

**ENGINE SPEED SENSING POWER STEERING**


- 1. Mounting bracket and rubber
- 2. Pipe clamp
- 3. Oil pipe and O-ring  
Inspect for clogging and damage
- 4. Tie rod end  
Inspection ..... page N-22  
Disassembly Note ..... Below
- 5. Locknut (tie rod end)
- 6. Boot clamp
- 7. Boot wire
- 8. Boot  
Disassembly Note ..... Below
- 9. Tie rod  
Inspection ..... page N-22  
Disassembly Note ..... page N-20
- 10. Washer (tie rod)
- 11. Locknut (adjusting cover)  
Disassembly Note ..... page N-20
- 12. Adjusting cover
- 13. Yoke spring  
Inspect for damage
- 14. Support yoke  
Inspect for damage
- 15. Dust cover
- 16. Snap ring
- 17. Housing cover
- 18. Locknut (pinion shaft)
- 19. Pinion shaft assembly  
Inspect teeth for wear and damage  
Inspect valve for clogging,  
damage and wear  
Disassembly Note ..... page N-20
- 20. Oil seal
- 21. Upper bearing  
Inspect for wear and damage  
Disassembly Note ..... page N-20
- 22. Seal ring  
Disassembly Note ..... page N-20
- 23. Clip  
Disassembly Note ..... page N-21
- 24. Rack stop  
Disassembly Note ..... page N-21
- 25. Rack  
Disassembly Note ..... page N-21  
Inspection ..... page N-22
- 26. Oil seal  
Disassembly Note ..... page N-21
- 27. Backup washer  
Disassembly Note ..... page N-21
- 28. Oil seal  
Disassembly Note ..... page N-21
- 29. Seal ring  
Disassembly Note ..... page N-21
- 30. O-ring  
Disassembly Note ..... page N-21
- 31. Lower bearing  
Disassembly Note ..... page N-21  
Inspect for wear and damage
- 32. Oil seal  
Disassembly Note ..... page N-21
- 33. Washer
- 34. Needle bearing  
Disassembly Note ..... page N-22  
Inspect for wear and damage
- 35. Gear housing  
Inspect for damage and cracks



**Disassembly note**


**Tie rod end**

Before loosening, mark the tie rod end as shown for reference during installation.




**Boot**


If the boot is difficult to remove, use a razor knife to cut open the small diameter end.

**Tie rod**


1. Unbend the washer
2. Remove the tie rod by using the SST.

**Locknut**

Remove the locknut by using the SST.


**Pinion shaft assembly**

Place a punch on the center of the shaft, and tap lightly with a hammer to remove it.


**Upper bearing****Note**

- The upper bearing does not need to be removed unless you are replacing it.


Remove the upper bearing by using the SST.

**Seal ring**


Remove the seal rings by using a small, cloth-wrapped screwdriver.

**Clip and rack stop**


1. Turn the rack stop in the direction that is easiest to turn, until the end of the clip comes out of the hole. Do not force the clip and rack stop when turning.
2. Turn the rack stop the opposite direction and remove the clip.
3. Remove the rack stop.

**Rack, oil seal and backup washer**


1. Set the SST into the end of the rack.
2. Pull out the rack assembly, with the oil seal and backup washer.

**Seal ring and O-ring**


1. Remove the seal ring by using a small screwdriver.
2. Remove the O-ring.

**Lower bearing**


- Drive the lower bearing out of the housing by using the SST.

**Oil seal**


- Remove the oil seal, being careful not to scratch the inner surface of the valve housing.

**Needle bearing**

1. Insert the SST (body) through the adjusting cover hole.
2. Set the SST (handle) against the SST of Step 1.



3. Press out the needle bearing by using SST.

**Inspection****Tie rod end**


1. Inspect the tie rod end for damage and the boot cracks. Replace as necessary.
2. Inspect the ball joint for looseness. Replace the tie rod end if necessary.
3. Shake and rotate the ball joint several times.
4. Measure the rotation torque of the ball joint by using the SST and a pull scale.

**Rotation torque:**

0.3–2.9 N·m {3–30 kgf·cm, 2.6–26 in·lbf}

**Pull scale reading: 3–29 N {0.3–3 kgf, 0.7–6.6 lbf}**

5. If not within specification, replace the tie rod end.

**Tie rod**


1. Inspect the tie rod for bending and damage. Replace it if necessary.
2. Inspect the ball joint for looseness. Replace the tie rod necessary.
3. Swing the tie rod several times.
4. Measure the swinging torque by using a pull scale.

**Swinging torque:**


0.1–3.4 N·m {1–35 kgf·cm, 0.9–30 in·lbf}

**Pull scale reading: 0.7–21 N {0.07–2 kgf, 0.16–4.8 lbf}**


5. If not within specification, replace the tie rod.

**Rack**


1. Inspect the rack for cracking, damage and tooth wear. Replace it if necessary.
2. Measure runout of the rack.  
**Runout: 0.4 mm {0.016 in} max.**
3. If not within specification, replace the rack.

**Assembly****1. Backup washer and oil seal**


- (1) Apply ATF to the new oil seal.
- (2) Install the backup washer and oil seal by using the SST.
- (3) After installing, shake the gear housing and verify that the backup washer does not rattle.
- (4) If it rattles, remove the oil seal and backup washer and reinstall them.

**2. Rack**


- (1) Apply ATF to a new O-ring and seal ring.
- (2) Install the O-ring then seal ring in the piston groove.



- (3) Apply grease to the friction surface and teeth of the rack.
- (4) Slide the vinyl sleeve supplied in the seal kit over the rack and slide the rack in from the tube side.
- (5) Remove the vinyl sleeve.


**3. Oil seal**

- (1) Set the SST onto the end of the rack.
- (2) Apply ATF to the new oil seal and slide it onto the end into the rack housing.

**4. Rack stop and clip**


- (1) Turn the rack stop into the housing until the holes of the stop and rack housing are aligned.
- (2) Install the new clip.
- (3) Turn the rack stop until the clip is fully installed (approx. 1.5 turns).






### 5. Hermetic inspection of cylinder

- (1) Connect the SST (adapters) to the cylinder housing.
- (2) Connect a vacuum pump to the SST (hose) and apply **53.3 KPa {400 mmHg}** vacuum.
- (3) Verify that vacuum is held for at least **30 seconds**. If not, replace the oil seals.




### 6. Needle bearing

- (1) Press in the needle bearing by using the SST.
- (2) Apply grease to the needle bearing.




### 7. Washer and oil seal

- (1) Install the washer
- (2) Apply ATF to the new oil seal.
- (3) Press in the oil seal by using the SST.




### 8. Seal ring

- (1) Apply ATF to the new seal rings.
- (2) Install the seal rings onto the pinion shaft assembly.
- (3) Pass the pinion shaft assembly back and forth through the SST to form the seal rings.




### 9. Upper bearing

- Press the upper bearing onto the pinion shaft assembly.



**10. Pinion shaft assembly and lower bearing**

- (1) Apply grease to the teeth of the rack.
- (2) Insert the pinion shaft assembly into the gear housing.
- (3) Apply grease to the lower bearing and install it onto the pinion shaft.
- (4) Seat the bearing by installing the housing cover and gradually tightening it until the tightening force suddenly increases.




- (5) Remove the housing cover.

**11. Locknut (pinion shaft)**

- (1) Temporarily install the tie rod to hold the rack.
- (2) Tighten the pinion shaft locknut.

**Tightening torque:**

29–29 N·m {2.0–3.0 kgf·m, 15–21 ft·lbf}




**12. Housing cover**

- (1) Apply a thin coat of sealant to the threads of the housing cover.
- (2) Install the housing cover.

**Tightening torque:**


59–69 N·m {5.9–7.0 kgf·m, 36–50 ft·lbf}

- (3) Stake the housing cover at two points by using a center punch.




**13. Oil seal (upper pinion shaft)**

- (1) Install the new oil seal by using the SST.
- (2) Install the new snap ring.
- (3) Install the dust cover.



**14. Support yoke assembly**

- (1) Apply grease to the friction surface of the support yoke.
- (2) Install the support yoke and the yoke spring.




### 15. Adjusting cover and locknut

- (1) Apply sealant to the threads of the adjusting cover.
- (2) Using the SST as shown in the figure, tighten the adjusting cover to **9.81 N·m{100 kgf·cm,86.8 in·lbf}** and return the adjusting cover **20°–25°**.
- (3) Modify the locknut tightening torque to allow for use of a to wrench-SST combination. (Refer to section GI "Torque Formulas".)
- (4) Using the SST as shown in the figure, hold the adjusting cover in a fixed position and tighten the locknut.  
(L = torque wrench length)

N·m	$N \cdot m \times L m \div (L m + 0.06)$
kgf·m	$kgf \cdot m \times L m \div (L m + 0.06)$
ft·lbf	$ft \cdot lbf \times L ft \div (L ft + 0.02)$

### Tightening torque:

**50–68 N·m{5.0–7.0 kgf·m,37–50 ft·lbf}**




### 16. Measurement of pinion preload

- (1) Attach the SST and a pull scale to the pinion shaft.
- (2) Measure the pinion preload. (Center of rack  $\pm 90$  degrees)

**Pinion preload: 1.5 N·m{15 kgf·cm,13 in·lbf}max.**  
**Pull scale reading: 14.7 N·m{15 kg, 3.3 lbf}max.**

- (3) If not within specification, repeat Steps 15 (2) and 15 (3).




### 17. Tie rod

- (1) Install the tie rod by using SST.

### Tightening torque:


**78–98 N·m{8.0–10.0 kgf·m,58–72 ft·lbf}**


- (2) Bend the new washer at two places to hold the tie rod.



### 18. Boot


- (1) Apply grease to the inner bore of the small end of the boot.
- (2) Install the boot. Wrap a new boot wire around the large end of the boot two times and then twist it 4–4.5 times. Bend the twisted part toward mounting bracket.
- (3) Install a new boot clamp on the small end of the boot.
- (4) Slide the rack its full stroke and verify that the boot is not twisted.





**19. Tie rod end**

Install the tie rod end and align the reference marks.



**20. Oil pipe and O-ring**

- (1) Install the new O-rings and the oil pipes.
- (2) Install the pipe clamp.

**Tightening torque**

**Return pipe: 24–29 N·m**

{2.4–3.0 kgf·m, 17–22 ft·lbf}

**Cylinder pipe: 9.81–15.6 N·m**

{100–160 kgf·cm, 86.9–138 in·lbf}

**Pipe clamp bolt: 5.0–6.8 N·m**

{50–70 kgf·cm, 44–60 in·lbf}


**21. Mounting rubber and bracket**

Install the mounting rubber and bracket

### POWER STEERING OIL PUMP

#### Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation:
  - (1) Adjust the belt deflection. (Refer to page N-31.)
  - (2) Check connections for fluid leakage. (Refer to page N-7.)
  - (3) Bleed air from the system. (Refer to page N-6.)



1. Locknut
2. Adjusting bolt
3. Drive belt
4. Nut
5. Pulley


Removal / Installation Note ..... below

Removal / Installation Note ..... below

6. Steering pressure sensor connector
7. Pressure hose
8. Return hose
9. Power steering oil pump

Disassembly / Inspection /

Assembly ..... page N-29




#### Removal / Installation note


##### Nut / Pulley

Hold the pulley by using the SST and loosen / tighten the nut.




**Disassembly note****Oil pump**

Install the pump to the SST, and hold the pump and SST in a vise.

**Assembly note****Cam ring**


Install the cam ring in the front pump body with the marks facing upward.

**Blade**

Place the blades in the rotor so that the rounded edges contact the cam.

**Pump body (rear)**

After installing the rear pump body, manually turn the shaft to verify that it rotates smoothly.



**DRIVE BELT**

**Inspection**


1. Check the drive belt for wear, cracks, and fraying. Replace if necessary.
2. Verify that the drive belt is correctly mounted on the pulleys.
3. Check the drive belt deflection when the engine is cold, or at least 30 minutes after the engine has stopped. Apply moderate pressure (98 N {10 kgf, 22 lbf}) midway between the specified pulleys.

**Deflection**

mm{in}		
New	Used	Limit
3.5-4 {0.14-0.15}*	4.5-5 {0.18-0.19}	6 {0.23}

\* A belt that has been on a running engine for less than 5 minutes

4. If the deflection is not within specification, adjust it.



**Drive belt tension check**

Belt tension can be checked in place of belt deflection. Check the drive belt tension when the engine is cold, or at least 30 minutes after the engine has stopped. Using the SST, check the belt tension between any two pulleys.

**Tension**

N {kgf, lbf}		
New	Used	Limit
740-880 {75-90, 165-198}	540-630 {55-65, 121-143}	320 {33, 73}

**Adjustment**


1. Loosen idler pulley locknut A, and adjust the belt deflection or tension by turning adjusting bolt B.
2. Tighten locknut A.

**Tightening torque**

A: 37-53 N·m {3.7-5.5 kgf·m, 27-39 ft·lbf}

**Replacement**

1. Loosen locknut A and adjusting bolt B.
2. Remove and replace the drive belt.
3. Adjust the deflection or tension.(Refer to above.)






Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.

# BRAKING SYSTEM

- INDEX ..... P - 2
- OUTLINE ..... P - 4
  - SPECIFICATIONS ..... P - 4
- CONVENTIONAL BRAKE SYSTEM ..... P - 5
  - PREPARATION ..... P - 5
  - TROUBLESHOOTING GUIDE ..... P - 6
  - AIR BLEEDING ..... P - 7
  - BRAKE LINE ..... P - 7
  - BRAKE FLUID ..... P - 8
  - VACUUM LINE ..... P - 8
  - BRAKE PEDAL ..... P - 9
  - MASTER CYLINDER ..... P -11
  - POWER BRAKE UNIT ..... P -16
  - PROPORTIONING BYPASS VALVE ..... P -19
  - FRONT BRAKE (DISC) ..... P -21
  - DISC PAD (FRONT) ..... P -24
  - DISC PLATE (FRONT) ..... P -24
  - CALIPER (FRONT) ..... P -26
  - REAR BRAKE (DISC) ..... P -27
  - DISC PAD (REAR) ..... P -29
  - DISC PLATE (REAR) ..... P -30
  - CALIPER (REAR) ..... P -31
- PARKING BRAKE SYSTEM ..... P -33
  - TROUBLESHOOTING GUIDE ..... P -33
  - PARKING BRAKE (LEVER TYPE) ..... P -33
  - PARKING CABLE (LEVER TYPE) ..... P -34
  - PARKING BRAKE LEVER ..... P -35
- ANTILOCK BRAKE SYSTEM (ABS) ..... P -37
  - PREPARATION ..... P -37
  - TROUBLESHOOTING GUIDE ..... P -38
  - SERVICE POINTS ..... P -53
  - HYDRAULIC UNIT ..... P -56
  - ABS CONTROL UNIT ..... P -59
  - WHEEL-SPEED SENSOR (FRONT) ..... P -60
  - SENSOR ROTOR (FRONT) ..... P -61
  - WHEEL-SPEED SENSOR (REAR) ..... P -62
  - SENSOR ROTOR (REAR) ..... P -63
  - RELAY ..... P -64

INDEX



- 1. Brake line
  - Inspection ..... page P-7
  - Removal / Installation ..... page P-7
- 2. Brake fluid
  - Inspection ..... page P-8
  - Replacement ... page P-8
- 3. Vacuum line
  - Inspection ..... page P-8
- 4. Brake pedal
  - Inspection (on-vehicle) ..... page P-9
  - Removal / Inspection / Installation ... page P-10
- 5. Master cylinder
  - Removal / Installation ..... page P-11
  - Disassembly / Inspection / Assembly .... page P-15
- 6. Power brake unit
  - Inspection (on-vehicle) ..... page P-16
  - Removal / Installation ... page P-18
- 7. Proportioning bypass valve
  - Inspection ..... page P-19
  - Replacement ..... page P-20
- 8. Front brake (disc)
  - Inspection (on vehicle) ..... page P-21
  - Removal / Inspection / Installation ... page P-22
- 9. Disc pad (front)
  - Replacement ..... page P-24
- 10. Disc plate (front)
  - Inspection .... page P-24
- 11. Caliper (front)
  - Disassembly / Inspection / Assembly .... page P-26
- 12. Rear brake (disc)
  - Inspection (on-vehicle) ..... page P-27
  - Removal / Inspection / Installation ... page P-28
- 13. Disc pad (rear)
  - Replacement .. page P-29
- 14. Disc plate (rear)
  - Inspection .... page P-30
- 15. Caliper (rear)
  - Disassembly / Inspection / Assembly .... page P-31
- 16. Parking brake (lever type)
  - Inspection ..... page P-33
  - Adjustment ... page P-33
- 17. Parking cable (lever type)
  - Removal / Inspection / Installation ... page P-34
- 18. Parking brake lever
  - Removal / Inspection / Installation ... page P-35
- 19. Hydraulic unit
  - Removal / Installation ..... page P-56
  - Disassembly / Inspection / Assembly .... page P-58
- 20. ABS control unit
  - Removal / Installation ..... page P-59
- 21. Relay
  - Removal / Installation ..... page P-64
  - Inspection .... page P-64
- 22. Wheel-speed sensor (front)
  - Removal / Installation ..... page P-60
  - Inspection .... page P-60
- 23. Wheel-speed sensor (rear)
  - Removal / Installation ..... page P-62
  - Inspection .... page P-62
- 24. Sensor rotor (front)
  - Removal / Installation ..... page P-61
- 25. Sensor rotor (rear)
  - Removal / Installation ..... page P-63















## OUTLINE

## SPECIFICATIONS

Item		Specifications	
<b>Brake pedal</b>			
Type		Suspended	
Lever ratio		4.1 : 1	
Maximum stroke	mm {in}	135 {5.31}	
<b>Master cylinder</b>			
Type		Tandem (with level sensor)	
		Portless, recessed type	
Bore	mm {in}	23.8 {0.94}	
<b>Front brake</b>			
Type		Disc (ventilated)	
Cylinder bore	mm {in}	36.1 {1.42}	
Pad dimension (area × thickness)	mm <sup>2</sup> × mm {in <sup>2</sup> × in}	Outer	4,500 × 10.3 {6.97 × 0.41}
		Inner	4,500 × 9.3 {6.97 × 0.37}
Disc plate dimension (outer diameter × thickness)	mm × mm {in × in}	294.0 × 22.0 {11.57 × 0.87}	
<b>Rear brake</b>			
Type		Disc (ventilated)	
Cylinder bore	mm {in}	34.9 {1.37}	
Pad dimension (area × thickness)	mm <sup>2</sup> × mm {in <sup>2</sup> × in}	3,210 × 8.0 {4.98 × 0.31}	
Disc plate dimension (outer diameter × thickness)	mm × mm {in × in}	294.0 × 20.0 {11.57 × 0.79}	
<b>Power brake unit</b>			
Type		Vacuum multiplier	
Size	mm {in}	209.5 + 215.2 {8 + 8}	
<b>Rear wheel hydraulic control system</b>			
Type		Proportioning bypass valve	
Switching point (master cylinder pressure)	kPa {kgf/cm <sup>2</sup> , psi}	3,920 {40.0, 570}	
<b>Parking brake</b>			
Type		Mechanical two-rear-wheel control	
Operation system		Hand lever	
<b>Brake fluid</b>			
Type		FMVSS 116 DOT-3	

CONVENTIONAL BRAKE SYSTEM

PREPARATION  
SST

<p>49 0259 770B Wrench, flare nut</p> 	<p>For removal / installation of brake pipe</p>	<p>49 B043 001 Gauge, adjustment</p> 	<p>For adjustment of push rod clearance</p>
<p>49 B043 003 lock tool, turning</p> 	<p>For adjustment of push rod clearance</p>	<p>49 B043 004 Wrench, socket</p> 	<p>For adjustment of push rod clearance</p>
<p>49 0208 701A Air-out tool, boot</p> 	<p>For removal of piston seal</p>	<p>49 0221 600C Expansion tool, disc brake</p> 	<p>For installation of disc pads</p>
<p>49 F033 001 Stopper, disc brake piston</p> 	<p>For removal of disc brake piston</p>	<p>49 FA18 602 Wrench, disc brake piston</p> 	<p>For removal of disc brake piston</p>
<p>49 1285 071 Puller, bearing</p> 	<p>For removal of bearing</p>	<p>49 B043 002 Installer, bearing</p> 	<p>For installation of bearing</p>
<p>49 U043 0A0 Gauge set, oil pressure</p> 	<p>For measurement of fluid pressure</p>	<p>49 U043 004 Gauge, oil pressure (Part of 49 U043 0A0)</p> 	<p>For measurement of fluid pressure</p>
<p>49 U043 005 Joint (Part of 49 U043 0A0)</p> 	<p>For measurement of fluid pressure</p>	<p>49 U043 006 Hose (Part of 49 U043 0A0)</p> 	<p>For measurement of fluid pressure</p>



P

# P

## CONVENTIONAL BRAKE SYSTEM

### TROUBLESHOOTING GUIDE

Problem	Possible cause	Action	Page
<b>Poor braking</b>	Leakage of brake fluid	Repair	—
	Air in system	Bleed air	P-7
	Worn disc pad	Replace	P-24, 29
	Brake fluid, grease, oil, or water on disc pad	Clean or replace	P-24, 29
	Hardening of disc pad surface, or poor contact	Grind or replace	P-24, 29
	Malfunction of caliper piston	Replace	P-26, 31
	Malfunction of master cylinder	Repair or replace	P-11, 15
	Malfunction of power brake unit	Replace	P-18
	Malfunction of check valve (vacuum hose)	Replace	P-8
	Damaged vacuum hose	Replace	P-8
	Deterioration of flexible hose	Replace	P-7
Malfunction of proportioning bypass valve (PBV)	Replace	P-20	
<b>Brakes pull to one side</b>	Worn disc pad	Replace	P-24, 29
	Brake fluid, grease, oil, or water on disc pad	Clean or replace	P-24, 29
	Hardening of disc pad surface, or poor contact	Grind or replace	P-24, 29
	Abnormal wear, distortion, or runout of disc plate	Repair or replace	P-24, 30
	Malfunction of automatic adjuster	Repair or replace	P-26, 31
	Loose or damaged dust cover mounting bolt	Tighten or replace	Section M
	Malfunction of caliper piston	Replace	P-26, 31
	Worn or improperly adjusted wheel bearing preload	Adjust or replace	Section M
	Improper adjustment of wheel alignment	Adjust	Section R
Unequal tire air pressure	Adjust	Section Q	
<b>Brakes do not release</b>	No brake pedal play	Adjust	P-9
	Improper adjustment of push rod clearance	Adjust	P-11
	Clogged master cylinder return port	Clean	—
	Brake pad not returning properly	Repair	—
	Improper return or malfunction of caliper piston	Repair or Replace	P-26, 31
	Excessive runout of disc plate	Replace	P-24, 30
Improper adjustment of wheel bearing preload	Adjust or replace	Section M	
<b>Pedal goes too far (excessive pedal stroke)</b>	Air in system, insufficient brake fluid	Add fluid and bleed air	P-7, 8
	Improper adjustment of pedal play	Adjust	P-9
	Worn disc pad	Replace	P-24, 29
<b>Abnormal noise or vibration during braking</b>	Worn disc pad	Replace	P-24, 29
	Damaged pad	Grind or replace	P-24, 29
	Brakes do not release	Repair	—
	Foreign material or scratches on disc plate contact surface	Clean	—
	Loose caliper mounting bolt	Tighten	P-22, 28
	Damaged disc plate contact surface	Replace	P-22, 28
	Poor contact of pad	Repair or replace	P-24, 29
	Insufficient grease on sliding parts	Apply grease	—



**AIR BLEEDING**

The brakes should be bled whenever a brake line is disconnected. If a hydraulic line is disconnected at the master cylinder, start at the slave cylinder farthest from the brake master cylinder, and move to the next closest slave cylinder until all four cylinders have been bled. If the disconnection point is anywhere except the master cylinder, start at the point closest to the disconnection, and move to the next farthest slave cylinder until all four cylinders have been bled.

1. On level ground, jack up the vehicle and support it evenly on safety stands.

**Caution**


• Brake fluid will damage painted surfaces. If brake fluid does get on a painted surface, wipe it off immediately.

2. Remove the bleeder cap and attach a vinyl tube to the bleeder screw.
3. Place the other end of the vinyl tube in a clear, fluid-filled container.
4. Have a helper depress the brake pedal several times, and then hold it in the depressed position.
5. Loosen the bleeder screw, drain out the fluid, and close the screw by using the SST.
6. Repeat steps 4 and 5 until no air bubbles are seen.
7. Modify the bleeder screw tightening torque to allow for use of a torque wrench-SST combination. (Refer to section G1 "Torque Formulas".)
8. Tighten the bleeder screw by using the SST.

**Tightening torque:**

5.9–8.8 N·m {60–90 kgf·cm, 53–78 in·lbf}

9. Perform the above steps for the remaining wheels.
10. Check for correct brake operation.
11. Check that there is no fluid leakage. Wipe off any spilled fluid immediately.
12. After bleeding the brakes, add brake fluid to MAX.




**BRAKE LINE**

**Inspection**


Check for the following and repair or replace parts as necessary.

1. Cracks, damage, and corrosion of brake lines
2. Damage to brake hose threads
3. Scars, cracks, and swelling of flexible hoses
4. Fluid leakage from brake lines




**Removal / Installation**

1. When disconnecting the flexible hose and brake line, loosen the nut by using the SST, then remove the holding clip.
2. When connecting the flexible hose, do not overtighten or twist it.
3. Install the holding clip and tighten the brake pipe nut by using the SST.
4. Verify that the hose does not contact other parts when the vehicle bounces or when the steering wheel is turned all the way to the left or right.
5. Bleed the air from the brake system. (Refer to above.)

**BRAKE FLUID****Inspection**

1. Depress the brake pedal several times, and check the brake system for leaks.




2. Verify that the fluid level in the reservoir is between MAX and MIN.
3. If the fluid level is extremely low, check the brake system for leaks.

**Fluid specification: FMVSS 116 DOT-3**

**Replacement****Caution**

- Brake fluid will damage painted surfaces. If brake fluid does get on a painted surface, wipe it off immediately.




1. Remove the brake fluid from the reservoir by using a suction pump.
2. Fill the reservoir with clean brake fluid.
3. Attach a vinyl tube to the farthest bleeder screw and place the other end of the tube in a clear container.
4. Remove all old brake fluid from the brake lines by loosening the bleeder screw and pumping the brake pedal until only clean fluid is seen. The reservoir should be kept about 3/4 full during this procedure to prevent air from re-entering the lines.
5. Modify the bleeder screw tightening torque to allow for use of a torque wrench-SST combination. (Refer to section G1 "Torque Formulas".)
6. Tighten the bleeder screw.


**Tightening torque:**

**5.9–9.8 N·m {60–100 kgf·cm, 53–86 in·lbf}**


7. Perform the above steps for the remaining wheels.
8. Fill the reservoir to MAX.

**VACUUM LINE****Inspection**

1. Remove the clamps and the hose.
2. Apply both suction and pressure to the engine side of the hose, and verify that air flows only toward that side. If air flows in both directions or not at all, replace the vacuum hose.







**BRAKE PEDAL**

**Inspection (on-vehicle)**

**Pedal height inspection**

Verify that the distance from the center of the upper surface of the pedal pad to the carpet is as specified.

**Pedal height: 164.5–176.0 mm {6.48–6.92 in}  
(with carpet)**


**Pedal height adjustment**

1. Disconnect the stoplight switch connector.
2. Loosen locknut B and turn switch A until it does not contact the pedal arm.
3. Loosen locknut D and turn rod C to adjust the height.
4. Adjust the pedal free play and tighten locknut D. (Refer to below.)
5. Turn switch A until it contacts the pedal arm; then turn the switch a half-turn more.
6. Tighten locknut B.

**Tightening torque:**

**13.8–17.6 N·m {140–180 kgf·cm, 122–156 in·lbf}**


7. Connect the stoplight switch connector.



**Pedal play inspection**

1. Depress the pedal a few times to eliminate the vacuum in the system.
2. Lightly depress the pedal by hand until resistance is felt, and check the free play.

**Free play: 3–8 mm {0.12–0.31 in}**



**Pedal play adjustment**


1. Loosen locknut D and turn rod C to adjust the free play.

**Free play: 3–8 mm {0.12–0.31 in}**

2. Tighten locknut D.

**Tightening torque:**

**24–34 N·m {2.4–3.5 kgf·m, 17–25 ft·lbf}**



**Pedal-to-floor clearance**


1. Check if the distance from the floor panel to the center of the upper surface of the pedal pad is as specified when the pedal is depressed with a force of 589 N {60 kgf, 132 lbf}.

**Pedal-to-floor clearance: 100 mm {3.94 in} min.  
(without carpet)**

2. If the distance is less than specified, inspect for air in the brake system.


**Removal / Inspection / Installation**

1. Remove the side wall. (Refer to section S.)
2. Remove the lower panel. (Refer to section S.)
3. Remove the column cover.
4. Remove in the order shown in the figure.
5. Inspect all parts and repair or replace as necessary.
6. Install in the reverse order of removal.
7. After installation, check and adjust the pedal height and free play.



N·m {kgf·m, ft·lbf}

- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Stoplight switch connector</li> <li>2. Spring clip</li> <li>3. Clevis pin</li> <li>4. Steering shaft bracket mounting nut<br/>Service ..... Section N</li> <li>5. Nut</li> </ol> | <ol style="list-style-type: none"> <li>6. Stoplight switch<br/>Inspection ..... below</li> <li>7. Pedal pad<br/>Inspect for wear and damage</li> <li>8. Brake pedal<br/>Inspect for bending and damage</li> </ol> |
|--|---|




**Inspection  
Stoplight switch**

1. Disconnect the stoplight switch connector.
2. Connect an ohmmeter to the terminals of the stop-light switch.
3. Verify continuity between the terminals when the brake pedal is depressed.

**MASTER CYLINDER**


**Removal / Installation**

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, perform the following.
  - (1) Add fluid and bleed the brakes. (Refer to page P-7.)
  - (2) Check for fluid leakage. (Refer to page P-8.)



1. Hose (MT)
2. Brake fluid level sensor connector
3. Brake pipe  
Removal Note ..... below  
Installation Note ..... page P-14
4. Pipe joint and bracket
5. Nut

6. Bracket
7. O-ring
8. Master cylinder  
Disassembly / Inspection /  
Assembly ..... page P-15  
Installation Note ..... page P-12




**Removal note**

**Brake pipe**

Loosen the brake pipe at the master cylinder by using the SST.

**Caution**

- Brake fluid will damage painted surfaces. If brake fluid does get on a painted surface, wipe it off immediately.



### Installation note

#### Master cylinder


#### Piston to push rod clearance

1. Turn the nut of the SST clockwise to fully retract the gauge rod. Attach the SST to the power brake unit.

#### Tightening torque:


9.9–15.6 N·m {100–160 kgf·cm, 87–138 in·lbf}

2. Apply 66.7 kPa {500 mmHg, 19.7 inHg} vacuum by using a vacuum pump.



3. Turn the adjusting nut of the SST counterclockwise until the gauge rod just contacts the end of the master cylinder push rod.


Push lightly on the end of the gauge rod to be sure it is seated. Verify that there is no gap between the adjusting nut and the SST body.



4. Remove the SST from the power brake unit without disturbing the adjusting nut. Set the SST onto the master cylinder as shown in the figure.

5. Push lightly on the end of the SST gauge rod to be sure it is bottomed in the master cylinder piston, but do not push so hard that the piston moves. Note any clearance between the SST body and the adjusting nut (clearance B) or between the body and the master cylinder (clearance C). Adjust the push rod as necessary, as outlined in "Adjustment" on the next page.

Measurement	Push rod
Clearance at (B)	Too short
Clearance at (C)	Too long
No clearance at (B) or (C)	OK




### Adjustment


The threads of the push rod are specially designed so that the bolt becomes harder to turn past a certain point. This is to prevent the bolt from coming loose. Turn the bolt only within this range when adjusting.

### Clearance at B

1. Push lightly on the end of the SST gauge rod, and measure the clearance between the adjusting nut and the SST body.




2. Using the SSTs, turn the nut to lengthen the master cylinder push rod an amount equal to the clearance measured at B.




### Clearance at C

1. Measure and record height D1 of the gauge rod.




2. Turn the adjusting nut until the SST body sets squarely on the master cylinder. (Turn only enough for the body to touch.)

3. Measure and record height D2 of the gauge rod.




4. Subtract D1 from D2. Using the SSTs, turn the nut to shorten the master cylinder push rod an amount equal to the difference.



**Note**

- The previous adjustment produces the following clearance.

Vacuum applied to unit	Push rod-to-piston clearance
Approx 66.7 kPa {500 mmHg, 19.7 inHg}	0.1–0.4 mm {0.004–0.016 in}



**Brake pipe**

1. Modify the brake pipe flare nut tightening torque to allow for use of a torque wrench-SST combination. (Refer to section G1 "Torque Formulas".)
2. Tighten the brake pipe flare nut by using the SST.

**Tightening torque:**


**12.8–21.5 N·m{130–220 kgf·cm, 113–190 in·lbf}**

Disassembly / Inspection / Assembly


**Caution**

- The brake master cylinder is made of aluminum, and can be easily damaged by tightening in a vise. When securing the master cylinder in a vise, tighten only the master cylinder flange.

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Brake fluid level sensor<br/>Inspection ..... page P-16</li> <li>2. Screw</li> <li>3. Reservoir assembly<br/>Inspect for damage and deformation</li> <li>4. Bushings</li> <li>5. Snap ring and spacer</li> <li>6. Primary piston assembly<br/>Inspect for abnormal wear, rust, and damage</li> </ol> | <ol style="list-style-type: none"> <li>7. Stop pin and O-ring<br/>Assembly Note ..... page P-16</li> <li>8. Secondary piston assembly<br/>Inspect for abnormal wear, rust, and damage</li> <li>9. Master cylinder body<br/>Inspect for damage and wear<br/>Inspect inside of body for corrosion</li> </ol> |
|--|--|




**Inspection**

**Brake fluid level sensor**

1. Disconnect the brake fluid level sensor connector.
2. Check continuity of the brake fluid level sensor.

Fluid level	Continuity
Below MIN	Yes
Above MIN	No


3. If not as specified, replace the brake fluid level sensor.



**Assembly note**

**Stop pin and O-ring**

1. Install a new O-ring onto the stop pin.
2. Install the secondary piston assembly with the hole in the piston facing the stop pin.
3. Install and tighten the stop pin.
4. Push and release the piston to verify that it is held by the stop pin.




**POWER BRAKE UNIT**

**Inspection (on-vehicle)**

**Power brake unit function check (Simple method)**


**Step 1**

1. With the engine stopped, depress the brake pedal a few times.
2. With the pedal depressed, start the engine.
3. If immediately after the engine starts the pedal moves down slightly, the unit is operating.



**Step 2**

1. Start the engine.
2. Stop the engine after it has run for **1 or 2 minutes**.
3. Depress the pedal with the usual force.
4. If the first pedal stroke is long and becomes shorter with subsequent strokes, the unit is operating.
5. If a problem is found, inspect for damage of the check valve or vacuum hose and examine the installation. Repair if necessary, and inspect it once again.




**Step 3**

1. Start the engine.
2. Depress the pedal with the usual force.
3. Stop the engine with the pedal held depressed.
4. Hold the pedal down for **about 30 seconds**.
5. If the pedal height does not change, the unit is operating.
6. If there is a problem, inspect for damage to the check valve or vacuum hose, and inspect the hose connections. Repair if necessary, and inspect once again.


If the nature of the problem is still not clear after the three steps above, follow the more detailed check described in "Using the testers". (Refer to page P-17).






**(Using the testers)**

1. Connect the **SST** or equivalent, vacuum gauge, and pedal depression force gauge as shown in the figure.
2. After bleeding the air from the **SST**, conduct the test as described in the steps below.




**a) Checking for vacuum loss**  
**Unloaded condition**

1. Start the engine.
2. Stop the engine when the vacuum gauge reading reaches **66.7 kPa {500 mmHg, 19.7 inHg}**.
3. Observe the vacuum gauge for 15 seconds. If the gauge shows **63.4–66.7 kPa {475–500 mmHg, 18.7–19.7 inHg}**, the unit is operating.



**Loaded condition**


1. Start the engine.
2. Depress the brake pedal with a force of **196 N {20 kgf, 44 lbf}**.
3. With the brake pedal depressed, stop the engine when the vacuum gauge reading reaches **66.7 kPa {500 mmHg, 19.7 inHg}**.
4. Observe the vacuum gauge for 15 seconds. If the gauge shows **63.4–66.7 kPa {475–500 mmHg, 18.7–19.7 inHg}**, the unit operating.



**b) Checking for hydraulic pressure**

1. If, with the engine stopped (vacuum **0 kPa {0 mmHg, 0 inHg}**), the fluid pressure is within specification, the unit is operating.

Pedal force	Fluid pressure kPa {kgf/cm <sup>2</sup> , psi}
196 N {20 kgf, 44 lbf}	590 {6, 85} min.




2. Start the engine. Depress the brake pedal when the vacuum reaches **66.7 kPa {500 mmHg, 19.7 inHg}**. If the fluid pressure is within specification, the unit is operating.

Pedal force	Fluid pressure kPa {kgf/cm <sup>2</sup> , psi}
196 N {20 kgf, 44 lbf}	7750 {79, 1120} min.


**Removal / Installation**

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. Add fluid and bleed the brakes. (Refer to page P-7.)
4. Check and adjust the brake pedal height. (Refer to page P-9.)
5. Check for fluid leakage. (Refer to page P-8.)



- 1. Hose (MT)
- 2. Brake fluid level sensor connector
- 3. Brake pipe
  - Removal Note ..... page P-11
  - Installation Note ..... page P-14
- 4. Pipe joint and bracket
- 5. Nut
- 6. Bracket
- 7. O-ring
- 8. Master cylinder
  - Removal / Installation ..... page P-11
  - Disassembly / Inspection / Assembly ..... page P-15

- 9. Vacuum hose
  - Inspection ..... page P- 8
- 10. Spring clip
- 11. Clevis pin
- 12. Nut
- 13. Power brake unit
  - Inspection ..... page P-16
- 14. Spacer
- 15. Gasket




**PROPORTIONING BYPASS VALVE**

**Inspection**

1. Connect the SST or equivalent to the inlet and outlet pipes to the rear brake system.
2. After bleeding the air from the SST, measure the fluid pressure from the master cylinder and to the rear brakes.

**Specification:**


	FLUID PRESSURE KPa {kgf/cm <sup>2</sup> , psi}	REAR BRAKE PRESSURE
MASTER CYLINDER PRESSURE	A = 3,920 {40,570}	A' = 3,630-4,210 {37-43, 530-610}
	B = 5,880 {60,850}	B' = 4,320-5,090 {44-52, 626-739}




3. If not as specified, replace the proportioning bypass valve assembly.
4. Add fluid and bleed the air. (Refer to page P-7.)
5. Check for fluid leakage. (Refer to page P-8.)

**Replacement**

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. Add fluid and bleed the brakes. (Refer to page P-7.)
4. Check for fluid leakage. (Refer to page P-8.)



- |   |   |
|---|---|
| <p>1. Brake pipe<br/>Removal Note ..... below<br/>Installation Note ..... below</p> | <p>2. Bolt<br/>3. Proportioning bypass valve<br/>Inspection ..... page P-19</p> |
|---|---|



**Removal note**

**Brake pipe**

Loosen the brake pipes by using the SST.

**Caution**

- Brake fluid will damage painted surfaces. If brake fluid does get on a painted surface, wipe it off immediately.


**Installation note**

**Brake pipe**

1. Modify the brake pipe flare nut tightening torque to allow for use of a torque wrench-SST combination. (Refer to section GI "Torque Formulas".)
2. Tighten the brake pipes by using the SST.

**Tightening torque:**

12.8-21.5 N·m{130-220 kgf·cm,113-190 in·lbf}



**FRONT BRAKE (DISC)**

**Inspection (on-vehicle)**

**Disc pad**


1. On level ground, jack up the front of the vehicle and support it on safety stands.
2. Remove the wheels.
3. Look through the caliper inspection hole and inspect the remaining thickness of the pads.

**Thickness: 1.0 mm {0.04 in} min.**

4. Replace the pads as a set (right and left wheels) if either is at or less than the minimum thickness.


**Removal / Inspection / Installation**

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Add fluid and bleed the air. (Refer to page P-7.)
5. Check for fluid leakage. (Refer to page P-8.)
6. Depress the pedal a few times, then verify that the brakes do not drag while the wheels are being rotated by hand.



N·m {kgf·m, ft·lbf}


- |  |   |  |
|--|---|--|
| <p>1. Brake hose<br/>Inspect for damage and cracks</p> <p>2. Brake pipe<br/>Removal Note<br/>..... page P-23<br/>Installation Note<br/>..... page P-23</p> <p>3. Bolt, spacer</p> <p>4. Bolt, brake pipe bracket</p> <p>5. Guard plate</p> | <p>6. Caliper<br/>Removal Note<br/>..... page P-23<br/>Disassembly / Inspection /<br/>Assembly .... page P-26</p> <p>7. M-spring</p> <p>8. Pad pin</p> <p>9. M-clip</p> <p>10. Disc pad<br/>Inspection .... page P-21<br/>Installation Note<br/>..... page P-23</p> | <p>11. Outer shim<br/>Installation Note<br/>..... page P-23</p> <p>12. Inner shim<br/>Installation Note<br/>..... page P-23</p> <p>13. Screw</p> <p>14. Disc plate<br/>Inspection .... page P-24</p> |
|--|---|--|



**Removal note**

**Brake pipe**


Remove the brake pipe by using the SST.



**Caliper**

**Caution**


- Loosening the caliper bridge bolts will damage the brake caliper. Do not loosen or remove the caliper bridge bolts.



**Installation note**

**Outer shim, inner shim**

Align the arrow with the disc plate rotation and install the shims.



**Disc pad**

1. Clean the piston.
2. Push the piston inward by using the SST.
3. Install the disc pads.

**Brake pipe**

1. Modify the brake pipe tightening torque to allow for a torque wrench-SST combination. (Refer to section G1 "Torque Formulas".)
2. Tighten the brake pipe by using the SST.


**Tightening torque:**

12.8–21.5 N·m{130–220 kgf·cm, 113–190 in·lbf}

**DISC PAD (FRONT)**

**Replacement**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation Note**.




1. M-clip
2. Pad pin
3. M-spring

4. Disc pad  
Installation Note  
..... Page P-23

5. Outer shim  
Installation Note  
..... page P-23

6. Inner shim  
Installation Note  
..... page P-23



**DISC PLATE (FRONT)**

**Inspection**

**Disc plate thickness**


1. Measure the thickness of the disc plate.

**Standard: 22.0 mm {0.87 in}**

**Minimum: 20.0 mm {0.79 in}**

2. If the thickness is less than minimum, replace the disc plate.





### Disc plate runout

1. Verify that there is no looseness in the wheel bearing.
2. Measure the runout at the outer edge of the contact surface.

**Runout: 0.1mm {0.004 in} max.**

3. If the runout exceeds specification, repair or replace the disc plate.

**CALIPER (FRONT)**

**Disassembly / Inspection / Assembly**


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.

**Caution**

- **Loosening the caliper bridge bolts will damage the brake caliper. Do not loosen or remove the caliper bridge bolts.**

2. Inspect all parts and repair or replace as necessary.

3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




1. Piston ring  
2. Dust boot  
Inspect for wear and cracks

3. Piston  
Disassembly Note  
..... page P-27  
Inspect for wear and cracks

4. Piston seal  
Disassembly Note  
..... page P-27

5. Bleeder cap  
6. Bleeder screw  
Disassembly Note  
..... page P-27  
Assembly Note  
..... page P-27


7. Caliper body  
Inspect for damage and wear



**Disassembly note**


**Piston**

1. Place the **SST** in the caliper.
2. Blow compressed air through the pipe hole to force the pistons out of the caliper.



**Piston seal**

Remove the piston seal from the caliper by using the **SST**.



**Bleeder screw**

Loosen the bleeder screw by using the **SST**.


**Assembly note**

**Bleeder screw**

1. Modify the bleeder screw tightening torque to allow for use of a torque wrench-**SST** combination. (Refer to section GI "Torque Formulas".)
2. Tighten the bleeder screw by using the **SST**.

**Tightening torque:**

5.9-9.8 N·m{60-100 kgf·cm,53-86 in·lbf}



**REAR BRAKE (DISC)**


**Inspection (on-vehicle)**

**Disc pad**

1. On level ground, jack up the rear of the vehicle and support it on safety stands.
2. Remove the wheel.
3. Look through the caliper inspection hole and inspect the remaining thickness of the pads.  
**Thickness: 1.0 mm {0.04 in} min.**
4. Replace the pads as a set (right and left wheels) if either is at or less than the minimum thickness.


**Removal / Inspection / Installation**

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Add fluid and bleed the air. (Refer to page P-7.)
5. Check for fluid leakage. (Refer to page P-8.)
6. Depress the pedal a few times, then verify that the brakes do not drag while the wheels are rotated by hand.



- |  |  |  |
|--|--|--|
| 1. Clip and rear parking cable   | 6. V-spring  | 10. Pad clip                                   |
| 2. Flexible brake hose<br>Inspect for damage and cracks                | 7. Disc pad<br>Inspection . . . . page P-27<br>Installation Note | 11. Bolt, washer                               |
| 3. Lock pin  | 8. Outer shim  | 12. Protector                                  |
| 4. Guide pin   | 9. Inner shim  | 13. Mounting support                           |
| 5. Caliper<br>Disassembly / Inspection /<br>Assembly . . . . page P-31 |  | 14. Disc plate<br>Inspection . . . . page P-30 |




**DISC PLATE (REAR)****Inspection****Disc plate thickness**

1. Measure the thickness of the disc plate.

**Standard: 20.0 mm {0.79 in}**

**Minimum: 18.0 mm {0.71in}**

2. If the thickness is less than minimum, replace the disc plate.

**Disc plate runout**

1. Verify that there is no looseness in the wheel bearing.
2. Measure the runout at the outer edge of the contact surface of the disc pad.


**Runout: 0.1mm {0.004 in} max.**

3. If the runout exceeds specification, repair or replace the disc plate.


**CALIPER (REAR)**

**Disassembly / Inspection / Assembly**

1. Disassembly in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- |   |  |  |
|---|--|--|
| <p>1. Cable bracket</p> <p>2. Retaining ring</p> <p>3. Dust boot</p> <p>4. Piston<br/>Disassembly Note<br/>..... page P-32<br/>Inspect for wear and damage<br/>Assembly Note<br/>..... page P-33</p> <p>5. Piston seal<br/>Disassembly Note<br/>..... page P-32</p> <p>6. Snap ring</p> | <p>7. Case cover</p> <p>8. Spring</p> <p>9. Spring washer</p> <p>10. Stopper</p> <p>11. Adjuster spindle<br/>Inspect for wear and damage</p> <p>12. O-ring</p> <p>13. Connecting link<br/>Inspect for wear and damage</p> <p>14. Lever spring</p> <p>15. Operating lever</p> <p>16. Lever boot</p> | <p>17. Bearing<br/>Disassembly Note<br/>..... page P-32<br/>Assembly Note<br/>..... page P-33</p> <p>18. Bleeder cap</p> <p>19. Bleeder screw<br/>Disassembly Note<br/>..... page P-32<br/>Assembly Note<br/>..... page P-32</p> <p>20. Caliper body<br/>Inspect for wear and damage</p> |
|---|--|--|



**Disassembly note**


**Piston**

Remove the piston by turning the **SST** counterclockwise.




**Piston seal**

Remove the piston seal by using the **SST**.




**Bearing**

1. Secure the caliper in a vise.
2. Remove the bearing from the caliper by using the **SST**.



**Bleeder screw**

Loosen the bleeder screw by using the **SST**.



**Assembly note**


**Bleeder screw**

1. Modify the bleeder screw tightening torque to allow for use of a torque wrench-SST combination. (Refer to section GI "Torque Formulas".)
2. Tighten the bleeder screw by using the **SST**.

**Tightening torque:**


5.9–9.8 N·m {60–100 kgf·cm, 53–86 in·lbf}





**Bearing**

Press the new bearing into the caliper with the SST until the SST bottoms against the caliper.



**Piston**

1. Clean the piston with clean brake fluid.
2. Install the new dust boot in the piston groove.
3. Install the piston into the caliper body by turning the SST clockwise, and align the piston grooves, as shown in the illustration.
4. Fit the dust boot into the caliper body.

**PARKING BRAKE SYSTEM**

**TROUBLESHOOTING GUIDE**

Problem	Possible cause	Action	Page
Brakes do not release	Improper return of parking cable or improper adjustment	Repair or adjust	P-34
Parking brake does not hold well	Excessive parking brake lever stroke	Adjust	P-33
	Parking cable stuck or damaged	Repair or replace	P-34
	Brake fluid or oil on pads	Clean or replace	P-29
	Hardening of pad surfaces, or poor contact	Grind or replace	P-29

**PARKING BRAKE (LEVER TYPE)**

**Inspection**

**Parking brake lever stroke**

1. Depress the brake pedal several times.
2. Pull and release the parking brake lever several times.
3. Verify that the stroke is within specification when the parking brake lever is pulled up with a force of 98 N {10 kgf, 22 lbf}.

**Stroke: 7-10 notches**

4. If not within specification, adjust the parking brake lever stroke. (Refer to below.)



**Adjustment**

**Parking brake lever stroke**

1. Depress the brake pedal several times.
2. Pull and release the parking brake lever several times.
3. Remove the console panel. (Refer to section S.)
4. Adjust the parking brake lever stroke by turning the adjusting nut.

**Stroke: 7-10 notches**


5. Pull the parking brake lever up one notch, and verify that the parking brake warning light comes on. Release the parking brake.
6. Turn the wheels by hand, and verify that the brakes do not drag.



### PARKING CABLE (LEVER TYPE)

#### Removal/Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.
4. After installation, check the parking brake lever stroke. (Refer to page P-33.)



1. Adjusting nut
2. Front parking cable  
Inspect for damage and wear


3. Clip
4. Bolt

5. Clip
6. Rear parking cable  
Inspect for damage and wear

**PARKING BRAKE LEVER**

**Removal / Inspection / Installation**


1. Remove the console panel. (Refer to section S.)
2. Remove the rear console. (Refer to section S.)
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. After Installation, check the parking brake lever stroke. (Refer to page P-33.)



1. Parking brake switch connector
2. Adjusting nut
3. Front parking cable

4. Bolt
5. Parking brake switch  
Inspection .... page P-36  
Installation Note  
..... page P-36

6. Parking brake lever  
Inspect for damage and bending



### Inspection

#### Parking brake switch

1. Remove the console panel. (Refer to section S.)
2. Disconnect the connector from the parking brake switch.
3. Pull the parking brake lever and check continuity between the terminal of the switch and a ground.


Parking brake lever	continuity
Released	No
Pulled	Yes

4. If not as specified, replace the parking brake switch.

### Installation note






#### Parking brake switch

1. Install the parking brake switch so that it contacts the parking brake lever when the lever is fully released.
2. Turn the ignition switch ON, and check that the parking brake warning lamp illuminates with the lever is pulled up one notch.



ANTILOCK BRAKE SYSTEM (ABS)

PREPARATION  
SST

<p>49 H066 003</p> <p>Harness, adapter</p> 	<p>For connecting ABS tester</p>	<p>49 0259 770B</p> <p>Wrench, flare nut</p> 	<p>For removal / installation of brake pipe</p>
<p>49 H028 2A0</p> <p>Set, rubber bushing replacer</p> 	<p>For installation of sensor rotor (front)</p>	<p>49 H028 204</p> <p>Attachment (Part of 49 H028 2A0)</p> 	<p>For installation of sensor rotor (front)</p>
<p>49 F026 104</p> <p>Installer, sensor rotor</p> 	<p>For installation of sensor rotor (rear)</p>		



## TROUBLESHOOTING GUIDE

## Outline

The ABS tester is used to locate the cause of a problem within the antilock brake system by retaining and reducing the hydraulic fluid pressure in the hydraulic unit.


Because there is no way to check the ABS control unit itself, replace the control unit assembly only after first confirming that the other electrical parts are not malfunctioning.

## ABS tester



## Connecting the ABS tester


1. Turn the ignition switch OFF.
2. Connect the SST between the hydraulic unit wiring harness connectors, and to the positive battery terminal.




3. Remove the trunk side trim.
4. Remove the ABS control unit.
5. Disconnect the control unit connector and connect the ABS tester to the control unit connector at the harness side.

Explanation of instruction procedure

EXPLANATION OF INSTRUCTION PROCEDURE



Example:  
5B "Brake light  
switch test"




### Troubleshooting procedure

ITEM	
<b>1. CONNECTION / POWER ON</b>	<ol style="list-style-type: none"> <li>1. Locate ABS control unit.</li> <li>2. Disconnect control unit harness connector from control unit.</li> <li>3. Connect ABS tester harness to control unit harness connector.</li> <li>4. Turn ignition key to ON position.</li> </ol>
<b>2. ALTERNATOR TEST</b> • Start engine	<p>Tester rapidly displays several messages during initial segment check.</p> <pre>           graph TD             Start(( )) --&gt; THEN[THEN]             THEN --&gt; MAZDA_ABS[MAZDA ABS 2 TEST]             MAZDA_ABS --&gt; ENG_RUN{YES ENG RUN? NO}             ENG_RUN --&gt; MAZDA_ALT[MAZDA ALT TEST]             MAZDA_ALT --&gt; CHK_ALT[CHK ALTERNATOR]             CHK_ALT --&gt; CONTINUE{YES CONTINUE? NO}             CONTINUE --&gt; CHK_ALT             CONTINUE --&gt; OFF[TURN OFF ENGINE]             CONTINUE -- No fault detected --&gt; OFF           </pre>
<b>3. ABS SYSTEM TEST</b> • Turn ignition key ON (Do not run engine)	<p>Tester rapidly displays several messages during initial segment check.</p> <pre>           graph TD             Start(( )) --&gt; THEN[THEN]             THEN --&gt; ENG_RUN{YES ENG RUN? NO}             ENG_RUN --&gt; MAZDA_ABS[MAZDA ABS 2 TEST]             MAZDA_ABS --&gt; Cont["(Cont.)"]           </pre>




**4. SYSTEM VOLTAGE CHECKS**

- If tester displays a fault message, check and repair or replace parts as necessary.




ANTILOCK BRAKE SYSTEM (ABS)


5. STATIC TESTS  
5A ABS WARNING LIGHT TEST



5B. BRAKE LIGHT SWITCH TEST



5C PUMP TEST



# ANTILOCK BRAKE SYSTEM (ABS)


## 6. DYNAMIC TESTS 6A WHEEL SELECTION OR EXIT

Each messages will displayed  
3-1/2 seconds  
Select one  
wheel to begin dynamic test  
sequence

OR

Press either switch under "PUSH  
TO EXIT" to return to "STAT  
TEST DYNAM" selection

**IMPORTANT:**  
After completing testing of selected  
wheel return to 6A "WHEEL  
SELECTION," to select another  
wheel  
Complete test procedures  
for all four wheels



On level ground, jack up the vehicle and support it evenly on  
safety stands.  
An extra person will be needed to spin wheels during the test.

## 6B WHEEL SENSOR TEST

SPIN TIRE

Display shows wheel selected  
in 6A

Spin wheel  
If speed is incorrect  
tester displays:


SPIN FASTER

OR

SPIN SLOWER

(Cont.)

## 6B WHEEL SENSOR TEST



## 6C SOLENOID TEST

Each solenoid test can be conducted for 15 seconds maximum.  
The tester will display the following message if the time limit is exceeded.

TIMEOUT EXPIRED

THEN

TRY TEST AGAIN

PUSH TEST 1

Press either switch  
to start test  
tester displays:


PRESS BRK ... HOLD

Apply firm pressure to  
brake pedal and hold  
firmly throughout solenoid  
tests 1 and 2

(Cont.)


# ANTILOCK BRAKE SYSTEM (ABS)

## 6C SOLENOID TEST






6C SOLENOID TEST



**IMPORTANT**—Continue returning to 6A until all four wheels have been tested






**Inspection of ABS system**

**Check system ground**

Check for an open circuit in (B) wire from terminals 1D, 1S, and AF of the ABS control unit O-01 connector and ground.


**Caution**

- To prevent damage to the terminals, create a probe by wrapping a thin wire around the tester lead before inserting.




**Check antilock warning light**

1. Remove the switch assembly. (Refer to 1994 RX-7 body electrical troubleshooting manual section Z4.)
2. Remove and check the ABS warning light bulb.
3. If a problem is found, replace the bulb.
4. If OK repair or replace the wiring harness. (Battery-ABS control unit-ABS warning light)




**Check ABS diode**

1. Check the wiring harness between the warning light and the control unit and hydraulic unit. Repair if necessary.
2. Disconnect the hydraulic unit O-02 connector.
3. Using an ohmmeter, check for continuity between the terminals of the connector (hydraulic unit side).



○-○: Continuity

4. If continuity is not specified, replace the hydraulic unit.




**Check front and rear valves**

1. Disconnect the negative battery cable.
2. Disconnect the hydraulic unit O-02 connector.
3. Check for continuity between terminals of the connector (hydraulic unit side).


Wire	Continuity	
(G/Y)	(Y/G)	Yes
	(BR)	Yes
	(B/W)	Yes

4. If not as specified, replace the hydraulic unit.




**Check stoplight switch**

1. Disconnect the stoplight switch connector.
2. Connect an ohmmeter between terminals of the switch.
3. Verify that there is continuity between the terminals when the brake pedal is depressed.
4. If there is no continuity, replace or adjust the stoplight switch.



**Check motor relay**

1. Disconnect the negative battery cable.
2. Remove the motor relay.




3. Using an ohmmeter, check continuity between terminals of the relay.

Connect to		a	b	c	d
12V	Ground		○	○	
—	—	○			○

○-○: Continuity

4. If cotinuity is not as specified, replace the motor relay.




**Check pump motor**

1. Disconnect the hydraulic unit O-03 connector.
2. Measure the voltage between wire (B/L) and a ground.

Wire	Voltage
(B/L)	Battery positive voltage


3. If not as specified, check the fuse (MAIN and ABS 60A) and repair or replace the wiring harness (battery-hydraulic unit).



4. If as specified, check for continuity between wire (G) of O-03 connector and a ground (hydraulic unit side).

Wire	Continuity
(R/Y)	Yes

5. If there is no continuity, replace the hydraulic unit.



**Check valve relay**

1. Disconnect the negative battery cable.
2. Remove the valve relay.
3. Using an ohmmeter, check for continuity between terminals of the relay.


Connect to		a	b	c	d	e
12V	Ground					
—	—		○	○	○	○
b	d	○				○

○-○: Continuity

4. If continuity is not as specified, replace the valve relay.
5. If as specified, connect the negative battery cable.
6. Disconnect the hydraulic unit O-02 connector.
7. Measure voltage between wire (W/R) of O-02 connector and ground.


Wire	Voltage
(W/R)	Battery positive voltage

8. If not as specified, check the fuse (MAIN and ABS 15A) and repair or replace the wiring harness (battery-hydraulic unit).




**Check rotor**


1. Check the rotor for looseness and missing or damaged teeth.
2. Replace if necessary.



**Check alternator**

Refer to section G.





**Check wheel-speed sensor**

1. Disconnect the O-01 connector.
2. Using an ohmmeter, check for continuity between the ABS control unit O-01 connector terminals.

Sensor \ Terminal	1K	1G	1O	1Q	1U	1F	1L	1P
Left front	○—○							
Right front					○—○			
Left rear			○—○					
Right rear							○—○	


○—○ : Continuity

2. If the continuity is not as specified, repair the wiring harness (wheel-speed sensor-ABS control unit).
3. If continuity is as specified, check voltage between the following terminals while rotating the wheel one rotation per second by hand.

Sensor	Terminal	Voltage
Left front	1K and 1G	50-60 mV*
Right front	1U and 1F	50-60 mV*
Left rear	1O and 1Q	50-60 mV*
Right rear	1L and 1P	50-60 mV*

\*Alternating current voltage

4. If voltage is not as specified, replace the wheel-speed sensor.
5. If voltage is as specified, replace the ABS control unit.




**Check hydraulics**

Verify that all brake fluid line connections are tight and that no fluid is leaking.

**Check hydraulic unit wiring**

1. Verify that the hydraulic unit connectors are properly secured.
2. Verify that the valve relay and motor relay are properly secured.

## SERVICE POINTS Circuit Diagram



**Electrical diagnosis support  
Hydraulic Unit (HU)**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Valve relay, motor relay and solenoid valve-ABS CU	System shut down ↓ Normal braking	System shut down ↓ Normal braking	NA
HU-Fuse-Battery	System shut down ↓ Normal braking	System shut down ↓ Normal braking Fuse (ABS) burns out	NA
Motor-Ground	System shut down ↓ Normal braking	No symptom	System shut down ↓ Normal braking
O-02 connector (B) -Ground	ABS warning light does not illuminate when ABS CU disconnected	No symptom	ABS warning light does not illuminate when ABS CU disconnected
HU-ABS warning light	ABS warning light does not illuminate when ABS CU disconnected	ABS warning light illuminates continuously	NA

**Wheel-speed sensor**

Circuit	Condition		
	Open circuit	Short circuit	Poor ground
Wheel speed sensor-ABS CU	Partial control	Partial control	NA

Partial control: If failure occurs during ABS operation, system is controlled by remaining sensors until ABS cycle is completed, then system is shut down.

NA: Not applicable

# ANTILOCK BRAKE SYSTEM (ABS)

**P**

## ABS Control Unit (ABS CU)


Circuit	Condition		
	Open circuit	Short circuit	Poor ground
ABS CU-Ignition switch-Battery	System shut down ↓ Normal braking	System shut down ↓ Normal braking Fuse (AIR CON 15A) burns out	NA
ABS CU-Stoplight switch-Battery	ABS controllability slightly down on low coefficient road, but no other effects	ABS controllability slightly down on low coefficient road, but no other effects Fuse (STOP 20A) burns out	NA
ABS CU-Alternator	ABS warning light remains illuminated after engine started  ABS control normal	ABS warning light remains illuminated after engine started  ABS control normal	NA
ABS CU-Ground	If all ground harnesses are open, system shut down	No symptom	If all ground harnesses are open, system shut down
ABS CU-ABS warning light	ABS warning light does not illuminate when ABS CU disconnected  ABS warning light does not illuminate when ignition switch is ON and system has been shut down	ABS warning light illuminates continuously	NA

NA: Not applicable

**HYDRAULIC UNIT**


**Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. The only serviceable parts of the hydraulic unit are the valve relay and the motor relay, if there is a failure of any other part, replace the hydraulic unit assembly.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Add fluid and bleed the air. (Refer to page P-7.)
6. Check for fluid leakage. (Refer to page P-8.)



- |                   |                               |                          |
|-------------------|-------------------------------|--------------------------|
| 1. Connector      | 3. Proportioning bypass valve | 7. ABS bracket           |
| 2. Brake pipe     | 4. Ground wire                | 8. Insulator and bracket |
| Removal Note      | 5. Nut                        |                          |
| ..... page P-57   | 6. Hydraulic unit             |                          |
| Installation Note | Disassembly / Inspection /    |                          |
| ..... page P-57   | Assembly ..... page P-58      |                          |





**Removal / note**  
**Brake pipe**

**Caution**

- Brake fluid will damage painted surfaces. If brake fluid does get on a painted surface, wipe it off immediately.

Loosen the brake pipe by using the SST.

**Installation note**  
**Brake pipe**


1. Modify the brake pipe flare nut tightening torque to allow for use of a torque wrench-SST combination. (Refer to section GI "Torque Formulas".)
2. Tighten the brake pipes by using the SST.

**Tightening torque:**

**12.8–21.5 N·m{130–220 kgf·cm,113–190 in·lbf}**

**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly.




1. Connector bolt
2. Pipe joint
3. Gasket
4. Proportioning bypass valve holder

5. Casing and mount rubber
6. Hex stud
7. Ground wire
8. Cover

9. Motor relay  
Inspection .... page P-64
10. Valve relay  
Inspection .... page P-64
11. Hydraulic unit

**ABS CONTROL UNIT  
Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove the luggage compartment side trim. (Refer to section S.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Bolt


2. Connector

3. ABS control unit

**WHEEL-SPEED SENSOR (FRONT)**


**Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Connector
2. Bolt

3. Wheel-speed sensor (front)  
Inspection ..... below



**Inspection**  
**Wheel speed sensor (front)**

1. Measure resistance between terminals of the wheel-speed sensor.


**Resistance: 0.8–1.2 kΩ**

2. If resistance is not as specified, replace the wheel-speed sensor.

**SENSOR ROTOR (FRONT)**

**Removal / Installation**


1. Remove the wheel hub assembly from the vehicle. (Refer to section M.)
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Install the wheel hub assembly to the vehicle. (Refer to section M.)



1. Sensor rotor (front)

Removal Note ..... below  
Installation Note ..... below

2. Front wheel hub assembly




**Removal note**  
**Sensor rotor (front)**

**Note**

- The sensor rotor does not need to be removed unless you are replacing it.

Remove the sensor rotor by using a brass bar and a hammer.




**Installation note**  
**Sensor rotor (front)**

Press on the new sensor rotor by using the SST.

WHEEL-SPEED SENSOR (REAR)


Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Connector
2. Bolt

3. Wheel-speed sensor (rear)  
Inspection ..... below



Inspection

Wheel-speed sensor (rear)

1. Measure resistance between terminals of the wheel-speed sensor.


Resistance: 0.8-1.2 kΩ

2. If resistance is not as specified, replace the wheel-speed sensor.

**SENSOR ROTOR (REAR)**

**Removal / Installation**

1. Remove the drive shaft from the vehicle. (Refer to section M.)
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Install the drive shaft to the vehicle. (Refer to section M.)




1. Boot band and boot

3. Drive shaft

2. Sensor rotor (rear)

Removal Note ..... below

Installation Note ..... below




**Removal note**

**Sensor rotor (rear)**

**Note**

- The sensor rotor does not need to be removed unless you are replacing it.

Tap the sensor rotor off the drive shaft by using a chisel and a hammer.



**Installation note**


**Sensor rotor (rear)**

Set a new sensor rotor on the drive shaft and press it on by using the SST.

**RELAY**


**Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



1. Cover
2. Motor relay  
Inspection ..... below

3. Valve relay  
Inspection ..... below




**Inspection  
Motor relay**

1. Using an ohmmeter, check for continuity between the relay terminals.

Connect to		a	b	c	d
12V	Ground				
—	—		○	○	
c	b	○			○

○—○: Continuity

2. If continuity is not as specified, replace the motor relay.



**Valve relay**

1. Using an ohmmeter, check for continuity between the relay terminals.

Connect to		a	b	c	d	e
12V	Ground					
—	—		○	○	○	○
b	d	○				○

○—○: Continuity

2. If continuity is not as specified, replace the valve relay.



# WHEELS AND TIRES

<b>OUTLINE</b> .....	<b>Q - 2</b>
<b>SPECIFICATIONS</b> .....	<b>Q - 2</b>
<b>TROUBLESHOOTING GUIDE</b> .....	<b>Q - 2</b>
<b>WHEELS AND TIRES</b> .....	<b>Q - 3</b>
<b>SPECIAL NOTES ABOUT WHEELS     AND TIRES</b> .....	<b>Q - 3</b>
<b>NOTES REGARDING TIRE     REPLACEMENT</b> .....	<b>Q - 3</b>
<b>INSPECTION/ADJUSTMENT</b> .....	<b>Q - 3</b>
<b>REMOVAL/INSTALLATION</b> .....	<b>Q - 4</b>
<b>TIRE ROTATION</b> .....	<b>Q - 5</b>
<b>WHEEL BALANCE ADJUSTMENT</b> .....	<b>Q - 5</b>

**OUTLINE**

**SPECIFICATIONS**

Item		Type	Standard	Temporary spare
wheel	Size		16 × 8JJ	16 × 4T
	Offset	mm {in}	50 {1.97}	40 {1.57}
	Pitch circle diameter	mm {in}	114.3 (4.50)	
	Material		Aluminum alloy	
Tire	Size		P225/50R16 91V P225/50 ZR 16	T135/70D16
	Air pressure	kPa {kgf/cm <sup>2</sup> , psi}	220 {2.2, 32}	415 {4.2, 60}

**TROUBLESHOOTING GUIDE**

Problem	Possible cause	Action	Page
<b>Excessive or irregular tire wear</b>	Refer to page Q-4 for details.		
<b>Premature tire wear</b>	Incorrect tire pressure	Adjust	Q-3
<b>Tire squeal</b>	Incorrect tire pressure	Adjust	Q-3
	Tire deterioration	Replace	—
<b>Road noise or body vibration</b>	Insufficient tire pressure	Adjust	Q-3
	Unbalanced wheel	Adjust	Q-5
	Deformed wheel or tire	Repair or replace	—
	Irregular tire wear	Replace	—
<b>Shake (steering wheel vibrates up/down)</b>	Excessive tire or wheel runout	Replace	—
	Loose lug nuts	Tighten	Q-4
	Unbalanced wheel	Adjust or replace	Q-5
	Cracked or worn engine mount rubber	Replace	Section C
	Cracked or worn transmission mount rubber	Replace	Section J, K
<b>Shimmy (steering wheel vibrates left/right)</b>	Cracked or worn steering gear mount rubber	Replace	Section N
	Loose steering gear mounting bolts	Tighten	Section R
	Stuck or damaged steering ball joint	Replace	Section N
	Excessive tire or wheel runout	Replace	—
	Loose lug nuts	Tighten	Q-4
	Unbalanced wheel	Adjust or replace	Q-5
	Insufficient tire pressure	Adjust	Q-3
	Unevenly worn tires	Replace	—
	Malfunction of shock absorber	Replace	Section R
	Loose shock absorber mounting bolts	Tighten	Section R
	Stuck or damaged lower arm ball joint	Replace	Section R
	Cracked or worn suspension bushings	Replace	Section R
	Damaged or worn front wheel bearing	Replace	Section M
Improperly adjusted front wheel alignment	Adjust	Section R	
<b>Uneven (onesided) braking</b>	Unequal tire pressures	Adjust	Q-3
<b>Steering wheel doesn't return properly or pulls left or right</b>	Incorrect tire pressure	Adjust	Q-3
	Irregular tire wear (left/right)	Replace	—
	Unequal tire pressures	Adjust	Q-3
	Different types or brands of tires mixed (left/right)	Replace	—
	Loose lug nuts	Tighten	Q-4
<b>General driving instability</b>	Unequal tire pressures	Adjust	Q-3
	Damaged or unbalanced wheel	Replace or adjust	Q-5
	Loose lug nuts	Tighten	Q-4
<b>Excessive steering wheel play</b>	Loose lug nuts	Tighten	Q-4

**WHEELS AND TIRES**


**SPECIAL NOTES ABOUT WHEELS AND TIRES**

1. Do not use wheels or tires other than the specified types.
2. Aluminum wheels are easily scratched. When washing them, use a soft cloth, never a wire brush. If the vehicle is steam cleaned, do not allow boiling water to contact the wheels.
3. If alkaline compounds (such as salt-water or road salts) get on aluminum wheels, wash them as soon as possible to prevent damage. Use only a neutral detergent.

**NOTES REGARDING TIRE REPLACEMENT**

Note the following points when tires are to be removed from or mounted onto the wheels.

1. Be careful not to damage the tire bead, the rim bead, or the edge of the rim.
2. Apply a soapy solution to the tire bead and the edge of the rim.
3. Use a wire brush, sandpaper, or cloth to clean and remove all rust and dirt from the rim edge and the rim bead. For aluminum wheels, use only a cloth for this purpose; never use a wire brush or sandpaper.
4. Remove pebbles, glass, nails, and other foreign items embedded in the tire tread.
5. Be sure the air valve is installed correctly.
6. After mounting a tire onto a wheel, inflate it to 250–300 kPa {2.5–3.0 kgf/cm<sup>2</sup>, 36–42 psi}. Verify that the bead is seated correctly onto the rim and that there are no air leaks. Then reduce the pressure to the specified level.
7. If a tire iron is used to change a tire on an aluminum wheel, be sure to use a piece of rubber between the iron lever and the wheel to avoid damage to the wheel. Work should be done on a rubber mat, not on a hard or rough surface.



**INSPECTION/ADJUSTMENT**


Perform the following inspections and adjust or replace as necessary.

1. Check the air pressure of all tires when they are cold, including the spare tire.

**Air pressure**

Standard tire: 220 kPa {2.2 kgf/cm<sup>2</sup>, 32 psi}

Temporary spare tire: 415 kPa  
{4.2 kgf/cm<sup>2</sup>, 60 psi}




2. Turn the wheel one full revolution and check the wheel runout.

**Wheel runout**

Horizontal: 2.0 mm {0.079 in} max.

Vertical: 1.5 mm {0.059 in} max.



3. Inspect for tire wear.

**Specifications**


**Remaining tread**

**Ordinary tires: 1.6 mm {0.063 in} min.**

(Tire should be replaced if wear indicators are exposed.)

**Snow tires: 50% of tread**


(Tire should be replaced if wear indicators are exposed.)



**Troubleshooting guide**

Abnormal tire wear patterns as shown in the illustration can occur. Refer to the chart for the possible causes and actions.


	Possible cause	Action
(a)	<ul style="list-style-type: none"> <li>• Underinflation (both sides worn)</li> <li>• Incorrect camber (one side worn)</li> <li>• Hard cornering</li> <li>• Lack of rotation</li> </ul>	<ul style="list-style-type: none"> <li>• Measure and adjust pressure</li> <li>• Repair or replace suspension parts</li> <li>• Reduce speed</li> <li>• Rotate tires</li> </ul>
(b)	<ul style="list-style-type: none"> <li>• Overinflation</li> <li>• Lack of rotation</li> </ul>	<ul style="list-style-type: none"> <li>• Measure and adjust Pressure</li> <li>• Rotate tires</li> </ul>
(c)	<ul style="list-style-type: none"> <li>• Incorrect toe-in</li> </ul>	<ul style="list-style-type: none"> <li>• Adjust toe-in</li> </ul>
(d)	<ul style="list-style-type: none"> <li>• Incorrect camber or caster</li> <li>• Malfunctioning suspension</li> <li>• Unbalanced wheel</li> <li>• Out-of-round brake drum or disc</li> <li>• Other mechanical conditions</li> <li>• Lack of rotation</li> </ul>	<ul style="list-style-type: none"> <li>• Repair or replace suspension parts</li> <li>• Repair or replace</li> <li>• Balance or replace</li> <li>• Correct or replace</li> <li>• Correct or replace</li> <li>• Rotate tires</li> </ul>



4. Cracks, damage, and foreign matter (such as metal pieces, nails, and stones) in the tire and cracks, deformation, and damage to the wheel.

5. Loose wheel lug nut (s).

6. Air leaking from valve stem.



**REMOVAL/INSTALLATION**


After making sure that the wheel-to-hub contact surfaces are clean, tighten the lug nuts to the specified torque in a crisscross pattern.

**Tightening torque:**


89–117 N·m{9.0–12.0 kgf·m,66–86 ft·lbf}

**Caution**

- Applying oil to the lug nuts, studs, or wheels will cause the lug nuts to loosen.



Mount the tires so that **OUTSIDE** marks face out, and rotation marks match the tire's rotation.




## TIRE ROTATION

To prolong tire life and assure uniform tire wear, rotate all tires as specified below except the "TEMPORARY USE ONLY" spare tire.

**USA : Every 6000km {3750miles}**


**Canada : Every 24000km {15000miles} or 15monthes (whichecker comes first)**



## WHEEL BALANCE ADJUSTMENT

If a wheel has becomes unbalanced or if a tire has been repaired or repaired, rebalance the wheel.

**Maximum unbalance (at rim edge): 8g {0.28 oz}**



When balancing a wheel:

- (1) Use no more than two balance weights on the inner or outer side of the wheel.
- (2) One balance weight should weigh no more than 60 g {2.1 oz}. If the total weight of all the balance weights on one side exceeds 100 g {3.53 oz}, then rebalance after repositioning the tire on the rim.
- (3) Select suitable balance weights for steel or aluminum alloy wheels.

### Caution

- Using an on-vehicle balancer may cause damage to the transmission. Always use an off-vehicle balancer whenever balancing a wheel.



Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.

R


## SUSPENSION

<b>INDEX</b> .....	R - 2
<b>OUTLINE</b> .....	R - 4
<b>SPECIFICATIONS</b> .....	R - 4
<b>TROUBLESHOOTING GUIDE</b> .....	R - 5
<b>WHEEL ALIGNMENT</b> .....	R - 6
<b>PRE-INSPECTION</b> .....	R - 6
<b>FRONT WHEEL ALIGNMENT</b> .....	R - 6
<b>REAR WHEEL ALIGNMENT</b> .....	R - 9
<b>FRONT SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)</b> .....	R -10
<b>PREPARATION</b> .....	R -10
<b>FRONT SHOCK ABSORBER AND SPRING</b> .....	R -12
<b>UPPER ARM</b> .....	R -16
<b>FRONT LOWER ARM</b> .....	R -19
<b>FRONT STABILIZER</b> .....	R -24
<b>FRONT STRUT BAR</b> .....	R -25
<b>REAR SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)</b> .....	R -26
<b>PREPARATION</b> .....	R -26
<b>REAR SHOCK ABSORBER AND SPRING</b> .....	R -27
<b>UPPER ARM</b> .....	R -32
<b>REAR LOWER ARM</b> .....	R -36
<b>TOE-CONTROL LINK</b> .....	R -40
<b>REAR STABILIZER</b> .....	R -41
<b>REAR STRUT BAR</b> .....	R -42

R

## INDEX

### FRONT SUSPENSION



### FRONT WHEEL ALIGNMENT (UNLADEN\*1)

Item		Inspection standard	Adjustment standard
Total toe-in	mm (in)	$2 \pm 3$ ( $0.08 \pm 0.11$ )	$2 \pm 1$ ( $0.08 \pm 0.04$ )
Toe-in (per side)	Degree	$0.1^\circ \pm 0.75^\circ$	$0.1^\circ \pm 0.05^\circ$
Maximum steering angle	In	$36^\circ \pm 2^\circ$	
	Out	$32^\circ \pm 2^\circ$	
Kingpin angle	Degree	$13^\circ 55'$	
Camber angle	Degree	$0.1^\circ \pm 0.75^\circ$	$0.1^\circ \pm 0.5^\circ$
	Difference between left and right	Degree	$1^\circ$ Max.
Caster angle	Degree	$6.08^\circ \pm 0.75^\circ$	$6.08^\circ \pm 0.5^\circ$
	Difference between left and right	Degree	$1^\circ$ Max.

\*1 Fuel tank full; radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions.


1. Front shock absorber and spring  
Removal / Installation  
..... page R-12  
Disassembly / Inspection /  
Assembly .... page R-13

2. Upper arm  
Removal / Inspection /  
Installation ... page R-16  
Inspection .... page R-17  
Disassembly / Inspection /  
Assembly .... page R-17

3. Front lower arm  
Removal / Inspection /  
Installation ... page R-19  
Inspection .... page R-20  
Disassembly / Inspection /  
Assembly .... page R-21

4. Front stabilizer  
Removal / Inspection /  
Installation ... page R-24  
5. Front strut bar  
Removal / Inspection /  
Installation ... page R-25

REAR SUSPENSION



REAR WHEEL ALIGNMENT (UNLADEN\*1)

Item		Inspection standard	Adjustment standard
Total toe-in	mm {in}	2 ± 3 {0.08 ± 0.11}	2 ± 1 {0.08 ± 0.04}
Toe-in (per side)	Degree	0.1° ± 0.1°	0.1° ± 0.05°
Camber angle	Degree	-1.22° ± 0.75°	-1.22° ± 1.0°
Difference between left and right	Degree	1° Max.	1° Max.
Thrust angle	Degree	0° ± 0.1°	0° ± 0.1°

\*1 Fuel tank full; radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions.

- 1. Rear shock absorber and spring  
Removal / Installation  
..... page R-27  
Disassembly / Inspection /  
Assembly .... page R-29
- 2. Upper arm  
Removal / Inspection  
Installation ... page R-32  
Disassembly / Inspection /  
Assembly .... page R-33

- 3. Rear lower arm  
Removal / Inspection  
Installation ... page R-36  
Disassembly / Inspection /  
Assembly .... page R-37
- 4. Toe-control link  
Removal / Inspection  
Installation ... page R-40

- 5. Rear stabilizer  
Removal / Inspection /  
Assembly .... page R-41
- 6. Rear strut bar  
Removal / Inspection /  
Assembly .... page R-42





## OUTLINE SPECIFICATIONS

Item	Transmission Suspension	MT		AT
		Standard suspension	Hard suspension	Standard suspension
<b>Front suspension</b>				
Suspension type		Double-wishbone		
Coil spring	Identification mark color	Red		Brown
	Wire diameter	mm {in}	12.3 {0.48}	12.5 {0.49}
	Coil center diameter	mm {in}	104.8 {4.126}	105.0 {4.134}
	Free length	mm {in}	270.0 {10.63}	276.3 {10.88}
	Active coil number		4.14	4.39
Shock absorber	Type	Cylindrical, double-acting, low-pressure gas-charged		
	Damping force characteristics	Standard	Hard	Standard
Stabilizer	Type	Torsion bar, hollow type		
	Diameter	mm {in}	28.6 {1.13}	
Front wheel alignment (unladen*1)	Inspection standard			
	Total toe-in	mm {in}	2 ± 3 {0.08 ± 0.11}	
	Toe-in (per side)	Degree	0.1° ± 0.75°	
	Maximum steering angle	in	36° ± 2°	
		out	32° ± 2°	
	Camber angle	Degree	0.1° ± 0.75°	
		Difference between left and right	Degree	1° max
	Caster angle	Degree	6.08° ± 0.75°	
		Difference between left and right	Degree	1° max
	King pin angle	Degree	13°55'	
	Adjustment standard			
	Total toe-in	mm {in}	2 ± 1 {0.08 ± 0.04}	
	Toe-in (per side)	Degree	0.1° ± 0.05°	
	Maximum steering angle	in	36° ± 2°	
		out	32° ± 2°	
	Camber angle	Degree	0.1° ± 0.5°	
		Difference between left and right	Degree	1° max
	Caster angle	Degree	6.08° ± 0.5°	
		Difference between left and right	Degree	1° max
	King pin angle	Degree	13°55'	
<b>Rear suspension</b>				
Suspension type		Double-wishbone		
Coil spring	Identification mark color	Purple		
	Wire diameter	mm {in}	12.2 {0.48}	
	Coil center diameter	mm {in}	114.7 {4.516}	
	Free length	mm {in}	303.0 {11.93}	
	Active coil number		4.21	
Shock absorber	Type	Cylindrical, double-acting, low-pressure gas-charged		
	Damping force characteristics	Standard	Hard	Standard
Stabilizer	Type	Torsion bar, hollow type		
	Diameter	mm {in}	13.8 {0.54}	
Rear wheel alignment (unladen*1)	Inspection standard			
	Total toe-in	mm {in}	2 ± 3 {0.08 ± 0.11}	
	Toe-in (per side)	Degree	0.1° ± 0.1°	
	Camber angle	Degree	-1.22° ± 0.75°	
		Difference between left and right	Degree	1° max
	Thrust angle	Degree	0° ± 0.1°	
	Adjustment standard			
	Total toe-in	mm {in}	2 ± 1 {0.08 ± 0.04}	
	Toe-in (per side)	Degree	0.1° ± 0.05°	
	Camber angle	Degree	-1.22° ± 0.5°	
		Difference between left and right	Degree	1° max
Thrust angle	Degree	0° ± 0.1°		

\*1 Fuel tank full; radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions.

## TROUBLESHOOTING GUIDE

Problem	Possible cause	Action	Page
<b>Body rolls</b>	Weak stabilizer or stabilizer link Damaged or worn stabilizer control link Worn or deteriorated upper arm or lower arm bushings Damaged shock absorber	Replace Replace Replace Replace	R-24, 41 R-24, 41 R-17, 21, 33, 37 R-12, 27
<b>Poor riding comfort</b>	Weak coil spring Damaged shock absorber	Replace Replace	R-13, 29 R-12, 27
<b>Body leans</b>	Weak coil spring Damaged or worn stabilizer control link Worn or deteriorated upper arm or lower arm bushings	Replace Replace Replace	R-13, 29 R-24, 41 R-17, 21, 33, 37
<b>Abnormal noise from suspension system</b>	Poor lubrication of or worn upper arm or lower arm ball joint Looseness of peripheral connections Damaged shock absorber Damaged or worn stabilizer control link Worn or deteriorated upper arm or lower arm bushings	Lubricate or replace Tighten Replace Replace Replace	R-17, 21 — R-12, 27 R-24, 41 R-17, 21, 33, 37
<b>General driving instability</b>	Weak coil spring Damaged shock absorber Worn or deteriorated upper arm or lower arm bushings Damaged or worn stabilizer control link Improperly adjusted wheel alignment Damaged or worn upper arm or lower arm ball joint Malfunction of steering system Damaged or unbalanced wheel	Replace Replace Replace Replace Adjust Replace — —	R-13, 29 R-12, 27 R-17, 21, 33, 37 R-24, 41 R-6 R-17, 21 Section N Section Q
<b>Heavy steering</b>	Poor lubrication of or worn upper arm or lower arm ball joint Improperly adjusted wheel alignment Malfunction of steering system Damaged or unbalanced wheel	Lubricate or replace Adjust — —	R-17, 21 R-6 Section N Section Q
<b>Steering wheel pulls to one side</b>	Weak coil spring Damaged or worn stabilizer control link Worn or deteriorated upper arm or lower arm bushings Damaged or worn upper arm or lower arm Improperly adjusted wheel alignment Malfunction of steering system Malfunction of braking system Damaged or unbalanced wheel	Replace Replace Replace Replace Adjust — — —	R-13, 29 R-24, 41 R-17, 21, 33, 37 R-17, 21, 33, 37 R-6 Section N Section P Section Q
<b>Shimmy occurs (steering wheel vibrates circumferential)</b>	Damaged or worn upper arm or lower arm ball joint Damaged shock absorber Loose shock absorber mounting Worn or deteriorated upper arm or lower arm bushings Damaged or worn stabilizer control link Improperly adjusted wheel alignment Damaged or worn wheel bearing Malfunction of steering system Damaged or unbalanced wheel	Replace Replace Tighten Replace Replace Adjust — — —	R-17, 21 R-12 R-12 R-17, 21 R-24 R-6 Section M Section N Section Q
<b>Steering wheel doesn't return properly</b>	Stuck or damaged upper arm or lower arm ball joint Improperly adjusted wheel alignment Malfunction of steering system Damaged or unbalanced wheel	Replace Adjust — —	R-17, 21 R-6 Section N Section Q



### WHEEL ALIGNMENT

#### PRE-INSPECTION

1. Check the tire inflations and set to the recommended pressure, if necessary.
2. Inspect the front wheel bearing play. Replace the bearing(s) as necessary.
3. Inspect the wheel and tire runout of all wheels.
4. Inspect the ball joints and steering linkage for excessive looseness.
5. Place the vehicle on level ground with no luggage or passenger load.
6. Rock the vehicle to settle the suspension.
7. Verify that the height difference between the left and right sides from the center of the wheel to the fender brim does not exceed specification.

**Specification: 10 mm {0.39 in}**


8. Verify that the height difference between the front and rear does not exceed specifications.

**Specification: 15 mm {0.59 in}**

### FRONT WHEEL ALIGNMENT Specifications (Unladen\*1)


Item		Specifications	Specifications
Total toe-in	mm (in)	$2 \pm 3$ { $0.08 \pm 0.11$ }	$2 \pm 1$ { $0.08 \pm 0.11$ }
Toe-in (per side)	Degree	$0.1^\circ \pm 0.75^\circ$	$0.1^\circ \pm 0.05^\circ$
Maximum steering angle	In	$36^\circ \pm 2^\circ$	
	Out	$32^\circ \pm 2^\circ$	
King pin angle		$13^\circ 55'$	
Camber angle	Degree	$0.1^\circ \pm 0.75^\circ$	$0.1^\circ \pm 0.5^\circ$
	Difference between left and right	Degree	$1^\circ$ max.
Caster angle	Degree	$6.08^\circ \pm 0.75^\circ$	$6.08^\circ \pm 0.5^\circ$
	Difference between left and right	Degree	$1^\circ$ max.

\*1 Fuel tank full; radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions.




#### Adjustment Toe-in

1. Remove the steering gear boot clamp.
2. Loosen the left and right tie rod locknuts and turn the tie rod equally. Both tie rods are right threaded, so turning the right tie rod toward the front of the vehicle and the left toward the rear increases toe-in.



**Note**

- Turning one tie rod one complete turn changes toe-in by about 0.42 in {10.6mm}.




3. Tighten the tie rod locknuts to the specified torque.

**Tightening torque:**

31-50 N·m {3.1-5.1 kgf·m, 23-36 ft·lbf}


4. Verify that the boot is not twisted. Install the boot clamp.



**Maximum steering angle**

1. Remove the steering gear boot clamp.
2. Loosen the tie rod locknut.
3. Turn the tie rod to provide the correct maximum steering angle.

**Maximum left / right difference: 3 mm {0.12 in}**




4. After adjustment, tighten the locknut to the specified torque.

**Tightening torque:**


31-50 N·m {3.1-5.1 kgf·m, 23-36 ft·lbf}

5. Adjust the toe-in. (Refer to page R-6.)
6. Verify that the boot is not twisted. Install the boot clamp.



**Caster**

1. Loosen the front or rear cam nut on the front lower arm.





### Note


- Turning the adjusting cam bolt one graduation changes the caster as shown in the illustration.

- Turn the adjusting cam bolt as indicated to provide the correct caster angle.

Caster	Left wheel		Right wheel	
	Front cam	Rear cam	Front cam	Rear cam
Increase	Counter-clockwise	Counter-clockwise	Clockwise	Clockwise
Decrease	Clockwise	Clockwise	Counter-clockwise	Counter-clockwise



- Adjust the camber and the toe-in.



### Camber


- Adjust the caster before adjusting the camber.
- Loosen the front or rear cam nut on the front lower arm.


### Note

- Turning the adjusting cam bolt one graduation changes the caster as shown in the illustration.


- Turn the adjusting cam bolt as indicated to provide the correct camber angle.

Camber	Left wheel		Right wheel	
	Front cam	Rear cam	Front cam	Rear cam
Positive	Counter-clockwise	Clockwise	Clockwise	Counter-clockwise
Negative	Clockwise	Counter-clockwise	Counter-clockwise	Clockwise





4. If the cam cannot be turned enough to make the adjustment, readjust the caster using the other cam.



5. Hand-tighten the cam nut and lower the vehicle.  
6. With the vehicle unloaded, tighten the cam nut to the specified torque.

**Tightening torque:**


**94–116 N·m {9.5–11.9 kgf·m, 69–86 ft·lbf}**

7. Adjust the toe-in.

**REAR WHEEL ALIGNMENT Specifications (Unladen\*1)**

Item		Inspection standard	Adjustment standard
Total toe-in	mm {in}	2 ± 3 {0.08 ± 0.11}	2 ± 1 {0.08 ± 0.04}
Toe-in (per side)	Degree	0.1° ± 0.1°	0.1° ± 0.05°
Camber angle	Degree	-1.22° ± 0.75°	-1.22° ± 0.5°
	Difference between left and right	Degree	1° max.
Thrust angle	Degree	0° ± 0.1°	0° ± 0.1°

\*1 Fuel tank full; radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions.




**Adjustment toe-in**

The specified thrust angle (0° ± 0.1°) must be maintained while adjusting the rear toe-in.

If the thrust angle cannot be maintained at that specification, check the body dimensions. Refer to the 1992 RX-7 Body Shop Manual (Form No. 3256-10-92A).


# R WHEEL ALIGNMENT, FRONT SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)



1. Loosen the left and right toe-control link locknuts and turn each link equally. Both are right threaded, so turning the right link toward the front of the vehicle and the left toward the rear increases toe-in.

**Note**


- Turning one link one complete turn changes toe-in by about 16.5 mm {0.65 in}.



2. Tighten the toe control link locknuts to the specified torque.

**Tightening torque:**

**35–50 N·m {3.5–5.1 kgf·m, 26–33 ft·lbf}**



**Camber**


1. Loosen the cam nut on the I-arm.

**Note**

- Turning the adjusting cam bolt one graduation changes the camber as shown in the illustration.

2. Turn the adjusting cam bolt as indicated to provide the correct camber angle.

Camber	Left wheel	Right wheel
Positive	Clockwise	Counterclockwise
Negative	Counterclockwise	Clockwise



3. Tighten the cam nut to the specified torque.

**Tightening torque:**



**94–116 N·m {9.5–11.9 kgf·m, 69–86 ft·lbf}**

4. Adjust the toe-in.

## FRONT SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)

















**PREPARATION**

**SST**

<p>49 0370 641</p>  <p>Screw, coil spring compressor</p>	<p>For removal / installation of coil spring</p>	<p>49 0223 640B</p>  <p>Arm, coil spring compressor</p>	<p>For removal / installation of coil spring</p>
---	--	---	--

# FRONT SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)

# R

<p>49 0118 850C Puller, ball joint</p> 	<p>For removal of ball joint</p>	<p>49 0180 510B Attachment, preload measuring</p> 	<p>For inspection of ball joint</p>
<p>49 F034 211 Guide, clip</p> 	<p>For installation of dust boot clip</p>	<p>49 F034 2A0 Replacer set, rubber bushing</p> 	<p>For removal / installation of bushing</p>
<p>49 G028 203 Support (Part of 49 F034 2A0)</p> 	<p>For removal of bushing</p>	<p>49 G028 206 Shaft (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>
<p>49 G028 207 Nut (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>	<p>49 G028 208 Installer (Part of 49 F034 2A0)</p> 	<p>For removal of bushing</p>
<p>49 G034 205 Bearing (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>	<p>49 F034 204 Support (Part of 49 F034 2A0)</p> 	<p>For removal of bushing</p>
<p>49 F034 203 Support (Part of 49 F034 2A0)</p> 	<p>For installation of bushing</p>	<p>49 F034 206 Shaft (Part of 49 F034 2A0)</p> 	<p>For installation of bushing</p>
<p>49 F034 209 Installer (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>	<p>49 F034 210 Guide, clip</p> 	<p>For installation of dust boot clip</p>
<p>49 F034 205 Support (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>	<p>49 F034 208 Installer (Part of 49 F034 2A0)</p> 	<p>For installation of bushing</p>



# R

## FRONT SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)


### FRONT SHOCK ABSORBER AND SPRING

#### Removal / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheel and tire.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Install the wheel and tire.

**Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–87 ft·lbf}**


6. Adjust the front wheel alignment. (Refer to page R-6.)



1. Clip (brake hose)
2. ABS wheel-speed sensor
3. Bolt, nut
4. Cap
5. Nut
6. Stopper rubber

7. Nut
8. Front strut bar  
Removal / Inspection /  
Installation  
..... page R-25
9. Insulator

10. Front shock absorber and  
spring  
Installation Note  
..... page R-13  
Disassembly / Inspection /  
Assembly .... page R-13




**Installation note**

**Front shock absorber and spring**

Install the shock absorber and spring so that the flexible hose bracket faces forward.

**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.




1. Nut  
Disassembly Note  
..... page R-14  
Assembly Note  
..... page R-15
2. Spacer
3. Mounting rubber  
Inspect for damage and  
deterioration  
Assembly Note  
..... page R-15

4. Bound stopper assembly  
Inspect for damage and  
cracks
5. Coil spring  
Inspect for damage and  
weakness  
Assembly Note  
..... page R-14

6. Lower spring seat  
Inspect for damage and  
cracks
7. Shock absorber  
Inspection .... page R-14

# R

## FRONT SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)





### Disassembly note Nut

#### Warning

- Removing the piston-rod nut is dangerous. The shock absorber and spring could fly off under tremendous pressure and cause serious injury or death. Secure the shock absorber in the SST before removing the piston-rod nut.


1. Secure the mounting rubber bracket in a vise.
2. Loosen the mounting rubber nut several turns, but do not remove it.
3. Assemble the SST.
4. Compress the coil spring by using the SST and remove the mounting nut.



### Inspection Shock absorber

Check the following and replace the shock absorber if necessary.

1. Inspect for damage and oil leakage.
2. (1) Compress the shock absorber rod and release it.  
(2) Verify that the rod extends fully at a normal speed.
3. Compress and extend the rod at least three times. Verify that the operational force does not change and that there is no unusual noise.



### Disposal of shock absorber


#### Warning

- The gas in the shock absorber is highly pressurized, and could spray metal chips into the eyes and face when drilling. Whenever drilling into a shock absorber, wear protective eye wear.

1. Lay the shock absorber flat.
2. Drill a hole in its body.


Drill size: 2-3 mm {0.08-0.12 in}

3. Allow the gas to escape from the shock absorber.
4. Discard the shock absorber.




### Assembly note Coil spring

1. Compress the coil spring by using the SST.
2. Install the spring so that the lower coil is seated on the step of the lower seat.




**Mounting rubber**

Install the mounting rubber as shown.



**Nut**

1. Tighten the mounting nut several turns.
2. Remove the SST.
3. Verify that the lower coil of the spring is seated on the step of the lower seat.



4. Secure the mounting rubber bracket in a vise.
5. Tighten the nut.

**Tightening torque:**

16-23 N·m {1.6-2.4 kgf·m, 12-17 ft·lbf}

# R

## FRONT SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)


### UPPER ARM

#### Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheel and tire.
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal.
6. Install the wheel and tire.

**Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–87 ft·lbf}**


7. Adjust the front wheel alignment. (Refer to page R-6.)



1. Clip (brake hose)
2. ABS wheel-speed sensor

3. Bolt, nut
4. Bolt
5. Bolt, nut

6. Upper arm  
Inspect for damage and cracks  
Inspect bushing for damage and wear  
Inspect boot for tearing and cracks  
Inspection . . . . page R-17  
Disassembly / Inspection /  
Assembly . . . . page R-17



**Inspection**

**Upper arm ball joint**

**Ball joint rotation torque**

1. Shake and rotate the ball joint stud several times.
2. Connect the SST to the stud and measure the starting torque and the rotation torque by using a pull scale.

**Starting torque:**

2.0–5.8 N·m {20–60 kgf·cm, 18–52 in·lbf}

**Pull scale reading:**

20–58 N {2.0–6.0 kgf, 4.4–13.2 lbf}

**Rotation torque:**

0.4–1.1 N·m {4–12 kgf·cm, 3.5–10.4 in·lbf}


**Pull scale reading:**

4–11N {0.4–1.2 kgf, 0.9–2.6 lbf}

3. If not within specification, replace the upper arm.

**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



1. Clip

2. Dust boot

Assembly Note ..... page R-18

3. Bushing

Disassembly Note ..... page R-18


Assembly Note ..... page R-18

4. Upper arm

Inspect for damage and cracks

# R


## FRONT SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)




### Disassembly note

#### Bushing

1. Cut away the projecting rubber of the bushing.



2. Remove the bushing by using the SST.




### Assembly note

#### Bushing

1. Apply soapy water to the new bushing.

2. Install the bushing by using the SST.



### Dust boot

1. Wipe the grease off the ball stud.

2. Fill the inside of the new dust boot with grease.

3. Install the dust boot onto the ball joint.

4. Set the SST over the boot and install a new clip.

5. Wipe off the excess grease.

**FRONT LOWER ARM**

**Removal / Inspection / Installation**

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheel and tire.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Loosely tighten the lower arm rear cam nut.
7. Install the wheel and tire.


**Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–87 ft·lbf}**

8. Lower the vehicle.

9. With the vehicle unloaded, tighten the lower arm rear cam nut to the specified torque.

**Tightening torque: 94–116 N·m {9.5–11.9 kgf·m, 69–86 ft·lbf}**

10. Adjust the front wheel alignment. (Refer to page R-6.)



1. Front stabilizer control link
2. Shock absorber and spring
3. Cotter pin
4. Nut
5. Nuts

Removal Note  
 ..... page R-20  
 Installation Note  
 ..... page R-20

6. Cam plates

Removal Note  
 ..... page R-20  
 Installation Note  
 ..... page R-20


7. Adjusting Cam bolt

Installation Note  
 ..... page R-20

8. Front lower arm


Removal Note  
 ..... page R-20  
 Inspect for damage and cracks  
 Inspect bushing for damage and wear  
 Inspect boot for tearing and cracks  
 Inspection .... page R-20  
 Disassembly / Inspection / Assembly .... page R-21





#### Removal note Nut and cam plate

Before loosening the nut, make a mark on the cam plate and the crossmember for reference during installation.




#### Front lower arm

1. Loosen the nut until it is flush with the end of the stud.
2. With the nut protecting the ball joint stud, separate the ball joint from the knuckle by using the SST.

#### Caution


- The sharp edges of the SST can slice the dust boot. Install the SST so that the sharp edges are between the dust boot and the knuckle.



#### Installation note

##### Nut, cam plate, and adjusting cam bolt

1. Install the cam plate so that the notch faces the same direction as the adjusting cam bolt.
2. Align the mark made before removing the adjusting cam bolt. Temporarily tighten the nut.



#### Inspection

##### Front lower arm ball joint

##### Ball joint rotation torque

1. Shake and rotate the ball joint stud at least five times.
2. Connect the SST to the stud and measure the starting torque and the rotation torque by using a pull scale.

##### Starting torque:

2.5–7.3 N·m {25–75 kgf-cm, 22–65 in·lbf}

Pull scale reading:

25–73 N {2.5–7.5 kgf, 5.5–16.5 lbf}

##### Rotation torque:

0.5–1.4 N·m {5–15 kgf-cm, 4.4–13.0 in·lbf}


Pull scale reading:

5–14 N {0.5–1.5 kgf, 1.1–3.3 lbf}


3. If not within specification, replace the front lower arm.

**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- |   |   |   |
|---|---|---|
| <p>1. Clip</p> <p>2. Dust boot<br/>Assembly Note<br/>..... page R-23</p> <p>3. Bushing (front)<br/>Disassembly Note<br/>..... below<br/>Assembly Note<br/>..... page R-22</p> | <p>4. Bushing (rear)<br/>Disassembly Note<br/>..... page R-22<br/>Assembly Note<br/>..... page R-22</p> | <p>5. Front lower arm<br/>Inspect for damage and<br/>cracks</p> |
|---|---|---|




**Disassembly note**  
**Bushing (front)**


1. Cut away the projecting rubber of the bushing.

# R

## FRONT SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)




2. Remove the bushing by using the SST.



### Bushing (rear)


Remove the bushing by using the SST.



### Assembly note


#### Bushing (rear)

1. Align the matching marks.



2. Apply soapy water to the new bushing.


3. Install the bushing by using the SST.



### Bushing (front)

1. Apply soapy water to the new bushing.

2. Install the bushing by using the SST.



**Dust boot**


1. Wipe the grease off the ball stud.
2. Fill the inside of the new dust boot with grease.
3. Install the dust boot onto the ball joint.
4. Set the SST over the boot and install a new clip.
5. Wipe off the excess grease.

### FRONT STABILIZER

#### Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it on safety stands.
2. Remove the wheels and tires and the undercover.
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Install the wheels and tires.


**Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–87 ft·lbf}**



1. Nut
2. Bolt
3. Stabilizer plate  
Inspect for damage and cracks
4. Stabilizer bushing  
Inspect for wear and deterioration

5. Stabilizer bar  
Inspect for damage and bending  
Installation Note  
..... page R-25


6. Bolt, nut
7. Stabilizer control link  
Inspect for damage and cracks  
Installation Note .... below



#### Installation note

##### Stabilizer control link

Install the stabilizer control links with the R (right) and L (left) marks as shown.




**Stabilizer bar**

Install the stabilizer bar with the white paint mark at the right side.

**FRONT STRUT BAR**

**Removal / Inspection / Installation**

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



N·m {kgf·m, ft·lbf}

1. Nut, washer  
2. Bolt

3. Front strut bar  
Inspect for damage and  
bending
















4. Nut  
5. Strut plate

# R

## REAR SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)

### REAR SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)

#### PREPARATION SST

<p>49 0370 641</p> <p>Screw, coil spring compressor</p> 	<p>For removal / installation of coil spring</p>	<p>490223 640B</p> <p>Arm, coil spring compressor</p> 	<p>For removal / installation of coil spring</p>
<p>49 F034 2A0</p> <p>Replacer set, rubber bushing</p> 	<p>For removal / installation of bushing</p>	<p>49 G028 203</p> <p>Support (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>
<p>49 G028 205</p> <p>Support (Part of 49 F034 2A0)</p> 	<p>For removal / installation of pillow ball</p>	<p>49 G028 206</p> <p>Shaft (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>
<p>49 G028 207</p> <p>Nut (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>	<p>49 G028 208</p> <p>Installer (Part of 49 F034 2A0)</p> 	<p>For removal / installation of pillow ball</p>
<p>49 G034 205</p> <p>Bearing (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>	<p>49 F034 207</p> <p>Installer (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>
<p>49 F034 203</p> <p>Support (Part of 49 F034 2A0)</p> 	<p>For installation of bushing</p>	<p>49 F034 206</p> <p>Shaft (Part of 49 F034 2A0)</p> 	<p>For installation of bushing</p>
<p>49 F034 209</p> <p>Installer (Part of 49 F034 2A0)</p> 	<p>For installation of pillow ball</p>	<p>49 F034 204</p> <p>Support (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>
<p>49 F034 208</p> <p>Installer (Part of 49 F034 2A0)</p> 	<p>For removal / installation of bushing</p>		


**REAR SHOCK ABSORBER AND SPRING**

**Removal / Installation**

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove the wheel and tire.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Install the wheel and tire.

**Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–87 ft·lbf}**

6. Check the rear wheel alignment. (Refer to page R-9.)



- 1. Nut
  - 2. Rear stabilizer control link
  - 3. Nut
  - 4. Rear strut bar
- Removal / Inspection /  
Installation ... page R-43


- 5. Nut
- 6. Stopper rubber
- 7. Insulator

- 8. Shock absorber and  
spring
- Installation Note  
..... page R-28  
Disassembly / Inspection /  
Assembly .... page R-29



# R


## REAR SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)



### Installation note

#### Shock absorber and spring


1. Install the insulator so that the notches in it face the studs as shown.



2. Install the shock absorber and spring so that the identification paint mark faces rearward.

**Disassembly / Inspection / Assembly**


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.



- 1. Nut  
Disassembly Note ..... page R-30  
Assembly Note ..... page R-31
- 2. Spacer  
..... page R-31
- 3. Mounting rubber  
Inspect for damage and deterioration  
Assembly Note ..... page R-31

- 4. Bound stopper assembly  
Inspect for damage and cracks
- 5. Coil spring  
Inspect for damage and weakness  
Assembly Note ..... page R-30

- 6. Lower spring seat  
Inspect for damage and cracks
- 7. Shock absorber  
Inspection ..... page R-30





### Disassembly note

#### Nut

#### Warning

- Removing the piston-rod nut is dangerous. The shock absorber and spring could fly off under tremendous pressure and cause serious injury or death. Secure the shock absorber in the SST before removing the piston-rod nut.

1. Secure the mounting rubber bracket in a vise.
2. Loosen the mounting rubber nut several turns, but do not remove it.
3. Assemble the SST.
4. Compress the coil spring by using the SST and remove the mounting nut.




### Inspection

#### Shock absorber

Check the following and replace the shock absorber if necessary.

1. Inspect for damage and oil leakage.
2. (1) Compress the shock absorber rod and release it.  
(2) Verify that the rod extends fully at a normal speed.
3. Compress and extend the rod at least three times. Verify that the operational force does not change and that there is no unusual noise.



### Disposal of shock absorber


#### Warning

- The gas in the shock absorber is highly pressurized, and could spray metal chips into the eyes and face when drilling. Whenever drilling into a shock absorber, wear protective eye wear.

1. Lay the shock absorber flat.
2. Drill a hole in its body.

Drill size: 2-3 mm {0.08-0.12 in}


3. Allow the gas to escape.
4. Discard the shock absorber.



### Assembly note


#### Coil spring

1. Compress the coil spring by using the SST.
2. Install the spring so that the lower coil is seated on the step of the lower seat.




**Mounting rubber**

Install the mounting rubber as shown.



**Nut**

1. Tighten the mounting nut several turns.
2. Remove the SST.
3. Verify that the lower coil of the spring is seated on the step of the lower seat.



3. Secure the mounting rubber bracket in a vise.
4. Tighten the nut.

**Tightening torque:**

16-23 N·m {1.6-2.4 kgf·m, 12-17 ft·lbf}

# R REAR SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)


## UPPER ARM

### Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove the wheel and tire.
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal.
6. Install the wheel and tire.

**Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–87 ft·lbf}**

7. Check the rear wheel alignment. (Refer to page R-9.)




1. Nut
2. Stabilizer control link

3. Nut, bolt
4. Nut, bolt

5. Upper arm  
Inspect for damage and cracks  
Inspect bushing for wear and deterioration  
Disassembly / Inspection / Assembly . . . . page R-33

**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




1. Rubber seal  
Disassembly Note ... below  
Assembly Note  
..... page R-35

4. Upper arm bushing  
Disassembly Note  
..... page R-34  
Assembly Note  
..... page R-34

5. Damper bushing  
Disassembly Note  
..... page R-34  
Assembly Note  
..... page R-34

6. Upper arm  
Inspect for damage and  
cracks




**Disassembly note  
Pillow ball**


1. Remove the rubber seal by using a screw driver as shown.
2. Remove the retaining ring.

# R

## REAR SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)




3. Remove the pillow ball by using the SST.




### Upper arm bushing

Remove the upper arm bushing by using the SST.



### Damper bushing


Remove the damper bushing by using the SST.



### Assembly note


#### Damper bushing

1. Apply soapy water to the new damper bushing.
2. Install the damper bushing by using the SST.




### Upper arm bushing

1. Apply soapy water to the new bushing.
2. Install the upper arm bushing by using the SST.



**Pillow ball**

1. With the SST, install the pillow ball so that the step faces into the upper arm.



2. Install the retaining ring.

3. Fill the space between the pillow ball and rubber seal with grease.


4. Install the rubber seal.



### REAR LOWER ARM

#### Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
  2. Remove the wheel and tire.
  3. Remove in the order shown in the figure, referring to **Removal Note**.
  4. Inspect all parts and repair or replace as necessary.
  5. Install in the reverse order of removal, referring to **Installation Note**.
  6. Loosely tighten the trailing link front nut.
  7. Install the wheel and tire.
- Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–87 ft·lbf}**
8. Lower the vehicle.
  9. With the vehicle unloaded, tighten the trailing link front nut to the specified torque.
- Tightening torque: 94–116 N·m {9.5–11.9 kgf·m, 69–86 ft·lbf}**
10. Check the rear wheel alignment. (Refer to page R-9.)




N·m {kgf·m, ft·lbf}


- |  |   |   |
|--|---|---|
| <p>1. Bolt</p> <p>2. Bolt, nut</p> <p>3. Trailing link<br/>Inspect for damage and cracks<br/>Inspect bushing for wear and deterioration<br/>Disassembly / Inspection / Assembly .... page R-37</p> | <p>4. Nut<br/>Removal Note ..... page R-20<br/>Installation Note ..... page R-20</p> <p>5. Cam plate<br/>Removal Note ..... page R-20<br/>Installation Note ..... page R-20</p> | <p>6. Adjusting cam bolt<br/>Installation Note ..... page R-20</p> <p>7. Nut</p> <p>8. Bolt</p> <p>9. I-arm<br/>Inspect for damage and cracks<br/>Inspect bushing for wear and deterioration<br/>Disassembly / Inspection / Assembly .... page R-37</p> |
|--|---|---|

**Disassembly / Inspection / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- |                            |                        |                        |
|----------------------------|------------------------|------------------------|
| 1. Stopper                 | 5. Pillow ball         | 7. Bushing             |
| 2. Pillow ball bushing     | Disassembly Note       | Disassembly Note       |
| Disassembly Note ... below | ..... page R-38        | ..... page R-38        |
| Assembly Note              | Assembly Note          | Assembly Note          |
| ..... page R-39            | ..... page R-39        | ..... page R-38        |
| 3. Rubber seal             | 6. I-arm               | 8. Trailing link       |
| 4. Retaining ring          | Inspect for damage and | Inspect for damage and |
|                            | cracks                 | cracks                 |




**Disassembly note**  
**Pillow ball bushing**


1. Cut away the flange of the bushing.

# R

## REAR SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)




2. Remove the pillow ball bushing by using the SST.




### Pillow ball

1. Remove the rubber seal by using a screwdriver as shown.
2. Remove the retaining ring.




3. Remove the pillow ball by using the SST.



### Bushing


Remove the bushing by using the SST.



### Assembly note


#### Bushing

1. Apply soapy water to the new bushing.
2. Install the bushing by using the SST.



**Pillow ball**


1. With the SST, install the pillow ball so that the step faces into the I-arm.



2. Install the retaining ring.

3. Fill the space between the pillow ball and rubber seal with grease.

4. Install the rubber seal.



**Pillow ball bushing**

1. Apply soapy water to the new pillow ball bushing.

2. Install the pillow ball bushing by using the SST.

# R

## REAR SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)


### TOE-CONTROL LINK

#### Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove the wheel and tire.
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Install the wheel and tire.

**Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–87 ft·lbf}**

7. Check the rear wheel alignment. (Refer to page R-9.)



1. Nut  
2. Bolt

3. Nut  
4. Bolt


5. Toe-control link  
Inspect bushing for wear  
and deterioration

**REAR STABILIZER**

**Removal / Inspection / Installation**

1. Jack up the rear of the vehicle and support it on safety stands.
2. Remove the wheels and tires and the undercover.
3. Remove in the order shown in the figure.
4. Inspect all parts and repair or replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Install the wheels and tires.


**Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 65–87 ft·lbf}**



1. Nut
2. Nut
3. Stabilizer control link  
Inspect for damage and cracks  
Installation Note  
..... page R-43

4. Bolt
5. Stabilizer plate  
Inspect for damage and cracks
6. Stabilizer bushing  
Inspect for wear and deterioration

7. Stabilizer bar  
Inspect for damage and bending  
Installation Note  
..... below




**Installation note**  
**Stabilizer bar**

Install the stabilizer bar with the white paint mark at the right side.

# R

## REAR SUSPENSION (DOUBLE WISHBONE, COIL SPRING TYPE)




### Stabilizer control link

Install the stabilizer control links with the R (right) and L (left) marks as shown.

### REAR STRUT BAR

#### Removal / Inspection / Installation

1. Remove the suspension tower cover. (Refer to section S.)
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal.



1. Nut
2. Nut, washer

3. Bolt
4. Strut plate

5. Rear strut bar  
Inspect for damage and bending

Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.


## BODY

<b>INDEX</b> .....	<b>S - 2</b>	<b>HEADLIGHT CLEANER</b> .....	<b>S -38</b>
<b>HOOD</b> .....	<b>S - 5</b>	COMPONENTS .....	<b>S -38</b>
COMPONENTS .....	<b>S - 5</b>	<b>WINDSHIELD</b> .....	<b>S -39</b>
<b>DOOR</b> .....	<b>S - 7</b>	PREPARATION .....	<b>S -39</b>
PREPARATION .....	<b>S - 7</b>	COMPONENTS .....	<b>S -39</b>
COMPONENTS .....	<b>S - 8</b>	<b>REAR HATCH GLASS</b> .....	<b>S -43</b>
<b>WINDOW REGULATOR, GLASS</b>		PREPARATION .....	<b>S -43</b>
<b>AND GUIDE</b> .....	<b>S -10</b>	COMPONENTS .....	<b>S -43</b>
COMPONENTS .....	<b>S -10</b>	<b>SLIDING SUNROOF</b> .....	<b>S -46</b>
<b>DOOR LOCK AND OPENER</b> .....	<b>S -11</b>	COMPONENTS .....	<b>S -46</b>
COMPONENTS .....	<b>S -11</b>	SLIDING SUNROOF DRIVE UNIT	
<b>REAR HATCH</b> .....	<b>S -12</b>	<b>ASSEMBLY</b> .....	<b>S -49</b>
COMPONENTS .....	<b>S -12</b>	<b>DASHBOARD AND CONSOLE</b> .....	<b>S -53</b>
<b>REAR HATCH LOCK AND</b>		COMPONENTS .....	<b>S -53</b>
<b>OPENER</b> .....	<b>S -14</b>	<b>TRIM</b> .....	<b>S -55</b>
PREPARATION .....	<b>S -14</b>	COMPONENTS .....	<b>S -55</b>
COMPONENTS .....	<b>S -14</b>	<b>FLOOR COVERING</b> .....	<b>S -59</b>
<b>FUEL-FILLER LID AND OPENER</b> .....	<b>S -15</b>	COMPONENTS .....	<b>S -59</b>
COMPONENTS .....	<b>S -15</b>	<b>HEADLINER</b> .....	<b>S -60</b>
<b>FRONT BUMPER</b> .....	<b>S -16</b>	COMPONENTS .....	<b>S -60</b>
COMPONENTS .....	<b>S -16</b>	<b>SEAT BELT</b> .....	<b>S -62</b>
<b>REAR BUMPER</b> .....	<b>S -18</b>	COMPONENTS .....	<b>S -62</b>
PREPARATION .....	<b>S -18</b>	SEAT BELT .....	<b>S -63</b>
COMPONENTS .....	<b>S -18</b>	<b>SEAT</b> .....	<b>S -64</b>
<b>EXTRACTOR CHAMBER</b> .....	<b>S -20</b>	COMPONENTS .....	<b>S -64</b>
COMPONENTS .....	<b>S -20</b>	<b>STORAGE COMPARTMENT</b> .....	<b>S -67</b>
<b>MOLDING</b> .....	<b>S -21</b>	COMPONENTS .....	<b>S -67</b>
PREPARATION .....	<b>S -21</b>		
COMPONENTS .....	<b>S -21</b>		
<b>SPOILER</b> .....	<b>S -27</b>		
COMPONENTS .....	<b>S -27</b>		
<b>COWL GRILLE</b> .....	<b>S -28</b>		
COMPONENTS .....	<b>S -28</b>		
<b>POWER OUTSIDE MIRROR</b> .....	<b>S -29</b>		
COMPONENTS .....	<b>S -29</b>		
<b>REARVIEW MIRROR</b> .....	<b>S -31</b>		
PREPARATION .....	<b>S -31</b>		
COMPONENTS .....	<b>S -31</b>		
<b>WINDSHIELD WIPER AND</b>			
<b>WASHER</b> .....	<b>S -33</b>		
COMPONENTS .....	<b>S -33</b>		
WINDSHIELD WIPER MOTOR .....	<b>S -35</b>		
<b>REAR WIPER AND WASHER</b> .....	<b>S -36</b>		
COMPONENTS .....	<b>S -36</b>		


**NOTE:** Refer to the 1994 RX-7 Body Electrical Troubleshooting Manual (No. 1380-10-93H) for servicing of the body electrical components.



## INDEX




- |                                     |       |           |
|-------------------------------------|-------|-----------|
| 1. Hood                             |       |           |
| Removal / Installation              | ..... | page S- 5 |
| Adjustment                          | ..... | page S- 6 |
| 2. Door                             |       |           |
| Removal / Installation              | ..... | page S- 8 |
| Adjustment                          | ..... | page S- 9 |
| 3. Window regulator glass and guide |       |           |
| Removal / Installation              | ..... | page S-10 |
| 4. Fuel-filler lid and opener       |       |           |
| Removal / Installation              | ..... | page S-15 |
| 5. Front bumper                     |       |           |
| Removal / Installation              | ..... | page S-16 |
| Disassembly / Assembly              | ..... | page S-17 |
| 6. Molding                          |       |           |
| Removal / Installation              | ..... | page S-21 |
| 7. Spoiler                          |       |           |
| Removal / Installation              | ..... | page S-27 |
| 8. Cowl grille                      |       |           |
| Removal / Installation              | ..... | page S-28 |
| 9. Power outside mirror             |       |           |
| Removal / Installation              | ..... | page S-29 |
| 10. Windshield wiper and washer     |       |           |
| Removal / Installation              | ..... | page S-33 |
| Adjustment                          | ..... | page S-34 |
| 11. Headlight cleaner               |       |           |
| Removal / Installation              | ..... | page S-38 |
| 12. Windshield                      |       |           |
| Removal / Installation              | ..... | page S-39 |



- 1. Door lock and opener  
Removal / Installation ..... page S-11
- 2. Rear hatch  
Removal / Installation ..... page S-12  
Adjustment ..... page S-13
- 3. Rear hatch lock and opener  
Removal / Installation ..... page S-14
- 4. Rear bumper  
Removal / Installation ..... page S-18  
Disassembly / Assembly ..... page S-19
- 5. Extractor chamber  
Removal / Installation ..... page S-20

- 6. Molding  
Removal / Installation ..... page S-21
- 7. Spoiler  
Removal / Installation ..... page S-27
- 8. Rear wiper and washer  
Removal/Installation ..... page S-36  
Adjustment ..... page S-37
- 9. Rear hatch glass  
Removal / Installation ..... page S-43
- 10. Sliding sunroof  
Removal / Installation ..... page S-46  
Disassembly / Assembly ..... page S-49

S




- 1. Rear hatch lock and opener  
Removal / Installation ..... page S-14
- 2. Fuel-filler lid and opener  
Removal / Installation ..... page S-15
- 3. Rearview mirror  
Removal / Installation ..... page S-31
- 4. Dashboard and console  
Removal / Installation ..... page S-53
- 5. Trim  
Removal / Installation ..... page S-55

- 6. Floor covering  
Removal / Installation ..... page S-59
- 7. Headliner  
Removal / Installation ..... page S-60
- 8. Seat belt  
Removal / Installation ..... page S-62  
Inspection ..... page S-63
- 9. Seat  
Removal / Installation ..... page S-64  
Disassembly / Assembly ..... page S-65

HOOD

COMPONENTS  
Removal/Installation

- 1. Remove in the order shown in the figure.
- 2. Install in the reverse order of removal.




- 1. Washer pipe
- 2. Protector
- 3. Hood insulator
- 4. Hood

Adjustment ..... page S-6

- 5. Hinge
- 6. Stay
- 7. Lock assembly
- 8. Release cable
- 9. Hood release Knob

Adjustment ..... page S-6




### Adjustment Hood

Adjust the hood laterally or vertically by loosening the hood-to-hinge mounting nuts and repositioning the hood.

Clearance: ①  $4.0 \pm 1.0$  mm { $0.16 \pm 0.04$  in}  
 ②  $4.5 \pm 1.0$  mm { $0.18 \pm 0.04$  in}

Tightening torque:  
 $19-25$  N·m { $1.9-2.6$  kgf·m,  $14-18$  ft·lbf}



### Lock assembly

1. Adjust the lock assembly after the hood has been aligned.
2. Loosen the lock mounting bolts and nut, and align the lock with the striker on the hood.

### Tightening torque

Bolts:  $7.9-10.7$  N·m { $80-110$  kgf·cm,  $70-95$  in·lbf}  
 Nut :  $7.9-10.7$  N·m { $80-110$  kgf·cm,  $70-95$  in·lbf}


**DOOR**

**PREPARATION**


TORX tool (T40)	For installation / removal of door lock striker
-----------------	---

**TORX TOOL (T40)**

**1. ILLUSTRATION**



**2. USAGE**




S

## COMPONENTS

### Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the checker, remove the front door trim and door screen. (Refer to page S-10.)
3. Install in the reverse order of removal. Adjust the door lock striker after adjusting the front door.



1. Harness connector

2. Checker pin

3. Door hinge


4. Door

Adjustment ..... page S-9

5. Door lock striker

Adjustment ..... page S-9

6. Checker




### Adjustment Door

Adjust the door laterally or vertically by loosening the door-hinge-to-body mounting bolts and repositioning the door.

**Clearance:** ①  $4 \pm 1 \text{ mm}$  { $0.2 \pm 0.04 \text{ in}$ }  
 ②  $6 \pm 2 \text{ mm}$  { $0.3 \pm 0.07 \text{ in}$ }  
 ③  $4 \pm 1 \text{ mm}$  { $0.2 \pm 0.04 \text{ in}$ }

### Tightening torque:

$18\text{--}29 \text{ N}\cdot\text{m}$  { $1.8\text{--}3.0 \text{ kgf}\cdot\text{m}$ ,  $14\text{--}21 \text{ ft}\cdot\text{lbf}$ }



### Door lock striker

1. Verify that the door can be closed easily and that there is no looseness. If there is a problem, loosen the striker mounting screws and move the striker horizontally or vertically.
2. Verify the rear offset of the door to the body. If there is a problem, move the door lock striker vertically.

### Tightening torque:

$18\text{--}26 \text{ N}\cdot\text{m}$  { $1.8\text{--}2.7 \text{ kgf}\cdot\text{m}$ ,  $14\text{--}19 \text{ ft}\cdot\text{lbf}$ }



### WINDOW REGULATOR, GLASS AND GUIDE

#### COMPONENTS


#### Removal / Installation

1. Lower the door glass 200 mm {0.79 in} from the fully raised position.
2. Disconnect the negative battery cable.

#### Note

- Remove the door screen carefully so that it may be reused.

3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Inner handle cover
2. Door trim  
Removal / Installation ..... page S-55
3. Door screen
4. Glass run channel

5. Glass guide A
6. Glass guide B
7. Door glass
8. Power window regulator

**DOOR LOCK AND OPENER**

**COMPONENTS**


**Removal / Installation**

1. Raise the front door glass fully.
2. Disconnect the negative battery cable.

**Note**

- Remove the door screen carefully so that it may be reused.

3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.




- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Inner handle cover</li> <li>2. Door trim</li> <li>Removal / Installation ..... page S-55</li> <li>3. Inner handle</li> <li>4. Door screen</li> <li>5. Glass guide B</li> </ol> | <ol style="list-style-type: none"> <li>6. Door lock</li> <li>7. Inner garnish</li> <li>8. Outer handle</li> <li>9. Lock cylinder retainer</li> <li>10. Lock cylinder</li> </ol> |
|--|---|

### REAR HATCH

#### COMPONENTS


##### Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the rear hatch hinges, remove the headliner. (Refer to page S-60.)
3. Install in the reverse order of removal.



- |  |           |
|--|-----------|
| 1. Rear hatch upper trim<br>Removal / Installation ..... | page S-55 |
| 2. Rear hatch side trim<br>Removal / Installation .....  | page S-55 |
| 3. Washer pipe   |           |

- |   |           |
|---|-----------|
| 4. Quarter trim<br>Removal / Installation ..... | page S-55 |
| 5. Stay damper                                  |           |
| 6. Rear hatch<br>Adjustment .....               | page S-13 |
| 7. Rear hatch hinge                             |           |



**Adjustment**


**Rear hatch**

Adjust the rear hatch laterally and vertically by loosening the rear-hatch-to-hinge mounting bolts and repositioning the rear hatch.

- Clearance:**
- ①  $7 \pm 1.5 \text{ mm} \{0.3 \pm 0.06 \text{ in}\}$
  - ②  $1^{+1.0}_{-1.5} \text{ mm} \{0.04^{+0.04}_{-0.06} \text{ in}\}$
  - ③  $4 \pm 2 \text{ mm} \{0.16 \pm 0.08 \text{ in}\}$
  - ④  $1 \pm 2 \text{ mm} \{0.04 \pm 0.08 \text{ in}\}$

**Tightening torque:**

$17\text{--}29 \text{ N}\cdot\text{m} \{1.7\text{--}3.0 \text{ kgf}\cdot\text{m}, 13\text{--}21 \text{ ft}\cdot\text{lbf}\}$



**Rear hatch lock**

1. Adjust the rear hatch lock after the rear hatch has been aligned.
2. Remove the trunk end trim. (Refer to page S-55.)
3. Loosen the rear hatch lock mounting bolts, and align the lock with the striker on the rear hatch.

**Tightening torque:**

$16\text{--}22 \text{ N}\cdot\text{m} \{1.6\text{--}2.3 \text{ kgf}\cdot\text{m}, 12\text{--}16 \text{ ft}\cdot\text{lbf}\}$

REAR HATCH LOCK AND OPENER


PREPARATION

TORX tool (T40)	For installation / removal of rear hatch striker
-----------------	--

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



Rear hatch lock

1. Rear hatch striker
2. Trunk end trim  
Removal / Installation ..... page S-55
3. Rear hatch lock  
Adjustment ..... page S-13

Rear hatch opener, rear hatch opener cable

4. Suspension tower cover
5. Suspension rear strut bar


6. Trunk side trim  
Removal / Installation ..... page S-55
7. Scuff plate  
Removal / Installation ..... page S-55
8. Quarter trim  
Removal / Installation ..... page S-55
9. Opener bezel
10. Opener lever
11. Stopper bracket
12. Opener cable

FUEL-FILLER LID AND OPENER

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



**Filler lid**

1. Filler lid
2. Stopper bracket
3. Filler lid opener

**Filler lid opener, opener lever, opener cable**

4. Trunk end trim  
Removal / Installation ..... page S-55
5. Suspension tower cover
6. Suspension rear strut bar


7. Trunk side trim  
Removal / Installation ..... page S-55
8. Scuff plate  
Removal / Installation ..... page S-55
9. Quarter trim  
Removal / Installation ..... page S-55
10. Opener bezel
11. Opener lever
12. Opener cable

### FRONT BUMPER

#### COMPONENTS

#### Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the front bumper, remove the left air duct bolt and receiver / drier bracket bolts. (Refer to the 1994 RX-7 Body Electrical Troubleshooting Manual, section E, when removing the front combination light.)
3. Install in the reverse order of removal.




1. Mud guard
2. Front combination light

3. Front bumper  
Disassembly / Assembly ..... page S-17

**Disassembly / Assembly**

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



N·m (kgf·m, ft·lbf)

1. Front bumper reinforcement
2. Support foam
3. Air guide

4. Front bumper fascia
5. Front air dam



### REAR BUMPER


#### PREPARATION

TORX tool (T30)	For installation / removal of rear bumper
-----------------	---

#### COMPONENTS

##### Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. (Refer to the 1994 RX-7 Body Electrical Troubleshooting Manual, section E, when removing the rear combination light, high-mount stoplight, and back-up light.)
3. Install in the reverse order of removal.




- 1. Rear combination light
- 2. Trunk end trim  
Removal / Installation ..... page S-55
- 3. Suspension tower cover
- 4. Suspension rear strut bar

- 5. Trunk side trim  
Removal / Installation ..... page S-55
- 6. High-mount stoplight
- 7. Back-up light
- 8. Rear bumper  
Disassembly / Assembly ..... page S-19

## Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.




1. Rear bumper reinforcement
2. Rear bumper bracket

3. Energy-absorbing foam
4. Rear bumper fascia

N·m (kgf·m, ft·lb)

**EXTRACTOR CHAMBER****COMPONENTS****Removal / Installation**



1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Extractor chamber

**MOLDING**


**PREPARATION  
SST**

<p>49 0305 870A Tool set, window</p> 	<p>For removal / installation of molding</p>	<p>49 G0501A0 Remover, sealant</p> 	<p>For removal of sealant</p>
--	--	--	-------------------------------

**COMPONENTS**

**Removal / Installation**

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.




1. Windshield molding  
Removal Note ..... page S-23  
Installation Note ..... page S-23
2. Rear hatch molding  
Removal Note ..... page S-23  
Installation Note ..... page S-25


3. Beltline molding  
Removal Note ..... page S-22
4. Drip molding  
Removal Note ..... page S-22


**Removal Note****Beltline molding**

1. Lower the door glass fully.
2. Remove the power outside mirror. (Refer to page S-29.)
3. Pull the beltline molding up to disengage the clips from the body.

**Drip molding**


1. Remove the drip molding mounting screws and grommet.
2. Pull the rear of the molding forward and remove the drip molding from the body.






**Windshield molding**

Lift the edge of the molding and cut the sealant to remove the molding.




**Rear hatch molding**

Lift the edge of the molding and cut the sealant to remove the molding.




**Installation Note  
Windshield molding**


1. Apply protective tape along the edge of the body to protect it from damage.
2. Cut the sealant by using a razor knife as shown.




3. Insert the blade of the SST into the sealant, and pull on the bar to cut the sealant near the body as shown.




4. Insert the blade of the SST into the sealant, and pull on the bar to cut the sealant under the glass as shown.




5. Cut the sealant at an angle shown.
6. Remove as much sealant as possible from between the body and the glass.
7. Carefully clean around the edge of the glass and the adhesion surface at the body.




8. If the protector is damaged, bond a new protector onto the body as shown,




9. Apply primer onto the bonding area of the glass, body, and new windshield molding by using a brush. Use only glass primer on the glass and body primer on the body and molding. Keep the bonding area free of dirt and grease, and do not touch the surface. Allow the primer to dry for approximately 30 minutes.



10. Apply a 3mm {0.12in} bead of repair sealant between the glass and the body.



11. Reshape the repair sealant as shown.




12. Install the molding.

- ① Align the white marks on the molding with the marks on the glass.
- ② Install the upper part of the molding.
- ③ Install the corner parts of the molding.
- ④ Install the side parts of the molding, starting from the bottom and working toward the top.

Hardening time of repair sealant


Temperature	Surface hardening time	Time required until car can be put into service
5°C (41°F)	Approx. 1.5 hr	12 hr
20°C (68°F)	Approx. 1hr	4 hr
35°C (95°F)	Approx. 10 min	2 hr

13. Check for water leaks. If a leak is found, wipe the water off well and repeat the installation.




Rear hatch molding

1. Apply protective tape along the edge of the hatch to protect it from damage.
2. Cut the sealant by using a razor knife as shown.




3. Insert the blade of the SST into the sealant and pull on the bar to cut the sealant near the hatch as shown.




4. Insert the blade of the SST into the sealant and pull on the bar to cut the sealant under the glass as shown.







5. Insert the blade of the SST into the sealant and pull on the bar to cut the sealant at an angle as shown.




6. Brush primer onto the bonding area of the glass, rear hatch, and new rear hatch molding. Use only glass primer on the glass and body primer on the hatch and molding. Keep the area free of dirt and grease, and do not touch the surface. Allow the primer to dry for approximately 30 minutes.



7. Apply a 3mm {0.12in} bead of repair sealant between the glass and the rear hatch.



8. Reshape the repair sealant as shown.  
 9. Install the molding while the repair sealant is soft.
- ① Align the white mark on the molding with that on the upper part of the glass.
  - ② Align the mark on the lower part of the glass with the molding joint.
  - ③ Install the upper part of the molding.
  - ④ Install the lower part of the molding.
  - ⑤ Install the side parts of the molding, starting from the top and working toward the bottom.
  - ⑥ Cut the molding to fit securely into the molding joint.
  - ⑦ Insert the molding into the molding joint.



**Hardening time of repair sealant**

Temperature	Surface hardening time	Time required until car can be put into service
5°C {41°F}	Approx. 1.5 hr	12 hr
20°C {68°F}	Approx. 1hr	4 hr
35°C {95°F}	Approx. 10 min	2 hr


10. Check for water leaks. If a leak is found, wipe the water off well and repeat the installation.

**SPOILER**

**COMPONENTS**

**Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



**Front air dam**  
1. Front air dam


**Rear spoiler**  
2. Rear hatch lower trim  
Removal / Installation ..... page S-55  
3. Rear spoiler

### COWL GRILLE

#### COMPONENTS

#### Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Windshield wiper arm and blade  
Adjustment ..... page S-34

2. Cowl cap  
3. Cowl grille

**POWER OUTSIDE MIRROR**

**COMPONENTS**


**Removal / Installation**

1. Disconnect the negative battery cable.

**Note**


- Remove the plastic surrounding the harness carefully so that it may be reused.

2. Remove in the order shown in the figure. (Refer to the 1994 RX-7 Body Electrical Troubleshooting Manual, section J1, when removing the door speaker.)
3. Install in the reverse order of removal.




1. Door trim  
Removal / Installation ..... page S-55
2. Power outside mirror switch

3. Door speaker
4. Power outside mirror  
Replacement of mirror glass  
..... page S-30


**Replacement of Mirror Glass**

1. Warm the frame and the mirror glass by using a hot air blower.




2. Insert a scraper between the mirror glass and the frame, and pry the glass loose.

3. Remove the remaining adhesive.




4. Warm the adhesive surface of the frame and the mirror by using a hot air blower.



5. Install the glass on the frame and gently press on the glass to secure it.

**REARVIEW MIRROR**


**PREPARATION  
SST**

<p>49 0305 870A Tool set, window</p>		<p>For removal / installation of mirror base</p>
--	---	--

**COMPONENTS**

**Removal / Installation**


1. Remove in order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.



1. Rearview mirror

2. Mirror base assembly


- a. Holder  
Installation Note ..... page S-32
- b. Cover
- c. Base  
Removal Note ..... page S-32  
Installation Note ..... page S-32

**Removal Note****Base**


1. Wind each end of the wire around a bar.
2. Saw through the sealant. Use a long sawing action to spread the work over the whole length of the wire to prevent it from breaking.
3. Remove the base.

**Installation Note****Base**

1. Cut away all of the original sealant by using a razor knife.
2. Clean and degrease the glass.
3. Apply primer to the glass and base. Use only glass primer on the glass and body primer on the base. Keep the area free of dirt and grease, and do not touch the surface. Allow the primer to dry for approximately **30 minutes**.




4. Apply a **3 mm {0.12 in}** bead of repair sealant on the base.
5. Center the base in the ceramic coating and press it onto the glass.



6. Remove any excessive repair sealant with ethyl alcohol before the sealant has hardened.

**Hardening time of repair sealant**

Temperature	Surface hardening time	Time required until car can be put into service
5°C {41°F}	Approx. 1.5 hr	12 hr
20°C {68°F}	Approx. 1hr	4 hr
35°C {95°F}	Approx. 10 min	2 hr

**Holder**


Install the holder on the cover as shown in the figure.

WINDSHIELD WIPER AND WASHER

COMPONENTS

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




Windshield wiper

1. Wiper arm cover
2. Wiper arm and blade
  - Adjustment ..... page S-34
  - Installation Note ..... page S-34
3. Cowl grille
4. Wiper motor
  - Disassembly / Assembly ..... page S-35
5. Wiper link

Windshield washer

6. Washer tank
7. Washer motor
8. Washer pipe
9. Washer nozzle
  - Adjustment ..... page S-34






### Adjustment

#### Windshield wiper arm and blade

1. Operate the wipers once to set them in the park position.
2. Set the height of the wiper arms as shown.


#### Tightening torque:

9.9–13.7 N·m {100–140 kgf·cm, 87–121 in·lbf}



### Windshield washer nozzle

Insert a needle or similar object into the nozzle hole and move the nozzle to adjust the spray direction.



### Installation Note


#### Wiper arm and blade

Clean the wiper arm connector shafts with a wire brush before installing the wiper arms.

**WINDSHIELD WIPER MOTOR**

**Disassembly / Assembly**

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Wiper motor
2. Brush plate holder


3. Motor gear shaft

## HEADLIGHT CLEANER

## COMPONENTS

## Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the pipe assembly, remove the front bumper (page S-16) and floor covering (page S-59). To remove the headlight cleaner switch, remove the console panel. (Refer to page S-53.) To remove the headlight cleaner motor and relay, remove the trunk end trim and trunk side trim. (Refer to page S-55.)
3. Install in the reverse order of removal.




1. Washer tank assembly
2. Pipe assembly
3. Check valve
4. Cleaner nozzle

5. Headlight cleaner switch
6. Headlight cleaner motor
7. Headlight cleaner relay

WINDSHIELD


PREPARATION  
SST

<p>49 0305 870A Tool set, window</p>		<p>For removal / installation of windshield</p>
--	---	---

COMPONENTS


Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to Removal Note.
3. Install in the reverse order of removal, referring to Installation Note.



- 1. Sunvisor and adapter
- 2. Rearview mirror
- 3. Overhead console
- 4. A-pillar trim  
Removal / Installation ..... page S-55
- 5. Windshield wiper arm and blade  
Adjustment ..... page S-34
- 6. Cowl grille


- 7. Windshield molding  
Removal / Installation ..... page S-21
- 8. Windshield  
Removal Note ..... page S-40  
Installation Note ..... page S-40
- 9. Spacer
- 10. Dam
- 11. Protector



### Removal Note Windshield


#### If the glass will not be reused

1. Use a tool like that shown in the figure and insert the blade into the sealant.
2. Pull through the sealant around the edge of the glass.
3. If the protector is damaged, remove it.
4. Remove the glass.




#### If the glass will be reused


1. Apply protective tape along the front edge of the headliner to protect it from damage.



2. Apply protective tape along the edge of the body to protect it from damage.
3. Make a hole through the sealant from the inside of the vehicle by using an awl.
4. Pass piano wire through the hole.




5. Wind each end of the wire around a bar.
6. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking.
7. Remove the glass.




### Installation Note Windshield


1. Cut away the old sealant by using a razor knife so that approximately 2 mm {0.08 in} of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it 30 minutes to dry. Then apply new sealant to create a 2mm {0.08in} layer.
2. Carefully clean an area 5 cm {1.97 in} wide around the circumference of the glass and clean the bonding area on the body.




3. Mark the outer edge of the glass with a marking pen to ensure proper reinstallation.



4. Apply primer with a brush to the bonding area of the glass and the body. Keep the area free of dirt and grease, and do not touch the surface. Allow it to dry for approximately 30 minutes.




5. Securely bond a new dam along the circumference of the glass 8mm {0.31in} from the edge. Allow it to dry completely.




6. Install the spacers onto the body as shown. If a spacer is damaged, replace it.

7. Set the glass onto the body and adjust the clearance between the top of the glass and the body to 7mm {0.27in} by moving the spacers up or down.


8. Remove the glass from the body.



9. Prepare the nozzle of the sealant tube so that it has a flange that can run along the edge of the glass and a V from which the sealant can flow. Apply repair sealant around the entire circumference to fill the gap between the dam and the edge of the glass with a ridge of sealant 11mm {0.43in} high. Keep the bead of sealant smooth and even, reshaping it where necessary with a spatula.




10. If the protector was removed, bond a new one onto the body as shown.




11. Align the glass marks with the notches in the spacers and install the glass onto the body.
12. Press firmly on the glass to compress the sealant.
13. To prevent the glass from being pushed out by air pressure if a door is closed, open all of the windows until the repair sealant has hardened.

**Hardening time of repair sealant**

Temperature	Surface hardening time	Time required until car can be put into service
5°C {41°F}	Approx. 1.5 hr	12 hr
20°C {68°F}	Approx. 1hr	4 hr
35°C {95°F}	Approx. 10 min	2 hr



14. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact. Adjust the upper and side sealants as shown, if necessary.




15. Install the molding.
  - ① Align the white marks on the molding with the marks on the glass.
  - ② Install the upper part of the molding.
  - ③ Install the corners of the molding.
  - ④ Install the sides of the molding, starting from the bottom and working toward the top.
16. If a leak is found, wipe the water off well and remove the glass. Reinstall the glass.

REAR HATCH GLASS

PREPARATION


SST

<p>49 0305 870A Tool set, window</p> 	<p>For removal / installation of rear hatch glass</p>
--	---

COMPONENTS

Removal/Installation






1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.



- |  |           |
|--|-----------|
| 1. Rear hatch upper trim<br>Removal / Installation ..... | page S-55 |
| 2. Rear hatch side trim<br>Removal / Installation .....  | page S-55 |
| 3. Rear hatch lower trim<br>Removal / Installation ..... | page S-55 |
| 4. Rear spoiler<br>Removal / Installation .....          | page S-27 |

- |   |           |
|---|-----------|
| 5. Rear wiper arm and blade<br>Adjustment .....       | page S-37 |
| 6. Rear hatch molding<br>Removal / Installation ..... | page S-21 |
| 7. Rear hatch glass<br>Removal Note .....             | page S-44 |
| Installation Note .....                               | page S-44 |
| 8. Dam  |           |



**Removal Note****Rear hatch glass**


1. Apply protective tape along the edge of the rear hatch to protect it from damage.
2. Make a hole through the sealant from the inside of the vehicle by using an awl.
3. Pass piano wire through the hole.
4. Wind each end of the wire around a bar.
5. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from bearking.
6. Remove the glass.

**Note**


- The rear hatch glass has locating studs at the top, bottom, and sides. If it is difficult to cut the sealant with the piano wire, use a razor knife from the inside of the vehicle where necessary.

**Installation Note****Rear hatch glass**

1. Cut away the old sealant with a razor knife so that 1 to 2 mm {0.04 to 0.08 in} of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply, apply primer after degreasing, and allow it 30 minutes to dry. Then put on new sealant to create a 2mm {0.08in} layer.
2. Carefully clean an area 5 cm {1.97 in} wide around the circumference of the glass and clean the bonding area on the rear hatch.
3. Apply primer with a brush to the bonding area of the glass and the body. Keep the area free of dirt and grease, and do not touch the surface. Allow it to dry for approximately 30 minutes.




4. Securely bond a new dam along the circumference of the glass 8mm {0.31in} from the edge. Allow it dry completely.



5. Prepare the nozzle of the sealant gun so that it has a flange that can run along the edge of the glass and a V from which the sealant can flow. Apply repair sealant around the entire circumference to fill the gap between the dam and the edge of the glass with a ridge of sealant 11mm {0.43in} high. Keep the bead of sealant smooth and even, reshaping it where necessary with a spatula.

6. Align the locating studs and install the glass onto the body. Verify that the clearance between the top of the glass and the rear hatch is 8 mm {0.31in}.

7. Press firmly on the glass to compress the sealant. Install the nuts onto the studs.




**Tightening torque:**

**2.0–2.9 N·m {20–30 kgf·cm, 18–26 in·lbf}**


8. To prevent the glass from being pushed out by air pressure if a door is closed, open all of the windows until the repair sealant has hardened.

**Hardening time of repair sealant**

Temperature	Surface hardening time	Time required until car can be put into service
5°C {41°F}	Approx. 1.5 hr	12 hr
20°C {68°F}	Approx. 1hr	4 hr
35°C {95°F}	Approx. 10 min	2 hr



9. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact. Adjust the upper and side sealants as shown, if necessary.



10. Install the molding.

- ① Align the white mark on the molding with that on the upper part of the glass.
- ② Align the mark on the lower part of the glass with the molding joint.
- ③ Install the upper part of the molding.
- ④ Install the lower part of the molding.
- ⑤ Install the side parts of the molding, starting from the top and working toward the bottom.
- ⑥ Cut the molding to fit securely into the molding joint.
- ⑦ Insert the molding into the molding joint.


11. If a leak is found, wipe the water off well and remove the glass. Reinstall the glass.

### SLIDING SUNROOF

#### COMPONENTS


#### Removal / Installation

1. Open the slide panel 100 mm {3.9 in} from the closed throttle position.
2. Disconnect the negative battery cable.
3. Remove in the order shown in the figure, referring to **Removal Note**. To remove the sunroof drive unit assembly, remove the headliner. (Refer to page S-61.)
4. Install in the reverse order of removal, referring to **Installation Note**.



- |                         |                 |
|-------------------------|-----------------|
| 1. Sunshade             |                 |
| 2. Decoration cover     |                 |
| Removal Note            | ..... page S-47 |
| 3. Lower panel cover    |                 |
| Removal Note            | ..... page S-47 |
| 4. Slide panel assembly |                 |
| Removal Note            | ..... page S-47 |
| Adjustment              | ..... page S-52 |


- |                                |                 |
|--------------------------------|-----------------|
| 5. Weatherstrip                |                 |
| 6. Sunroof shim                |                 |
| 7. Drain hose                  |                 |
| Installation Note              | ..... page S-48 |
| 8. Sunroof drive unit assembly |                 |
| Removal Note                   | ..... page S-47 |
| Installation Note              | ..... page S-47 |
| Disassembly / Assembly         | ..... page S-49 |



**Removal Note**


**Decoration cover, lower panel cover**

Remove the decoration covers and lower panel cover in the order shown in the figure.




**Slide panel**

1. Fully close the slide panel by using the emergency handle (supplied in vehicle).
2. Remove the slide panel fixing nuts. Push the slide panel up from the inside and remove it from the guide.



**Sunroof drive unit assembly**


1. Remove bolts A.
2. Loosen nuts C.
3. Loosen height adjusting nuts B and remove the sunroof drive unit from the body.




**Installation Note**

**Sunroof drive unit assembly**

1. Align the locator pins and set the sunroof drive unit to the roof panel.




2. Loosely install the sunroof drive unit to the roof panel with the height adjusting nuts.



- Loosen the set bracket attaching nuts. Position the set bracket so that it touches the roof panel fixing bracket. Tighten the fixing bracket bolts, then tighten the nuts.

**Tightening torque:**


7.9–10.7 N·m {80–110 kgf·cm, 70–95 in·lbf}



- Affix the rear of the sunroof frame to the roof panel.

**Tightening torque:**

7.9–10.7 N·m {80–110 kgf·cm, 70–95 in·lbf}




**Slide panel**

Install the slide panel to the guide. If the height difference between the slide panel and the roof panel is greater than 2.0 mm {0.08 in}, loosen the slide panel attaching nuts and insert shim(s) between the panels.

**Tightening torque:**

7.9–10.7 N·m {80–110 kgf·m, 70–95 in·lbf}



**Drain hose**


Apply soapy water to the drain hose and insert it fully into the sunroof frame.

- On the A-pillar side, insert one end of the hose into the sunroof frame, set the hose along the A-pillar, and insert the other end into the cowl side panel hole.
- On the B-pillar side, insert one end of the hose into the sunroof frame and insert the other end into the rear fender panel hole via the hole in the upper part of the B-pillar.

**SLIDING SUNROOF DRIVE UNIT ASSEMBLY**


**Disassembly / Assembly**

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- |                        |           |
|------------------------|-----------|
| 1. Sunroof motor       |           |
| Disassembly Note ..... | page S-50 |
| Assembly Note .....    | page S-51 |
| Adjustment .....       | page S-52 |
| 2. Drive unit          |           |
| 3. Guide pillar        |           |
| Disassembly Note ..... | page S-50 |
| Assembly Note .....    | page S-51 |
| 4. Guide rail          |           |
| Disassembly Note ..... | page S-50 |
| Assembly Note .....    | page S-52 |


- |                        |           |
|------------------------|-----------|
| 5. Shutting assembly   |           |
| Disassembly Note ..... | page S-50 |
| Assembly Note .....    | page S-51 |
| 6. Guide               |           |
| Disassembly Note ..... | page S-50 |
| Assembly Note .....    | page S-51 |
| 7. Sunroof relay       |           |
| 8. Sunroof frame       |           |

**Disassembly Note****Sunroof motor**


1. Remove the screws and remove the motor from the sunroof frame.
2. Disconnect the motor harness connector.

**Guide pillar**


1. Remove the guide pillar mounting nuts and screw.
2. Pull the guide pillar to remove it from the guide rail.

**Guide rail**

- Pull the guide rail with the guide to remove them from the sunroof frame.

**Shutting assembly, guide**


1. Pull the shutting assembly to remove it from the guide rail.
2. Pull the guide to remove it from the guide rail.



**Assembly Note**


**Shutting assembly, guide**

1. Insert the guide into the guide rail.
2. Insert the shutting assembly into the guide rail.




**Guide rail**

Insert the guide rail with the guide into the sunroof frame.




**Guide pillar**

1. Insert the guide pillar into the guide rail.
2. Install the guide pillar mounting nuts and screw.




**Sunroof motor**

1. Remove the motor cover. Position the mark on the timing gear as shown in the figure by using the emergency handle (supplied in vehicle).



2. Move the guide fully forward by hand.
3. Install the motor to the sunroof frame.
4. Connect the motor harness connector.






### Adjustment Slide panel Height

Adjust the height difference between the slide panel and the roof panel according to the following procedure.

**Allowable height difference: 2.0 mm {0.08 in} max.**




1. Remove the headliner. (Refer to page S-60.)
2. Loosen the set bracket attaching nuts.
3. Turn the height adjusting nuts to adjust the sunroof frame height.

### Note


- Clockwise rotation increases the frame height.

4. After adjustment, securely install the sunroof to the roof panel.



### Gap


1. Verify that the slide panel does not interfere with the roof panel when operated.
2. If necessary, loosen the slide panel mounting nuts and move the panel.
3. If the above adjustment is not enough, loosen the mounting screws and bolts of the sun roof frame and set bracket and adjust again. (Refer to page S-47 Installation Note for the sunroof drive unit assembly.)



### Sunroof motor

1. Measure the operation time of the slide panel from wide open throttle to closed throttle position or vice versa.

**Specified time: 4-7 sec.**



2. If not as specified, adjust it by turning the locknut on the sunroof motor.


- (1) Remove the housing cover attaching screw and the E-ring. Remove the housing cover from the motor.
- (2) Unfold the pole washers indicated by the arrows.
- (3) Hold the motor shaft with the emergency handle (supplied in vehicle) and turn the locknut to adjust the torque.
- (4) Fold the pole washers against the locknut.

DASHBOARD AND CONSOLE

COMPONENTS


Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**. To remove the dashboard, remove the parking brake lever. (Refer to Section P.) (Refer to the 1994 RX-7 Body Electrical Troubleshooting Manual, section J1, when removing the audio unit.)
3. Install in the reverse order of removal.




- 1. Column cover
- 2. Ashtray
- 3. Console panel  
Removal Note ..... page S-54
- 4. Rear console
- 5. Meter hood and instrument cluster
- 6. Center panel
- 7. Side wall  
Removal Note ..... page S-54


- 8. Hood release knob  
Removal / Installation ..... page S-5
- 9. Lower panel
- 10. Side panel  
Removal Note ..... page S-54
- 11. Steering shaft  
Removal Note ..... page S-54
- 12. Dashboard
- 13. Audio unit
- 14. Glove compartment

**Removal Note****Console panel**


1. Remove the ashtray.
2. Insert a protected screwdriver at point A to pry out the rear of the panel.
3. Pull the console panel upward to disengage the clips from the body.
4. Remove the ashtray lamp.
5. Disconnect the harness connector from the switches.

**Side wall  
(driver side)**


1. Remove the installation fastener.
2. Pull the side wall forward disengage the clips from the body.

**(passenger side)**

1. Remove the installation fastener.
2. Pull the side wall forward disengage the clips from the body.

**Side panel**

Pull the rear of the side panel forward to disengage the clips from the body.

**Steering shaft**


1. Protect the steering wheel with a clean rag.
2. Remove the steering shaft mounting bolts to lower the shaft.

**TRIM**


**COMPONENTS**

**Removal / Installation**


1. Remove in the order shown in the figure, referring to **Removal Note**. To remove the trunk end trim and trunk side trim, remove the acoustic wave guide assembly. (Refer to the 1994 RX-7 Body Electrical Troubleshooting Manual, section J1.)
2. Install in the reverse order of removal.




- |  |   |
|--|---|
| 1. Scuff plate<br>Removal Note ..... page S-56   | 7. Trunk end trim<br>Removal Note ..... page S-57         |
| 2. A-pillar trim<br>Removal Note ..... page S-56   | 8. Suspension tower cover                                 |
| 3. Front side trim   | 9. Suspension rear strut bar                              |
| 4. Quarter trim<br>Removal Note ..... page S-56  | 10. Trunk side trim                                       |
| 5. Door trim<br>Removal Note (driver side) .... page S-56<br>Removal Note<br>(passengerside) ..... page S-57 | 11. Rear hatch upper trim<br>Removal Note ..... page S-57 |
| 6. Rear package tray   | 12. Rear hatch side trim<br>Removal Note ..... page S-57  |
|  | 13. Rear hatch lower trim<br>Removal Note ..... page S-58 |

**Removal Note****A-pillar trim**


1. Remove the seaming welt.
2. Pull the A-pillar trim to disengage the clips from the body.
3. Pull the A-pillar trim up to remove it.

**Scuff plate**


Pull the scuff plate up to disengage the clips from the body.

**Quarter trim**


1. Remove the scuff plate.
2. Remove the seaming welt.
3. Remove the seat belt lower anchor. (Refer to page S-62.)
4. Remove the installation screw and fasteners.
5. Pull the quarter trim to disengage the clips from the body.

**Door trim  
(driver side)**

1. Remove the recess cover and the installation screw.
2. Remove the inner handle cover.
3. Remove the door trim installation screws.




4. Pull the door trim to disengage the clips from the body.
5. Lift the door trim up to remove it.
6. Disconnect the harness connectors.




**(passenger side)**

1. Remove the recess cover and the installation screw.
2. Remove the inner handle.
3. Disconnect the harness connector.
4. Remove the cap and door trim mounting screws.




5. Pull the door trim to disengage the clips from the body.
6. Lift the door trim up to remove it.




**Trunk end trim**

1. Remove the rear washer cap.
2. Remove the installation fasteners.
3. Pull the trunk end trim to disengage the clips from the body.
4. Lift the trunk end trim up to remove it.




**Rear hatch upper trim**

1. Remove the installation fasteners.
2. Pull the rear hatch upper trim to disengage the clips from the body.



**Rear hatch side trim**


1. Remove the rear hatch upper trim.
2. Remove the fasteners.
3. Pull the rear hatch side trim to disengage the clips from the body.

**Rear hatch lower trim**

1. Remove the rear hatch side trim (page S-57).
2. Rotate the strap hangers 90° and remove them.
3. Remove the fasteners.
4. Pull the rear hatch lower trim to disengage the clips from the body.

**FLOOR COVERING****COMPONENTS****Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove the following:
  - a. Seats (Refer to page S-64.)
  - b. Scuff plates (Refer to page S-55.)
  - c. Seat belt lower anchor (Refer to page S-62.)
  - d. Quarter trim (Refer to page S-55.)
  - e. Storage compartment (Refer to page S-67.)
  - f. Dashboard and console (Refer to page S-53.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Cabin carpet

2. Trunk carpet



### SEAT BELT


#### COMPONENTS

#### Removal / Installation

##### Caution

- The ELR (emergency locking retractor) has a spring that will unwind if the retractor's cover is removed. The spring cannot be rewound by hand. If this occurs, the ELR will not work properly. Therefore, do not disassemble the retractor.

1. Removal in the order shown in the figure.
2. Install in the reverse order of removal.




1. Scuff plate  
Removal / Installation ..... page S-55
2. Quarter trim  
Removal / Installation ..... page S-55


3. Seat belt assembly  
A. Upper anchor  
B. Lower anchor  
C. Retractor  
Inspection ..... page S-63
4. Buckle

**SEAT BELT****Inspection****Webbing and fittings**

1. Inspect the webbing for scars and tears.
2. Inspect the fittings for deformation.
3. If any problem is found, replace the seat belt assembly.

**Emergency locking retractor (ELR)**

1. Pull out the seat belt slowly and then release it. Verify that it returns smoothly.
2. Verify that the retractor locks when the belt is quickly pulled.
3. Remove the retractor.
4. Hold the retractor as it would be installed.
5. Slowly incline the retractor while pulling out the belt.
6. Verify that the retractor locks at angle of approximately **30 degrees**.
7. If not as specified, replace the seat belt assembly.




## SEAT

### COMPONENTS

#### Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Adjuster cover

2. Seat


Disassembly / Assembly ..... page S-65

**Disassembly / Assembly**


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly.



- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Knuckle knob</li> <li>2. Knuckle cover</li> <li>3. Recliner knuckle</li> </ol> | <ol style="list-style-type: none"> <li>4. Seat back</li> <li>5. Slide adjuster</li> <li>6. Seat cushion</li> </ol> |
|--|--|
- Disassembly Note ..... page S-66

**Disassembly Note  
Recliner knuckle**

1. Remove the hog rings from the seat back.



2. Turn over the seat back cover to reveal the recliner knuckle mounting bolts.


3. Remove the mounting bolts and the recliner knuckle.

**STORAGE COMPARTMENT**

**COMPONENTS**

**Removal / Installation**

- 1. Remove in the order shown in the figure.
- 2. Install in the reverse order of removal.



1. Luggage compartment panel

3. Storage compartment

2. Quarter trim

Removal / Installation ..... S-55

# **SPECIAL TOOLS**

GENERAL INFORMATION .....	ST- 2
ENGINE .....	ST- 3
CLUTCH AND MANUAL TRANSMISSION .....	ST- 4
AUTOMATIC TRANSMISSION .....	ST- 5
FRONT AND REAR AXLES .....	ST- 6
DIFFERENTIAL .....	ST- 7
BRAKING SYSTEM .....	ST- 8
STEERING SYSTEM AND SUSPENSION .....	ST- 9
HEATER AND AIR CONDITIONER SYSTEMS .....	ST-10
CHECKER AND OTHER EQUIPMENT .....	ST-11

**GENERAL INFORMATION**

The letters A and B in the priority column indicate the degree of importance of each tool.

**A . . . Indispensable**

The tools ranked A in this list are indispensable for performing operations satisfactorily, easily, safely, and efficiently. It is, therefore advisable that all service shops have these tools.

**B . . . Selective**









The tools in this list are not as necessary as tools ranked A, but all service shops should have these tools to perform repairs more easily and more efficiently.









**Note**

- When ordering tool sets which consist of several tools, check the list in the Special Service Tools Booklet (4063-12-87J) etc. to make sure that some tools are duplicated in other sets which may already have been purchased. If so, order only those new tools which are needed.





ENGINE


TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0107 680A Engine stand	A	
49 0813 215A Puller, tubular dowel & A/T oil pump	A	
49 0813 250 Seal case	B	
49 0813 240 Installer & puller, rotor bush	A	
49 0820 035 Box wrench, flywheel	A	
49 F011 101 Brake, ring gear (Manual transmission)	A	
49 1285 071 Puller, bearing	A	
49 2113 010B Gauge set, air pump	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 1114 005 Hanger, engine stand	A	
49 0813 225 Remover, oil seal	B	
49 0813 235 Puller & installer, main bearing	A	
49 0839 165 Gauge, corner seal	A	
49 1881 055A Stopper, counter weight (Automatic transmission)	A	
49 0839 305A Puller, counter weight	A	
49 F011 1A1 Installer set, bearing	A	
49 0187 280 Oil pressure gauge	B	




ST



### AUTOMATIC TRANSMISSION (CONT'D)

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 L019 001 Bolt	A	
49 G019 0A7A Compressor set, return spring	A	








TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 F019 0A0 Adapter set	A	








### FRONT AND REAR AXLES

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 F026 103 Puller, wheel hub	A	
49 G033 105 Attachment	A	
49 F027 0A1 Installer set, bearing	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 H034 201 Support block	A	
49 G033 102 Handle	A	







DIFFERENTIAL







TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 M005 561 Hanger, diff. carrier	A	
49 B001 795 Installer, oil seal	A	
49 F027 0A0 Gauge set, pinion height adjustment	A	
49 J027 002 Collar	A	
49 8531 565 Pinion model	A	
49 V001 795 Installer, oil seal	A	
49 0727 570 Pinion height gauge	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 G030 338 Attachment E	A	
49 J027 001 Installer, bearing	A	
49 S120 710 Holder, coupling flange	B	
49 UB71 525 Installer, bearing	A	
49 U027 003 Installer, oil seal	A	
49 H027 002 Remover, bearing	A	
49 0660 555 Gauge block	A	









ST









### BRAKING SYSTEM

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0259 770B Wrench, flare nut	A	
49 F026 104 Installer, sensor rotor	A	
49 0221 600C Expand tool, disc brake	B	
49 E043 003 Turning lock tool	A	
49 B043 004 Socket wrench	A	
49 H028 204 Attachment	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 U043 0A0 Gauge set, oil pressure	A	
49 F033 001 Stopper, disc brake piston	A	
49 FA18 602 Wrench, disc brake piston	B	
49 B043 001 Adjust gauge	A	
49 0208 701A Boot air out tool	B	
49 B043 002 Installer, bearing	A	







STEERING SYSTEM AND SUSPENSION







TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0180 510B Attachment, preload measuring	A	
49 0118 850C Puller, ball joint	A	
49 0223 640B Arm, coil spring compressor	A	
49 1232 670A Gauge set, power steering	A	
49 H002 671 Adapter, power steering gauge	A	
49 F034 2A0 Replacer set, rubber bush	A	
49 H032 322 Adapter set, power steering	A	
49 W023 585A Adjust wrench	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 F032 313 Wrench	A	
49 G032 3A1 Joint hose	A	
49 0370 641 Screw, coil spring compressor	A	
49 F032 305 Handle	A	
49 F032 303 Handle	A	
49 F032 301 Hanger, power steering pump	A	
49 1243 785 Installer, boot	A	
49 F032 310 Protector	A	


ST


### STEERING SYSTEM AND SUSPENSION (CONT'D)

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 D032 316 Protractor	A	
49 H032 328 Seal ring former	A	
49 F034 210 Guide, clip	A	
49 F034 211 Guide, clip	A	
49 0710 520 Puller, bearing	A	
49 F032 304 Body	A	









TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 H032 301 Wrench	A	
49 F032 306A Body	A	
49 F032 317 Remover, oil seal	A	
49 F032 318 Installer, bearing and oil seal	A	
49 F032 319 Installer, oil seal	A	
49 L033 102 Adapter, caster, camber gauge	A	









### HEATER AND AIR CONDITIONER SYSTEMS

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
4992-02-020 Pressure plate remover	A	



TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 L061 001 Stopper, magnetic clutch	A	



CHECKER AND OTHER EQUIPMENT

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0839 285 Checker, fuel thermometer	A	
49 L018 901 Injector checker	A	
49 F018 9A0 Compression tester	A	
49 H066 002 Deployment tool	A	
49 B019 9A0 System selector	A	
49 H066 003 Adapter harness	A	
49 H018 9A1 Self-diagnosis checker	A	
49 F018 002 Igniter checker	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0305 870A Tool set, window (bond type)	A	
49 F013 102 Hose, injector checker	A	
49 UN01 050 Removing tool	A	
49 H080 740 Pressure tester	A	
49 F018 003 Adapter harness	A	
49 F018 903 Sheet	A	
49 F018 902 Adapter harness	A	
49 G050 1A0 Remover, sealant	A	

### CHECKER AND OTHER EQUIPMENT (CONT'D)

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 9200 162 A Monitor, engine signal	A	
49 9200 164 ABS tester	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 G018 904 Sheet (EC-AT) Except CANADA	A	
49 H019 905 Adapter harness (EC-AT) Except CANADA	A	



# TECHNICAL DATA

ENGINE .....	TD- 2
LUBRICATING SYSTEM .....	TD- 3
COOLING SYSTEM .....	TD- 4
FUEL AND EMISSION CONTROL SYSTEMS .....	TD- 4
ENGINE ELECTRICAL SYSTEM .....	TD- 5
CLUTCH .....	TD- 5
MANUAL TRANSMISSION .....	TD- 6
AUTOMATIC TRANSMISSION .....	TD- 8
PROPELLER SHAFT .....	TD-13
FRONT AND REAR AXLES .....	TD-13
STEERING SYSTEM .....	TD-13
BRAKING SYSTEM .....	TD-14
WHEELS AND TIRES .....	TD-15
SUSPENSION .....	TD-15
BODY ELECTRICAL SYSTEM .....	TD-16
HEATER AND AIR CONDITIONER SYSTEMS .....	TD-17
STANDARD BOLT AND NUT TIGHTENING TORQUE .....	TD-17

### C. ENGINE

Item			Engine	13B (Turbo)	
Type			Rotary engine		
Displacement			ml {cc, cu in}	654 {654, 40.0} × 2	
Number of rotors and arrangement			2 rotors, longitudinal		
Combustion chamber type			Bathtub		
Compression ratio			9.0: 1		
Port timing	Intake	Open	Primary	45° BTDC	
			Secondary	32° BTDC	
		Close	Primary	50° ABDC	
			Secondary	50° ABDC	
	Exhaust	Open	75° BBDC		
		Close	48° ATDC		
Compression pressure kPa {kgf/cm <sup>2</sup> , psi}-rpm		Minimum	686 {7.0, 100}-250		
		Maximum difference between chambers	147 {1.5, 21}-250		
Side housing (Front, intermediate and rear housing)		Distortion limit	mm {in}	0.04 {0.002}	
		Side seal wear limit	mm {in}	0.10 {0.004}	
		Side seal wear limit, overlapping oil seal wear	mm {in}	0.01 {0.0004}	
		Side seal wear limit, outside oil seal wear	mm {in}	0.10 {0.004}	
		Oil seal wear limit	mm {in}	0.02 {0.0008}	
Rotor housing		Width	mm {in}	80 {3.1}	
		Maximum width difference	mm {in}	0.06 {0.0024}	
Rotor		Width (Apex)	mm {in}	79.675 {3.1368}	
		Clearance of side housing to rotor	mm {in}	Standard	0.12-0.21 {0.0048-0.0082}
			mm {in}	Min.	0.10 {0.0039}
		Diameter of corner seal groove	mm {in}	11.000-11.018 {0.4331-0.4338}	
		Width of side seal groove	mm {in}	0.714-0.739 {0.0281-0.0291}	
Width of apex seal groove	mm {in}	1.995-2.012 {0.0785-0.0792}			
Apex seal and spring		Width	mm {in}	2.0 {0.079}	
		Height (upper and lower)	mm {in}	Standard	8.5 {0.33}
			mm {in}	Min.	6.5 {0.256}
		Clearance of apex seal and rotor groove	mm {in}	Standard	0.051-0.101 {0.002-0.039}
			mm {in}	Max.	0.15 {0.0059}
		Spring free height	mm {in}	Long	Standard
Short	Standard			3.5 {0.138}	
Side seal and spring		Thickness	mm {in}	0.661-0.686 {0.0260-0.0270}	
		Clearance of side seal to rotor groove	mm {in}	Standard	0.028-0.078 {0.0011-0.0030}
			mm {in}	Max.	0.10 {0.0039}
		Height	mm {in}	3.0 {0.118}	
		Protrusion min.	mm {in}	0.50 {0.020}	
Clearance of side seal to corner seal		mm {in}	Standard	0.05-0.15 {0.0020-0.0059}	
			Max.	0.40 {0.016}	
Corner seal and spring		Outer diameter	mm {in}	10.990-11.014 {0.4327-0.4336}	
		Height	mm {in}	7.0 {0.276}	
		Protrusion min.	mm {in}	0.50 {0.020}	
Rotor oil seal and spring		Height	mm {in}	5.6-5.8 {0.220-0.228}	
		Oil seal lip width max.	mm {in}	0.50 {0.020}	
		Protrusion min.	mm {in}	0.50 {0.020}	
Main bearing	Inner diameter	mm {in}	43.025-43.050 {1.6939-1.6949}		
Rotor bearing	Inner diameter	mm {in}	74.025-74.050 {2.9144-2.9153}		

Item		Engine	13B (Turbo)	
Eccentric shaft	Runout max.	mm {in}	0.06 {0.0024}	
	End play	mm {in}	Standard	0.040-0.070 {0.0016-0.0027}
			Limit	0.09 {0.0035}
	Main journal diameter	mm {in}	43 {0.37}	
	Clearance of main journal	mm {in}	Standard	0.08-0.11 {0.0032-0.0043} ... outside 0.06-0.08 {0.0024-0.0031} ... inside
			Limit	0.13 {0.0051} ... outside 0.11 {0.0043} ... inside
	Rotor journal diameter	mm {in}	74 {2.9}	
Clearance of rotor journal	mm {in}	Standard	0.060-0.080 {0.0024-0.0031}	
		Limit	0.10 {0.0039}	
Drive belt deflection at 98 N {10 kgf, 22 lbf} mm {in}	Alternator and Air pump	Used	7.0-7.5 {0.28-0.29}	
	P/S pump and A/C compressor	Used	4.5-5.0 {0.18-0.19}	

D. LUBRICATING SYSTEM

Item		Engine	13B (Turbo)	
Lubrication system			Forced-fed	
Oil pump	Type		Trochoid	
	Lobe clearance of outer rotor to inner rotor	mm {in}	Standard	0.03-0.12 {0.0012-0.0047}
			Max.	0.15 {0.0059}
	Clearance of outer rotor to pump body	mm {in}	Standard	0.20-0.25 {0.0079-0.0098}
			Max.	0.30 {0.0118}
End float	mm {in}	Standard	0.03-0.125 {0.0012-0.0049}	
		Max.	0.15 {0.0059}	
Pressure control valve	Relief pressure	kPa {kgf/cm <sup>2</sup> , psi}	1,080 {11.0, 156}	
Oil cooler	Type		Air-cooled, with bypass valve	
	Relief temperature	°C {°F}	60-65 {140-149} or below	
	Relief pressure dif.	kPa {kgf/cm <sup>2</sup> , psi}	349 {3.56, 50} at 60°C {140°F}	
	Bypass valve protrusion	mm {in}	6 {0.24} min.	
Regulator valve	Relief pressure	kPa {kgf/cm <sup>2</sup> , psi}	490 {5.0, 71}	
Oil filter	Type		Full flow, paper element	
	Relief pressure dif.	kPa {kgf/cm <sup>2</sup> , psi}	98 {1.0, 14}	
Eccentric shaft bypass valve	Relief temperature	°C {°F}	60 {140} or below	
	Protrusion	mm {in}	6 {0.24} or more	
Engine oil	Total (Dry engine)	L {US qt, Imp qt}	4.9 {5.2, 4.3} *5.4 {5.7, 4.8}	
	Oil replacement	L {US qt, Imp qt}	3.6 {3.8, 3.2}	
	Oil replacement (with oil filter)	L {US qt, Imp qt}	3.8 {4.0, 3.3}	
	Oil filter	L {US qt, Imp qt}	Factory installed	0.19 {0.20, 0.17}
			Service part	0.17 {0.18, 0.15}
	Grade		API Service SG, SH (EC II) ILSAC (Mineral oil only)	
	Above -25°C {-10°F}		10W-30	
Below 0°C {32°F}		5W-30		

\* R1 model

TD

### E. COOLING SYSTEM

Item		Engine	13B (Turbo)			
Cooling method			Water-cooled, forced circulation			
Water pump	Type		Centrifugal			
	Pulley ratio (Speed)		1: 1.22			
Thermostat	Type		Wax, bottom bypass			
	Opening temperature	°C {°F}	80.5–83.5 {177–182}			
	Full-open temperature	°C {°F}	95 {203}			
	Full-open lift min.	mm {in}	8–10 {0.31–0.39}			
Radiator	Type		Corrugated fin			
Coolant filler cap	Relief pressure	kPa {kgf/cm <sup>2</sup> , psi}	115–145 {1.15–1.45, 16.4–20.6}			
Coolant fan	Type		Electrical			
	Capacity	W	160 × 2			
	Number of blades		No1: 5, No2: 4			
	Outer diameter	mm {in}	300 {11.8}			
Drive belt deflection at 98 N {10 kgf, 22 lbf}	mm {in}	Alternator and air pump	Used	7.0–7.5 {0.28–0.29}		
Coolant	Capacity	L {US qt, imp qt}	8.8 {9.3, 7.7}			
Antifreeze solution	Mixture		Mixture percentage %		Specific gravity at 20°C {68°F}	
	Protection		Water	Antifreeze		
	Above –16°C {3°F}		65	35		1.054
	Above –26°C {–15°F}		55	45		1.066
		Above –40°C {–40°}		45	55	1.078

### F. FUEL AND EMISSION CONTROL SYSTEMS

Item		Specification
Idle speed*	rpm	700–750
Ignition timing	Leading	ATDC 5°
	Trailing	ATDC 20°
<b>Air cleaner housing</b>		
Element type		Oil permeated
<b>Throttle body</b>		
Type		Horizontal draft (2 stage-3 barrel)
Throat diameter	Primary	mm {in} 45 {1.772}
	Secondary	mm {in} 50 {1.969} × 2
Dashpot touch angle		8
Water thermovalve operation (full open) temperature	°C {°F}	55–65 {131–149} or more
<b>Charge air cooler</b>		
Type		Air cooled
Core size {w × h × t}	mm {in}	294 × 114 × 65 {11.575 × 4.4882 × 2.5591}
<b>Turbocharger</b>		
System type		Sequential twin turbocharged
Cooling method		Water + engine oil
Boost control actuator		Turbo precontrol + wastegate control
Boost control method		Solenoid valve (duty-controlled) × 2
<b>Fuel filter</b>		
Type	Low-pressure	Nylon element
	High-pressure	Paper element
<b>Pressure regulator</b>		
Type		Diaphragm
Regulated pressure	kPa {kgf/cm <sup>2</sup> , psi}	250–260 {2.5–2.6, 35.6–37.0}

\* TEN terminal of data link connector grounded

Item		Specification
<b>Fuel pump</b>		
Type	Impeller (In tank)	
Output pressure	kPa {kgf/cm <sup>2</sup> , psi}	490-740 {5.0-7.5, 71.1-106.7}
<b>Injector</b>		
Type	Side-feeding	
Injection volume	Primary	ml {cc, fl oz}/min 550 {550, 165}
	Secondary	ml {cc, fl oz}/min 850 {850, 255}
<b>Three-way catalyst</b>		
Type	Warm-up three-way catalyst	Metal
	Three-way catalyst	Monolithic
<b>Air pump</b>		
Capacity	cm <sup>3</sup> {cc}/rev	375 {375}
Output	L/min	MT 130-200, AT 160-200
<b>Fuel</b>		
Specification	Unleaded premium (RON95 or higher)	

**G. ENGINE ELECTRICAL SYSTEM**

Item		Transmission		MT	AT	
Voltage		V		12, negative ground		
Battery	Type and capacity (5-hour rate)		65D23L (43Ah)		75D26L (52Ah)	
Ignition system	Spark timing (TEN terminal grounded)		Leading : ATDC 5° (BTDC - 5°) Trailing : ATDC 20° (BTDC - 20°) at idle (AT: P range)			
	Spark advance		Electronic spark advance (ESA)			
	Spark plug	Type	Leading	NGK: BUR7EQP*1, BUR6EQP, BUR7EQ, BUR6EQ		
		Trailing	NGK: BUR9EQ*1, BUR8EQP, BUR9EQP, BUR8EQ			
	Plug gap	mm {in}	1.1-1.7 {0.044-0.066}			
Alternator	Output		V-A		12-100	
	Regulated voltage		V		14.1-14.7 (With temperature gradient characteristics)	
	Brush length	Standard	mm {in}	21.5 {0.846}		
		Minimum	mm {in}	8.0 {0.315}		
Stator	Type			Direct	Reduction	
	Output		V-kW		12-1.2	12-2.0
	Output (no load)	Voltage		V		11
		Current		A		Max 90
		Speed		rpm		Min 3000
	Brush length	Standard	mm {in}	17.5 {0.689}		18 {0.71}
Minimum		mm {in}	12 {0.47}		11 {0.43}	

\*1 Standard plug

**H. CLUTCH**

Item		Transmission	R15M-D
Clutch control			Hydraulic
<b>Clutch pedal</b>			
Type		Suspended	
Pedal ratio		6.35	
Full stroke	mm {in}	135 {5.32}	
Height (with carpet)	mm {in}	165.5-177.0 {6.516-6.968}	
Free play	mm {in}	0.6-3.2 {0.02-0.13}	
Distance from carpet when clutch is fully disengaged	mm {in}	48 {1.9} min.	

TD


Transmission		R15M-D	
<b>Item</b>			
<b>Flywheel</b>			
Runout limit	mm {in}	0.2 {0.008}	
<b>Clutch disc</b>			
Type		Single dry-plate	
Runout limit	mm {in}	0.6 {0.024}	
Wear limit	mm {in}	0.3 {0.012} from rivet head	
Outer diameter	mm {in}	236 {9.29}	
Inner diameter	mm {in}	160 {6.30}	
Facing thickness	mm {in}	Flywheel side	3.5 {0.14}
		Pressure plate side	3.5 {0.14}
<b>Clutch cover</b>			
Type		Diaphragm spring	
Set load	N {kgf, lbf}	7220 {736, 1619}	
Clutch master cylinder	Inner diameter	mm {in}	15.87 {0.625}
Clutch release cylinder	Inner diameter	mm {in}	19.05 {0.750}
Clutch fluid		FMVSS116 DOT-3	

### J. MANUAL TRANSMISSION (R15M-D)

Engine		13B (Turbo)	
<b>Item</b>			
<b>Specifications</b>			
Transmission type		R15M-D	
Transmission control		Floor shift	
Synchronization mechanism		Forward : Synchromesh Reverse : Synchromesh	
Gear ratio	1st	3.483	
	2nd	2.015	
	3rd	1.391	
	4th	1.000	
	5th	0.719	
	Reverse	3.288	
Final gear ratio		4.100	
Speedometer gear ratio (driven gear/drive gear)		0.304 (23/7)	
Oil	Grade	API service GL-4 or GL-5	
	Viscosity	All-season	SAE 75W-90
		Above 10°C {50°F}	SAE 80W-90
Capacity	L {US qt, Imp qt}	2.5 {2.6, 2.2}	
<b>Runout</b>			
Mainshaft	mm {in}	0.03 {0.0012}	
<b>Clearance</b>			
Each gear inner diameter and mainshaft outer diameter		mm {in}	0.15 {0.006}
Each clutch hub sleeve groove and shift fork	mm {in}	Standard	0.2-0.3 {0.008-0.012}
		Maximum	0.5 {0.020}
Reverse idler gear and shaft	mm {in}	Standard	0.02-0.05 {0.0008-0.0020}
		Maximum	0.15 {0.006}
Synchronizer ring (all) and flank surface of gear	mm {in}	Standard	1.5 {0.059}
		Minimum	0.8 {0.031}
Control rod lever and shift rod gate		mm {in}	0.8 {0.031}
<b>Thrust plan</b>			
Synchronizer key and synchronizer ring (4th)	mm {in}	Standard	0.66-2.0 {0.026-0.079}
		Available thrust washer thicknesses	2.5 {0.098}, 3.0 {0.118}, 3.5 {0.138}

# TECHNICAL DATA

# TD

Item		Engine	13B (Turbo)
Thrust lock washer and C-washers (5th gear thrust play)	mm {in}	Standard	0.1-0.2 {0.004-0.008}
		Available thrust lock washer thicknesses	6.2 {0.244}, 6.3 {0.248}, 6.4 {0.252}, 6.5 {0.256}, 6.6 {0.260}, 6.7 {0.264}
C-washers and mainshaft groove	mm {in}	Standard	0-0.1 {0-0.004}
		Available C-washer thicknesses	2.9 {0.114}, 3.0 {0.118}, 3.1 {0.122}, 3.2 {0.126}
Clutch housing and main drive gear bearing	mm {in}	Standard	0-0.1 {0-0.004}
		Available adjust shim thicknesses	0.3 {0.012}, 0.4 {0.016}, 0.5 {0.020}, 0.6 {0.024}, 0.7 {0.028}
Mainshaft front bearing	mm {in}	Standard	0-0.05 {0-0.002}
		Available adjust shim thicknesses	0.1 {0.004}, 0.3 {0.012}
Countershaft front bearing	mm {in}	Bearing height	0.9-1.0 {0.035-0.039}
		Available adjust shim thicknesses	0.1 {0.004}, 0.3 {0.012}
<b>Reference</b>			
Detent ball spring	Free length	mm {in}	22.5 {0.886}
5th/reverse retaining spring	Free length	mm {in}	73.00 {2.874}
Select lock spindle spring	Free length	mm {in}	43.25 {1.703}
Synchronizer key dimensions		1st and 2nd	① 18.00 {0.709}, ② 5.45 {0.215}, ③ 6.00 {0.236}
		3rd, 4th, 5th and Reverse	① 17.00 {0.669}, ② 4.25 {0.167}, ③ 5.00 {0.197}

TD

### K. AUTOMATIC TRANSMISSION

Item		Transmission	RB4A-EL	
Gear ratio		1st gear	3.027	
		2nd gear	1.619	
		Third gear	1.000	
		Fourth gear	0.694	
		Reverse	2.272	
Final gear ratio			3.909	
Automatic transmission fluid (ATF)	Type	Dexron®II or M-III		
	Capacity	L (US qt, Imp qt)	8.6 {9.1, 7.6}	
Torque converter	Stall torque ratio	2.200		
Number of drive plates / driven plates	Reverse clutch	2/2		
	High clutch	4/7		
	Forward clutch	6/6		
	Overrunning clutch	3/5		
	Low and reverse brake	7/7		
Band servo	mm {in}	Servo piston outer dia. / inner dia.	80.0 {3.15} / 50.0 {1.97}	
		4GR servo piston outer dia.	72.0 {2.83}	
<b>Mechanical system test</b>				
Engine stall speed	rpm	D, S, L, R range	3,000-3,300	
Time lag	sec.	N → D range	Approx. below 1.0	
		N → R range	Approx. below 1.2	
Line pressure kPa {kgf/cm <sup>2</sup> , psi}	D range	Idle	500-520 {5.0-5.4, 72-76}	
		Stall	1,200-1,270 {12.2-13.0, 174-184}	
	S range	Idle	500-520 {5.0-5.4, 72-76}	
		Stall	1,200-1,270 {12.2-13.0, 174-184}	
	L range	Idle	500-520 {5.0-5.4, 72-76}	
		Stall	1,200-1,270 {12.2-13.0, 174-184}	
	R range	Idle	620-650 {6.3-6.7, 90-95}	
		Stall	1,510-1,570 {15.3-16.1, 218-228}	
<b>Shift point km/h {MPH}</b>				
POWER	D range	Wide open throttle	D <sub>1</sub> → D <sub>2</sub>	50-56 {31-35}
			D <sub>2</sub> → D <sub>3</sub>	103-111 {64-69}
			D <sub>3</sub> → D <sub>4</sub>	178-188 {111-117}
		Half throttle	D <sub>1</sub> → D <sub>2</sub>	35-41 {22-25}
			D <sub>2</sub> → D <sub>3</sub>	81-93 {50-58}
			D <sub>3</sub> → D <sub>4</sub>	126-144 {78-99}
			Lockup ON (D <sub>3</sub> )	94-106 {58-66} (*81-93 {50-58})
			Lockup ON (D <sub>4</sub> )	174-192 {108-119} (*126-144 {78-89})
		Closed throttle position	D <sub>4</sub> → D <sub>3</sub>	39-45 {24-28}
			D <sub>3</sub> → D <sub>2</sub>	13-19 {8-12}
			D <sub>2</sub> → D <sub>1</sub>	5-11 {3-7}
		Kickdown (Wide open throttle)	D <sub>4</sub> → D <sub>3</sub>	142-152 {88-94}
			D <sub>3</sub> → D <sub>2</sub>	91-99 {57-62}
			D <sub>2</sub> → D <sub>1</sub>	38-44 {24-27}

#### Caution

- Lockup indicates complete lockup.
- \* mark indicates lockup points when the engine coolant temperature is above 115°C {239°F}.



Item			Transmission	RB4A-EL
NORMAL	D range (A/C ON)	Wide open throttle	D <sub>1</sub> → D <sub>2</sub>	50-56 {31-35}
			D <sub>2</sub> → D <sub>3</sub>	103-111 {64-69}
			D <sub>3</sub> → D <sub>4</sub>	178-188 {111-117}
		Half throttle	D <sub>1</sub> → D <sub>2</sub>	32-38 {20-24}
			D <sub>2</sub> → D <sub>3</sub>	80-92 {50-57}
			D <sub>3</sub> → D <sub>4</sub>	126-144 {78-89}
			Lockup ON (D <sub>3</sub> )	94-106 {58-66} (*80-92 {50-57})
		Closed throttle position	Lockup ON (D <sub>4</sub> )	174-192 {108-119} (*126-144 {78-89})
			D <sub>4</sub> → D <sub>3</sub>	39-45 {24-28}
			D <sub>3</sub> → D <sub>2</sub>	13-19 {8-12}
		Kickdown (Wide open throttle)	D <sub>2</sub> → D <sub>1</sub>	5-11 {3-7}
			D <sub>4</sub> → D <sub>3</sub>	142-152 {88-94}
	D <sub>3</sub> → D <sub>2</sub>		91-99 {57-62}	
	D range (A/C OFF)	Wide open throttle	D <sub>2</sub> → D <sub>1</sub>	38-44 {24-27}
			D <sub>1</sub> → D <sub>2</sub>	50-56 {31-35}
			D <sub>2</sub> → D <sub>3</sub>	103-111 {64-69}
		Half throttle	D <sub>3</sub> → D <sub>4</sub>	178-188 {111-117}
			D <sub>1</sub> → D <sub>2</sub>	32-38 {20-24}
			D <sub>2</sub> → D <sub>3</sub>	80-92 {50-57}
			D <sub>3</sub> → D <sub>4</sub>	126-144 {78-89}
		Closed throttle position	Lockup ON (D <sub>3</sub> )	94-106 {58-66} (*80-92 {50-57})
			Lockup ON (D <sub>4</sub> )	174-192 {108-119} (*126-144 {78-89})
			D <sub>4</sub> → D <sub>3</sub>	35-41 {22-25}
		Kickdown (Wide open throttle)	D <sub>3</sub> → D <sub>2</sub>	13-19 {8-12}
D <sub>2</sub> → D <sub>1</sub>			5-11 {3-7}	
D <sub>4</sub> → D <sub>3</sub>	142-152 {88-94}			
HOLD	D range	—	D <sub>3</sub> → D <sub>2</sub>	7-13 {4-8}
			D <sub>2</sub> → D <sub>3</sub>	15-25 {9-16}
			Lockup ON (D <sub>3</sub> )	94-106 {58-66} (*39-51 {24-32})
			D <sub>4</sub> → D <sub>3</sub>	180-186 {112-116}
NORMAL	S range	Wide open throttle	S <sub>1</sub> → S <sub>2</sub>	50-56 {31-35}
			S <sub>2</sub> → S <sub>3</sub>	103-111 {64-69}
		Half throttle	S <sub>1</sub> → S <sub>2</sub>	35-41 {22-25}
			S <sub>2</sub> → S <sub>3</sub>	81-93 {50-58}
			Lockup ON (S <sub>3</sub> )	94-106 {58-66} (*81-93 {50-58})
		Closed throttle position	S <sub>3</sub> → S <sub>2</sub>	13-19 {8-12}
			S <sub>2</sub> → S <sub>1</sub>	5-11 {3-7}
		Kickdown (Wide open throttle)	S <sub>3</sub> → S <sub>2</sub>	91-99 {57-62}
			S <sub>2</sub> → S <sub>1</sub>	38-44 {24-27}
		HOLD	—	S <sub>3</sub> → S <sub>2</sub>

TD

**Caution**

- Lockup indicates complete lockup.
- \* mark indicates lockup points when the engine coolant temperature is above 115°C {239°F}.

Transmission		RB4A-EL	
Item			
<b>Forward clutch</b>			
Clutch clearance	mm {in}	With new drive / driven plates	0.45–0.85 {0.018–0.033}
		With reusing drive / driven plates	0.45–1.85 {0.018–0.073}
Retaining plate size	mm {in}	8.0 {0.315}, 8.2 {0.323}, 8.4 {0.331}, 8.6 {0.339}, 8.8 {0.346}, 9.0 {0.354}, 9.2 {0.362}	
Return spring	mm {in}	Outer diameter	9.7 {0.38}
		Free length	35.8 {1.41}
<b>Overrunning clutch</b>			
Clutch clearance	mm {in}	With new drive / driven plates	1.0–1.4 {0.039–0.055}
		With reusing drive / driven plates	1.0–2.0 {0.039–0.079}
Retaining plate size	mm {in}	4.0 {0.157}, 4.2 {0.165}, 4.4 {0.173}, 4.6 {0.181}, 4.8 {0.189}, 5.0 {0.197}, 5.2 {0.205}	
<b>Low and reverse brake</b>			
Brake clearance	mm {in}	With new drive / driven plates	0.8–1.2 {0.031–0.047}
		With reusing drive / driven plates	0.8–2.6 {0.031–0.102}
Retaining plate size	mm {in}	6.2 {0.244}, 6.4 {0.252}, 6.6 {0.260}, 6.8 {0.268}, 7.0 {0.276}, 7.2 {0.283}, 7.4 {0.291}, 7.6 {0.299}, 7.8 {0.307}, 8.0 {0.315}	
Return spring	mm {in}	Outer diameter	11.6 {0.457}
		Free length	22.3 {0.878}
<b>Low one-way clutch inner race</b>			
Seal ring clearance	mm {in}	Standard	0.10–0.25 {0.004–0.010}
		Maximum	0.25 {0.010}
<b>Total end play</b>			
Standard end play	mm {in}	0.25–0.55 {0.010–0.022}	
Bearing race size	mm {in}	0.8 {0.031}, 1.0 {0.039}, 1.2 {0.047}, 1.4 {0.055}, 1.6 {0.063}, 1.8 {0.071}, 2.0 {0.079}	
<b>Reverse clutch end play</b>			
Standard end play	mm {in}	0.55–0.90 {0.022–0.035}	
Thrust washer size	mm {in}	0.7 {0.028}, 0.9 {0.035}, 1.1 {0.043}, 1.3 {0.051}, 1.5 {0.059}, 1.7 {0.067}, 1.9 {0.075}	
<b>Torque converter distance (A)</b>			
Torque converter distance (A)	mm {in}	29.0 {1.14} min.	

**L. PROPELLER SHAFT**

Item	Transmission	R15M-D
Length	mm {in}	863 {33.98}
Outer diameter	mm {in}	75 {3.0}
Max. permissible runout	mm {in}	0.4 {0.02}

**M. FRONT AND REAR AXLES**

Item		Specifications
<b>Drive shaft</b>		
Type	Wheel side	BJ (bell joint)
	Differential side	TJ (Tripod joint)
Outer diameter of large boot end mm {in}	Wheel side	105.3 {4.146}
	Differential side	100.5 {3.957}
Grease amount g {oz}	Wheel side	100-120 {3.53-4.23}
	Differential side	170-190 {6.01-6.70}
Shaft length*	mm {in}	791.2-801.2 {31.15-31.54}
<b>Front axle</b>		
Bearing play axil direction	mm {in}	0.05 {0.002} max.
<b>Rear axle</b>		
Bearing play axil direction	mm {in}	0.05 {0.002} max.
<b>Differential</b>		
Backlash (Ring gear and drive pinion)	mm {in}	0.09-0.11 {0.0035-0.0043}
Drive pinion preload (without oil seal)	N·m {kgf·cm, in·lbf}	1.3-1.7 {13-18, 12-15}
Differential oil	Grade	API Service GL-4 or 5
	Viscosity	Above -18°C {0°F} : SAE 90 Below -18°C {0°F} : SAE 80
	Capacity	L {US qt, Imp qt}
		1.30 {1.38, 1.14}

\* Before measuring the drive shaft length, lift the boot to equalize the pressure within it.

**N. STEERING SYSTEM**

Item		Specifications
<b>Steering wheel</b>		
Outer diameter	mm {in}	380 {15.0}
Free play	mm {in}	0-30 {0-1.18}
Wheel effort	N {kgf, lbf}	30-38 {3.0-3.9, 6.6-8.5}
Lock-to-lock	turns	2.9
<b>Steering shaft</b>		
Shaft type		Collapsible
Joint type		2-cross joint
<b>Power steering system</b>		
Gear type		Rack and pinion
Gear ratio		∞ (infinite)
Rack stroke	mm {in}	160 {6.30}
Power steering fluid		ATF Dexron®II or M-III
Fluid capacity	L {US qt, Imp qt}	0.96 {1.01, 0.84}
Fluid pressure	kPa {kgf/cm <sup>2</sup> , psi}	7620-8350 {77.7-85.2, 1110-1210}

### P. BRAKING SYSTEM

Item		Specifications	
<b>Brake pedal</b>			
Type		Suspended	
Height (with carpet)	mm {in}	164.5–176.0 {6.48–6.92}	
Free play	mm {in}	3–8 {0.12–0.31}	
Reserve travel (When depressed at 590 N {60 kgf, 132 lbf}) (without carpet)	mm {in}	100 {3.94} min.	
<b>Master cylinder</b>			
Type		Tandem (with level sensor)	
		Portless & recessed type	
Push rod-to-piston clearance	mm {in} Power brake unit at 66.7 kPa {500 mmHg, 19.7 inHg}	0.1–0.4 {0.004–0.015}	
<b>Front brake</b>			
Type		Ventilated disc	
Disc pad thickness	Standard mm {in}	Outer	10.3 {0.41}
		Inner	9.3 {0.37}
	Limit	mm {in}	1.0 {0.04}
Disc plate	Runout limit		mm {in} 0.1 {0.004}
	Thickness	Standard	mm {in} 22.0 {0.87}
		Limit	mm {in} 20.0 {0.79}
<b>Rear brake</b>			
Type		Ventilated disc	
Disc pad thickness	Standard	mm {in} 8.0 {0.31}	
	Limit	mm {in} 1.0 {0.04}	
Disc plate	Runout limit		mm {in} 0.1 {0.004}
	Thickness	Standard	mm {in} 20.0 {0.79}
		Limit	mm {in} 18.0 {0.71}
<b>Power brake unit</b>			
Type		Tandem diaphragm	
Fluid pressure when pedal depressed at 200 N {20 kgf, 44 lbf} kPa {kgf/cm <sup>2</sup> }	Power brake unit at 0 kPa {0 mmHg, 0 inHg}	590 {6} min.	
	Power brake unit at 66.7 kPa {500 mmHg, 19.7 inHg}	7750 {79} min.	
<b>Rear wheel hydraulic control system</b>			
Type		Proportioning bypass valve	
Switching point	kPa {kgf/cm <sup>2</sup> , psi}	3900 {40.0, 570}	
<b>Parking brake</b>			
Type		Mechanical, two-rear-wheel control	
Operation system		Hand lever type	
Parking lever stroke (When pulled at 200 N {20 kgf, 44 lbf})	notches	7–10	
<b>Brake fluid</b>			
Type		FMVSS 116 DOT-3	
<b>Anti-lock brake system (ABS)</b>			
Type		4-sensor, 3-channel system	
Resistance between terminals of wheel speed sensor	kΩ	0.8–1.2	

**Q. WHEELS AND TIRES**

Item		Specifications	
<b>Standard tire</b>			
Tires	Size	P225/50R16 91V P225/50 ZR 16	
	Air pressure	kPa {kgf/cm <sup>2</sup> , psi} 220 {2.2, 32}	
	Remaining tread	Ordinary tires mm {in}	1.6 {0.063} min.
		Snow tires %	50 min.
Wheels	Size	16 × 8JJ	
	Material	Aluminum alloy	
	Offset	mm {in} 50.0 {1.97}	
	Pitch circle diameter	mm {in} 114.3 {4.50}	
<b>Temporary spare tire</b>			
Tires	Size	T135/70D16	
	Air pressure	kPa {kgf/cm <sup>2</sup> , psi} 415 {4.2, 60}	
Wheels	Size	16 × 4T	
	Material	Aluminum alloy	
	Offset	mm {in} 40.0 {1.57}	
	Pitch circle diameter	mm {in} 114.3 {4.50}	
<b>Wheel and tire</b>			
Runout limit	mm {in}	Horizontal 2.0 {0.08}	
		Vertical 1.5 {0.06}	
Maximum unbalance (at rim edge)		g {oz} 8 {0.28}	

**R. SUSPENSION**

Item	Transmission Suspension	MT		AT
		Standard	Hard	Standard
<b>Front suspension</b>				
Suspension type		Double-wishbone		
Coil spring	Identification mark color	Red		Brown
	Wire diameter	mm {in}	12.3 {0.48}	12.5 {0.49}
	Coil center diameter	mm {in}	104.8 {4.126}	105.0 {4.134}
	Free length	mm {in}	270.0 {10.63}	276.3 {10.88}
	Active coil number		4.14	4.39
Shock absorber	Type	Cylindrical, double-acting, low-pressure gas charged		
	Damping force characteristics	Standard	Hard	Standard
Stabilizer	Type	Torsion bar, hollow type		
	Diameter	mm {in}	28.6 {1.13}	
Front wheel alignment (unladen*1)	Inspection standard			
	Total toe-in	mm {in}	2 ± 3 {0.08 ± 0.11}	
	Toe-in (per side)	Degree	0.1° ± 0.75°	
	Maximum steering angle	in	36° ± 2°	
		out	32° ± 2°	
	Camber angle	Degree	0.1° ± 0.75°	
	Difference between left and right	Degree	1.0° max.	
		Degree	6.08° ± 0.75°	
	Difference between left and right	Degree	1.0° max.	
		Degree	13°55'	
	Adjustment standard			
	Total toe-in	mm {in}	2 ± 1 {0.08 ± 0.04}	
	Toe-in (per side)	Degree	0.1° ± 0.05°	
	Maximum steering angle	in	36° ± 2°	
out		32° ± 2°		

\*1 Fuel tank full; radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions.

Item	Transmission		MT		AT
	Suspension		Standard	Hard	Standard
Front wheel alignment (unladen*1)	Camber angle		Degree	0.1° ± 0.5°	
		Difference between left and right	Degree	1.0° max.	
	Caster angle		Degree	6.08° ± 0.5°	
		Difference between left and right	Degree	1.0° max.	
	King pin angle		Degree	13°55'	
<b>Rear suspension</b>					
Suspension type			Double-wishbone		
Coil spring	Identification mark color		Purple		
	Wire diameter	mm {in}	12.2 {0.48}		
	Coil center diameter	mm {in}	114.7 {4.516}		
	Free length	mm {in}	303.0 {11.93}		
	Active coil number		4.21		
Shock absorber	Type		Cylindrical, double-acting, low-pressure gas charged		
	Damping force characteristics		Standard	Hard	Standard
Stabilizer	Type		Torsion bar, hollow type		
	Diameter	mm {in}	13.8 {0.54}		
Rear wheel alignment (unladen*1)	Inspection standard				
	Total toe-in		mm {in}	2 ± 3 {0.08 ± 0.11}	
	Toe-in (per side)		Degree	0.1° ± 0.1°	
	Camber angle		Degree	-1.22° ± 0.75°	
		Difference between left and right	Degree	1.0° max	
	Thrust angle		Degree	0° ± 0.1°	
	Adjustment standard				
	Total toe-in		mm {in}	2 ± 1 {0.08 ± 0.04}	
	Toe-in (per side)		Degree	0.1° ± 0.05°	
	Camber angle		Degree	-1.22° ± 0.5°	
		Difference between left and right	Degree	1.0° max	
	Thrust angle		Degree	0° ± 0.1°	

\*1 Fuel tank full; radiator coolant and engine oil at specified levels; spare tire, jack, and tools in designated positions.

### T. BODY ELECTRICAL SYSTEM

Item	Specification (W) (BULB TRADE NO.)	
Front exterior lights	Headlight (Halogen)	60/55 [HB <sub>2</sub> ]
	Parking light	5
	Front turn signal	27 (3497)
	Front fog light	35
	Daytime running light (For Canada)	27 (3496)
	Front side marker light	4.9 (168)
Rear exterior lights	Back-up light	27 (1156)
	License plate light	5
	Stop / Tail light	27/8 (1157)
	High-mount stoplight	18.4 (921)
	Rear turn signal light	27 (1156)
	Rear side marker light	3.8 (194)
Interior lights	Interior light	5
	Glove compartment light	3.4
	Cargo compartment light	8

Item		Specification (W) (BULB TRADE NO.)
Warning lights	Seat belt ABS Brake	1.4
	Alternator Oil-level Fuel-level Coolant level	3
	Air bag system	2
Indicator	Shift-up	2
	High beam Turn signal Security light Check Rear window defroster Cruise set HOLD	1.4
Illumination lights	Instrument cluster Head light cleaner switch Front fog light switch Heater unit Cigarette lighter Ash tray	3.4
	Retractor switch Automatic selector Rear window defroster switch Cruise control main switch Door key cylinder Ignition key	1.4

**U. HEATER AND AIR CONDITIONER SYSTEMS**

Item		Specifications	
		R-12	R-134a
Refrigerant amount	g{oz}	750-850 {26.5-30.0}	450-550 {15.9-19.4}
Compressor oil	Oil type	ND-OIL 7	ND-OIL 9
	Amount	ml {cc, fl oz}	100-140 {100-140, 3.0-4.2}
Refrigerant normal pressure at 25°C {77°F}	Low pressure	0.15-0.20 {1.5-2.0, 21-28}	0.15-0.25 {1.5-2.5, 21-36}
	High pressure	1.42-1.47 {14.5-15.0, 206-213}	1.37-1.57 {14-16, 199-228}

**STANDARD BOLT AND NUT TIGHTENING TORQUE**

Diameter mm {in}	Pitch mm {in}	4T			6T			8T		
		N·m	kgf·m	ft·lbf	N·m	kgf·m	ft·lbf	N·m	kgf·m	ft·lbf
6 {0.236}	1 {0.039}	4.2-6.2	0.43-0.63	3.1-4.6	6.9-9.8	0.7-1.0	5.0-7.2	7.8-11.8	0.8-1.2	5.8-8.8
8 {0.315}	1.25 {0.049}	9.8-14.7	1.0-1.5	7.2-10.8	16-23	1.6-2.3	12-17	18-26	1.8-2.7	13-20
10 {0.394}	1.25 {0.049}	20-28	2.0-2.9	14-21	31-46	3.2-4.1	23-34	36-54	3.7-5.5	27-40
12 {0.472}	1.5 {0.059}	34-50	3.5-5.1	25-37	55-80	5.6-8.2	41-59	63-93	6.4-9.5	46-69
14 {0.551}	1.5 {0.059}	—	—	—	75-103	7.7-10.5	56-76	102-137	10-14	75-101
16 {0.630}	1.5 {0.059}	—	—	—	116-157	12-16	85-116	156-211	16-22	115-156
18 {0.709}	1.5 {0.059}	—	—	—	167-225	17-23	123-166	221-299	23-31	163-221
20 {0.787}	1.5 {0.059}	—	—	—	231-314	24-32	171-231	308-417	31-43	227-307
22 {0.866}	1.5 {0.059}	—	—	—	314-423	32-43	231-312	417-564	43-58	307-416
24 {0.945}	1.5 {0.059}	—	—	—	475-546	41-56	298-403	536-726	55-74	396-536